



BMW Motorrad

[bmw-motorrad.com](http://bmw-motorrad.com)



The Ultimate  
Riding Machine

Rider's Manual (US Model)

**F 700 GS**

## Motorcycle/Retailer Data

### Motorcycle Data

Model

Vehicle identification number

Color number

Initial registration

License plate

### Retailer Data

Contact in Service

Ms./Mr.

Phone number

Retailer's address/phone number (company stamp)

## Welcome to BMW

Congratulations on choosing a motorcycle from BMW Motorrad and welcome to the community of BMW motorcycle owners and riders. Familiarize yourself with your new motorcycle so that you can ride it safely and confidently in all highway traffic situations.

### About this Rider's Manual

Please read this Rider's Manual carefully before starting to use your new BMW. It contains important information on how to operate the controls and how to get the most benefit from your BMW's advanced technical features.

In addition, it contains information on maintenance and care to help you maintain your motorcycle's reliability and safety, as well as its value.

Documentation confirming performance of scheduled maintenance is a precondition for generous handling of out-of-warranty claims and goodwill warranty treatment.

Should you want to sell your BMW one day, please also remember to turn over the Ride's Manual to the new owner. It is an important part of your motorcycle.

### Suggestions and complaints

If you have any questions concerning your motorcycle, your authorized BMW Motorrad retailer is always happy to provide advice and assistance.

We wish you many miles of safe and enjoyable riding on your BMW

BMW Motorrad.

01 40 8 393 987



# Table of Contents

|                                        |           |                                             |           |                                              |           |
|----------------------------------------|-----------|---------------------------------------------|-----------|----------------------------------------------|-----------|
| <b>1 General instructions ....</b>     | <b>5</b>  | Onboard computer display .....              | 25        | Electronic suspension adjustment (ESA) ..... | 50        |
| Overview .....                         | 6         | Warning lights .....                        | 25        | Riding mode .....                            | 52        |
| Abbreviations and symbols .....        | 6         | Service display .....                       | 36        | Heated handlebar grips .....                 | 53        |
| Equipment .....                        | 7         | Fuel gage .....                             | 37        | Seat .....                                   | 54        |
| Technical data .....                   | 7         | Fuel reserve .....                          | 37        | <b>5 Alarm system .....</b>                  | <b>55</b> |
| Notice concerning current status ..... | 7         | Ambient temperature .....                   | 38        | Overview .....                               | 56        |
| <b>2 Overviews .....</b>               | <b>9</b>  | Tire inflation pressures .....              | 38        | Activation .....                             | 56        |
| General view, left side .....          | 11        | <b>4 Operation .....</b>                    | <b>39</b> | Alarm function .....                         | 57        |
| General view, right side .....         | 13        | Steering and ignition lock .....            | 40        | Deactivation .....                           | 58        |
| Underneath seat .....                  | 14        | Emergency on/off switch (kill switch) ..... | 42        | Programming .....                            | 59        |
| Under fairing .....                    | 15        | Lights .....                                | 42        | Logging on additional remote controls .....  | 61        |
| Multifunction switch, left ....        | 16        | Hazard warning lights system .....          | 43        | Synchronizing .....                          | 62        |
| Multifunction switch, right .....      | 17        | Turn indicators .....                       | 44        | Battery .....                                | 62        |
| Instrument panel .....                 | 18        | Display .....                               | 44        | <b>6 Setting .....</b>                       | <b>65</b> |
| <b>3 Displays .....</b>                | <b>21</b> | Clock .....                                 | 46        | Mirrors .....                                | 66        |
| Indicator and warning lights .....     | 22        | Stopwatch .....                             | 47        | Headlight .....                              | 66        |
| Multifunction display .....            | 23        | Antilock Brake System (ABS) .....           | 48        | Clutch .....                                 | 68        |
| Multifunction display .....            | 24        | Automatic Stability Control (ASC) .....     | 49        | Brakes .....                                 | 68        |
|                                        |           |                                             |           | Spring preload .....                         | 69        |
|                                        |           |                                             |           | Damping .....                                | 70        |

## **7 Riding..... 71**

Safety information..... 72

Observe checklist ..... 74

If there is a change in the  
loading condition: ..... 74

Before every journey:..... 74

At every third refueling  
stop: ..... 75

Starting..... 75

Running in ..... 78

Shifting gears ..... 79

Off-road riding ..... 79

Brakes ..... 80

Parking your motorcycle .... 81

Refueling ..... 82

Securing motorcycle for  
transport ..... 84

## **8 Technology in detail..... 87**

General notes ..... 88

Antilock Brake System  
(ABS)..... 88

Automatic Stability Control  
(ASC) ..... 90

Tire pressure control

(RDC) ..... 91

Riding mode ..... 92

## **9 Maintenance ..... 95**

General instructions ..... 96

Tool kit ..... 96

Service tool kit ..... 96

Front wheel stand ..... 97

Engine oil ..... 98

Brake system ..... 100

Clutch ..... 104

Coolant..... 105

Tires ..... 106

Rims and tires..... 106

Wheels ..... 107

Air filter..... 114

Light sources ..... 115

Fairings and panels ..... 121

Jump-starting ..... 122

Battery ..... 123

Fuses ..... 126

Diagnostic connector..... 127

Chain..... 127

## **10 Accessories ..... 131**

General notes ..... 132

Onboard power

sockets..... 132

Luggage ..... 133

Case ..... 134

Topcase..... 137

## **11 Care ..... 141**

Care products ..... 142

Washing your motorcy-  
cle..... 142

Cleaning sensitive motorcy-  
cle parts..... 143

Paint care ..... 143

Paint preservation ..... 144

Store motorcycle..... 144

Return motorcycle to  
use ..... 144

## **12 Technical data ..... 145**

Troubleshooting chart..... 146

Threaded fasteners ..... 147

Fuel ..... 149

Engine oil ..... 150

Engine ..... 151

Clutch ..... 152

|                         |     |
|-------------------------|-----|
| Transmission .....      | 152 |
| Rear-wheel drive .....  | 153 |
| Frame .....             | 153 |
| Suspension .....        | 153 |
| Brakes .....            | 154 |
| Wheels and tires .....  | 155 |
| Electrical system ..... | 156 |
| Dimensions .....        | 158 |
| Weights .....           | 159 |
| Performance data .....  | 159 |

### **13 Service ..... 161**

|                                        |     |
|----------------------------------------|-----|
| Reporting safety defects .....         | 162 |
| BMW Motorrad Service ...               | 163 |
| BMW Motorrad Mobility Services .....   | 163 |
| Maintenance procedures .....           | 163 |
| Maintenance schedule ....              | 167 |
| Confirmation of maintenance work ..... | 168 |
| Confirmation of service ....           | 182 |

### **14 Appendix..... 185**

|                                              |     |
|----------------------------------------------|-----|
| Certificate for Electronic Immobilizer ..... | 186 |
|----------------------------------------------|-----|

### **15 Index ..... 188**

## General instructions

|                                       |   |
|---------------------------------------|---|
| Overview .....                        | 6 |
| Abbreviations and symbols .....       | 6 |
| Equipment .....                       | 7 |
| Technical data .....                  | 7 |
| Notice concerning current status .... | 7 |

## Overview

Chapter 2 of this Rider's Manual will provide you with an initial overview of your motorcycle. All maintenance and repair work carried out on your motorcycle will be documented in Chapter 13. Documentation confirming performance of scheduled maintenance is a precondition for generous handling of out-of-warranty claims and goodwill warranty treatment.

When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

## Abbreviations and symbols



**CAUTION** Hazard with low risk. Failure to avoid this hazard can result in minor or moderate injury.



**WARNING** Hazard with moderate risk. Failure to avoid this hazard can result in death or serious injury.



**DANGER** Hazard with high risk. Failure to avoid this hazard results in death or serious injury.



**ATTENTION** Special instructions and precautionary measures. Non-compliance can cause damage to the vehicle or accessories and warranty claims may be denied as a result.



**NOTICE** Special information on operating and inspecting your motorcycle as well as maintenance and adjustment procedures.



Indicates the end of an item of information.



Instruction.



Result of an activity.



Reference to a page with more detailed information.



Indicates the end of accessory or equipment-dependent information.



Tightening torque.



Technical data.



Optional extra.  
BMW Motorrad optional extras are already completely installed during motorcycle production.

|     |                                                                                                                                |
|-----|--------------------------------------------------------------------------------------------------------------------------------|
| OA  | Optional accessory. BMW Motorrad optional accessories can be purchased and installed at your authorized BMW Motorrad retailer. |
| EWS | Electronic immobilizer.                                                                                                        |
| DWA | Anti-theft alarm.                                                                                                              |
| ABS | Anti-Lock Brake System.                                                                                                        |
| ASC | Automatic Stability Control.                                                                                                   |
| ESA | Electronic Suspension Adjustment.                                                                                              |
| TPC | Tire Pressure Control (TPC).                                                                                                   |

## Equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional equipment (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences.

If your motorcycle comes with equipment not described here, you can find the descriptions in a separate manual.

## Technical data

All dimensions, weights and performance data contained this Rider's Manual refer to the German DIN standards and comply

with their tolerance specifications. Versions for individual countries may differ.


## Notice concerning current status

The high safety and quality standards of BMW motorcycles are maintained by consistent, ongoing development efforts embracing their design, equipment and accessories. For this reason, aspects of your motorcycle may vary from the descriptions in this Operating instructions. In addition, BMW Motorrad cannot guarantee the total absence of errors. We hope you will appreciate that no claims can be recognized based on the data, illustrations or descriptions in this manual.



## Overviews

|                                   |    |
|-----------------------------------|----|
| General view, left side .....     | 11 |
| General view, right side .....    | 13 |
| Underneath seat .....             | 14 |
| Under fairing .....               | 15 |
| Multifunction switch, left .....  | 16 |
| Multifunction switch, right ..... | 17 |
| Instrument panel .....            | 18 |



## General view, left side

- 1 Power socket (➡ 132)
- 2 Seat lock (➡ 54)
- 3 Oil fill location and oil dipstick (➡ 98)





## General view, right side

- 1** Fuel filler cap (➡ 83)
- 2** Adjusting spring preload (➡ 69)
- 3** Brake-fluid reservoir, rear (➡ 103)
- 4** Brake-fluid reservoir, front (➡ 102)
- 5** Vehicle identification number, type plate (on steering head at right)
- 6** Coolant level indicator (behind side fairing) (➡ 105)
- 7** Damping adjustment (➡ 70)

## Underneath seat

- 1 Storage  
– with first-aid kit<sup>OA</sup>  
First-aid kit
- 2 Tool kit (► 96)
- 3 Tyre inflation pressure table
- 4 Load capacity table
- 5 Rider's Manual (US Model)  
(► 6)
- 6 Diagnostic connector  
(► 127)
- 7 Tools for adjusting spring preload (► 69)






## Under fairing

- 1 Battery (➡ 123)
- 2 Air cleaner housing (➡ 114)
- 3 Connector for optional accessories
- 4 Fuse (➡ 126)

## Multifunction switch, left

- 1 High-beam headlight and headlight flasher (➡ 43)
- 2 INFO button  
Selecting display readings (➡ 44).  
– with onboard computer<sup>OE</sup>  
Resetting average data (➡ 46).
- 3 Hazard warning lights system (➡ 43)
- 4 Turn indicators (➡ 44)
- 5 Horn
- 6 – with Electronic Suspension Adjustment (ESA)<sup>OE</sup>  
ESA (➡ 51).
- 7 ABS (➡ 48).  
– with Automatic Stability Control (ASC)<sup>OE</sup>  
ASC (➡ 49).






## Multifunction switch, right

- 1** – with heated grips<sup>OE</sup>  
Operating heated grips (➡ 53).
- 2** MODE button  
Setting riding mode (➡ 52).
- 3** Starter (➡ 75)
- 4** Emergency on/off switch (kill switch) (➡ 42)

## Instrument panel

- 1 Indicator and warning lights (►► 22)
- 2 Speedometer
- 3 Button  
Set clock (►► 46).  
– with onboard computer<sup>OE</sup>  
Operating stopwatch (►► 47).
- 4 Multifunction display  
- without optional equipment<sup>OE</sup> (standard) (►► 23)  
- with optional equipment<sup>OE</sup> (►► 24)
- 5 Button  
Selecting display readings (►► 44),  
Resetting trip odometer (►► 45).



- 6** Photo sensor (brightness control)  
– with onboard computer<sup>OE</sup>  
Activating the engine speed warner (▮▮▮▮ 79).  
– with anti-theft alarm system (DWA)<sup>OE</sup>  
DWA LED  
General information on DWA (▮▮▮▮ 56)
- 7** Tachometer




## Displays

|                                    |    |
|------------------------------------|----|
| Indicator and warning lights ..... | 22 |
| Multifunction display .....        | 23 |
| Multifunction display .....        | 24 |
| Onboard computer display .....     | 25 |
| Warning lights .....               | 25 |
| Service display .....              | 36 |
| Fuel gage .....                    | 37 |
| Fuel reserve .....                 | 37 |
| Ambient temperature .....          | 38 |
| Tire inflation pressures .....     | 38 |

## Indicator and warning lights

- 1 – with Automatic Stability Control (ASC)<sup>OE</sup>  
ASC (▮▮▮ 49).
- 2 ABS (▮▮▮ 48).
- 3 Fuel reserve (▮▮▮ 37)  
Fuel gage (▮▮▮ 29)
- 4 Turn indicator, right
- 5 Neutral position (idling)
- 6 Turn indicator, left
- 7 High-beam headlamp
- 8 General warning light (▮▮▮ 25)





## Multifunction display

- without heated grips<sup>OE</sup>
- without onboard computer<sup>OE</sup>
- without riding modes Pro<sup>OE</sup>
- without Electronic Suspension Adjustment (ESA)<sup>OE</sup>

- 1 Warning light for electronic engine management (➡ 30)
- 2 Clock (➡ 46)
- 3 Coolant-temperature warning indicator (➡ 29)
- 4 Service display (➡ 36)
- 5 Indication range for values Odometer (➡ 44) Tripmeter (➡ 45)
- 6 Fuel gage (➡ 37)
- 7 Riding modes (➡ 52)
- 8 Warning symbol (➡ 25)
- 9 Tripmeter (➡ 45)

## Multifunction display

- with heated grips<sup>OE</sup>
- with onboard computer<sup>OE</sup>
- with riding modes Pro<sup>OE</sup>
- with Electronic Suspension Adjustment (ESA)<sup>OE</sup>

- 1 Set heating stage (➡ 53)
- 2 Stopwatch (➡ 47)
- 3 Displays for OE  
ESA (➡ 51)  
Engine speed warner (➡ 79)
- 4 Onboard computer display (➡ 44)  
Symbols (➡ 25)
- 5 Riding modes (➡ 52)
- 6 Gear indicator, "N" indicates 'neutral'



## Onboard computer display

– with onboard computer<sup>OE</sup>

 Mileage covered since reaching the fuel reserve (➡ 37)

 Average fuel consumption

 Average speed

 Current fuel consumption

 Outside temperature (➡ 38)

 Coolant temperature

## Warning lights Displays

Warnings are displayed with appropriate warning lights.



Warnings for which no separate warning lamp is available are indicated by the 'universal' warning lamp **1** in conjunction with a warning notice or a warning symbol in the multifunction display. The universal warning light lights up in either yellow or red depending on the urgency of the warning.



Adjacent to the numerical data display **2** a warning triangle **3** may also appear. These warnings alternate with the odometers (➡ 44).

The universal warning light lights up for the most urgent warning.

The following page contains a list of potential warnings.

## Overview of warning indicators

| Indicator and warning lights                                                                      | Warning symbols in the display panel                                                                             | Meaning                                    |
|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|--------------------------------------------|
|  lights up yellow |  + "EWS" is indicated           | EWS active (►► 29)                         |
|  lights up        |                                                                                                                  | Fuel down to reserve (►► 29)               |
|  lights up red    |  flashes                        | Coolant temperature too high (►► 29)       |
|  lights up yellow |  The engine symbol is displayed | Engine in emergency-operation mode (►► 30) |
|  lights up red    |  The engine symbol is displayed | Engine warning (►► 30)                     |
|  lights up yellow |  + "LAMP" is indicated          | Bulb defective (►► 31)                     |
|                                                                                                   | "x . x ° F" flashes                                                                                              | Outside temperature warning (►► 31)        |
|  flashes          |                                                                                                                  | ABS self-diagnosis not completed (►► 32)   |

## Indicator and warning lights

## Warning symbols in the display panel

## Meaning

|                                                                                  |                  |                                                                                                        |                                                                       |
|----------------------------------------------------------------------------------|------------------|--------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|  | lights up        |                                                                                                        | ABS switched off (→ 32)                                               |
|  | lights up        |                                                                                                        | ABS error (→ 32)                                                      |
|  | flashes rapidly  |                                                                                                        | ASC intervention (→ 32)                                               |
|  | flashes slowly   |                                                                                                        | ASC self-diagnosis not completed (→ 32)                               |
|  | lights up        |                                                                                                        | ASC switched off (→ 33)                                               |
|  | lights up        |                                                                                                        | ASC error (→ 33)                                                      |
|  | lights up yellow |  + "DWA" is indicated | DWA battery drained (→ 33)                                            |
|  | lights up yellow |  + "x . x" flashes    | Tire inflation pressure in limit area of permissible tolerance (→ 34) |

| Indicator and warning lights                                                                      | Warning symbols in the display panel                                                                             | Meaning                                                      |
|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
|  flashes red      |  + "x . x" flashes              | Tire inflation pressure outside permissible tolerance (➡ 34) |
|  lights up yellow |  + "--" or "-- --" is displayed | Sensor defective or system fault (➡ 35)                      |
|  lights up yellow |  + "RdC" is displayed.          | Battery of tire-inflation pressure sensor weak (➡ 35)        |
|                                                                                                   |  + "--" or "-- --" is displayed | Transmission error (➡ 35)                                    |

## EWS active



General warning light shows yellow.



+ "EWS" is indicated.

Possible cause:

The key being used is not authorized for starting, or communication between the key and engine electronics is disrupted.

- Remove other motorcycle keys from the ignition key ring.
- Use the reserve key.
- Have the defective key replaced, preferably by an authorized BMW Motorrad retailer.

## Fuel down to reserve



Fuel-reserve warning light lights up.



## WARNING

### Rough engine running or switching off of the engine due to a fuel shortage

Accident hazard, damage to catalytic converter

- Do not drive to the extent that the fuel tank is completely empty. ◀

Possible cause:

At the most, the fuel tank still contains the reserve fuel quantity.



Reserve fuel quantity

min 2.9 quarts (min 2.7 l)

- Refueling (► 83).

### Coolant temperature too high



General warning light shows red.



The temperature symbol flashes.



## ATTENTION

### Riding with overheated engine

Engine damage

- Be sure to observe the measures listed below. ◀

Possible cause:

Coolant level is too low.

- Checking coolant level (► 105).

If coolant level is too low:

- Topping up coolant (► 105).
- Have the coolant system checked at a specialist workshop, preferably by an authorized BMW Motorrad retailer.

Possible cause:

The coolant temperature is too high.

- If possible, continue driving in the part-load range to cool down the engine.
- Should the coolant temperature frequently be too high, have the coolant system checked as quickly as possible by a specialist workshop, preferably by an authorized BMW Motorrad retailer.

### Engine in emergency-operation mode



General warning light shows yellow.



Engine symbol appears on the display.



### WARNING

#### Unusual handling when engine is in emergency operating mode

Accident hazard

- Adapt riding style: Avoid rapid acceleration and passing maneuvers. ◀

Possible cause:

The engine control unit has diagnosed a fault which impairs the engine performance or throttle response. The engine is running in the emergency-operation mode. In exceptional cases, the engine stops and can no longer be started.

- Have the malfunction corrected as soon as possible at an authorized service facility, preferably an authorized BMW Motorrad Retailer.
- » It is possible to continue riding, however the engine perfor-

mance and engine speed range may be impaired and not function as normal.

### Engine warning



General warning light shows red.



Engine symbol appears on the display.



### WARNING

#### Damage to the engine when it is in the emergency operating mode

Accident hazard

- Adapt riding style: Ride slowly, avoid rapid acceleration and passing maneuvers.
- If possible, have the motorcycle picked up and the malfunction source eliminated by a specialized service facility, preferably an authorized BMW Motorrad Retailer. ◀

Possible cause:

The engine control unit has diagnosed a fault, which can lead to a severe secondary fault. The engine is in the emergency-operation mode.

- Avoid high load and engine speed ranges if possible.
  - Have the malfunction corrected as soon as possible at an authorized service facility, preferably an authorized BMW Motorrad Retailer.
- » Continued driving is possible, however it is not recommended.

## Bulb defective



General warning light shows yellow.



+ "LAMP" is indicated.



## WARNING

### Overlooking the vehicle in traffic due to a defective light source on the vehicle

Safety risk

- Replace defective bulbs as soon as possible; it is best always to carry a complete set of spare bulbs on the motorcycle. ◀

Possible cause:

Light source defective.

- Locate defective light source with visual check.
- Replacing light sources for low-beam and high-beam headlight (➡ 115).
- Replacing light source for parking light (➡ 116).
- Replace the LED for brake and rear light (➡ 118).
- Replacing front and rear turn indicator light sources (➡ 118).

## Outside temperature warning

– with onboard computer<sup>OE</sup>

"x . x ° F" (outside temperature) flashes.

Possible cause:

The ambient temperature measured at the vehicle is lower than 37 °F (3 °C).



## WARNING

### Risk of black ice, even above 37 °F (3 °C)

Accident hazard

- At a low outside temperature, icy conditions must be expected on bridges and in shady road areas. ◀
- Think well ahead when driving.

## ABS self-diagnosis not completed



ABS indicator light flashes.

Possible cause:



ABS self-diagnosis routine not completed

ABS is not available, as the self-diagnosis routine was not completed. (The motorcycle must reach a specified minimum speed before the system can check operation of the wheel speed sensors: 3 mph (5 km/h))

- Ride off slowly. It must be noted that the ABS function is not available until the self-diagnosis has been completed.

## ABS switched off



ABS indicator light lights up.

Possible cause:

The ABS system has been deactivated by the rider.

- Switching the ABS function on (➡ 49).

## ABS error



ABS indicator light lights up.

Possible cause:

The ABS control unit has detected an error.

- It remains possible to continue riding. It must be noted that the ABS function is not available. Observe additional information on special situations which can lead to ABS fault codes (➡ 89).
- Have the malfunction corrected as soon as possible at an authorized workshop, preferably

an authorized BMW Motorrad retailer.

## ASC intervention

- with Automatic Stability Control (ASC)<sup>OE</sup>



ASC indicator and warning light flashes rapidly.

ASC has detected instability at the rear wheel and responded by reducing the torque. The warning light flashes longer than the ASC intervention lasts. This feature continues to furnish the rider with visual feedback confirming that the system has initiated active closed-loop intervention even after the critical situation has passed.

## ASC self-diagnosis not completed

- with Automatic Stability Control (ASC)<sup>OE</sup>



ASC indicator and warning light flashes slowly.

Possible cause:



ASC self-diagnosis routine not completed

ASC is not available because the self-diagnosis routine was not completed. (The motorcycle must reach a specified minimum speed before the system can check operation of the wheel sensors: min 3 mph (min 5 km/h))

- Ride off slowly. It must be noted that the ASC function is not available until the self-diagnosis has been completed.

### ASC switched off

- with Automatic Stability Control (ASC)<sup>OE</sup>



ASC indicator and warning light lights up.

Possible cause:

The ASC has been deactivated by the rider.

- Switch ASC on.

### ASC error

- with Automatic Stability Control (ASC)<sup>OE</sup>



ASC indicator and warning light lights up.

Possible cause:

The ASC control unit has detected an error.

- It remains possible to continue riding. It must be noted that the ASC function is not available. You should also take account of the additional information on situations that can lead to an ASC fault (► 90).
- Have the malfunction corrected as soon as possible at an

authorized service facility, preferably an authorized BMW Motorrad Retailer.

### DWA battery drained

- with anti-theft alarm system (DWA)<sup>OE</sup>



General warning light shows yellow.



+ "DWA" is indicated.



### NOTICE

This fault message is only shown for a short time immediately following the Pre-Ride-Check. ◀

Possible cause:

The anti-theft alarm system battery is completely discharged. Operation of the anti-theft alarm system is no longer ensured when the motorcycle's battery is disconnected.

- Contact an authorized service facility, preferably an authorized BMW Motorrad retailer.

### Tire inflation pressure in limit area of permissible tolerance

- with Tire Pressure Control (TPC)<sup>OE</sup>



General warning light shows yellow.



+ "x . x" (the critical tire pressure) flashes.

Possible cause:

The measured tire inflation pressure is in the limit area of the permissible tolerance.

- Correct tire inflation pressure in accordance with instructions on back of cover of Rider's Manual.



### NOTICE

Before adjusting the tire inflation pressure, observe the information on temperature compensation and on inflation pressure adjustment in the chapter "Technology in detail".◀

### Tire inflation pressure outside permissible tolerance

- with Tire Pressure Control (TPC)<sup>OE</sup>



General warning light flashes red.



+ "x . x" (the critical tire pressure) flashes.

Possible cause:

The measured tire inflation pressure is outside the approved tolerance range.

- Check tire for damage and suitability for continued use. If it is still possible to drive with tire:



### WARNING

### Tire inflation pressure is outside approved range.

Poorer handling characteristic of the motorcycle.

- Adapt your style of riding accordingly.◀
- Correct tire inflation pressure at the next opportunity.
- Have the tire checked for damage at an authorized service facility, preferably an authorized BMW Motorrad retailer.

If you are unsure about the tire's suitability for continued riding:

- Do not continue riding.
- Contact roadside service.
- Have the tire checked for damage at an authorized service

facility, preferably an authorized BMW Motorrad retailer.

an authorized BMW Motorrad retailer.

## Sensor defective or system fault

- with Tire Pressure Control (TPC)<sup>OE</sup>



General warning light shows yellow.



+ "---" or "-- --" is displayed.

Possible cause:

Wheels without RDC (TPC) sensors are mounted.

- Retrofit wheel set with RDC (TPC) sensors.

Possible cause:

1 or 2 RDC (TPC) sensors have failed.

- Have fault eliminated by a specialized workshop, preferably

Possible cause:

A system fault has occurred.

- Have fault eliminated at a specialist service facility, preferably an authorized BMW Motorrad retailer.

## Battery of tire-inflation pressure sensor weak

- with Tire Pressure Control (TPC)<sup>OE</sup>



General warning light shows yellow.



+ "RdC" is displayed.



## NOTICE

This fault message is only shown for a short time immediately following the Pre-Ride-Check.◀

Possible cause:

The battery of the tire inflation pressure sensor has almost no capacity anymore. The operation of the tire inflation pressure control is only ensured for a limited time.

- Contact a specialist service facility, preferably an authorized BMW Motorrad retailer.

## Transmission error

- with Tire Pressure Control (TPC)<sup>OE</sup>



+ "---" or "-- --" is displayed.

Possible cause:

The vehicle's speed has not exceeded the threshold of approx. 19 mph (30 km/h). The RDC (TPC) sensors do not transmit their signal until a speed above this threshold is reached (► 91).

- Watch the RDC (TPC) display at a higher rate of speed. A

continuous error is only present if the general warning lamp also lights up. In this case:

- Have fault eliminated at a specialist service facility, preferably an authorized BMW Motorrad retailer.

Possible cause:

There is a fault in the radio connection to the RDC (TPC) sensors. Possible causes are radio systems in the surrounding area, which interfere with the connection between the RDC (TPC) control unit and the sensors.

- Watch the RDC (TPC) display in another environment. A continuous error is only present if the general warning light also lights up.

In this case:

- Have fault eliminated at a specialist service facility, preferably an authorized BMW Motorrad retailer.

## Service display



If the time remaining until the next service will elapse within one month, the service date **1** appears briefly following the Pre-Ride-Check. The month and year are shown with two and four digits respectively separated by a colon. In this example the display means "June 2014".



If the motorcycle covers high annual mileages then shorter service intervals may be required. When the odometer reading for the recalculated early service falls to within 621 miles (1000 km), the remaining miles (kilometers) **1** are counted down in 62-miles steps (100-km steps). They are briefly displayed following the Pre-Ride-Check.



When a service date elapses without service, the universal warning light lights up in yellow, appearing together with the date and mileage (kilometer)

display. The "Service" message is displayed continuously.




## NOTICE

If the service display appears more than a month before the service date, the stored date must be adjusted in the instrument cluster. This situation can occur if the battery has been disconnected from the vehicle for an extended period of time. Consult a certified service facility, preferably an authorized BMW Motorrad retailer, for setting of the date.◀

## Fuel gage

Due to the complex fuel tank geometry, the fill level cannot be determined in the upper filling range. For this reason, the fuel level indicator only details the lower half of the filling range.



The **2** tip indicates that the fuel tank is more than half full. If the fuel gage drops to the  $\frac{1}{2}$  mark **1**, the fuel tank is still half full. Now, the fill level is exactly displayed. If the fuel reserve has been reached, the low-fuel warning light is switched on.

## Fuel reserve

The fuel quantity that is in the fuel tank when the low-fuel warning light switches on depends on the riding dynamics: the more substantially the fuel is moved in

the tank (as a result of frequently changing lean angles, frequent braking and acceleration), the more difficult it becomes to determine the fuel reserve. However, the fuel tank still contains at least the fuel reserve specified on the back cover.



After the low-fuel warning light is switched on, the distance ridden since this point in time is indicated.

The distance that can still be traveled with the fuel reserve depends on the riding style (on the consumption) and on the fuel quantity that was still available at the time of switch-on (see previous explanation).

The odometer for the fuel reserve is reset when the fuel quantity after refueling is greater than the fuel reserve.

## Ambient temperature


– with onboard computer<sup>OE</sup>

**°F** Engine heat can lead to spurious readings of ambient temperature when the motorcycle is stationary. When the effects of engine heat on the monitored temperature become excessive the display responds by temporarily reverting to -- as the display reading.

When ambient temperatures drop below 37 °F (3 °C) the temperature display responds by flashing a warning indicating possible ice formation on the road surface. The display automatically switches from any other mode to the temperature reading when the temperature drops below this threshold for the first time.

## Tire inflation pressures

– with Tire Pressure Control (TPC)<sup>OE</sup>



The displayed tire inflation pressures refer to a tire temperature of 68 °F (20 °C). The figure on the left side **1** indicates the front tire's inflation pressure, while the figure on the right **2** shows the inflation pressure in the rear tire. Immediately after switching on the ignition, "-- --" is displayed, as the transfer of the inflation pressure values does not begin until a speed of 19 mph

(30 km/h) is exceeded for the first time.

**⚠** If the warning triangle **3** is also shown, a warning display is concerned. Critical inflation pressure flashes. The universal warning lamp lights up in yellow when the critical figure is at the limit of the approved tolerance range. If the monitored tire inflation pressure is outside the specified range the general warning lamp will flash in red.

Additional information on the BMW Motorrad Tire Pressure Monitor is provided starting on page (➡ 91).

## Operation

|                                              |    |
|----------------------------------------------|----|
| Steering and ignition lock .....             | 40 |
| Emergency on/off switch (kill switch) .....  | 42 |
| Lights .....                                 | 42 |
| Hazard warning lights system .....           | 43 |
| Turn indicators .....                        | 44 |
| Display .....                                | 44 |
| Clock .....                                  | 46 |
| Stopwatch .....                              | 47 |
| Antilock Brake System (ABS) .....            | 48 |
| Automatic Stability Control (ASC) .....      | 49 |
| Electronic suspension adjustment (ESA) ..... | 50 |
| Riding mode .....                            | 52 |
| Heated handlebar grips .....                 | 53 |

|            |    |
|------------|----|
| Seat ..... | 54 |
|------------|----|

## Steering and ignition lock

### Vehicle keys

You are provided with 2 ignition keys.

Should you lose your keys please refer to the information regarding the electronic immobilizer (EWS) (▮▮▮ 41).


The ignition lock, fuel filler cap and seat lock are operated with the same key.

- with case<sup>OA</sup>
- with Topcase<sup>OA</sup>

The cases and the topcase can also be ordered with locks for the same key on request. Please contact an authorized workshop for this purpose, preferably an authorized BMW Motorrad retailer.

### Locking handlebars

- Turn handlebars to left.




- Turn the ignition key to position **1** while moving the handlebars somewhat.
  - » Ignition, lights and all electrical circuits are switched off.
  - » Handlebars are locked.
  - » The ignition key can now be removed.

### Switching on ignition



- Insert motorcycle key into the steering and ignition lock. Turn key to position **1**.
  - » Parking lights and all function circuits are switched on.
  - » Engine can be started.
  - » Pre-Ride-Check is carried out. (▮▮▮ 76)
  - » ABS self-diagnosis is performed (▮▮▮ 76)
  - » ASC self-diagnosis in progress (▮▮▮ 77)

## Switch off ignition



- Turn ignition key to position **1**.
  - » Light is switched off.
  - » Handlebars are not locked.
  - » The ignition key can now be removed.
  - » Electrically powered accessories remain operational for a limited period of time.
  - » Battery can be charged via on-board socket.

## Electronic immobilizer (EWS)

The motorcycle's electronic circuitry monitors the data stored in the ignition key through a ring antenna incorporated in the steering and ignition lock. The engine control unit does not enable engine starting until this ignition key is recognized as "authorized" for your motorcycle.



### NOTICE

A further key attached to the same ring as the ignition key used to start the engine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The EWS warning is shown in the multifunction display.

Always store further vehicle keys separately from the ignition key.◀

If you lose a ignition key, you can have it disabled by your authorized BMW Motorrad retailer. When having a key disabled you should also bring all of the motorcycle's remaining keys with you.

The engine can no longer be started using a disabled ignition key; however, a disabled ignition key can be enabled again.

Emergency and spare keys are only available through an authorized BMW Motorrad retailer. As the ignition keys are part of an integrated security system, the retailer is under an obligation to check your legitimacy.

## Emergency on/off switch (kill switch)



- 1 Emergency on/off switch (kill switch)




### WARNING

#### Operation of the emergency ON/OFF switch when riding

Danger of falling due to blocking of rear wheel

- Do not operate the emergency ON/OFF switch when riding.◀

The engine can be switched off easily and quickly using the emergency on/off switch.



- A Engine is switched off  
B Operating position

## Lights Parking lights

The parking lights switch on automatically when the ignition is switched on.



### NOTICE

The parking lights are a strain on the battery. Do not leave the

ignition switched on longer than absolutely necessary.◀

## Headlight low beam

The low-beam headlight is automatically switched on under the following conditions:

- If the engine was started.
- If the vehicle is pushed while the ignition is switched on.



### NOTICE

With the engine switched off, you can switch on the lights by switching on the high-beam headlight with the ignition switched on or by operating the headlight flasher.◀

## High-beam headlight and headlight flasher



- Press switch **1** toward front to switch on high beams.
- Pull switch **1** rearward to actuate headlight flasher.

## Parking lamp

- Switch off ignition.



- Immediately after switching off the ignition push button **1** to the left and hold until the parking lamps come on.
- Switch ignition on and then off again to switch off parking lamp.

## Hazard warning lights system

### Operating hazard warning flashers

- Switch on ignition.



### NOTICE

The hazard warning flashers place a strain on the battery. Do not use the hazard warning flashers for longer than absolutely necessary.◀



### NOTICE

If a turn indicator button is pressed with the emergency flashing function switched on, the flashing function replaces the emergency flashing function as long as the button is pressed. If the turn indicator button is released, the emergency flasher function becomes active again.◀



- Press button **1** to switch on hazard warning flashers.  
» Ignition can be switched off.
- Press button **1** again to switch off hazard warning flashers.

## Turn indicators

### Operating turn indicators

- Switch on the ignition.



### NOTICE

The turn indicators automatically switch off when the defined driving time and distance have been reached. The defined riding time and distance can be set

by an authorized BMW Motorrad retailer. ◀



- Press button **1** to left to switch on left-side turn indicators.
- Press button **1** to right to switch on right-side turn indicators.
- Press button **1** into center position to switch off turn indicators.

## Display


### Selecting display readings

- Switching on ignition (▶▶ 40).



- Press button **1** to select the display in value area **2**.  
The following values can be indicated:
  - Total kilometers (in illustration)
  - Trip distance 1 (Trip I)
  - Trip distance 2 (Trip II)
  - with Tire Pressure Control (TPC)<sup>OE</sup>
  - Tire inflation pressures ◀

- Warnings if necessary
- with onboard computer<sup>OE</sup>



- Actuate INFO **1** to select the display in the value range **2**. The following data can be displayed:



Outside temperature



Coolant temperature



Average speed



Average fuel consumption



Current fuel consumption



Mileage covered since reaching the fuel reserve


- Press button **3** to select the display in value area **4**. The following values can be indicated:

- Total kilometers (in illustration)
- Trip distance 1 (Trip I)
- Trip distance 2 (Trip II)
- with Tire Pressure Control (TPC)<sup>OE</sup>
- Tire inflation pressures<1
- Warnings if necessary<1

## Resetting trip odometer

- Switching on ignition (III → 40).
- Selecting display readings (III → 44).

- » The desired trip odometer is selected.
- TRIP I or TRIP II is displayed.



- Keep INFO **1** pressed down until the trip odometer **2** is reset.

– with onboard computer<sup>OE</sup>



- Press and hold button **1** until tripmeter **2** has been reset.◀

## Resetting average data

– with onboard computer<sup>OE</sup>

- Switching on ignition (▶▶▶ 40).
- Selecting display readings (▶▶▶ 44).



Average fuel consumption



Average speed

» The symbol of the desired average value is displayed.



- Keep INFO **1** pressed down until the displayed average value is reset.

## Clock

### Set clock




**WARNING**

### Adjusting the clock while riding

Accident hazard

- Adjust the clock only when the motorcycle is stationary.◀

- Switching on ignition (▶▶▶ 40).




- Press and hold button **1** until hours **2** flash.
- Press button **1** repeatedly until desired hours are shown.
- Press and hold button **1** until minutes **3** flash.
- Press button **1** repeatedly until desired minutes are shown.
- Press and hold button **1** until minutes do not flash anymore.
- » Setting is completed.

## Stopwatch

– with onboard computer<sup>OE</sup>

### Stopwatch function




As an alternative to the odometer, the stopwatch **1** can be displayed. The display consists of hours, minutes, seconds and tenths of a second separated by dots.

The stopwatch continues to run in the background when the display is temporarily switched over to the odometer. The stopwatch also continues to run

when the ignition is temporarily switched off.

### Operating stopwatch



- If necessary, switch over from odometer to stopwatch with button **1**.
- With stopwatch stopped, press button **2** to start stopwatch.
- With stopwatch running, press button **2** to stop stopwatch.
- Press and hold button **2** to re-set stopwatch.


## Laptimer



To enable improved operation of the stopwatch while riding (as a Laptimer), the functions of the INFO **1** button and the functions of the **2** button can be interchanged. The stopwatch and the odometer are then operated using INFO **1** button; the onboard computer must be operated using the **2** button.

### Interchanging button functions

- Switching on ignition (➡ 40).



- Press and hold button **1** and button **2** simultaneously until display changes.
  - » FLASH (engine speed warning indicator) and ON or OFF are shown.
- Press button **2**.
  - » LAP (Laptimer) and ON or OFF are shown.
- Press button **1** repeatedly until desired state is shown.
  - » ON: stop watch is operated by INFO button on left-hand multifunction switch.

» OFF: operation of stopwatch with button **2** in instrument cluster.

- To save the setting made, press and hold button **1** and button **2** simultaneously until the display changes.

## Antilock Brake System (ABS)

### Switching the ABS function off

- Switching on ignition (▶▶ 40).



#### NOTICE

Switch the ABS function off at standstill only.◀



- Press and hold the **1** button until the ABS indicator and warning light changes its display behavior.



ABS indicator light lights up.


- with Automatic Stability Control (ASC)<sup>OE</sup>
  - » The ASC symbol's display behavior changes first. Press and hold the **1** button until the ABS indicator and warning light reacts. In this case, the ASC setting does not change.◀
- Release button **1** within two seconds.



ABS indicator light continues to be lit up.

» The ABS function is switched off.

## Switching the ABS function on



- Switching on ignition (▮▮▮▮ 40).



### NOTICE

Switch the ABS function on at standstill only.◀

- Press and hold the **1** button until the ABS indicator and

warning light changes its display behavior.



ABS indicator light goes out, and starts to flash if self-diagnosis has not been completed.

- Release button **1** within two seconds.



ABS indicator light remains off or continues to flash.

» The ABS function is switched on.

- As an alternative, the ignition can also be switched off and then on again.



### NOTICE

If the ABS indicator and warning light lights up after the ignition is turned off and on and then riding continues at more than 3 mph (5 km/h), an ABS fault has occurred.◀

## Automatic Stability Control (ASC)

– with Automatic Stability Control (ASC)<sup>OE</sup>


## Switching the ASC function off

- Switching on ignition (▮▮▮▮ 40).



### NOTICE

The ASC function can also be deactivated while driving.◀



- Press and hold the **1** button until the ASC indicator and

warning light changes its display behavior.



ASC indicator and warning light lights up.


- Release button **1** within two seconds.



ASC indicator and warning light continues to be lit up.

- » The ASC function is switched off.

## Switching the ASC function on



- Switching on ignition (➡ 40).



### NOTICE

The ASC function can also be switched on while riding.◀

- Press and hold the **1** button until the ASC indicator and warning light changes its display behavior.



ASC indicator and warning light goes out, and starts to flash if self-diagnosis has not been completed.

- Release button **1** within two seconds.



ASC indicator and warning light remains off or continues to flash.

- » The ASC function is switched on.
- As an alternative, the ignition can also be switched off and then on again.



### NOTICE

If the ASC indicator and warning light lights up after the ignition is turned off and on and then riding continues at more than 3 mph (5 km/h), an ASC fault has occurred.◀

## Electronic suspension adjustment (ESA)

- with Electronic Suspension Adjustment (ESA)<sup>OE</sup>


### Adjustment options

You can use the ESA electronic chassis and suspension adjustment feature to adapt damping on the rear wheel to the road surface. There is a choice of 3 damper settings. ESA calibrates itself at regular intervals when the vehicle is at a standstill and the engine is running to ensure that the system is

functioning properly. The chassis and suspension cannot be adjusted while the system is being calibrated.

## Viewing current setting

- Switching on ignition (➡ 40).



- Press **1** button to display the current chassis and suspension adjustment.




The adjusted damping is shown in the multifunction display, in area **1**. The displays provide the following information:

- COMF: Comfortable damping
- NORM: Normal damping
- SPORT: Sporty damping

» The display automatically disappears again after a short time.

## Setting suspension compliance

- Switching on ignition (➡ 40).



- Press button **1** to display the current setting.

To select a different setting for damping action:

- Press button **1** repeatedly until the desired setting appears in the multifunction display.



### NOTICE

The damping cannot be adjusted while the motorcycle is being ridden.◀

» If button **1** is not pressed for a longer time, damping is set as indicated.

- » The ESA display disappears once the adjustment procedure has been completed.

## Riding mode

### Use of the riding modes

BMW Motorrad has developed 3 riding scenarios for your motorcycle from which you can select the one matching your situation:

#### Highway operation

- Riding on wet roads.
- Riding on dry roads.
- with riding modes Pro<sup>OE</sup>

#### Off-road mode

- Riding off-road with road tires

For each of those 3 scenarios, the optimum balance between engine torque, throttle response, ABS and ASC feedback control is provided.



### NOTICE

Details on the selectable driving modes are provided in the chapter "Technology in Detail".◀

### Setting riding mode

- Switching on ignition (▶ 40).



### NOTICE

If a riding mode was selected prior to switching the ignition off, it remains further active after switching the ignition on again.◀



- Actuate MODE 1.

- » The selection arrow **2** is displayed.

- Actuate MODE **1** enough times for the selector arrow **2** to point to the desired riding mode.
- » The most recent riding mode setting **3** remains on the display.
- » While parked:
  - Activation takes place after approx. 2 seconds.
- » While in motion, the selected riding mode is activated provided that the following requirements have been satisfied:
  - Throttle grip is in neutral position for a short time.
  - Brake lever is not being operated.
- » Activation process has finished.
- The riding mode setting **3** is displayed without the selector arrow **2**.

When riding on wet roads with road tires:

- Activate the RAIN riding mode.

When riding on dry roads with road tires:

- Activate the ROAD riding mode.

– with riding modes Pro<sup>OE</sup>



When riding off-road with road tires:

- Activate the **4** ENDURO riding mode.<

## Heated handlebar grips

– with heated grips<sup>OE</sup>

### Operating heated grips

- Starting engine (→ 75).



#### NOTICE

The heated grips option can only be activated when the engine is running.<



#### NOTICE

The increase in power consumption caused by the heated grips can drain the battery if you are riding at low engine speeds. If the battery is inadequately charged, the heated grips are switched off to ensure starting capability.<



- Press button **1** repeatedly until desired heating level **2** is shown.

The handlebar grips can be heated at two different levels. The second level is used for fast heating of the grips; the switch should then be switched back to the first level.



Approx. 50 % heater output



100 % heating output

- » If no further changes are made the selected heating level is adopted as the setting.
- To switch off the heated grip, press button **1** repeatedly until heated grip symbol **2** is not shown anymore in the display.

## Seat


### Remove seat

- Park motorcycle, ensuring that support surface is firm and level.



- Turn seat lock **1** to left with ignition key and hold while

pressing seat downward at front to support movement.



- Raise seat bench **2** at front and release the ignition key.
- Take off seat and place on a clean surface with spacer buffers facing downward.

### Install seat



- Insert seat in brackets **3**.
- Firmly press down on seat at front.
- » The seat's detent mechanism will be heard to engage.

## Alarm system

|                                            |    |
|--------------------------------------------|----|
| Overview .....                             | 56 |
| Activation .....                           | 56 |
| Alarm function .....                       | 57 |
| Deactivation .....                         | 58 |
| Programming .....                          | 59 |
| Logging on additional remote controls..... | 61 |
| Synchronizing.....                         | 62 |
| Battery.....                               | 62 |

## Overview

- with anti-theft alarm system (DWA)<sup>OE</sup>

## General information on DWA

Any attempt to move the vehicle, change its position, start it without authorization, or disconnect the vehicle battery, results in the alarm being triggered. The sensitivity of the system is designed so that minor vibrations of the motorcycle do not trigger an alarm. Each theft attempt is signaled following activation of the system acoustically with the siren and optically with synchronized flashing of all 4 turn indicators. You can adjust the behavior of your DWA in partial areas to meet your needs.


## Protection of motorcycle battery

To protect the motorcycle battery and to maintain the starting capability, the activated DWA switches off automatically after several days. However, it remains active for at least 10 days.

## Radio interference

Radio systems or devices which transmit on the same frequency as the remote control of the DWA can interfere with its function. With corresponding problems point the remote control at the motorcycle from a different direction.

## Controls



- 1** LED
- 2** Right-hand button (▮▮▮ 58)
- 3** Left-hand button (ribbed) (▮▮▮ 57)

## Activation

- with anti-theft alarm system (DWA)<sup>OE</sup>

## Activation with motion sensor



The alarm function can be activated in 2 different ways:

- Pressing the **1** button once on the remote control. The alarm function is enabled after 15 seconds. If switched off more than one minute ago, the **1** button must be pressed for longer than one second.
- Turning off the ignition (if programmed). The alarm function is enabled after 45 seconds.

Activation is confirmed by two flashes of the turn signals and the sounding of two alarm tones.

## Protection of the battery in the control unit (DWA disabled)

After approx. one hour in the deactivated state, the DWA switches off to protect the battery. To activate the alarm function after this period, the ignition must be switched on and then off again.

## Motion sensor when transporting the motorcycle

If, for example, the motorcycle is to be transported by train, it is advisable to switch off the motion sensor. The strong movements could result in an accidental triggering of the alarm.

## Deactivating motion sensor



- Press button **1** of the remote control again during the activation phase.
  - » Turn indicators are illuminated three times.
  - » Alarm tone sounds three times.
  - » Motion sensor is deactivated.

## Alarm function

- with anti-theft alarm system (DWA)<sup>OE</sup>

## Alarm triggering

The DWA alarm can be set off by:

- Movement sensor.
- Switching on ignition with an unauthorized motorcycle key.
- Disconnection of the DWA from the motorcycle battery (DWA battery assumes the power supply).

## Alarm



The duration of the alarm is 26 seconds. The system is reactivated after another 12 seconds. A triggered alarm can be canceled at any time by

pressing the **1** button on the remote control. This function does not change the state of the anti-theft alarm system.

After the alarm has been triggered, an alarm tone sounds and the turn signals flash. The type of alarm sound can be programmed.

## Reason for triggering of the alarm

After the alarm function has been deactivated, the DWA LED indicates the reason for any alarm activation which may have occurred for one minute:

- 1x flash: movement sensor: motorcycle was tilted forward/back.
- 2x flashes: movement sensor: motorcycle was tilted to the side.
- 3x flashes: ignition was switched on using an unauthorized key.

- 4x flashes: anti-theft alarm system was disconnected from the vehicle battery.

## Note on alarm triggering

If an alarm was triggered after the last activation of the alarm function, then this is pointed out with a single signal tone after the ignition is switched on.

## Deactivation

- with anti-theft alarm system (DWA)<sup>OE</sup>

## Deactivate alarm function



### NOTICE

The alarm function can only be deactivated with the ignition key if the emergency ON/OFF switch is in the operating position.◀



## NOTICE

If the alarm function is deactivated by means of the remote control and the ignition then not switched on, the alarm function is automatically reactivated after 30 seconds if "Activation after ignition off" has been programmed.◀



- Actuate the **1** button on the remote control once **or** switch on the ignition with an authorized ignition key.
- » Turn indicators light up once.

- » Alarm tone sounds once (if programmed).
- » Alarm function is deactivated.

## Protection of the battery (DWA activated)

After approx. one hour in the activated state, the receiver for the remote control in the DWA switches off to protect the battery. The ignition must be switched on to deactivate the alarm function after this period.

## Programming

- with anti-theft alarm system (DWA)<sup>OE</sup>

## Programming options

The anti-theft alarm system can be adapted to individual needs in the following points:

- Confirmation alarm tone after activation/deactivation of the

DWA in addition to the turn signals lighting up.

- Rising and falling or intermittent alarm tone.
- Automatic activation of the alarm function when the ignition is switched off.

## Factory settings

The anti-theft alarm system is delivered with the following factory settings:

- Confirmation alarm tone after activation/deactivation of the DWA: no.
- Alarm tone: intermittent.
- Automatic activation of the alarm function when the ignition is switched off: no.

## Program DWA



- Deactivate alarm function (see 58).
- Switch on the ignition.
- Press button **1** three times.
- » Acknowledgment tone sounds once.
- Switch off the ignition within ten seconds.
- Press button **2** three times.
- » Acknowledgment tone sounds once.
- Switch on the ignition within ten seconds.
- » Acknowledgment tone sounds three times.

» The programming function is active.

The actual programming is carried out in 4 steps, and Step 2 is not assigned any function. The number of flashing signals on the DWA LED of the vehicle indicates the active programming step. Actuating the **1** button is confirmed by an alarm tone, and actuating the **2** button by an acknowledgment tone.

- **Step 1:** is a confirmation tone to sound after the DWA is activated/deactivated?

yes:

- Press button **1**.

no:

- Press button **2**.

### • **Step 2:**

This step is not assigned any function.

- Actuate the **1** button or **2** button.

- **Step 3:** Which alarm tone is to be selected?

rising and falling:

- Press button **1**.

intermittent:

- Press button **2**.

- **Step 4:** Is the alarm function to be automatically activated after the ignition is switched off?

yes:

- Press button **1**.

no:

- Press button **2**.

## When is the programming canceled?

Programming is terminated by switching off the ignition before the last program step, or automatically whenever more than 30 seconds lapse between 2 programming steps.

The data are not saved when programming is canceled.

## Save programming

Programming is stored when the ignition is switched off after the last programming step, or automatically 30 seconds after the last programming step.

The DWA LED goes out, and 4 acknowledgement tones sound.

## Logging on additional remote controls

– with anti-theft alarm system (DWA)<sup>OE</sup>

### When is it necessary to log on a remote control?

Should you log on an additional remote control or want to replace a lost remote control, then you must always log on all remote controls with the DWA. You can

log on a maximum of 4 remote controls.

## Logging on remote control



- Deactivate alarm function.
- Switch on the ignition.
- Press button **2** three times.
  - » Acknowledgment tone sounds once.
- Switch off the ignition within ten seconds.
- Press button **2** three times.
  - » Acknowledgment tone sounds once.

- Switch on the ignition within ten seconds.
  - » Acknowledgment tone sounds twice.

You can log on a maximum of 4 remote controls for the anti-theft alarm system. The logon for each remote control is carried out in 3 steps.

- Press and hold button **1** and button **2**.
  - » LED flashes for ten seconds.
- As soon as the LED goes out, release the **1** button and the **2** button.
  - » LED lights up.
- Actuate the **1** button or **2** button.
  - » Alarm tone sounds once.
  - » LED goes out.
  - » Remote control is logged on.
- For every other remote control, repeat the 3 previous operations.

## Logon ended

The logon is ended in the following situations:

- 4 remote controls have been logged on.
- Ignition is switched off.
- No button was pressed for 30 seconds after the ignition was switched off.
- No button was pressed for 30 seconds after a remote control was logged on.

After the logon is completed, the LED flashes and the acknowledgment tone sounds three times.

## Synchronizing

- with anti-theft alarm system (DWA)<sup>OE</sup>

## When is it necessary to synchronize the remote control?

The remote control must be synchronized when the buttons of the remote control has been operated more than 256 times outside the range of the receiver. In this case, the receiver on the motorcycle no longer reacts to the signals of the remote control.

## Synchronize remote control



- Press and hold button **1** and button **2**.

- » LED flashes for ten seconds.
- As soon as the LED goes out, release the **1** button and the **2** button.
- » LED lights up.
- Actuate the **1** button or the **2** button.
- » LED goes out.
- Remote control is synchronized.

## Battery

- with anti-theft alarm system (DWA)<sup>OE</sup>

## When is a battery change required?

The batteries of the remote control must be replaced after 2–3 years. A weak battery can be recognized from the fact that the LED does not light up at all or only briefly when a button is pressed.

## Replace battery




### ATTENTION

#### Unsuitable or improperly inserted batteries


Component damage

- Use specified battery (see "Technical Data" chapter).
- When inserting the battery, make sure that the polarity is correct.◀



- Remove screw **1** and take off lower housing section **2**.
- Slide old battery **3** forwards under retainer **4**.

- Install new battery. Ensure that positive terminal of battery is at top.
- Fit lower housing section to lug **5** on front edge and close it. When doing so, pay attention to the guide pins **6**.
- Install screw.
- » The LEDs on the remote control light up, i.e. the remote control must be activated.



- To activate the remote control within the range of the receiver, press the button **1** twice.

- » LED **2** begins to flash and goes out after a few seconds.
- » The remote-control is again ready to be used.



## Setting

|                      |    |
|----------------------|----|
| Mirrors .....        | 66 |
| Headlight .....      | 66 |
| Clutch .....         | 68 |
| Brakes .....         | 68 |
| Spring preload ..... | 69 |
| Damping .....        | 70 |

## Mirrors

### Adjusting mirrors



- Move mirror to the desired position by turning it.

### Adjusting mirror arm



- Slide protective cap **1** up over screw connection on mirror arm.
- Loosen the nut **2**.
- Turn mirror arm into desired position.
- Tighten the nut to the specified torque while holding the mirror arm to ensure that it does not move out of position.



Locknut (mirror) on clamping piece

Joint compound: Multi-Wax Spray



Locknut (mirror) on clamping piece

15 lb/ft (20 Nm)

- Slide protective cap over threaded fastener.

## Headlight

### Adjusting headlight for RHD/LHD traffic

This motorcycle's headlight features a symmetrical low beam. No special adjustments or procedures are required prior to operating the motorcycle in a country where traffic travels on the side of the road opposite to that of your home country (left-hand drive to right-hand drive or vice versa).

## Headlight range and spring preload

The headlight range generally remains constant due to the adjustment of the spring preload to the loading state.

Spring preload adjustment may only be insufficient when the motorcycle is very heavily loaded. In this case, the headlight range must be adjusted to the weight.



### NOTICE


If there are doubts as to the correct headlight range, have the adjustment checked by a specialized workshop, preferably by an authorized BMW Motorrad retailer. ◀

## Headlamp range adjustment



- Loosen screws **1** on left and right.
- Adjust headlight by tilting slightly.
- Tighten screws **1** on left and right.

## Basic headlight range adjustment



- Loosen screws **1** on left and right.
- Adjust headlight by tilting slightly so that tip **2** points to marking **3**.
- Tighten screws **1** on left and right.

## Clutch

### Adjusting clutch lever




#### WARNING

#### Adjusting the clutch lever while driving

Accident hazard

- Only adjust the clutch lever when the motorcycle is stationary.◀



- Turn adjusting screw **1** clockwise to increase distance between clutch lever and handlebar grip.

- Turn adjusting screw **1** counterclockwise to decrease distance between clutch lever and handlebar grip.



#### NOTICE

The adjusting screw can be turned more easily if you press the clutch lever forward when doing so.◀

## Brakes

### Adjusting brake lever



#### WARNING

#### Modified position of the brake fluid reservoir

Air in the brake system

- Do not twist the handlebar fitting or the handlebars.◀




#### WARNING

#### Adjusting the brake lever while driving

Accident hazard

- Only adjust the brake lever when the motorcycle is stationary.◀



- Turn the adjusting screw **1** clockwise in order to increase the clearance between the brake lever and handlebar grip.
- Turn the adjusting screw **1** counterclockwise in order to reduce the clearance between the brake lever and handlebar grip.



## NOTICE

The adjusting screw is easier to turn if you push the brake lever forwards.◀

## Spring preload

### Setting

It is essential to set the spring preload of the rear suspension to suit the load carried by the motorcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

### Adjusting spring preload at rear wheel

- Remove seat (▶ 54).



- Remove toolkit 2.



## WARNING

**Uncoordinated settings of spring preload and spring strut damping.**

Poorer handling.

- Adjust damping characteristic to changed spring preload.◀
- To increase spring preload, turn adjustment wheel **1** clockwise using toolkit.
- To decrease spring preload, turn adjustment wheel **1** counterclockwise using toolkit.



Basic setting of spring preload, rear

Turn adjustment wheel counterclockwise as far as possible. (One-up without load)

Turn adjustment wheel as far as possible counterclockwise, then 12 turns clockwise. (One-up with load)

Turn adjuster wheel clockwise up to stop. (Two-up with load)

- Remount toolkit.
- Install seat (▶ 54).

## Damping Setting

Damping must be adjusted to the road conditions and the spring preload.

- A rough road surface requires softer damping than a smooth road surface.
- An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

### Adjusting damping on rear wheel

- without Electronic Suspension Adjustment (ESA)<sup>OE</sup>
- Park motorcycle, ensuring that support surface is firm and level.



- Adjust damping via adjusting screw **1**.



- To increase damping, turn adjusting screw **1** in arrow direction H.

- To decrease damping, turn adjusting screw **1** in arrow direction S.



Basic setting of rear wheel rear-wheel damping

Turn adjusting screw as far as possible clockwise, then turn back 1.5 turns. (One-up without load)

Turn adjusting screw as far as possible clockwise, then turn back 1.5 turns. (One-up with load)

Turn adjusting screw as far as possible clockwise, then turn back 1 turn. (Two-up with load)

## Riding

|                                                         |    |
|---------------------------------------------------------|----|
| Safety information .....                                | 72 |
| Observe checklist .....                                 | 74 |
| If there is a change in the loading<br>condition: ..... | 74 |
| Before every journey: .....                             | 74 |
| At every third refueling stop: .....                    | 75 |
| Starting .....                                          | 75 |
| Running in .....                                        | 78 |
| Shifting gears .....                                    | 79 |
| Off-road riding .....                                   | 79 |
| Brakes .....                                            | 80 |
| Parking your motorcycle .....                           | 81 |
| Refueling .....                                         | 82 |
| Securing motorcycle for trans-<br>port .....            | 84 |

## Safety information

### Rider's equipment

The following clothing protects you while riding:

- Helmet
- Rider's suit
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorized BMW Motorrad retailer will be happy to advise you and has the correct clothing for every purpose.

### Correct loading



#### WARNING

**Reduced riding stability caused by overloading and uneven loading**

Accident hazard

- Do not exceed the gross weight limit and observe the loading information.◀
- Adjust spring preload and damping rate for the current gross motorcycle weight.
- with case<sup>OA</sup>
- Ensure that case volumes on left and right are equal.
- Make sure that weight is uniformly distributed between right and left.
- Pack heavy pieces of luggage to bottom and inside of cases.
- Observe the maximum payload and maximum speed as indicated on the label in the case (see also the chapter "Accessories").◀
- with Topcase<sup>OA</sup>
- Observe the maximum payload and maximum speed as indicated on the label in the

topcase (see also the chapter "Accessories").◀

- with tank bag<sup>OA</sup>
- Observe the maximum load capacity of the tank rucksack and the maximum speed at which the motorcycle may travel with a tank rucksack fitted.



Payload of tank rucksack

max 11 lbs (max 5 kg)



Speed limit for driving with tank rucksack

max 81 mph (max 130 km/h)◀

- with rear bag<sup>OA</sup>
- Observe the maximum load capacity of the rear bag and the maximum speed at which the motorcycle may travel with a rear bag fitted.



Payload of rear bag

max 3 lbs (max 1.5 kg)◀

## Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle, e.g.:

- Incorrect settings of spring-strut and shock absorber system
- Imbalanced load
- Loose clothing
- Insufficient tire inflation pressure
- Poor tire tread
- Installed luggage systems, such as cases, topcases and tank rucksacks.

## Maximum speed with studded or winter tyres



### DANGER

**Maximum speed of the motorcycle is higher than the permissible maximum rated speed of the tires.**

Risk of accident due to tire damage at high speed.

- Observe the maximum permissible speed for the tyres.◀

With studded or winter tyres, the maximum permissible speed for the tyres must be observed. Attach a label specifying the maximum permissible speed in the field of view of the instrument cluster.

## Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colorless and odorless but highly toxic.



### WARNING

#### Harmful exhaust gas

Danger of suffocation

- Do not inhale exhaust fumes.
- Do not run the engine in closed rooms.◀

## Burn hazard



### CAUTION

#### Intense heating up of engine and exhaust system while riding

Burn hazard

- After parking the motorcycle, make sure that no persons or objects come into contact with the engine and exhaust system.◀

## Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

The following must be observed:

- Do not run the fuel tank dry
- Do not run the engine with the spark-plug cap removed
- Stop the engine immediately if it misfires
- Use unleaded fuel only
- Comply with all specified maintenance intervals.



### ATTENTION

## Unburned fuel in the catalytic converter

Damage to catalytic converter

- Note the points listed for protection of the catalytic converter.◀

## Danger of overheating



### ATTENTION

## Engine idling for a lengthy period while at a standstill

Overheating due to insufficient cooling; in extreme cases vehicle fire

- Do not allow the engine to idle unnecessarily.
- After starting, ride off immediately.◀

## Modifications



### ATTENTION

## Modifications to the motorcycle (e.g. engine control unit, throttle valves, clutch)

Damage to the affected parts, failure of safety-relevant functions, expiration of warranty

- Do not make any modifications.◀

## Observe checklist

- Use the following checklist to check your motorcycle at regular intervals.

## If there is a change in the loading condition:

- without Electronic Suspension Adjustment (ESA)<sup>OE</sup>
- Adjusting spring preload at rear wheel (▮▮▮ 69).
- Adjusting damping on rear wheel (▮▮▮ 70).◀
- with Electronic Suspension Adjustment (ESA)<sup>OE</sup>
- Setting suspension compliance (▮▮▮ 51).◀

## Before every journey:

- Check operation of the brake system.
- Check operation of the lighting and signal system.

- Check clutch function (104).
- Checking tire tread depth (106).
- Checking tire pressure (106).
- Check secure hold of cases and luggage.

## At every third refueling stop:

- Checking engine oil level (98).
- Check front brake pad thickness (100).
- Check rear brake pad thickness (101).
- Checking front brake fluid level (102).
- Checking rear brake fluid level (103).
- Checking coolant level (105).
- Lubricating chain (127).
- Check chain sag (128).

## Starting Starting engine

### ATTENTION

#### Sufficient transmission gear-box lubrication only when the engine is running.

Transmission damage

- Do not allow the motorcycle to roll for longer periods or push it over longer distances with the engine switched off.◀
- Switching on ignition (40).
  - » Pre-Ride-Check is carried out. (76)
  - » ABS self-diagnosis is performed (76)
  - » ASC self-diagnosis in progress (77)
- Engage neutral, or pull back clutch lever if a gear is engaged.

### NOTICE

You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if it is started with the transmission in neutral and then a gear is engaged before retracting the side stand.◀

- For cold starts and at low ambient temperatures: pull lever to disengage clutch and twist throttle grip slightly.



- Press starter button 1.



## NOTICE

The starting attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you attempt to start the engine again, or use jumper cables and a donor battery to start. More detailed information can be found in the "Maintenance" chapter under "Jump-starting". ◀



Engine starts.

- » If the engine fails to start, the troubleshooting chart in chapter "Technical Data" may provide assistance. (▮▮▮ 146)

## Pre-Ride-Check

When the ignition is switched on the instrument cluster performs a test routine including the analog display instruments as well as the warning and indicator lights - this is the "Pre-Ride-Check." Starting

the engine before the test routine is completed will cancel the remainder of the routine.

### Phase 1

The needles on the tachometer and speedometer rotate to their end stops. Simultaneously all warning and indicator lights are activated sequentially.

### Phase 2

The universal warning light changes from yellow to red.

### Phase 3

The needles on the tachometer and speedometer return to their initial positions. At the same time, the previously activated warning and indicator lights are now switched off in reverse sequence.

If one of the needles fails to move, or if one of the warning and indicator lamps fails to light up:

- Have the malfunction corrected as soon as possible at an authorized service facility, preferably an authorized BMW Motorrad Retailer.

## ABS self-diagnosis

The self-diagnosis routine checks whether the BMW Motorrad Integral ABS is ready for operation. The self-diagnosis routine launches automatically when you switch on the ignition.

### Phase 1

- » Check on system components monitored by diagnostic system while motorcycle is parked. ABS indicator light flashes.



## Phase 2

- » Check wheel sensors while starting off.



ABS indicator light flashes.

### ABS self-diagnosis completed

- » The ABS indicator and warning light goes out.



ABS self-diagnosis routine not completed

ABS is not available, as the self-diagnosis routine was not completed. (The motorcycle must reach a specified minimum speed before the system can check operation of the wheel speed sensors: 3 mph (5 km/h))

If an ABS error is displayed after the ABS self-diagnosis is completed:

- It remains possible to continue riding. Bear in mind that neither the ABS function nor the integral function is available.
- Have the malfunction corrected as soon as possible at an authorized service facility, preferably an authorized BMW Motorrad Retailer.

### ASC self-diagnosis

The self-diagnosis routine checks whether the BMW Motorrad ASC is ready for operation. The self-diagnosis routine runs automatically when you switch on the ignition.

## Phase 1

- » Check on system components monitored by the diagnostic system while motorcycle is parked.



ASC indicator and warning light flashes slowly.

## Phase 2

- » Checking the diagnosable system components while the motorcycle is moving.



ASC indicator and warning light flashes slowly.

### ASC self-diagnosis completed

- » The ASC indicator and warning light goes out.

- Check the display of all indicator and warning lights.



ASC self-diagnosis routine not completed

ASC is not available because the self-diagnosis routine was not completed. (The motorcycle must reach a specified minimum speed before the system can check operation of the wheel sensors: min 3 mph (min 5 km/h))

If an ASC error is indicated following completion of the ASC self-diagnosis routine:

- It remains possible to continue riding. It must be noted that the ASC function is not available.
- Have the malfunction corrected as soon as possible at an authorized service facility, preferably an authorized BMW Motorrad Retailer.

## Running in Engine

- In the period preceding the initial inspection attempt to change rpm and engine load as frequently as possible, avoiding extended periods at constant rpm.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding highways if possible.

- Observe the engine run-in speeds.



Engine run-in speed

<5000 min<sup>-1</sup>

- Observe mileage, after which the running-in check should be performed.



Mileage until first running-in check

311...746 miles  
(500...1200 km)

## Brake pads

New brake pads have to be broken in before they can achieve their optimum frictional force. This initial reduction in braking efficiency can be compensated for by exerting greater pressure on the brake levers.



## WARNING

### New brake pads

Extension of the braking distance, accident hazard

- Brake early.◀

## Tyres

New tires have a smooth surface. This must be roughened by riding in a restrained manner at various lean angles until the tires are run in. Only once the surface has been roughened can the tires achieve maximum grip.



## WARNING

### Loss of adhesion of new tires on wet roads and at extreme angles

Accident hazard

- Always think well ahead and avoid extreme angles.◀

## Shifting gears

– with onboard computer<sup>OE</sup>

## Engine speed warner




The engine speed warner signals to the rider that the red engine speed range has been reached. The red indicator lamp **1** of the engine speed warner flashes to provide this signal.

This signal lamp continues to flash until the rider either upshifts to a higher gear or reduces the engine speed. The engine speed warner can be activated or deactivated by the rider.

## Activating the engine speed warner

- Switching on ignition (III 40).



- Press and hold button **1** and button **2** simultaneously until display changes.
  - » FLASH **3** and ON or OFF are displayed.
- Press button **1** until desired state is shown.
  - » ON: engine speed warner activated.
  - » OFF: engine speed warner deactivated.

- To save the setting made, press and hold button **1** and button **2** simultaneously until the display changes.

## Off-road riding

### After driving offroad

BMW Motorrad recommends that the following be observed after driving offroad:

### Tire inflation pressure



### WARNING

**When riding off-road, reduce the tire pressure when riding on paved surfaces.**

Risk of accident due to poorer driving characteristics.

- Ensure proper tyre inflation pressure. ◀

## Brakes



### WARNING

#### Riding on unpaved or dirty roads.

Delayed braking effect caused by dirty brake discs and brake pads.

- Brake early until the brakes are braked clean.◀



### ATTENTION

#### Riding on unpaved or dirty roads

Increased brake pad wear

- Check the brake pad thickness more often and replace the brake pads sooner.◀

#### Spring preload and damping



### WARNING

#### Modified values for spring preload and spring strut

#### damping when riding off-road.

Poorer driving characteristics on paved surfaces.

- Before returning to on-road use, reset the correct spring preload and spring strut damping.◀

#### Rims

BMW Motorrad recommends checking the rims for possible damage after riding offroad.

#### Air cleaner insert



### ATTENTION

#### Dirty air filter element

Engine damage

- When driving in dusty terrain, check air filter insert for soiling at short intervals and clean or replace if necessary.◀

Use under very dusty conditions (deserts, savannas, etc.) requires

the use air cleaner inserts specially developed for these kinds of applications.

## Brakes

### How do you achieve the shortest stopping distances?

The dynamic load distribution between the front and rear wheel changes during braking. The heavier you brake, the greater the weight transfer to the front wheel. Increases in the load on an individual wheel are accompanied by a rise in the effective braking force that the wheel can provide.

To achieve the shortest possible braking distance, the front brake must be applied quickly and with progressively greater levels of force. This procedure provides ideal exploitation of the extra weight transfer to the front

wheel. The clutch should also be disengaged at the same time. With the frequently instructed "forced braking," in which the brake pressure is generated as quickly as possible and with great force, dynamic load distribution lags behind the progressive increases in deceleration rate and the braking force cannot be completely transferred to the road surface. The front wheel can lock up.

Locking up of the front wheel is prevented by BMW Motorrad ABS.

## Descending mountain passes

### **WARNING**

**Braking only with the rear-wheel brake when descending mountain passes**

Reduced of braking action, destruction of the brakes caused by overheating

- Use both front and rear brakes, and make use of the engine's braking effect as well.◀

## Wet, soiled brakes

Moisture and dirt on the brake rotors and the brake pads result in a decrease in the braking action.

Delayed or poorer braking action must be expected in the following situations:

- When driving in the rain and through puddles.
- After washing the vehicle.
- When driving on roads spread with salt.
- After working on the brakes due to oil or grease residues.
- When driving on soiled roads or offroad.



### **WARNING**

## Poorer braking action due to moisture and dirt

Accident hazard

- Brake until brakes are dry or clean; clean if necessary.
- Brake early until the full braking action is available again.◀

## Parking your motorcycle

### Side stand

- Switch off engine.



### **ATTENTION**

## Poor ground conditions in area of stand

Component damage cause by tipping over

- Always check that the ground under the stand is level and firm.◀

**ATTENTION****Loading of the side stand with additional weight**

Component damage cause by tipping over

- Do not sit on the motorcycle when it is parked on the side stands.◀
- Fold out side stand and park motorcycle.
- If the slope of the road permits, turn the handlebars to the left.
- On slopes point the motorcycle uphill and engage 1st gear.

**Center stand**

– with center stand<sup>OE</sup>

- Switch off engine.

**ATTENTION****Poor ground conditions in area of stand**

Component damage cause by tipping over

- Always check that the ground under the stand is level and firm.◀

**ATTENTION****Center stand folds if subject to sharp movements.**

Component damage cause by tipping over

- Do not sit on the motorcycle while it is resting on the center stand.◀
- Fold out center stand and jack up motorcycle.
- On slopes point the motorcycle uphill and engage 1st gear.

**Refueling****Fuel specifications Requirement**

For optimal fuel economy, the gasoline should be sulfur-free or very low in sulfur content.

**ATTENTION****Refueling with leaded fuel**

Damage to catalytic converter

- Do not refuel with leaded gasoline or gasoline with metallic additives, e.g. manganese or iron.◀

**ATTENTION****Use of Ethanol E85 as fuel**

Damage to the engine and fuel supply

- Do not refuel with E85, i.e. fuel with an ethanol content of 85 %, or with Flex Fuel.◀

- Fuels with a maximum ethanol content of 10%, i.e. E10, can be used.



Recommended fuel quality

Super unleaded (max. 10 % ethanol, E10)  
89 AKI (95 ROZ/RON)  
89 AKI

– with regular-grade gasoline, unleaded<sup>OE</sup>

Regular unleaded (minor restrictions with regard to power and fuel consumption) (max. 10 % ethanol, E10)  
87 AKI (91 ROZ/RON)  
87 AKI◀

## Refueling



### WARNING

#### Fuel is highly flammable

Fire and explosion hazard

- Do not smoke. Never bring a naked flame near the fuel tank.◀



### WARNING

#### Escaping of fuel due to expansion under exposure to heat with overfilled fuel tank

Accident hazard

- Do not overfill the fuel tank.◀



### ATTENTION

#### Contact of fuel and plastic surfaces


Damage to surfaces (become unattractive or cloudy)

- Immediately clean plastic surfaces after contact with fuel.◀
- Make sure ground is level and firm and place motorcycle on side stand.



### NOTICE

The available fuel tank volume can only be fully utilized with the vehicle standing on the side stand.◀



- Open protective cap **1**.
- Unlock fuel-tank cap **2** with ignition key by turning clockwise, then swivel it up.



- Refuel with a fuel meeting the specifications below, continuing until fuel is no higher than lower edge of fuel filler neck.

### NOTICE

When refueling after running on fuel reserve, the resulting total fuel quantity must be greater than the fuel reserve, so that the new filling level is detected and the low-fuel warning light is switched off.◀

### NOTICE

The "usable fuel quantity" specified in the technical data is the fuel quantity, which can be refueled if the fuel tank was completely emptied, i.e., if the engine dies off due to lack of fuel.◀



Usable fuel quantity

Approx. 4.2 gal (Approx. 16 l)



Reserve fuel quantity

min 2.9 quarts (min 2.7 l)

- Press fuel tank cap down firmly to close.
- Remove vehicle key and close protective cap.

## Securing motorcycle for transport

- Protect all components, along which straps are routed, against scratching. For example, use adhesive tape or soft cloths.



### ATTENTION


#### Motorcycle tips to the side when raising

Component damage caused by tipping over

- Secure the motorcycle against tipping to the side, preferably

with the assistance of a second person.◀

- Push motorcycle onto transport surface, and do not place on side stand or center stand.



## ATTENTION

### Pinching of components

Component damage

- Do not pinch components, e.g. brake lines or wiring harnesses.◀
- Fasten straps at front on both sides on lower fork bridge and tension.



- Fasten straps at rear on both sides on rear frame and tension.
- Tension all straps evenly; the motorcycle should be pulled down against its springs with the suspension compressed as much as possible.



## Technology in detail

|                                            |    |
|--------------------------------------------|----|
| General notes .....                        | 88 |
| Antilock Brake System (ABS) .....          | 88 |
| Automatic Stability Control<br>(ASC) ..... | 90 |
| Tire pressure control (RDC) .....          | 91 |
| Riding mode .....                          | 92 |

## General notes

More information on the topic of technology is available at:

**[bmw-motorrad.com/technology](http://bmw-motorrad.com/technology)**

## Antilock Brake System (ABS)

### How does ABS work?

The maximum braking force that can be transferred to the road surface is partially dependent on the friction coefficient of the road surface. Gravel, ice, snow and wet roads offer a considerably poorer friction coefficient than a dry, clean asphalt surface. The poorer the friction coefficient of the road surface is, the longer the braking distance will be. If the maximum transferable braking force is exceeded when the driver increases the brake pressure, the wheels begin to lock and driving stability is lost, and a

fall can result. Before this situation occurs, ABS intervenes and adjusts the brake pressure to the maximum transferable braking force. This enables the wheels to continue to turn and maintains riding stability regardless of the road condition.

### What happens when rough roads are encountered?

Bumpy or rough roads can briefly lead to a loss of contact between the tires and the road surface, until the transferable braking force is reduced to zero. If braking is carried out in this situation, ABS must reduce the brake pressure to ensure driving stability when restoring contact to the road. At this point in time, the BMW Motorrad ABS must assume extremely low friction coefficients (gravel, ice, snow) so that the running wheels turn in

every imaginable case and the driving stability is ensured. After detecting the actual conditions, the system adjusts the optimum brake pressure.

### Lifting off rear wheel

During extremely heavy and rapid decelerations, however, it is possible under certain circumstances that the BMW Motorrad Antilock Brake System cannot prevent the rear wheel from lifting off the ground. In these cases, the motorcycle can also flip end over end.



### WARNING

#### Lifting off of the rear wheel due to heavy braking

Accident hazard

- When braking heavily, bear in mind that the ABS control cannot always be relied on to prevent the rear wheel from lifting off the ground. ◀

## What are the design characteristics of the BMW Motorrad ABS?

The BMW Motorrad ABS ensures driving stability on any surface within the limits of driving physics. The system is not optimized for special requirements resulting under extreme weather conditions offroad or on the race track.

### Special situations

To detect the tendency of the wheels to lock up, the speeds of the front and rear wheel are compared. If implausible values are detected over a longer period of time, the ABS function is deactivated for safety reasons and an ABS error is indicated. A self-diagnosis routine must be completed before the error will be displayed.

Apart from problems with the BMW Motorrad ABS, unusual

riding conditions can also cause a fault message to be generated:

- Driving on the rear wheel (wheelie) for a longer period.
- Rear wheel rotating with the vehicle held stationary by applying the front brake (burn-out).
- Warm-up on the center or auxiliary stand at idle or with gear engaged.
- Locked-up rear wheel for a longer period of time, e.g. when riding downhill offroad.

Should a fault code occur due to an unusual driving condition, the ABS function can be reactivated by switching the ignition off and then on again.

## How important is regular maintenance?



### WARNING

#### Brake system not regularly serviced

Accident hazard

- To ensure that the BMW Motorrad ABS is in a properly maintained condition, it is vital that the specified service intervals are kept to. ◀

#### Reserves for safety

But remember: the potentially shorter braking distances which BMW Motorrad ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Be careful in curves! When you apply the brakes on a corner, the motorcycle's weight and

momentum take over and even BMW Motorrad ABS is unable to counteract their effects.

## Automatic Stability Control (ASC)

– with Automatic Stability Control (ASC)<sup>OE</sup>

### How does ASC work?

BMW Motorrad ASC compares the wheel speeds of the front and rear wheels. Differences in the relative rotation speeds allow the system to determine the slip rate, and thus the stability reserves at the rear wheel. The engine control adapts the engine torque when the slip limit is exceeded.

## What are the design features of BMW Motorrad ASC?

BMW Motorrad ASC has been designed to provide the rider with extra assistance during motor-cycle operation on public roads. The extent to which the rider affects ASC control can be considerable (weight shifts when cornering, loose luggage on the motorcycle), especially when approaching the limits imposed by the laws of physics.

The ENDURO riding mode should be activated for off-road riding. In this mode, the controlling intervention by the ASC is carried out later, enabling controlled drifting.

The system is not optimized for the special conditions encountered under extreme weather during off-road and racing use. BMW Motorrad ASC can be

switched off under these conditions.



## WARNING

### Risky riding style

Accident hazard despite ASC

- The rider is always responsible for adapting his/her driving style.
- Do not reduce the system's extra safety margin with careless riding or unnecessary risks. ◀

### Special situations

As lean angles increase, acceleration potential is also progressively restricted by the laws of physics. This can result in delayed acceleration when coming out of very tight curves.

The system compares the rotation speeds of the front and rear wheels to detect any tendency for the rear wheel to spin or lose traction. If the system registers

implausible data for an extended period of time it will deactivate the ASC functionality as safety precaution and a display will alert you to an ASC error. A self-diagnosis routine must be completed before the error will be displayed.

The following non-standard operating conditions may lead to automatic deactivation of BMW Motorrad ASC:

- Riding on the rear wheel only (wheelie).
- Rear wheel rotating with the vehicle held stationary by applying the front brake (burn-out).
- Warm-up on the center or auxiliary stand at idle or with gear engaged.

ASC is reactivated by switching the ignition off and on and then riding at a speed above 3 mph (5 km/h).

If the front wheel loses contact with the ground under extreme acceleration, the ASC reduces the engine torque, maintaining the reduction until the front wheel makes contact with the ground again.

BMW Motorrad recommends that you respond to this condition by twisting back the throttle grip somewhat to return to stable dynamic operating conditions as quickly as possible.

On a slippery surface, the throttle grip should never be suddenly twisted back completely unless the clutch is disengaged at the same time. The engine's braking torque could cause the rear wheel to lock, resulting in unstable motorcycle conditions. BMW Motorrad ASC is unable to intervene effectively under these conditions.

## Tire pressure control (RDC)

– with Tire Pressure Control (TPC)<sup>OE</sup>

### Operation

A sensor located in each tire monitors the air temperature and the inflation pressure inside the tire and transmits this information to the control unit.

The sensors are equipped with a centrifugal controller, which does not enable the transmission of the measured values until a speed of approx. 18.5 mph (30 km/h) is reached. Before initial reception of the tire inflation pressure, — is shown in the display for each tire. The sensors continue to transmit the monitored data for approx. 15 minutes after the motorcycle comes to a stop.

## Temperature compensation

The inflation pressure within a tire is sensitive to temperature: it responds to higher tire temperatures by increasing, and to lower temperatures by dropping. Tire temperature, in turn, varies according to the ambient temperature as well as in response to driving style and trip duration.

The tire inflation pressures are shown temperature-compensated in the multifunction display; they refer to a tire temperature of 68 °F (20 °C). No temperature compensation is available in the inflation pressure gauges at filling stations, meaning that the measured tire inflation pressure varies according to tire temperature. As a result, the pressure figures indicated by the gauges at filling stations will usually vary

from those appearing in the multifunction display.

## Tire inflation pressure ranges

The RDC control unit distinguishes between three inflation pressure ranges matched to the motorcycle:

- Inflation pressure within the permissible tolerance.
- Inflation pressure at the limits of the permissible tolerance.
- Inflation pressure outside the permissible tolerance.

## Adjusting inflation pressure

Compare the TPC/RDC value in the multifunction display with the value on the back cover of the Rider's Manual. The difference between the two values must be compensated with the air pressure tester at the filling station.

Example: According to the Rider's Manual, the tire inflation pressure is to be 36 psi (2.5 bar), however 33 psi (2.3 bar) is shown in the multifunction display. The tester at the filling station indicates 34.8 psi (2.4 bar). This value must be increased by 3 psi (0.2 bar) to 37.8 psi (2.6 bar) in order to produce the correct tire inflation pressure.

## Riding mode Selection

In order to adjust the motorcycle to the road condition, one of 3 riding modes can be selected:

- RAIN
- ROAD (standard mode)

- with riding modes Pro<sup>OE</sup>
- ENDURO

For each of the 3 riding modes, adapted settings for the ABS and ASC systems and for the throttle response are available.

In every mode, ABS and/or ASC can be turned off. The following explanations refer to the systems that are switched on.

### **Throttle response**

- In the RAIN and ENDURO riding modes: the response behavior of the engine is reticent. The maximum torque is not provided. The torque curve for rain applies.
- In the ROAD riding mode: The engine's response is optimal and direct. The maximum torque is provided.

### **ABS**

- In the RAIN and ROAD riding modes, the ABS is matched to the road conditions and the use of road tires. Intervention of the ABS occurs at such an early stage that maximum ride stability (i.e. roadholding) is achieved. This also applies to lift-off detection for the rear wheel.
- In the ENDURO riding mode, ABS is matched to off-road operation using road tires. Intervention of the ABS occurs later than during on-road operation. When riding off-road, slight lifting of the rear wheel is tolerated by the system.

### **ASC**

- The front wheel lift-off detection is switched on in all riding modes and it offers maximum support.

- In the RAIN and ROAD riding modes, the ASC is matched to road operation.
- Intervention of the ASC occurs in the RAIN riding mode at such an early stage that maximum ride stability (i.e. roadholding) is achieved. Intervention of the ASC occurs in the ROAD riding mode later than in the RAIN riding mode. Slipping of the rear wheel is avoided whenever possible.
- The ENDURO riding mode is designed for road tires in off-road mode. Intervention of the ASC occurs later, enabling slight drifts to occur.

### **Changing setting**

The process of changing between the ABS and ASC functions for the prevailing riding mode is only possible while in motion if certain operating conditions are met:

- No drive torque at rear wheel.
- No brake pressure in the braking system.

This operating mode is active when the motorcycle is stopped with the ignition switched ON. As an alternative, the following steps must be carried out:

- Turn back throttle grip.
- Do not actuate brake lever.

First the desired riding mode is preselected. The new selection is not activated until the specified conditions are present in all affected systems.

## Maintenance

|                           |     |
|---------------------------|-----|
| General instructions..... | 96  |
| Tool kit .....            | 96  |
| Service tool kit .....    | 96  |
| Front wheel stand .....   | 97  |
| Engine oil .....          | 98  |
| Brake system .....        | 100 |
| Clutch .....              | 104 |
| Coolant .....             | 105 |
| Tires .....               | 106 |
| Rims and tires .....      | 106 |
| Wheels .....              | 107 |
| Air filter .....          | 114 |
| Light sources .....       | 115 |
| Fairings and panels ..... | 121 |
| Jump-starting.....        | 122 |


|                            |     |
|----------------------------|-----|
| Battery.....               | 123 |
| Fuses .....                | 126 |
| Diagnostic connector ..... | 127 |
| Chain .....                | 127 |

## General instructions

The "Maintenance" chapter describes work involving the checking and replacement of wear parts that can be performed with a minimum of effort. If special tightening torques are to be taken into account for assembly, these are listed. An overview of all required tightening torques is contained in the chapter "Technical Data". Information on additional maintenance and repair work is provided in the Repair Manual for your vehicle on DVD, which you can obtain from your authorized BMW Motorrad retailer.

Special tools and thorough specialized knowledge are required to carry out some of the work described here. If you are in doubt, consult an authorized workshop, preferably your authorized BMW Motorrad retailer.

## Tool kit




- 1** Screwdriver handle
- 2** Reversible screwdriver insert with Phillips and straight blade
  - without LED turn indicator<sup>OE</sup>
  - Remove light sources in front and rear turn indicators (➡ 118).
  - Replacing light source for license-plate light (➡ 119).
  - Removing battery (➡ 125).

- 3** Open-ended wrench  
Wrench size: 17 mm  
– Adjusting mirror arm (➡ 66).
- 4** Torx wrench T40  
– Headlamp range adjustment (➡ 67).
- 5** Reversible screwdriver insert  
Phillips PH1 and Torx T25  
– Removing center fairing panel (➡ 121).

## Service tool kit

- with service tool set<sup>OA</sup>



For more extensive service operations (such as wheel removal and installation), BMW Motorrad has put together a service tool kit matched to your motorcycle. You can purchase this tool kit from your authorized BMW Motorrad retailer.

## Front wheel stand

### Mount front wheel stand




#### ATTENTION

### Use of the BMW Motorrad front wheel stand without an auxiliary stand


Component damage caused by tipping over

- Place the motorcycle on an auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand. ◀
- Place motorcycle on a suitable auxiliary stand.
- with center stand <sup>OE</sup>
- Place motorcycle onto center stand. ◁




- Use basic stand (83 30 0 402 241) with front wheel mount (83 30 0 402 242).

- Loosen mounting bolts **1**.
- Push two mounts **2** outward, continuing until front suspension fits between them. Adjust support pin to match front suspension.
- Use locating pins **3** to set front wheel stand to desired height.
- Center front wheel stand relative to front wheel and push it against front axle.



- Align two mounts **2** so that front suspension rests securely on them.
- Tighten securing screws **1**.



- Apply uniform pressure to push front wheel stand down and raise motorcycle.

– with center stand<sup>OE</sup>



### ATTENTION

#### Lifting-off of the center stand if the vehicle is raised too high

Component damage cause by tipping over

- When raising the motorcycle, make sure that the center stand remains on the ground.

- Adjust the height of the front wheel stand if necessary.◀
- Ensure that motorcycle is standing securely.<

## Engine oil

### Checking engine oil level



### ATTENTION

**Misinterpretation of the oil filling quantity, as the oil level is temperature-dependent (the higher the temperature, the higher the oil level)**

Engine damage

- Only check the oil level after a longer journey or when the engine is warm.◀
- Wipe area around oil filler location clean.
- Allow engine to idle until fan starts, then let it continue running for an additional minute.
- Switch off engine.

- Make sure ground is level and firm and hold motorcycle at operating temperature vertically.
- with center stand<sup>OE</sup>
- Make sure ground is level and firm and place motorcycle at operating temperature on its center stand.<



### ATTENTION


#### Motorcycle tips to the side when raising

Component damage cause by tipping over


- Secure the motorcycle against tipping to the side, preferably

with the assistance of a second person.◀

- Remove oil dipstick **1**.



- Wipe off the graduated section **2** with a dry cloth
- Position oil dipstick on oil filler opening, but do not screw in.
- Remove oil dipstick and read fluid level.



 Specified level of engine oil

Between the **MIN** and **MAX** marks



Engine oil, quantity for topping up

SAE 15W-50, API SJ/ JASO MA2, Additives (for instance, molybdenum-based substances) are prohibited, because they would attack the coatings on engine components, BMW Motorrad recommends BMW Motorrad ADVANTEC Pro Oil

max 0.4 quarts (max 0.4 l) (Difference between MIN and MAX)

If the oil level is below MIN mark:

- Topping up engine oil (100).

If oil level is above MAX mark:

- Have fluid level corrected by an authorized workshop, preferably an authorized BMW Motorrad retailer.
- Install oil dipstick.

## Topping up engine oil

- Make sure ground is level and firm and park motorcycle.
- Clean the area adjacent to the oil filler opening.



- Remove oil dipstick **1**.



### ATTENTION

#### Use of too little or too much engine oil

Engine damage

- Always make sure that the oil level is correct.◀

- Add engine oil up to specified level.
- Checking engine oil level (▶▶ 98).
- Install oil dipstick.

## Brake system

### Checking brake operation

- Actuate the handbrake lever.
  - » Pressure point must be clearly perceptible.
- Actuate the footbrake lever.
  - » Pressure point must be clearly perceptible.

If no clear pressure points are perceptible:



### ATTENTION

#### Improper working on the brake system


Endangering of the operating safety of the brake system

- Have all work on the brake system carried out by experts.◀



- Have the brakes checked at an authorized workshop, preferably an authorized BMW Motorrad retailer.

## Check front brake pad thickness

- Make sure ground is level and firm and park motorcycle.



- Visually inspect left and right brake pads to determine their thickness. Direction of view: between wheel and front wheel control to brake calipers **1**.



min 0.04 in (min 1.0 mm)  
(Only friction material without  
carrier plate. The wear mark-  
ings, i.e. the grooves, must be  
clearly visible.)

If the wear indicators are no  
longer clearly visible:



**Dropping below the minimum  
pad thickness**

Reduced braking action, damage  
to the brake


- In order to ensure the operat-  
ing reliability of the brake sys-  
tem, make sure that the brake  
pads are not worn beyond their  
minimum thickness. ◀
- Have the brake pads replaced  
at an authorized service facil-  
ity, preferably an authorized  
BMW Motorrad dealer.

### Check rear brake pad thickness

- Park motorcycle, ensuring that  
support surface is firm and  
level.



- Conduct a visual inspection of  
the brake pad thickness. Direc-  
tion of view: from rear at brake  
caliper **1**.



min 0.04 in (min 1.0 mm)  
(Only friction material without  
carrier plate.)

If brake pads are worn:

## ⚠ WARNING

### Dropping below the minimum pad thickness

Reduced braking action, damage to the brake

- In order to ensure the operating reliability of the brake system, make sure that the brake pads are not worn beyond their minimum thickness. ◀
- Have brake pads replaced by a specialist service facility, preferably an authorized BMW Motorrad retailer.

### Checking front brake fluid level

- Make sure ground is level and firm and hold motorcycle vertically.
- with center stand<sup>OE</sup>
- Make sure ground is level and firm and place motorcycle on its center stand. ◀

- Move handlebars into straight-ahead position.



## ⚠ WARNING

### Insufficient brake fluid in the brake-fluid reservoir

Considerably reduced braking performance caused by air in the brake system

- Check brake fluid level regularly. ◀
- Check brake fluid level in front brake-fluid reservoir **1**.

## 🔑 NOTICE

The brake fluid level in the brake-fluid reservoir drops due to brake pad wear. ◀



 Front brake fluid level (visual check)

Brake fluid, DOT4


You should never allow the brake fluid level to drop below the **MIN** mark.

If brake fluid level falls below the approved level:

- Have the defect corrected as soon as possible by an authorized workshop, preferably an authorized BMW Motorrad retailer.

## Checking rear brake fluid level

- Make sure ground is level and firm and hold motorcycle vertically.  
– with center stand<sup>OE</sup>
- Make sure ground is level and firm and place motorcycle on its center stand.◀



### **WARNING**

#### **Insufficient brake fluid in the brake-fluid reservoir**

Considerably reduced braking performance caused by air in the brake system

- Check brake fluid level regularly.◀
- Read brake fluid level at rear brake-fluid reservoir **1**.



### **NOTICE**

The brake fluid level in the brake-fluid reservoir drops due to brake pad wear.◀



Rear brake fluid level (visual check)

Brake fluid, DOT4

You should never allow the brake fluid level to drop below the **MIN** mark.

If brake fluid level falls below the approved level:

- Have the defect corrected as soon as possible by an authorized workshop, preferably an authorized BMW Motorrad retailer.

## Clutch

### Check clutch function

- Pull back the clutch lever.
- » Pressure point must be clearly perceptible.

If no clear pressure point can be felt:

- Have the clutch checked by an authorized workshop, preferably an authorized BMW Motorrad retailer.

### Check clutch pedal free play



- Actuate the clutch lever until resistance can be felt. Observe cut-out between edges **1** and **2** in the handlebar fitting.
- » The inner edge of cable mount **1** should move to outer edge **2** of the handlebar fitting.




Clutch cable play

0.12...0.2 in (3...5 mm) (Handlebars in straight-ahead position)

If clutch pedal free play is outside tolerance:

- Adjust clutch pedal free play (▶ 104).

### Adjust clutch pedal free play



- Slide rubber grommet **1** to the side.
- Loosen the nut **2**.
- To increase clutch pedal free play: turn adjusting screw **3** into handlebar fitting.
- To decrease clutch pedal free play: turn adjusting screw **3** out of handlebar fitting.

- Check clutch pedal free play (104).
- Tighten nut **2** while holding adjusting screw **3** to ensure that it does not move out of position.
- Pull rubber grommet **1** over the nut.

## Coolant

### Checking coolant level

- Make sure ground is level and firm and park motorcycle.



- Read off coolant level on expansion tank **1**. Viewing di-

rection: from front through windshield and right-hand side panel.



Coolant, specified level

between MIN – MAX mark on the expansion tank (Engine cold)

If coolant level drops below approved level:

- Add coolant.

## Topping up coolant



- Open cap **1** of expansion tank.
- Add coolant up to specified level using a suitable funnel.
- Close cap of expansion tank.

## Tires

### Checking tire pressure



#### WARNING

#### Incorrect tire inflation pressure

Poorer handling characteristic of motorcycle, reduction of tire service life

- Ensure proper tire inflation pressure. ◀



#### WARNING

#### Automatic opening of vertically installed valve cores at high speeds.

Sudden loss of tyre inflation pressure.

- Use valve caps with rubber sealing ring and screw on firmly. ◀
- Park motorcycle, ensuring that support surface is firm and level.

- Check tire pressures against data below.



Tire pressure, front

31.9 psi (2.2 bar) (One-up, with cold tires)

31.9 psi (2.2 bar) (Driver with passenger and/or load, with cold tire)



Tire pressure, rear

36.3 psi (2.5 bar) (One-up, with cold tires)

42.1 psi (2.9 bar) (Driver with passenger and/or load, with cold tire)

If tire pressure is too low:

- Correct tire pressure.

## Rims and tires

### Check wheel rims

- Make sure ground is level and firm and park motorcycle.
- Subject wheel rims to visual inspection for defects.
- Have damaged rims checked and, if necessary, replaced by a specialist service facility, preferably an authorized BMW Motorrad retailer.

### Checking tire tread depth



#### WARNING

#### Riding with heavily worn tyres

Risk of accident due to poorer rideability

- If necessary, replace the tyres before the legally specified minimum tread depth is reached. ◀

- Make sure ground is level and firm and park motorcycle.
- Measure tire tread depth in main tread grooves with wear indicating marks.



## NOTICE

Tread wear marks are integrated into the main grooves on every tire. If the tire tread has worn down to the level of the marks, the tire is completely worn. The locations of the marks are indicated on the edge of the tire, e.g. by the letters TI, TWI or by an arrow. ◀

When the minimum tread depth is reached:

- Replace tires concerned.

## Wheels

### Affect of wheel sizes on suspension control systems

The wheel sizes play a major role in the ABS and ASC suspension control systems. The diameter and width of the wheels stored in the control unit have particular significance as the basis for all necessary calculations. A change in these sizes resulting from conversion to wheels not installed as standard equipment can seriously affect the control comfort of these systems.

The sensor rings are essential for correct wheel speed detection; they too must match the motorcycle's control systems and consequently cannot be replaced. If you want to equip your motorcycle with different wheels, please contact a specialist service facility, preferably a

BMW Motorrad retailer. In some cases the data stored in the control units can be adapted for the new wheel sizes.

### Removing front wheel

- Make sure ground is level and firm and park motorcycle.



- Remove screw **1** and extract the ABS sensor from its socket.



- Remove screws **2** of right-hand brake caliper.



- Push brake pads **3** apart slightly by turning the brake caliper **4** back and forth against the brake rotor **5**.

- Mask off parts of wheel rim that could be scratched when removing brake caliper.



## ATTENTION

### Unintentional pressing together of brake pads

Component damage when mounting the brake caliper or when pressing the brake pads apart


- Do not actuate the brakes with the brake caliper removed.◀
- Carefully pull brake calipers back to remove them from the brake rotor.
- Place motorcycle on a suitable auxiliary stand.  
– with center stand<sup>OE</sup>
- Place motorcycle on center stand, ensuring that it is resting on a firm and level support surface.<

- Park motorcycle, ensuring that support surface is firm and level.
- Raise front of motorcycle, preferably using a BMW Motorrad front wheel stand, continuing until the wheel rotates freely.
- Mount front wheel stand (▶ 97).



- Remove right-hand axle clamping screw **1**.
- Remove axle **2** while supporting wheel.
- Do not remove grease on axle.


- Roll front wheel forward to remove it.



- Remove distance bushings **3** on the left and right from the wheel hub.

### RDC sticker

- with Tire Pressure Control (TPC)<sup>OE</sup>



### ATTENTION

#### Improper tire removal

Damage to the TPC/RDC sensors

- Inform a specialist service facility or an authorized BMW Motorrad retailer on the fact that the wheel is equipped with a TPC/RDC sensor.◀

On motorcycles equipped with RDC, a corresponding sticker is located on the wheel rim in close proximity to the RDC sensor.

## Installing front wheel



### WARNING

**Use of a wheel which does not comply with series specifications**

Malfunctions during control interventions by ABS and ASC

- Please see the information on the effect of wheel sizes on the ABS and ASC chassis control systems at the beginning of this chapter.◀




### ATTENTION

**Tightening of screwed connections with incorrect tightening torque**

Damage or loosening of screwed connections

- Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer.◀



- Mount distance bushings **3** on the left and right on the wheel hub.



### ATTENTION

#### Front wheel installation opposite the running direction

Accident hazard

- Observe running direction arrows on tire or rim. ◀
- Roll front wheel into front suspension while guiding brake disk between brake pads of left-hand brake caliper.



- Lift front wheel and install axle **2** with appropriate torque.



Front quick-release axle  
in axle mount

22 lb/ft (30 Nm)

- Remove front wheel stand.
  - without center stand<sup>OE</sup>
- Remove auxiliary stand. ◀
- Place right-hand brake caliper on brake disk.



- Tighten screws **2** to the specified tightening torque.



Brake caliper on telescopic forks

28 lb/ft (38 Nm)



- Insert ABS sensor in its socket and install screw **1**.
- Remove adhesive tape from wheel rim.
- Operate brakes several times until brake pads contact brake disk.
- Firmly compress spring forks several times.



- Tighten the right-hand axle clamping screw **1** with the specified torque.



Clamping screw (quick-release axle) in telescopic forks

14 lb/ft (19 Nm)

## Removing rear wheel


- Make sure ground is level and firm and place motorcycle on a suitable auxiliary stand.

– with center stand<sup>OE</sup>

- Make sure ground is level and firm and place motorcycle on center stand.◀




- Remove screw **1** and take speed sensor out of hole.



- Remove axle nut **2**.
- Loosen lock nuts **3** on left and right by turning counterclockwise.
- Loosen adjusting screws **4** on left and right by turning clockwise.
- Remove adjusting plate **5** and slide axle as far as possible toward inside.



- Remove quick-release axle **6** and take out adjusting plate **7**.



- Roll rear wheel as far forward as possible and remove chain **8** from chain sprocket.

- Roll rear wheel toward rear out of swinging arm.



### NOTICE

The camshaft sprocket and the spacer sleeves on the left and right are loosely inserted in the wheel. Exercise care during the removal, in order that the parts are not damaged or lost.◀

### Install rear wheel



### WARNING

**Use of a wheel which does not comply with series specifications**

Malfunctions during control interventions by ABS and ASC

- Please see the information on the effect of wheel sizes on the ABS and ASC chassis control systems at the beginning of this chapter.◀




## ATTENTION


### Tightening of screwed connections with incorrect tightening torque

Damage or loosening of screwed connections

- Always have the tightening torques checked by a specialized workshop, preferably an authorized BMW Motorrad retailer. ◀
- Roll rear wheel into swing arm while guiding brake disk between brake pads.



- Roll rear wheel as far forward as possible and lay chain **8** on chain sprocket.




- Mount left-hand adjusting plate **7** in swing arm and install

quick-release axle **6** in brake caliper and rear wheel.

- Make sure that axle fits in cutout of adjusting plate.



- Insert right-hand adjusting plate **5**.



- Install axle nut **2** but do not yet tighten it down.

– without center stand<sup>OE</sup>

- Remove auxiliary stand.<




- Insert speed sensor in hole and install screw **1**.

- Check chain sag (114 ➔ 128).


## Air filter

### Removing air cleaner

- Removing center fairing panel (114 ➔ 121).




- Remove four screws **1**.
- Remove air cleaner cover **2**.  
For this purpose, slightly push the fairing side panels outwards.




- Take out air filter **3**.

### Installing air cleaner



- Install air filter **3**.




- Mount the air filter cover **2**. For this purpose, slightly push the fairing side panels outwards.
- Install screws **1** with washers.
- Installing center fairing panel (→ 121).


## Light sources

### Replacing light sources for low-beam and high-beam headlight


- Park motorcycle, ensuring that support surface is firm and level.
- Switch off ignition.



- Turn cover panel **1** on high-beam headlamp or cover panel **2** on lowbeam headlamp to the left.
- Remove cover **1** or **2**.



- Disconnect plug **1**.



- Remove wire spring clip **1** from the retainers and fold to side.
- Remove bulb **2**.
- Replace defective light source.

 Bulb for high-beam headlight


H7 / 12 V / 55 W

 Bulbs for low-beam headlight


H7 / 12 V / 55 W

- To avoid leaving contamination deposits on the new bulb's


glass surface, always hold it by its base.



- Insert the light source, taking care to ensure that the lug **6** is positioned correctly.
- Close the spring clamp **4** and lock it in place.



- Connect plug **3**.




- Install cover **1** or cover **2**.

## Replacing light source for parking light

- Park motorcycle, ensuring that support surface is firm and level.
- Switch off ignition.



- Remove cover **2**.



- Remove bulb holder **3** from the headlight housing.



- Remove light source from socket.

- Replace defective light source.




Bulb for parking light

W5W / 12 V / 5 W

- To protect glass on new bulb against contamination, always use a clean, dry cloth to hold it; do not touch with bare fingers.



- Press light source into socket.



- Insert bulb holder **3** into the headlight housing.



- Install cover **2**.

## Replace the LED for brake and rear light

- The LED tail light can only be completely replaced. For details please contact a specialist service facility, preferably an authorized BMW Motorrad Retailer.

## Replace LED turn indicator

- with LED turn indicator<sup>OE</sup>
- LED turn indicators can only be replaced as a complete unit. For details please contact a specialist service facility, preferably an authorized BMW Motorrad Retailer.<

## Replacing front and rear turn indicator light sources

- with LED turn indicator<sup>OE</sup>
- LED turn indicators can only be replaced as a complete

unit. For details please contact a specialist service facility, preferably an authorized BMW Motorrad Retailer.<


- without LED turn indicator<sup>OE</sup>
- Park motorcycle, ensuring that support surface is firm and level.
- Turn off ignition.



- Remove the screw **1**.



- Pull glass on screw connection side out of mirror housing.



- Remove the light source **2** from the light housing by pressing it in and turning it counterclockwise.

- Replace defective light source.

 Bulbs for flashing turn indicators, front

R10W / 12 V / 10 W

– with LED turn indicator<sup>OE</sup>

LED<


- To protect glass on new bulb against contamination, always use a clean, dry cloth to hold it; do not touch with bare fingers.



- Insert inside end of lens into light housing and close.



- Fit the screw **1**.<




- Install the light source **2** by pressing it into the light housing and turning it clockwise.

## Replacing light source for license-plate light

- Park motorcycle, ensuring that support surface is firm and level.
- Switch off ignition.



- Remove screw **1** in mudguard cover and remove the cover.



- Pull the socket **2** out of the bulb holder.



- Pull the light source out of the socket.


- Replace defective light source.




Light source for license  
plate light

W5W / 12 V / 5 W

- To protect the glass on the new bulb against contamination, always use a clean, dry cloth to hold it; do not touch with bare fingers.



- Insert bulb **1** in bulb socket.



- Insert bulb socket **1** in bulb holder.



- Position mudguard cover and install screw **1**.


## Fairings and panels

### Removing center fairing panel

- Remove seat (🔧➡ 54).




- Remove screws **1** on left and right.




- Remove screws **2**.
- Disconnect plug connection at onboard socket **1**.
- Remove center fairing panel.

### Installing center fairing panel


- Connect plug connection to onboard socket.



- Lay on center fairing panel. Make sure that three tabs **4** on left and right grip into side panels.



- Install four screws **2**.



- Install screws **1** on left and right.
- Install seat (➡ 54).

## Jump-starting



### ATTENTION

#### Current too high when jump-starting the motorcycle

Cable fire or damage to the motorcycle electronics

- Do not jump-start the motorcycle using the power socket, only via the battery terminal.◀



### ATTENTION

#### Contact between crocodile clips of jump leads and motorcycle

Danger of short circuit

- Use jump leads fitted with fully insulated crocodile clips at both ends.◀




### ATTENTION

#### Jump-starting with a voltage higher than 12 V

Damage to the motorcycle's electronics

- The battery of the donor motorcycle must have a voltage of 12 V.◀
- Remove seat (➡ 54).
- Removing center fairing panel (➡ 121).
- Do not disconnect the battery from the onboard electrical sys-

tem when jump-starting the engine.



- First connect positive terminal of the discharged battery to positive terminal on the donor battery with red jumper cable (positive terminal on this motorcycle: position **2**).
- Connect black jumper cable to negative terminal of donor battery and then to negative terminal of the discharged battery (negative terminal on this motorcycle: position **1**).

- Allow engine on support motorcycle to run while jump-starting.
- Start engine of motorcycle with discharged battery in usual way; if engine does not start, wait a few minutes before repeating attempt in order to protect starter motor and donor battery.
- Allow both engines to run for several minutes before disconnecting the jumper cables.
- Disconnect jumper cables first from negative, then from positive terminal.



## NOTICE

To start the engine, do not use start sprays or similar items.◀

- Installing center fairing panel (121).
- Install seat (54).

## Battery

### Maintenance instructions

Correct battery maintenance combined with proper charging and storage procedures extends the battery's service life, and is also required for warranty claims. Compliance with the points below is important in order to maximize battery life:

- Keep the surface of the battery clean and dry.
- Do not open the battery.
- Do not top up with water.
- Be sure to read and comply with the instructions for charging the battery on the following pages.
- Do not turn the battery upside down.



## ATTENTION

### Discharging of the connected battery by the vehicle electronics (e.g. clock)

Total discharge of battery leading to a rejection of warranty claims

- During riding breaks of more than 4 weeks, connect a trickle-charger to the battery.◀



## NOTICE

BMW Motorrad has developed a trickle-charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods when the motorcycle is not being used without having to disconnect the battery from the motorcycle's onboard systems. Additional information is available at your authorized BMW Motorrad retailer.◀

## Charging a connected battery

- Remove devices connected to onboard power sockets.



### ATTENTION

#### Charging the battery connected to the vehicle using the battery terminals

Damage to the motorcycle's electronics

- Disconnect the battery before charging on the battery terminals.◀



### ATTENTION

#### Charging a fully discharged battery via the power socket or additional onboard socket

Damage to the motorcycle's electronics

- Always charge a fully discharged battery (battery voltage below 9 V; with the ignition switched on,

the indicator lights and the multifunction display remain off) directly at the poles of the **disconnected** battery.◀



### ATTENTION

#### Unsuitable chargers connected to the power socket

Damage to charger and vehicle electronics

- Use suitable BMW chargers. The correct charger is available through your authorized BMW Motorrad retailer.◀
- Charge connected battery via power socket.



### NOTICE

The motorcycle's onboard electronics know when the battery is fully charged. The onboard socket is switched off when this happens.◀

- Comply with operating instructions of charger.



### NOTICE

If you are unable to charge the battery via the onboard socket, you may be using a charger that is not compatible with your motorcycle's electronics. In this case, charge the battery directly from the terminals of the battery disconnected from the vehicle.◀

## Charging a disconnected battery

- Charge battery using a suitable charger.
- Comply with operating instructions of charger.
- After charging, remove terminal clamps of the charger from the battery terminals.




## NOTICE

In the case of longer periods when the motorcycle is not being used, the battery must be recharged regularly. See the instructions for caring for your battery. Always fully recharge the battery before returning it to use.◀

## Removing battery

- Park motorcycle, ensuring that support surface is firm and level.
- with anti-theft alarm system (DWA)<sup>OE</sup>
- Switch off anti-theft alarm system if necessary.
- Deactivate alarm function (► 58).◀
- Turn off ignition.
- Remove seat (► 54).

- Removing center fairing panel (► 121).



## ATTENTION

### Incorrect battery disconnection

Danger of short circuit

- Follow the disconnection sequence.◀
- Disconnect the battery earth lead **1** first.
- Then loosen positive battery cable **2**.

- Remove screws **3** on the left and right and take off battery carrier forward from the battery.
- Lift battery up and out, using tilting movements if it is difficult to move.

## Install battery




## NOTICE

If the motorcycle was disconnected from the battery for a longer time, the current date must be entered in the instrument cluster to ensure the proper operation of the service display.

Consult a certified service facility, preferably an authorized BMW Motorrad retailer, for setting of the date.◀

- Turn off ignition.
- Insert battery into battery compartment, with positive terminal on right in direction of travel.



- Ensure cables are correctly routed in battery carrier **4**.
- Install screws **3** on left and right.



### ATTENTION

#### Incorrect battery connection

Danger of short circuit

- Follow the installation sequence.◀
- Install positive battery cable **2**.
- Install negative battery cable **1**.
- Installing center fairing panel (▮▮▮ 121).
- Install seat (▮▮▮ 54).

- Set clock (▮▮▮ 46).
- with anti-theft alarm system (DWA)OE
- Switch on the alarm system if necessary.◀

## Fuses

### Replacing main fuse




### ATTENTION

#### Bypassing defective fuses

Risk of short circuit and fire

- Do not bypass defective fuses.
- Replace defective fuses with new fuses.◀
- Switch off ignition.
- Park motorcycle, ensuring that support surface is firm and level.
- Removing center fairing panel (▮▮▮ 121).



- Replace defective fuse **1**.



### NOTICE

If the fuses blow frequently, have the electrical system checked by an authorized specialized workshop, preferably an authorized BMW Motorrad retailer.◀



Main fuse

30 A (Voltage regulator)

- Installing center fairing panel (▮▮▮ 121).

## Diagnostic connector


### Removing the diagnostic connector

#### CAUTION

**Incorrect procedure followed when disconnecting the data link connector for the On-Board Diagnostics.**

Motorcycle experiences malfunctions

- Only have the data link connector disconnected by a specialist workshop or other authorized persons during your next BMW Service appointment.
- Have the work performed by appropriately trained staff.
- Refer to the vehicle manufacturer specifications.◀
- Remove seat (➡ 54).



- Press locks **1** on both sides.
- Remove the diagnostic connector **2** from the bracket **3**.
  - » The diagnosis and information system interface can be connected at the diagnostic connector **2**.

### Secure the data link connector

- Disconnect the diagnosis and information system interface.



- Seat diagnostic connector **2** into the bracket **3**.
  - » The locks **1** engage.
- Install seat (➡ 54).

## Chain

### Lubricating chain

#### ATTENTION

**Insufficient cleaning and lubrication of the drive chain**


Increased wear

- Clean and lubricate the drive chain regularly.◀

- Lubricate drive chain at least every 620 mls (1000 km). After driving through water or dust and dirt, carry out lubricate earlier accordingly.
- Switch off ignition and engage Neutral.
- Clean drive chain with suitable cleaning agent, dry and apply chain lubricant.
- Wipe off excess lubricant.

### Check chain sag

- Park motorcycle, ensuring that support surface is firm and level.
- Turn the rear wheel until the position with the lowest chain sag is reached.



- Press chain upward and downward using a screwdriver and measure difference **A**.



Chain sag

1.2...1.6 in (30...40 mm) (Motorcycle unloaded on side stand)

– with low-slung<sup>OE</sup>


0.8...1.2 in (20...30 mm) (Motorcycle unloaded on side stand) <

If the measured value is outside the approved tolerance:

- Adjusting chain sag (► 128).

### Adjusting chain sag

- Park motorcycle, ensuring that support surface is firm and level.



- Loosen quick-release axle nut **1**.
- Loosen lock nuts **2** on left and right.
- Adjust chain sag with adjusting screws **3** on left and right.
- Check chain sag (► 128).

- Ensure that the figures **4** indicating the adjustment settings are identical on left and right.
- Tighten locknuts **2** on left and right with appropriate torque.

 Locknut of drive-chain tensioning screw

14 lb/ft (19 Nm)

- Tighten quick-release axle nut **1** to specified torque.


 Rear-wheel quick-release axle in swinging arm

74 lb/ft (100 Nm)

## Check chain wear

- Make sure ground is level and firm and park motorcycle.
- Engage 1st gear.
- Rotate rear wheel toward front of vehicle until the chain is tensioned.

- Determine chain length below the rear wheel swinging arm with 9 rivets.



Permissible chain length

max 5.7 in (max 144.30 mm)  
(Measured over the **center** of 10 rivets, chain tensioned)

If the chain has reached the maximum approved length:

- Contact an authorized service facility, preferably an authorized BMW Motorrad dealer.



## Accessories

|                             |     |
|-----------------------------|-----|
| General notes .....         | 132 |
| Onboard power sockets ..... | 132 |
| Luggage .....               | 133 |
| Case .....                  | 134 |
| Topcase .....               | 137 |

## General notes

BMW Motorrad recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose. Your authorized BMW Motorrad retailer will be happy to provide qualified advice on the selection of genuine BMW parts and accessories as well as other BMW-approved products.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for these products.

BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.

Note the information on the importance of wheel sizes for suspension control systems (►► 107).



## CAUTION

### Use of products from other manufacturers

Safety risk

- BMW Motorrad cannot examine or test each product of outside origin to ensure that it can be used on or in connection with BMW motorcycles without constituting a safety hazard. Nor is this guarantee provided when the official approval of a specific country has been granted. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances.
- Use only parts and accessories approved by BMW for your motorcycle.◀

Whenever you are planning modifications, comply with all the legal requirements. The motorcycle must not violate the regulations governing motorcycle approval for highway use applicable in your own country.

More information on the topic of accessories is available at:

**[bmw-motorrad.com/accessories](http://bmw-motorrad.com/accessories)**

## Onboard power sockets

Information on using onboard power sockets:

### Automatic deactivation

Onboard sockets are switched off automatically under the following conditions:

- If the battery voltage falls below the level required to start the vehicle.

- If the maximum load specified in the technical data is exceeded.
- During starting.

### Operating electrical accessories

Additional devices connected to onboard sockets can only be put into operation when the ignition is switched on. The accessory remains operational if the ignition is subsequently switched off. Onboard sockets are switched off approx. 15 minutes after switching off the ignition to reduce the strain on the onboard electrical system.

Additional devices with low power consumption are possibly not detected by the vehicle electronics. In these cases, onboard sockets are already switched off shortly after the ignition is switched off.

### Cable routing

Observe the following when routing cable from power sockets to additional devices:

- Cables must not hinder the rider's movement.
- Cables must not restrict the steering angle and driving characteristics.
- Cables must not become trapped.

## Luggage

### Lash down luggage



- Route luggage belts **1** as shown in this example with a luggage roll.
- Secure luggage belt at back on luggage rack or case carrier to prevent slippage.
- Check piece of luggage for secure hold.


## Case

### Open case

– with case<sup>OA</sup>



- Turn key **1** in case lock perpendicular to direction of travel.
- Hold down yellow locking device **2** and fold out carrying handle **3**.




- Press yellow button **4** downward while opening case lid.

### Close case

– with case<sup>OA</sup>

- Turn key in case lock perpendicular to direction of travel.
- Close case lid.
- » The lid clicks audibly into place.



### ATTENTION

#### Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the case lock is perpendicular to the direction of travel. ◀
- Fold carrying handle **3** down.
- Turn key in case lock in the direction of travel and remove.

## Adjust case volume

– with case<sup>OA</sup>

- Open and empty case.




- Engage pivot lever **1** in upper end position to obtain smaller volume.
- Engage pivot lever **1** in lower end position to set larger volume.
- Close case.

## Remove case

– with case<sup>OA</sup>



- Turn key **1** in case lock perpendicular to direction of travel.
- Hold down yellow locking device **2** and fold out carrying handle **3**.




- Pull up red release lever **4**.  
» Locking flap **5** pops up.
- Fold locking flap all the way open.
- Remove case from mount by its handle.


## Mounting case

– with case<sup>OA</sup>


- Turn key in case lock perpendicular to direction of travel.



- Fold up locking flap **5** completely by pulling red release lever **4** upward if necessary.



- Insert case in case carrier **6**, then swing as far as possible onto mount **7**.



- Press locking flap **5** downward as far as possible and hold in place.
- Press red release lever **4** downward.
  - » The locking flap **5** clicks into place.



### ATTENTION

#### Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the case lock is per-

pendicular to the direction of travel. ◀

- Fold carrying handle down.
- Turn key in direction of travel and remove.

### Maximum payload and maximum speed

Observe maximum payload and maximum speed as indicated on label in case.

If you cannot find your combination of motorcycle and case on the label, contact your BMW Motorrad Retailer. The following values apply to the combination described here:



Maximum speed for riding with case

max 112 mph (max 180 km/h)



Payload per case

max 22 lbs (max 10 kg)

## Topcase

### Open the Topcase

– with Topcase<sup>OA</sup>



- Turn key **1** in Topcase lock into vertical position.
- Hold down yellow locking device **2** and fold out carrying handle **3**.



- Press yellow button **4** toward front while pressing Topcase lid upward.

### Closing the Topcase

– with Topcase<sup>OA</sup>

- Turn key in Topcase lock into vertical position.



- Close Topcase lid with firm pressure.



### ATTENTION

#### Folding down the carrying handle when the case is locked

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the topcase lock is vertical.◀
- Fold carrying handle **3** down.  
» Carrying handle audibly engages.

- Turn key in Topcase lock into horizontal position and remove.

## Adjusting Topcase volume

– with Topcase<sup>OA</sup>

- Open and empty Topcase.



- Engage pivot lever **1** in front end position to set larger volume.
- Engage pivot lever **1** in rear end position to set smaller volume.
- Close Topcase.

## Removing topcase

– with Topcase<sup>OA</sup>



- Turn key **1** in topcase lock into vertical position.
- Hold down yellow locking device **2** and fold out carrying handle **3**.



- Pull red release lever **4** toward rear.
- » Locking flap **5** pops up.
- Fold locking flap **5** all the way open.
- Remove topcase from mounting by its handle.


## Mounting the topcase

– with Topcase<sup>OA</sup>

- Turn key in Topcase lock into vertical position.



- Fold up locking flap **5** completely by pulling red release lever **4** toward rear if necessary.



- Hook topcase into front holders **1** of topcase retaining plate.

- Press topcase onto topcase retaining plate at rear.



- Fold locking flap **5** closed as far as possible and hold in place.
- Press red release lever **4** toward front.
- » Locking flap clicks into place.



### ATTENTION

#### **Folding down the carrying handle when the case is locked**

Damage to the locking tab

- Before folding down the carrying handle, make sure that the slot of the topcase lock is vertical.◀
- Fold carrying handle down.
- Turn key into horizontal position and remove.

#### **Maximum payload and maximum speed**

Observe maximum payload and top speed as indicated on label in Topcase.

If you cannot find your combination of motorcycle and topcase on the label, contact your BMW Motorrad Retailer.

The following values apply to the combination described here:



Maximum speed limit for driving with a Topcase

max 112 mph (max 180 km/h)



Payload of Topcase

max 11 lbs (max 5 kg)

## Care

|                                              |     |
|----------------------------------------------|-----|
| Care products .....                          | 142 |
| Washing your motorcycle .....                | 142 |
| Cleaning sensitive motorcycle<br>parts ..... | 143 |
| Paint care .....                             | 143 |
| Paint preservation.....                      | 144 |
| Store motorcycle .....                       | 144 |
| Return motorcycle to use .....               | 144 |

## Care products

BMW Motorrad recommends that you use cleaning and care products available at your authorized BMW Motorrad retailer. BMW Motorrad Care Products have been materials tested, laboratory tested, and field tested and provide optimum care and protection for the materials used in your vehicle.



### ATTENTION

#### Use of unsuitable cleaning and care agents

Damage to motorcycle parts

- Do not use any solvents such as nitro thinners, cold cleaners, fuel or similar, and do not use cleaning agents that contain alcohol. ◀

## Washing your motorcycle

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on painted parts prior to washing the motorcycle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to bright sunlight and do not wash it in the sun.

Make sure that the motorcycle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after completion of every trip.



### WARNING

**Damp brake disks and brake pads after washing the mo-**

**torcycle, after riding through water or in the rain**

Poorer braking action, accident hazard

- Brake early until the brake rotors and brake pads are dry. ◀



### ATTENTION

**Increased effect of salt caused by warm water**

Corrosion

- Only use cold water to remove road salt. ◀



### ATTENTION

**Damage caused by high water pressure from high-pressure cleaners or steam-jet devices**

Corrosion or short circuit, damage to labels, to seals, to hydraulic brake system, to the electrical system and the seat

- Exercise caution when using high-pressure or steam-jet devices. ◀

## Cleaning sensitive motorcycle parts

### Plastics



#### ATTENTION

### Use of unsuitable cleaning agents

Damage to plastic surfaces

- Do not use abrasive cleaners or cleaners containing alcohol or solvents.
- Do not use insect sponges or sponges with a hard surface. ◀

### Fairings and panels

Clean fairings and panels with water and BMW plastic cleaner.

### Windshields and lenses are manufactured in plastic

Clean off dirt and insects with a soft sponge and plenty of water.



#### NOTICE

Soften stubborn dirt and dead insects by covering the affected areas with a wet cloth. ◀

### Chrome

Clean chrome sections carefully with plenty of water and a solvent cleaner from the BMW Motorrad Care Products range. This is required in particular for removing road salt. Use chrome polish for additional treatment.

### Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



#### ATTENTION

### Bending of radiator fins

Damage to radiator fins

- When cleaning, ensure that the cooler fins are not bent. ◀

### Rubber

Treat rubber components with water or BMW rubber protection coating agent.



#### ATTENTION

### Use of silicone sprays for care of rubber seals

Damage to rubber seals

- Do not use silicone sprays or care products that contain silicone. ◀

### Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your

motorcycle is ridden in areas with high air pollution or natural sources of dirt, e.g. tree resin or pollen.

At the same time, you should remove particularly aggressive materials immediately; otherwise changes in the paint and discoloration can occur. These include spilled fuel, oil, grease and brake fluid as well as bird droppings. We recommend you use BMW Motorrad gloss polish or BMW paint cleaner.

Contamination on the paint finish is particularly easy to see after the motorcycle has been washed. Remove this type of soiling with cleaning naphtha or spirit on a clean cloth or cotton ball. BMW Motorrad recommends using BMW tar remover for removing tar spots. Then add a protective wax coating to the paint at these locations.

## Paint preservation

BMW Motorrad recommends applying BMW car wax or products containing carnauba wax or synthetic wax to preserve your paintwork.

When water fails to form beads on the paint surface this indicates it is time to apply wax.

## Store motorcycle

- Clean motorcycle.
- Completely fill the motorcycle's fuel tank.
- Removing battery (➡ 125).
- Spray the brake and clutch lever, and the center and side stand pivots with a suitable lubricant.
- Protect metal and chrome-plated parts with an acid-free grease (Vaseline).

- Park the motorcycle in a dry space in such a way that both wheels are under no load (preferably by using the front and rear-wheel stands available from BMW Motorrad).

## Return motorcycle to use

- Remove the protective wax coating.
- Clean motorcycle.
- Install battery (➡ 125).
- Observe checklist (➡ 74).

## Technical data

|                             |     |
|-----------------------------|-----|
| Troubleshooting chart ..... | 146 |
| Threaded fasteners .....    | 147 |
| Fuel.....                   | 149 |
| Engine oil .....            | 150 |
| Engine .....                | 151 |
| Clutch .....                | 152 |
| Transmission .....          | 152 |
| Rear-wheel drive.....       | 153 |
| Frame .....                 | 153 |
| Suspension .....            | 153 |
| Brakes .....                | 154 |
| Wheels and tires .....      | 155 |
| Electrical system.....      | 156 |
| Dimensions .....            | 158 |
| Weights.....                | 159 |

|                        |     |
|------------------------|-----|
| Performance data ..... | 159 |
|------------------------|-----|

## Troubleshooting chart

Engine does not start.

| Possible cause                                                                                                   | Remedy                                                                                     |
|------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| Side stand extended and gear engaged                                                                             | Engage neutral or fold up the side stand.                                                  |
| Gear engaged and clutch not disengaged                                                                           | Place transmission in neutral or disengage clutch.                                         |
| No fuel in tank                                                                                                  | Refueling (▮▮▮ 83).                                                                        |
| Battery drained                                                                                                  | Charging a connected battery (▮▮▮ 124).                                                    |
| Overheating protection for starter motor has activated. Starter motor can only be actuated for a limited period. | Leave the starter motor to cool down for around 1 minute until it becomes available again. |

## Threaded fasteners

| Front wheel                                                    | Value             | Valid |
|----------------------------------------------------------------|-------------------|-------|
| <b>Brake caliper on telescopic forks</b>                       |                   |       |
| M10 x 40                                                       | 28 lb/ft (38 Nm)  |       |
| <b>Clamping screw (quick-release axle) in telescopic forks</b> |                   |       |
| M8 x 20                                                        | 14 lb/ft (19 Nm)  |       |
| <b>Front quick-release axle in axle mount</b>                  |                   |       |
| M16 x 1.5                                                      | 22 lb/ft (30 Nm)  |       |
| Rear wheel                                                     | Value             | Valid |
| <b>Locknut of drive-chain tensioning screw</b>                 |                   |       |
| M8                                                             | 14 lb/ft (19 Nm)  |       |
| <b>Rear-wheel quick-release axle in swinging arm</b>           |                   |       |
| M16 x 1.5                                                      | 74 lb/ft (100 Nm) |       |

| Mirrors                                          | Value            | Valid |
|--------------------------------------------------|------------------|-------|
| <b>Locknut (mirror) on clamping piece</b>        |                  |       |
| M10 x 1.5<br>Multi-Wax Spray                     | 15 lb/ft (20 Nm) |       |
| <b>Clamping piece (mirror) on clamping block</b> |                  |       |
| M10 x 1.5                                        | 22 lb/ft (30 Nm) |       |

## Fuel

|                                                       |                                                                                                                                           |
|-------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Recommended fuel quality                              | Super unleaded (max. 10 % ethanol, E10)<br>89 AKI (95 ROZ/RON)<br>89 AKI                                                                  |
| – with regular-grade gasoline, unleaded <sup>OE</sup> | Regular unleaded (minor restrictions with regard to power and fuel consumption) (max. 10 % ethanol, E10)<br>87 AKI (91 ROZ/RON)<br>87 AKI |
| Usable fuel quantity                                  | Approx. 4.2 gal (Approx. 16 l)                                                                                                            |
| Reserve fuel quantity                                 | min 2.9 quarts (min 2.7 l)                                                                                                                |
| Emission standard                                     | Euro 4                                                                                                                                    |

## Engine oil

|                             |                                                                                                                                                                                                   |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Engine oil, capacity        | Approx. 3.1 quarts (Approx. 2.9 l), with filter replacement                                                                                                                                       |
| Viscosity rating            |                                                                                                                                                                                                   |
| SAE 15W-50, API SJ/JASO MA2 | Additives (for instance, molybdenum-based substances) are prohibited, because they would attack the coatings on engine components, BMW Motorrad recommends BMW Motorrad ADVANTEC Pro Oil          |
| Oil additives               | BMW Motorrad does not recommend the use of oil additives, as these can adversely affect the operation of the clutch. Ask your BMW Motorrad retailer for engine oils suitable for your motorcycle. |

**BMW recommends** **ADVANTEC**  
ORIGINAL BMW ENGINE OIL

## Engine

|                                                       |                                                                                                                                               |
|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Engine number location                                | On crankcase at lower right                                                                                                                   |
| Engine design                                         | Water-cooled 2-cylinder four-stroke engine with four rocker-arm-actuated valves per cylinder, two overhead camshafts and dry-sump lubrication |
| Displacement                                          | 798 cc (798 cm <sup>3</sup> )                                                                                                                 |
| Cylinder bore                                         | 3.2 in (82 mm)                                                                                                                                |
| Piston stroke                                         | 3 in (75.6 mm)                                                                                                                                |
| Compression ratio                                     | 12:1                                                                                                                                          |
| Rated output                                          | 75 hp (55 kW), at engine speed: 7000 min <sup>-1</sup>                                                                                        |
| – with regular-grade gasoline, unleaded <sup>OE</sup> | 71 hp (52 kW), at engine speed: 7000 min <sup>-1</sup>                                                                                        |
| – with reduction of power to 35 kW <sup>OE</sup>      | 48 hp (35 kW), at engine speed: 7000 min <sup>-1</sup>                                                                                        |
| Torque                                                | 57 lb/ft (77 Nm), at engine speed: 5500 min <sup>-1</sup>                                                                                     |
| – with regular-grade gasoline, unleaded <sup>OE</sup> | 55 lb/ft (75 Nm), at engine speed: 5500 min <sup>-1</sup>                                                                                     |
| – with reduction of power to 35 kW <sup>OE</sup>      | 44 lb/ft (60 Nm), at engine speed: 5000 min <sup>-1</sup>                                                                                     |
| Maximum engine speed                                  | max 9000 min <sup>-1</sup>                                                                                                                    |
| Idle speed                                            | 1250 <sup>+50</sup> min <sup>-1</sup> , With motorcycle stopped                                                                               |

## Clutch

|               |                            |
|---------------|----------------------------|
| Clutch design | Multi-disk oil-bath clutch |
|---------------|----------------------------|

## Transmission

|                          |                                                                                                                                                                                                                                                           |
|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Transmission design      | Claw-shifted 6-speed manual transmission integrated in engine housing                                                                                                                                                                                     |
| Transmission gear ratios | 1.943 (35/68 teeth), Primary gear ratio<br>1:2.462 (13/32 teeth), 1st gear<br>1:1.750 (16/28 teeth), 2nd gear<br>1:1.381 (21/29 teeth), 3rd gear<br>1:1.174 (23/27 teeth), 4th gear<br>1:1.042 (24/25 teeth), 5th gear<br>1:0.960 (25/24 teeth), 6th gear |

## Rear-wheel drive

|                                                       |                                    |
|-------------------------------------------------------|------------------------------------|
| Type of final drive                                   | Chain drive                        |
| Type of rear suspension                               | Two-arm cast aluminum swinging arm |
| Number of teeth of rear-wheel drive (Pinion/sprocket) | 17/42                              |

## Frame

|                                               |                                       |
|-----------------------------------------------|---------------------------------------|
| Frame design                                  | Lattice-tube frame                    |
| Location of type plate                        | Frame at front left on steering head  |
| Location of the vehicle identification number | Frame at front right on steering head |

## Suspension

### Front wheel

|                                |                           |
|--------------------------------|---------------------------|
| Type of front suspension       | Telescopic forks          |
| Spring travel, front           | 6.7 in (170 mm), On wheel |
| – with low-slung <sup>OE</sup> | 5.5 in (140 mm), On wheel |

**Rear wheel**

|                                                                |                                                                                                |
|----------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| Type of rear suspension                                        | Two-arm cast aluminum swinging arm                                                             |
| Type of rear suspension                                        |                                                                                                |
| – without Electronic Suspension Adjustment (ESA) <sup>OE</sup> | Directly articulated central spring strut with steplessly adjustable rebound-stage damping     |
| – with Electronic Suspension Adjustment (ESA) <sup>OE</sup>    | Directly articulated central spring strut with electronically adjustable rebound-stage damping |
| Spring travel at rear wheel                                    | 6.7 in (170 mm), On wheel                                                                      |
| – with low-slung <sup>OE</sup>                                 | 5.3 in (135 mm), On wheel                                                                      |

**Brakes****Front wheel**

|                          |                                                                                                 |
|--------------------------|-------------------------------------------------------------------------------------------------|
| Type of front brake      | Hydraulically operated twin disc brake with 2-piston floating calipers and floating brake discs |
| Front brake pad material | Sintered metal                                                                                  |

**Rear wheel**

|                           |                                                                                       |
|---------------------------|---------------------------------------------------------------------------------------|
| Type of rear brake        | Hydraulically operated disk brake with 1-piston floating caliper and fixed brake disk |
| Rear brake pad material   | Organic                                                                               |
| Rear brake-disk thickness | min 0.18 in (min 4.5 mm), Wear limit                                                  |

## Wheels and tires

|                                                                                                                      |                                            |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------|
| Speed category of front/rear tires                                                                                   | H, minimum requirement: 130 mph (210 km/h) |
| <b>Front wheel</b>                                                                                                   |                                            |
| Front wheel design                                                                                                   | Aluminum cast wheel, MT H2                 |
| Front-wheel rim size                                                                                                 | 2.50" x 19" MT H2                          |
| Front tire designation                                                                                               | 110/80 R 19                                |
| Load index for front tire                                                                                            | At least 42                                |
| Permissible front-wheel imbalance                                                                                    | max 0.2 oz (max 5 g)                       |
| Balance weight for front wheel (Half of each weights must be attached on the right and left of the rim respectively) | max 2.8 oz (max 80 g)                      |
| <b>Rear wheel</b>                                                                                                    |                                            |
| Rear wheel design                                                                                                    | Aluminum cast wheel, MT H2                 |
| Rear-wheel rim size                                                                                                  | 3.50" x 17" MT H2                          |
| Rear tire designation                                                                                                | 140/80-17                                  |
| Load index for rear tire                                                                                             | At least 66                                |
| Permissible rear-wheel imbalance                                                                                     | max 1.6 oz (max 45 g)                      |
| Balance weight for rear wheel (Half of each weights must be attached on the right and left of the rim respectively)  | max 2.8 oz (max 80 g)                      |

**Tire inflation pressure**

|                      |                                                                                                                      |
|----------------------|----------------------------------------------------------------------------------------------------------------------|
| Tire pressure, front | 31.9 psi (2.2 bar), One-up, with cold tires<br>31.9 psi (2.2 bar), Driver with passenger and/or load, with cold tire |
| Tire pressure, rear  | 36.3 psi (2.5 bar), One-up, with cold tires<br>42.1 psi (2.9 bar), Driver with passenger and/or load, with cold tire |

**Electrical system**

|                                      |                                                                                                                                                                                                                |
|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Main fuse                            | 30 A, Voltage regulator                                                                                                                                                                                        |
| Fuses                                | All electrical circuits are electronically protected. If an electronic fuse trips and de-energizes a circuit, the circuit is active as soon as the ignition is switched on after the fault has been rectified. |
| Electrical rating of onboard sockets | 5 A                                                                                                                                                                                                            |

**Battery**

|                  |                                     |
|------------------|-------------------------------------|
| Battery design   | AGM (Absorptive Glass Mat) battery. |
| Battery voltage  | 12 V                                |
| Battery capacity | 12 Ah                               |

**Spark plugs**

|                                           |                  |
|-------------------------------------------|------------------|
| Spark plugs, manufacturer and designation | NGK DCPR 8 E     |
| Electrode gap of spark plug               | 0.04 in (0.9 mm) |

**Light sources**

|                                                   |                      |
|---------------------------------------------------|----------------------|
| Bulb for high-beam headlight                      | H7 / 12 V / 55 W     |
| Bulbs for low-beam headlight                      | H7 / 12 V / 55 W     |
| Bulb for parking light                            | W5W / 12 V / 5 W     |
| Bulb for taillight/brake light                    | LED                  |
| Maximum number of defective LEDS in the tail-lamp | 6, Brake / taillight |
| Light source for license plate light              | W5W / 12 V / 5 W     |
| Bulbs for flashing turn indicators, front         | R10W / 12 V / 10 W   |
| – with LED turn indicator <sup>OE</sup>           | LED                  |
| Bulbs for flashing turn indicators, rear          | R10W / 12 V / 10 W   |
| – with LED turn indicator <sup>OE</sup>           | LED                  |

## Dimensions

|                                                                 |                                                                              |
|-----------------------------------------------------------------|------------------------------------------------------------------------------|
| Motorcycle length                                               | 89.8 in (2280 mm), across front wheel to license-plate carrier               |
| Motorcycle height                                               | 47.8 in (1215 mm), incl. windshield, without driver, with DIN unladen weight |
| – with low-slung <sup>OE</sup>                                  | 46.7 in (1185 mm), incl. windshield, without driver, with DIN unladen weight |
| Motorcycle width                                                | 34.6 in (880 mm), with mirrors                                               |
|                                                                 | 33.7 in (855 mm), without mounted parts                                      |
| Rider's seat height                                             | 32.3 in (820 mm), without rider at unladen weight                            |
| – with comfort seat <sup>OE</sup>                               | 32.9 in (835 mm), without rider at unladen weight                            |
| – with seat low <sup>OE</sup>                                   | 31.1 in (790 mm), without rider at unladen weight                            |
| – with seat low <sup>OE</sup><br>– with low-slung <sup>OE</sup> | 30.1 in (765 mm), without rider at unladen weight                            |
| Rider's inside-leg arc, heel to heel                            | 71.3 in (1810 mm), without rider at unladen weight                           |
| – with comfort seat <sup>OE</sup>                               | 72.4 in (1840 mm), without rider at unladen weight                           |
| – with seat low <sup>OE</sup>                                   | 69.3 in (1760 mm), without rider at unladen weight                           |

- with seat low<sup>OE</sup>
- with low-slung<sup>OE</sup>

67.3 in (1710 mm), without rider at unladen weight

## Weights

|                                |                                                                                         |
|--------------------------------|-----------------------------------------------------------------------------------------|
| Vehicle curb weight            | 467 lbs (212 kg), DIN unladen weight, ready for road, 90 % full tank of gas, without OE |
| Permissible gross weight       | 961 lbs (436 kg)                                                                        |
| – with low-slung <sup>OE</sup> | 769 lbs (349 kg)                                                                        |
| Maximum payload                | 494 lbs (224 kg)                                                                        |
| – with low-slung <sup>OE</sup> | 302 lbs (137 kg)                                                                        |

## Performance data

|                                                       |                    |
|-------------------------------------------------------|--------------------|
| Top speed                                             | 119 mph (192 km/h) |
| – with regular-grade gasoline, unleaded <sup>OE</sup> | 117 mph (189 km/h) |
| – with reduction of power to 35 kW <sup>OE</sup>      | 103 mph (165 km/h) |
| Top speed                                             | 119 mph (192 km/h) |
| – with regular-grade gasoline, unleaded <sup>OE</sup> | 117 mph (189 km/h) |
| – with reduction of power to 35 kW <sup>OE</sup>      | 103 mph (165 km/h) |



**Service**

|                                           |     |
|-------------------------------------------|-----|
| Reporting safety defects .....            | 162 |
| BMW Motorrad Service .....                | 163 |
| BMW Motorrad Mobility<br>Services .....   | 163 |
| Maintenance procedures .....              | 163 |
| Maintenance schedule .....                | 167 |
| Confirmation of maintenance<br>work ..... | 168 |
| Confirmation of service .....             | 182 |

## Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying BMW of North America, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your retailer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

## BMW Motorrad Service

With its worldwide retailer network, BMW Motorrad can attend to you and your motorcycle in over 100 countries around the globe. Authorized BMW Motorrad retailers have the technical information and expertise needed to conduct reliable service and repairs covering every aspect of your BMW.

You will find the nearest authorized BMW Motorrad retailer to you at our website:

**bmw-motorrad.com**



### WARNING

#### **Improperly performed maintenance and repair work**

Accident hazard caused by subsequent damage

- BMW Motorrad recommends having corresponding work on the motorcycle carried out

by a specialized workshop, preferably by an authorized BMW Motorrad retailer. ◀

To ensure that your BMW consistently remains in optimal condition BMW Motorrad urges you to observe the recommended service intervals.

Have all maintenance and repair work confirmed in the "Service" chapter in this manual. Documentation confirming regular maintenance is essential for generous treatment of claims submitted after the warranty period has expired (goodwill).

You can obtain information on the contents of the BMW Services from your BMW Motorrad retailer.

## BMW Motorrad Mobility Services

The BMW Motorrad Mobility Services furnish you and your new BMW motorcycle with extra security by offering a wide array of assistance services in the event of a breakdown (BMW Roadside Assistance, breakdown assistance, vehicle recovery and retrieval, etc.).

Contact your authorized BMW Motorrad retailer for additional information on available mobility-maintenance services.

## Maintenance procedures

### **BMW Pre-Delivery Check**

The BMW pre-delivery check is carried out by your authorized BMW Motorrad retailer before it turns over the vehicle to you.

## BMW Running-in Check

The BMW running-in check must be carried out between 300 mls and 750 mls (500 km and 1200 km).

## BMW Service

BMW Service is carried out once a year. The scope of the services performed may be dependent on the motorcycle owner and the mileage driven. Your BMW Motorrad retailer confirms that the service has been performed and enters the date for the next service.

For riders who drive long distances annually, it may be necessary to come in for service before the entered date. In this case a corresponding maximum odometer reading will also be entered in the confirmation of service. If this odometer reading is reached before the next service date, service must be performed sooner.

The service display in the multi-function display reminds you of the next service date approx. one month or 620 miles (1000 km) before the entered values.

More information on the topic of service is available at:

**[bmw-motorrad.com/service](http://bmw-motorrad.com/service)**

The required scope of maintenance work for your motorcycle can be found in the following maintenance schedule:



[illegible]

## Maintenance schedule

- 1** BMW running-in check
- 2** BMW Service Standard  
Scope
- 3** Engine oil change with filter
- 4** Check valve clearance
- 5** Replace all spark plugs
- 6** Replacing air cleaner insert
- 7** Check or replace the air filter element
- 8** Change brake fluid in entire system
  - a** annually or every 6000 miles (10000 km) (whichever comes first)
  - b** when used off-road, annually or every 6000 miles (10000 km) (whichever comes first)
  - c** for the first time after one year, then every 2 years

## Confirmation of maintenance work

### BMW Service standard scope

The activities of the BMW Service standard scope are listed in the following. The actual scope of maintenance work applicable for your vehicle may differ.

- Performing the brief test using the BMW Motorrad diagnosis system
- Checking coolant level
- Checking/adjusting clutch play
- Checking front brake pads and brake disks for wear
- Checking rear brake pads and brake disk for wear
- Checking front and rear brake fluid level
- Visually inspect the brake lines, brake hoses and connections
- Checking tire pressure and tread depth
- Checking and lubricating the chain drive
- Checking side stand for ease of movement
- Checking steering-head bearing
- Checking the lighting and signal system
- Functional check for engine starting suppression
- Final inspection and check for road safety
- Set the service due date and remaining distance before next service
- Checking charging state of battery
- Confirm the BMW service in the vehicle literature

## BMW Pre-Delivery Check

Conducted

on \_\_\_\_\_

\_\_\_\_\_  
Stamp, Signature

## BMW Running-in Check

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

\_\_\_\_\_  
Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

Yes

No

BMW Service standard scope

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

Yes

No

BMW Service standard scope

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

Yes

No

BMW Service standard scope

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

Yes

No

BMW Service standard scope

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

BMW Service standard scope

Yes

No

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

**BMW Service**

Conducted

on \_\_\_\_\_

Odometer reading \_\_\_\_\_

Next service

at the latest

on \_\_\_\_\_

or, if reached sooner

Odometer reading \_\_\_\_\_

Work carried out

Yes

No

BMW Service standard scope

☐☐

Engine oil change with filter

☐☐

Checking valve clearance

☐☐

Replacing all spark plugs

☐☐

Replacing air cleaner element

☐☐

Checking or replacing air cleaner element (maintenance)

☐☐

Oil change - telescopic fork

☐☐

Changing brake fluid in entire system

☐☐

Information

-----

-----

-----

-----

-----

-----

-----

-----

\_\_\_\_\_

Stamp, Signature

The table is intended as proof of maintenance and repair work, the installed optional accessories and any special campaign (recall) work carried out.

[illegible]

| Work carried out | Odometer reading | Date |
|------------------|------------------|------|
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |
|                  |                  |      |



## Appendix

|                                              |     |
|----------------------------------------------|-----|
| Certificate for Electronic Immobilizer ..... | 186 |
|----------------------------------------------|-----|

## FCC Approval

### Ring aerial in the ignition switch



To verify the authorization of the ignition key, the electronic immobilizer exchanges information with the ignition key via the ring aerial.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. ◀

## Approbation de la FCC

### Antenne annulaire présente dans le commutateur d'allumage



Pour vérifier l'autorisation de la clé de contact, le système d'immobilisation électronique échange des

informations avec la clé de contact via l'antenne annulaire.

Le présent dispositif est conforme à la partie 15 des règles de la FCC. Son utilisation est soumise aux deux conditions suivantes :

- (1) Le dispositif ne doit pas produire d'interférences nuisibles, et
- (2) le dispositif doit pouvoir accepter toutes les interférences extérieures, y compris celles qui pourraient provoquer une activation inopportune.



Toute modification qui n'aurait pas été approuvée expressément par l'organisme responsable de l'homologation peut annuler l'autorisation accordée à l'utilisateur pour utiliser le dispositif. ◀

**A**

Abbreviations and symbols, 6

**ABS**

Control, 16

Operating, 48

Self-diagnosis, 76

Technology in detail, 88

Warning light, 32

**Accessories**

General instructions, 132

**Air filter**

Installing, 114

Position on motorcycle, 15

Removing, 114

**Alarm**

triggering, 58

**Alarm function**

Activate motion sensor, 57

Deactivating, 58

**Ambient temperature**

Display, 38

Outside temperature

warning, 31

**Anti-theft alarm system, 55, 56**

Indicator lamp, 33

**ASC**

Control, 16

Operating, 49

Self-diagnosis, 77

Warning light, 32

**Average values**

Resetting, 46

**B****Battery**

change, 63

Charging a disconnected

battery, 124

Installing, 125

Maintenance instructions, 123

Position on motorcycle, 15

Recharging connected

battery, 124

Removing, 125

Technical data, 156

**Brake fluid**

Checking fluid level at rear, 103

Checking front fluid level, 102

Front fluid tank, 13

Rear fluid reservoir, 13

**Brake pads**

Breaking in, 78

Check rear, 101

Checking front, 100

**Brakes**

Adjusting handlebar lever, 68

Checking operation, 100

Safety information, 80

Technical Data, 154

**Breaking in, 78****Bulbs**

License plate light, 119

Parking lamps, replacing, 116

Replace high-beam

headlight, 115

Replace low-beam

headlight, 115

Replacing bulb for brake and

rear light, 118

Technical Data, 157

Turn indicators, 118

Warning for bulb failure, 31

**C**

- Care
  - Paint, 143
- Case
  - Operating, 134
- Chain
  - Adjusting sag, 128
  - Checking sag, 128
  - Checking wear, 129
  - Lubricating, 127
- Checklist, 74
- Clock
  - Adjusting, 46
  - Control, 18
- Clutch
  - Adjust play, 104
  - Adjusting handlebar lever, 68
  - Checking operation, 104
  - Checking play, 104
  - Technical Data, 152
- Confirmation of maintenance work, 168

**Coolant**

- Checking level, 105
- Fluid level indicator, 13
- Overtemperature warning indicator, 29
- Topping up, 105

**D**

- Damping
  - Adjustment element, 13
- Deactivating
  - Alarm function, 58
  - Motion sensor, 57
- Diagnostic connector
  - fasten, 127
  - Loosen, 127
- Dimensions
  - Technical Data, 158

**E**

- Electrical system
  - Technical Data, 156
- Emergency on/off switch (kill switch)
  - Control, 17
  - Operating, 42

**Engine**

- Severe fault, 30
- Starting, 75
- Technical Data, 151
- Warning light, 30

**Engine oil**

- Checking level, 98
- Filling location, 11
- Oil dipstick, 11
- Technical Data, 150
- Topping up, 100

- Engine speed warning
  - Switching on, 79
  - Warning light, 18

**Equipment, 7****ESA**

- Control, 16
- Operating, 50

**F**

- Factory settings, 59
- Fairing
  - Installing center section, 121
  - Removing center section, 121

First-aid kit  
Position on motorcycle, 14

Frame  
Technical Data, 153

Front wheel stand  
Mounting, 97

Fuel  
Filling location, 13  
Fluid level indicator, 37  
Fuel reserve, 37  
Refueling, 83  
Technical data, 149  
Technical Data, 149

Fuel reserve  
Warning indicator, 29

Fuses  
Replacing, 126

## H

Hazard warning flashers  
Control, 16  
Operating, 43

Headlight  
Adjusting for RHD/LHD  
traffic, 66  
Headlamp range  
adjustment, 67  
Headlight range, 67  
Heated handlebar grips  
Control, 17  
Operating, 53  
Helmet holder  
Position on motorcycle, 14  
Horn  
Control, 16

## I

Ignition  
Switching off, 41  
Switching on, 40  
Immobilizer  
Spare key, 41  
Warning light, 29  
Indicator lights  
Overview, 22  
Instrument cluster  
Overview, 18  
Photosensor, 18

## J

Jump-start, 122

## K

Keys, 40

## L

Laptimer, 47  
Interchanging button  
functions, 47  
Lights  
Control, 16  
Headlight low beam, 42  
Operating headlight flasher, 43  
Operating high-beam  
headlight, 43  
Operating parking lamp, 43  
Parking lights, 42  
logon  
Remote control, 61  
Luggage  
Loading information, 72  
Tying down, 133

**M**

- Maintenance
  - General instructions, 96
  - Maintenance schedule, 167
- Maintenance intervals, 163
- Mirrors
  - Adjusting, 66
- Mobility Services, 163
- Motion sensor
  - Deactivating, 57
- Motorcycle
  - Care, 141
  - Cleaning, 141
  - Parking, 81
  - Returning to use, 144
  - Storage, 144
  - Tying down, 84
- Multifunction display, 18
  - Control, 16
  - Meaning of symbols, 25
  - Overview, 24
  - Overview of standard display, 23
  - Selecting display readings, 44

- Multifunction switch
  - General view, left, 16
  - General view, right, 17

**N**

- Notice concerning current status, 7

**O**

- Odometer
  - Control, 18
  - Resetting, 45
- Off-road mode
  - Adjusting, 52
  - Technology in detail, 92
- Offroad riding, 79
- Onboard power socket
  - Information on use, 132
  - Position on motorcycle, 11
- Onboard tool kit
  - Position on motorcycle, 14
- Overview of warning indicators, 26
- Overviews
  - Indicator and warning lights, 22
  - Instrument panel, 18

- Left side of motorcycle, 11
- Multifunction display, 23, 24
- Multifunction switch, left, 16
- Multifunction switch, right, 17
- Right side of motorcycle, 13
- Under fairing, 15
- Underneath seat, 14

**P**

- Paint care, 143
- Performance data
  - Technical data, 159
- Pre-Ride-Check, 76
- Programming, 60

**R**

- RDC
  - Display, 38
  - Rim sticker, 109
  - Technology in detail, 91
  - Warning indicators, 34
- Rear-wheel drive
  - Technical Data, 153
- Refueling, 83

Remote control  
  logging on, 61  
  synchronize, 62  
Rider's Manual (US Model)  
  Position on motorcycle, 14  
Riding mode, 52

**S**

Safety instructions  
  On braking, 80  
  On riding, 72  
Seat  
  Installing, 54  
  Locking mechanism, 11  
  Removing, 54  
Service, 163  
  Reporting safety defects, 162  
Service display, 36  
Spark plugs  
  Technical data, 157  
Speedometer, 18  
Spring preload  
  Adjusting, 69  
  Adjustment element, 13  
  Tool, 14

Starting, 75  
  Control, 17  
Steering lock  
  Locking, 40  
Stopwatch  
  Operating, 47  
Suspension  
  Technical Data, 153  
Switching off, 81  
Symbols  
  Meaning, 25

**T**

Tachometer, 18  
Technical data  
  Battery, 156  
  Brakes, 154  
  Clutch, 152  
  Dimensions, 158  
  Electrical system, 156  
  Engine, 151  
  Engine oil, 150  
  Frame, 153  
  Fuel, 149  
  Light sources, 157

Performance data, 159  
Rear-wheel drive, 153  
Spark plugs, 157  
Standards, 7  
Suspension, 153  
Transmission, 152  
Weights, 159  
Wheels and tires, 155  
Threaded fasteners, 147  
Tires  
  Breaking in, 78  
  Checking tire inflation  
    pressures, 106  
  Checking tire tread depth, 106  
  Checking tread depth, 106  
  Inflation pressures, 156  
  Technical Data, 155  
  Top speed, 73  
  Tyre inflation pressure table, 14  
Topcase  
  Operating, 137  
Torques, 147  
Traction Control  
  ASC, 90

- Transmission
  - Technical Data, 152
- Troubleshooting chart, 146
- Turn indicators
  - Control, 16
  - Operating, 44
- Type plate
  - Position on motorcycle, 13

## **V**

- Vehicle identification number
  - Position on motorcycle, 13

## **W**

- Warning lamps
  - ABS, 32
  - Alarm system, 33
  - ASC, 32
  - Bulb failure, 31
  - Coolant temperature, 29
  - Displays, 25
  - Electronic engine management, 30
  - Electronic immobilizer, 29
  - Engine warning, 30
  - Fuel reserve, 29

- Outside temperature
  - warning, 31
- Overview, 22
- TPC/RDC, 34
- Weights
  - Load capacity table, 14
  - Technical Data, 159
- Wheels
  - Check wheel rims, 106
  - Checking rims, 106
  - Install rear wheel, 112
  - Installing front wheel, 109
  - Removing front wheel, 107
  - Removing rear wheel, 111
  - Size change, 107
  - Technical Data, 155



The descriptions and illustrations in this manual may vary from your own motorcycle's actual equipment, depending upon its equipment level and accessories as well as your specific national version. No claims stemming from these differences can be recognized.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

Original Rider's Manual, printed in Germany.

© 2016 Bayerische Motoren  
Werke Aktiengesellschaft  
80788 Munich, Germany

Reprints and duplication of this work, in whole or part, are prohibited without the express written approval of BMW Motorrad, Aftersales.

## Fuel

### Tire inflation pressure

**BMW recommends ADVANTEC**  
ORIGINAL BMW ENGINE OIL

