

Rider's Manual

R 1200 S



BMW Motorrad



The Ultimate Riding
Machine

Motorcycle data/dealership details

Motorcycle data

Model

Vehicle identification number

Colour code

Date of first registration

Registration number

Dealership details

Person to contact in Service department

Ms/Mr

Phone number

Dealership address/phone number (company stamp)

Welcome to BMW

We congratulate you on your choice of a motorcycle from BMW and welcome you to the community of BMW riders. Familiarise yourself with your new motorcycle so that you can ride it safely and confidently in all traffic situations.

Please read this Rider's Manual carefully before starting to use your new BMW motorcycle. It contains important information on how to operate the controls and how to make the best possible use of all your BMW's technical features.

In addition, it contains information on maintenance and care to help you maintain your motorcycle's reliability and safety, as well as its value.

If you have questions concerning your motorcycle, your authorised

BMW Motorrad dealer will gladly provide advice and assistance.

We hope that you will enjoy riding your BMW and that all your journeys will be pleasant and safe.

BMW Motorrad.

Table of Contents

You can also consult the index at the end of this Rider's Manual if you want to find a particular topic or item of information.

1 General instructions 5

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Currency	7

2 General views 9

General view, left side	11
General view, right side	13
Underneath the seat	14
Handlebar fitting, left	15
Handlebar fitting, right	16
Instrument cluster	17
Headlight	18

3 Status indicators 19

Standard status indicators	20
Status indicators with on-board computer	21
Status indicators with tyre-pressure monitoring (RDC) ^{OE}	22
Standard warnings	22
Warnings issued by the on-board computer ^{OE}	26
ABS warnings ^{OE}	28
RDC warnings ^{OE}	30
Anti-theft alarm status indicators ^{OE}	35

4 Operation..... 39

Ignition switch and steering lock	40
Electronic immobiliser (EWS)	41
Clock	42
Odometer and tripmeters	43
On-board computer	45

Tyre pressure monitoring RDC ^{OE}	49
Lights	50
Turn indicators	51
Hazard warning flashers	51
Emergency off switch (kill switch)	52
Grip heating ^{OE}	53
BMW Motorrad ABS ^{OE}	53
Clutch	54
Brakes	55
Mirrors	56
Suspension settings.....	56
Settings, standard suspension	56
Settings, sport suspension ^{OE}	57
Tyres.....	63
Headlight	63
Front and rear seats.....	64
Securing helmet to motorcycle	66
Luggage loops	66

5 Riding	69	Rims	97	Rear-wheel drive	128
Safety instructions	70	Wheels	97	Running gear	129
Checklist	71	Front-wheel stand	102	Brakes	130
Starting	72	Rear-wheel stand	103	Wheels and tyres	131
Running in	74	Bulbs	104	Electrics	134
Brakes	75	Jump starting	111	Frame	135
Parking your motorcycle	76	Battery	112	Dimensions	136
Refuelling	77	9 Care	117	Weights	136
6 Engineering details	79	Care products	118	Riding specifications	137
Brake system with BMW Mo-		Washing motorcycle	118	11 Service	139
torrad ABS ^{OE}	80	Cleaning easily damaged		BMW Motorrad service	140
Tyre pressure monitoring		components	118	BMW Motorrad service	
RDC ^{OE}	82	Paint care	119	quality	140
7 Accessories	83	Protective wax coating	120	BMW Motorrad Service	
General instructions	84	Laying up motorcycle	120	Card: on-the-spot break-	
Power socket	84	Restoring motorcycle to		down assistance	140
8 Maintenance	87	use	120	BMW Motorrad service net-	
General instructions	88	10 Technical data	121	work	141
Toolkit	88	Troubleshooting chart	122	Maintenance work	141
Engine oil	89	Threaded fasteners	123	Confirmation of mainten-	
Brake system, general	91	Engine	125	ance work	142
Brake pads	92	Fuel	126	Confirmation of service	147
Brake fluid	94	Engine oil	126		
Clutch	95	Clutch	127		
Tyres	96	Transmission	128		

General instructions

Overview	6
Abbreviations and symbols	6
Equipment	7
Technical data	7
Currency	7

Overview

Chapter 2 of this Rider's Manual will provide you with an initial overview of your motorcycle. All maintenance and repair work on the motorcycle is documented in Chapter 11. This record of the maintenance work you have had performed on your motorcycle is a precondition for generous treatment of goodwill claims. When the time comes to sell your BMW, please remember to hand over this Rider's Manual; it is an important part of the motorcycle.

Abbreviations and symbols



Indicates warnings that you must comply with for reasons of your safety and the safety of others, and to protect your motorcycle against damage.



Specific instructions on how to operate, control, adjust or look after items of equipment on the motorcycle.



Indicates the end of an item of information.



Instruction.



Result of an activity.



Reference to a page with more detailed information.



Indicates the end of a passage relating to specific accessories or items of equipment.



Tightening torque.



Item of technical data.

OE

Optional extra

The motorcycles are assembled complete with all the BMW optional extras originally ordered.

OA

Optional accessory

You can obtain optional accessories through your authorised BMW Motorrad dealer; optional accessories have to be retrofitted to the motorcycle.

EWS

Electronic immobiliser (Elektronische Wegfahrsicherung).

DWA

Anti-theft alarm (Diebstahlwarnanlage)

ABS

Anti-lock brake system

RDC

Tyre pressure control (ReifenDruck-Control)

Equipment

When you ordered your BMW motorcycle, you chose various items of custom equipment. This Rider's Manual describes optional extras (OE) offered by BMW and selected optional accessories (OA). This explains why the manual may also contain descriptions of equipment which you have not ordered. Please note, too, that your motorcycle might not be exactly as illustrated in this manual on account of country-specific differences. If your BMW was supplied with equipment not described in this Rider's Manual, you will find these features described in separate manuals.

Technical data


All dimensions, weights and power ratings stated in the Rider's Manual are quoted to the standards and comply with the tolerance requirements of the Deutsche Institut für Normung e.V. Versions for individual countries may differ.

Currency

The high safety and quality standards of BMW motorcycles are maintained by constant development work on designs, equipment and accessories. Because of this, your motorcycle may differ from the information supplied in the Rider's Manual. Nor can BMW Motorrad entirely rule out errors and omissions. We hope you will appreciate that no claims can be entertained on the basis of the data, illustrations or descriptions in this manual.


General views

General view, left side.....	11
General view, right side	13
Underneath the seat	14
Handlebar fitting, left	15
Handlebar fitting, right	16
Instrument cluster	17
Headlight	18



General view, left side

- 1 Adjuster for headlight beam throw (underneath the instrument cluster) (▮▮▮ 64)
- 2 Seat lock (▮▮▮ 65)
- 3 Adjuster for spring preload, rear (▮▮▮ 56)
- 4 Adjuster for damping, rear, standard suspension (▮▮▮ 56)
- 5 Engine oil level indicator (▮▮▮ 89)
- 6 Engine-oil filler neck (▮▮▮ 91)
- 7 Adjuster for damping, front, sport suspension^{OE} (▮▮▮ 59)
- 8 Adjuster for spring preload, front, sport suspension^{OE} (▮▮▮ 57)
- 9 Clutch-fluid reservoir (▮▮▮ 95)





General view, right side

- 1 Power socket (➡ 84)
- 2 Fuel filler neck (➡ 77)
- 3 Brake-fluid reservoir, front (➡ 94)
- 4 Brake-fluid reservoir, rear (➡ 95)
- 5 Adjuster for rebound-stage damping, rear, sport suspension^{OE} (➡ 61)
- 6 Adjuster for compression-stage damping, rear, sport suspension^{OE} (➡ 62)

Underneath the seat

- 1 Hook wrench
- 2 Unlocking rear seat (➡ 65)
- 3 Table of tyre pressures
- 4 Toolkit (➡ 88)
- 5 Battery (➡ 114)







Handlebar fitting, left

- 1** Operating the odometer (➡ 43), Operating the on-board computer^{OE} (➡ 45)
- 2** Operating the ABS^{OE} (➡ 54)
- 3** Horn
- 4** Flashing turn indicators, left (➡ 51), Hazard warning flashers (➡ 51)
- 5** Headlight flasher and high-beam headlight (➡ 50)

Handlebar fitting, right

- 1 Emergency off switch (kill switch) (➡ 52)
- 2 Starter button (➡ 72)
- 3 Grip heating^{OE} (➡ 53)
- 4 Flashing turn indicators, right (➡ 51), Hazard warning flashers (➡ 51)
- 5 Cancel button, flashing turn indicators (➡ 51), Pushbutton, cancel hazard warning flashers (➡ 52)






Instrument cluster

- 1 Speedometer
- 2 Rev. counter
- 3 Telltale lights (➡ 20)
- 4 Multifunction display (➡ 20)
- 5 Telltale light, anti-theft alarm (OE) and sensor for instrument lighting
- 6 Select the readings (➡ 43)
Reset the tripmeter (➡ 44)
Set the clock (➡ 42)

▶ The instrument-cluster lighting has automatic day and night switchover.◀

Headlight

- 1 Low-beam headlight
- 2 High-beam headlight
- 3 Parking light




Status indicators

Standard status indicators	20
Status indicators with on-board computer.....	21
Status indicators with tyre-pressure monitoring (RDC) ^{OE}	22
Standard warnings	22
Warnings issued by the on-board computer ^{OE}	26
ABS warnings ^{OE}	28
RDC warnings ^{OE}	30
Anti-theft alarm status indicators ^{OE}	35

Standard status indicators

Multifunction display



- 1 Clock (→ 42)
- 2 Gear indicator (→ 20)
- 3 Engine temperature (→ 20)
- 4 Odometer and tripmeters (→ 43)

Telltale lights



- 1 Flashing turn indicators, left
- 2 High-beam headlight
- 3 Idle
- 4 Flashing turn indicators, right

Gear indicator

N The gear engaged or **N** for neutral appears on the display.

N If no gear is engaged, the 'neutral' telltale light also lights up.

Engine temperature

 The horizontal bars below the temperature symbol indicate the engine temperature.

Service-due indicator



If the next service is due in less than one month, the date for the next service is shown briefly after the Pre-Ride Check completes. Month and year are both shown as two-digit numbers with a line as separator, so in this example the next service is due in March 2007.



If the motorcycle covers long distances in the course of the year, under certain circumstances it might be necessary to have it serviced at a date in advance of the forecast due date. If the countdown distance to the odometer reading at which a service will be due is less than 1000 km, the distance is counted down in steps of 100 km and is shown briefly after the Pre-Ride Check completes.

If service is overdue, the due date or the odometer reading at which service was due is accom-


panied by the 'General' warning light showing yellow. The word "Service" remains permanently visible.

▶ If the service-due indicator appears more than a month in advance of the actual due date or if the word "Service" does not show permanently even though a service is overdue, the date stored in memory in the instrument cluster is incorrect and must be set. This situation can occur if the battery was disconnected for a prolonged period of time.

If you want to have the date set consult a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Status indicators with on-board computer

Mode of presentation



- 1 Status-indicator panel of the on-board computer^{OE} (45)
- 2 Fuel capacity (21)

Fuel capacity

 The horizontal bars below the fuel-pump symbol indicate the remaining quantity of fuel.

When the fuel in the tank is topped up the gauge briefly

shows the original level, before the reading is updated.


Status indicators with tyre-pressure monitoring (RDC)^{OE}



- 1** Tyre pressures alternate with the clock; if the motor-cycle is fitted with an on-board computer tyre pressures displayed as an additional set of readings by the on-board computer.^{OE} (→ 49)

Standard warnings

Mode of presentation



Warnings are indicated by the 'General' warning light **1** showing in combination with a warning word, for example **2** or in combination with one of the warning symbols **3**. The 'General' warning light shows red or yellow, depending on the urgency of the warning. If two or more warnings occur at the same time, all the appropriate warning lights and warning symbols appear, alternating with warning words as applicable.

The possible warnings are listed on the next page.

Warnings, overview

			Meaning
	Lights up yellow	EWS ! appears on the display.	Electronic immobiliser active (➡ 24)
	Lights up yellow	FUEL ! appears on the display.	Fuel down to reserve (➡ 24)
	Lights up yellow	 Appears on the display	Engine in emergency-operation mode (➡ 24)
	Flashes red	 Appears on the display	Insufficient engine oil pressure (➡ 24)
	Lights up red	 Appears on the display	Insufficient battery charge current (➡ 25)
	Lights up yellow	LAMPR ! appears on the display.	Rear light bulb defective (➡ 25)
		LAMPF ! appears on the display.	Front light bulb defective (➡ 26)
	Lights up yellow	LAMPS ! appears on the display.	Bulbs defective (➡ 26)

Electronic immobiliser active

General warning light shows yellow.

EWS ! appears on the display. The key being used is not authorised for starting, or communication between key and engine electronics is disrupted.

- Remove all other vehicle keys from the same ring as the ignition key.
- Use the reserve key.
- Have the defective key replaced, preferably by an authorised BMW Motorrad dealer.

Fuel down to reserve

General warning light shows yellow.

FUEL ! appears on the display.




Lack of fuel can result in the engine misfiring and cutting out unexpectedly. Misfiring can damage the catalytic converter; a hazardous situation

can result if the engine cuts out unexpectedly.

Do not run the fuel tank dry. ◀

The fuel tank contains no more than the reserve quantity of fuel.



- Refuelling (➡ 77)

Engine in emergency-operation mode

General warning light shows yellow.



Engine symbol appears on the display.



The engine is running in emergency operating mode. Engine power might be reduced and this can cause hazardous situations, particularly if you attempt to overtake other road users.

Engine power level might be lower than normal: adapt your style of riding accordingly. ◀

The engine control unit has diagnosed a fault. In exceptional cases, the engine stops and refuses to start. Otherwise, the engine runs in emergency operating mode.

- You can continue to ride, but bear in mind that the usual engine power might not be available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient engine oil pressure

General warning light flashes red.



Oil-can symbol appears on the display.

The oil pressure in the lube-oil system is too low. Stop immediately and switch off the engine.



The insufficient oil pressure warning does not fulfil the function of an oil gauge. The only way of checking whether the oil level is correct is to check the oil sight glass.◀

A low oil level is one reason why a warning indicating insufficient oil pressure is issued.

- Check the engine oil level (→ 89)

If the oil level is too low:

- Top up the engine oil.

If the engine oil level is correct:



Riding when engine-oil pressure is low can result in engine damage.

Do not continue your journey.◀

- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Insufficient battery charge current



General warning light shows red.



Battery symbol appears on the display.



A discharged battery can cause the engine to die suddenly, and this could result in a dangerous situation in traffic. Have faults rectified as soon as possible.◀



If the battery is not charging, continuing to ride can cause it to discharge completely, in which case it will suffer irreparable damage.

If possible, do not continue your journey.◀

Battery is not being charged.

- You can continue to ride until the battery is discharged. Bear in mind, however, that the engine could cut out suddenly and that the battery could discharge until completely flat, in which case it might have suffered irreparable damage.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Rear light bulb defective



General warning light shows yellow.

LAMPR ! appears on the display.



A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle. Replace defective bulbs as

soon as possible; always carry a complete set of spare bulbs if possible.◀

Rear light or brake light bulb defective.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Front light bulb defective

LAMPF ! appears on the display.

 A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle. Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible.◀

Low-beam headlight, high-beam headlight, side-light or turn-indicator bulb defective.

- Replacing high-beam/low-beam headlight bulb (➡ 105)
- Replacing parking-light bulb (➡ 107)
- Replacing front turn indicator bulb (➡ 108)
- Replacing rear turn indicator bulb (➡ 110)

Bulbs defective

 General warning light shows yellow.

LAMPS ! appears on the display.


 A defective bulb places your safety at risk because it is easier for other users to oversee the motorcycle. Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible.◀

A combination of the bulb defects described above has occurred.

- See the fault descriptions above.

Warnings issued by the on-board computer^{OE}

Mode of presentation



Warnings issued by the on-board computer appear in panel **1**. The possible warnings are listed on the next page.

Warnings, overview

Meaning



Appears on the display

Engine-oil level too low (28)

Check Oil appears on the display.



Appears on the display

Ice warning (28)

Engine-oil level too low



Oil-level symbol appears on the display.

Check Oil appears on the display.

The electronic oil-level sensor has registered an excessively low oil level.

The only exact way of checking whether the oil level is correct is to check the oil sight glass. The next time you stop for fuel:

- Check the engine oil level (➡ 89)

If the oil level is too low:

- Top up the engine oil (➡ 91)

The oil sensor might be defective if the "Check oil level" message appears even though a check at the oil sight glass reveals that the oil level is correct.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Ice warning



Ice-crystal symbol appears on the display.

The air temperature measured at the motorcycle is lower than 3 °C.



The ice warning does not mean that there is no risk of black ice forming at measured temperatures above 3 °C.

Always take extra care and think well ahead when temperatures are low; remember that the danger of black ice is particularly high on bridges and where the road is in the shade.◀

- Ride carefully and think well ahead.

ABS warnings^{OE}

Mode of presentation



ABS warnings are indicated by ABS warning light **1**.

The way in which the ABS warning light indicates status can differ in some countries.



Possible national variant.

The detailed descriptions relating to BMW Motorrad ABS start on page (➡ 80), and you will find an overview listing the possible warnings on the next page.

Warnings, overview

		Meaning
	Flashes	Self-diagnosis not completed (→ 30)
	Lights up	ABS deactivated (→ 30)
	Lights up	ABS fault (→ 30)

Self-diagnosis not completed



ABS warning light flashes.

The ABS function is not available, because self-diagnosis did not complete. The motorcycle has to move forward a few metres for the wheel sensors to be tested.

- Pull away slowly. Bear in mind that the ABS function is not available until self-diagnosis has completed.

ABS deactivated



ABS warning light shows.

The rider has switched off the ABS system.
with OE Anti-lock braking system (ABS):

- Activate the ABS function
(54)

ABS fault




ABS warning light shows.

The ABS control unit has detected a fault. The ABS function is not available.

- You can continue to ride the motorcycle, but make due provision for the fact that the ABS function is not available. Bear in mind the more detailed information on situations that can lead to an ABS fault (81).
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

RDC warnings^{OE}

Mode of presentation



Warning symbol **2** indicates a critical tyre pressure, and the corresponding reading for the front tyre pressure **3** or the rear tyre pressure **4** flashes.

If the critical value is close to the limit of the permissible tolerance range, 'General' warning light **1** shows yellow. If the tyre pressure registered by the sensor is outside the permissible tolerance range, the 'General' warning light flashes red.

The detailed descriptions relating to BMW Motorrad RDC start on page (➡ 82), and you will find an overview listing the possible warnings on the next page.

Warnings, overview

Meaning

	Lights up yellow		Tyre pressure close to limit of permitted tolerance (→ 33)
		The critical tyre pressure flashes.	
	Flashes red		Tyre pressure outside permitted tolerance (→ 33)
		The critical tyre pressure flashes.	
		" - - " or " - - - - "	Signal transmission disrupted (→ 33)
		appears on the display	
	Lights up yellow		Sensor defective or system error (→ 34)
		" - - " or " - - - - "	
		appears on the display	
	Lights up yellow	RDC ! appears on the display.	Battery of tyre-pressure sensor weak (→ 34)

Tyre pressure close to limit of permitted tolerance



General warning light shows yellow.



Tyre symbol appears on the display.

The critical tyre pressure flashes. Measured tyre pressure is close to the limit of permitted tolerance.

- Correct the tyre pressure as stated on the inside cover of the Rider's Manual.



The tyre-pressures listed on the inside cover are temperature-compensated; the reference tyre temperature for these readings is always 20 °C. The procedure for correcting tyre pressures when the tyres are not at this reference temperature is as follows:

Calculate the difference between the specified value stated in the Rider's Manual and the reading

shown by the RDC system. Use the public air line at a petrol station or motorway service area to adjust the tyre pressure by this amount.◀

Tyre pressure outside permitted tolerance



General warning light flashes red.



Tyre symbol appears on the display.

The critical tyre pressure flashes. Measured tyre pressure is outside permitted tolerance.

- Check the tyre for damage and to ascertain whether the motorcycle can be ridden with the tyre in its present condition.

If the motorcycle can be ridden with the tyre in its present condition:



Incorrect tyre pressures impair the motorcycle's handling characteristics.

If tyre pressure is incorrect it is essential to adapt your style of riding accordingly.◀

- Correct the tyre pressure at the earliest possible opportunity.
- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad dealer.

If you are unsure whether the motorcycle can be ridden with the tyre in its present condition:

- Do not continue your journey.
- Notify the breakdown service.
- Have the tyre checked for damage by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Signal transmission disrupted

" - - " or " - - - - " appears on the display.

The motorcycle has not yet accelerated past the threshold of approximately 30 km/h. The RDC sensors do not start transmitting signals until the motorcycle reaches a speed above this threshold (➡ 82).

- Increase speed above this threshold and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Wireless communication with the RDC sensors has been disrupted. Possible causes include radio-communication systems operating in the vicinity and interfering

with the link between the RDC control unit and the sensors.

- Move to another location and observe the RDC readings. Assume that a permanent fault has not occurred unless the 'General' warning light comes on to accompany the symptoms. Under these circumstances:
- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Sensor defective or system error



General warning light shows yellow.



Tyre symbol appears on the display.

" - - " or " - - - - " appears on the display.

Motorcycle is fitted with wheels not equipped with RDC sensors.

- Fit wheels and tyres equipped with RDC sensors.

One or two RDC sensors have failed.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

A system error has occurred.

- Have the fault rectified by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Battery of tyre-pressure sensor weak



General warning light shows yellow.

RDC ! appears on the display.




This error message appears only briefly after the pre-ride check completes. ◀

The integral battery in the tyre-pressure sensor has lost a significant proportion of its original capacity. There is no assurance of how long the tyre pressure control system can remain operational.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Anti-theft alarm status indicators^{OE}

Mode of presentation



Anti-theft alarm warnings appear as plain-text warnings **2** in combination with the 'General' warning light **1** showing after the Pre-Ride Check and relate to the capacity of the internal battery that supplies power to the anti-theft alarm.

The possible warnings are listed on the next page.

Meaning

	DWALO ! appears on the display.	Anti-theft alarm battery weak ( 37)
 Lights up yellow	DWA ! appears on the display.	Anti-theft alarm battery flat ( 37)

Anti-theft alarm battery weak

DWALO ! appears on the display.

 This error message appears only briefly after the pre-ride check completes.◀

The integral battery in the anti-theft alarm has lost a significant proportion of its original capacity. There is no assurance of how long the anti-theft alarm can remain operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Anti-theft alarm battery flat

General warning light shows yellow.

DWA ! appears on the display.

 This error message appears only briefly after the pre-ride check completes.◀

The integral battery in the anti-theft alarm has lost its entire original capacity. There is no assurance that the anti-theft alarm will be operational if the motorcycle's battery is disconnected.

- Seek the advice of a specialist workshop, preferably an authorised BMW Motorrad dealer.

Operation

Ignition switch and steering lock	40	Mirrors	56
Electronic immobiliser (EWS)	41	Suspension settings	56
Clock	42	Settings, standard suspension	56
Odometer and tripmeters	43	Settings, sport suspension ^{OE}	57
On-board computer	45	Tyres	63
Tyre pressure monitoring RDC ^{OE}	49	Headlight	63
Lights	50	Front and rear seats	64
Turn indicators	51	Securing helmet to motorcycle	66
Hazard warning flashers	51	Luggage loops	66
Emergency off switch (kill switch)	52		
Grip heating ^{OE}	53		
BMW Motorrad ABS ^{OE}	53		
Clutch	54		
Brakes	55		


Ignition switch and steering lock

Keys

You receive one master key and one spare key. Please consult the information on the electronic immobiliser (EWS) if a key is lost or mislaid (➡ 41).

Ignition switch and steering lock, tank filler cap lock and seat lock are all operated with the same key.

Switching on ignition




- Turn the key to position **1**.

- » Side light and all function circuits switched on.
- » Engine can be started.
- » Pre-ride check is performed. (➡ 73)

with OE Anti-lock braking system (ABS):

- Turn the key to position **1**.
- » ABS self-diagnosis is performed in addition to the checks outlined above. (➡ 73)◁


Switching off ignition



- Turn the key to position **2**.

- » Lights switched off.
- » Handlebars not locked.
- » Key can be removed.
- » Electrically powered accessories remain operational for a limited period of time.
- » The battery can be recharged via the on-board socket.

Locking handlebars



! If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handle-

bars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock.◀

- Turn the handlebars to the full left or right lock position.
- Turn the key to position **3**, while moving the handlebars slightly.
 - » Ignition, lights and all function circuits switched off.
 - » Handlebars locked.
 - » Key can be removed.

Electronic immobiliser (EWS)

Protection against theft

The electronic immobiliser helps protect your BMW motorcycle from theft, and this enhanced security is at your disposal without any need for you to set parameters or activate additional systems.

The engine of a motorcycle fitted with this electronic immobiliser can be started only with the keys that belong to the vehicle. You can also have your authorised BMW Motorrad dealer bar individual keys, for example if a particular key goes missing. The engine cannot be started with a key that has been barred.

In-key electronics

The motorcycle's electronics exchange certain continuously changing signals with the electronics in the key; these signals are specific to your motorcycle and they are transmitted via the ring aerial in the ignition lock. The ignition is not enabled for starting until the key has been recognised as "authorised" for your motorcycle.

 A spare key attached to the same ring as the ignition key used to start the en-

gine could "irritate" the electronics, in which case the enabling signal for starting is not issued. The **EWS** warning appears in the multifunction display.

Always keep the spare key separately from the ignition key.◀

Replacement and extra keys


You can obtain replacement/extra keys only through an authorised BMW Motorrad dealer. The keys are part of an integrated security system, so the dealer is under an obligation to check the legitimacy of all applications for replacement/extra keys. If you want to have a lost key barred, you have to bring with you all the other keys that belong to the motorcycle. A key that has been barred can subsequently be cleared and reactivated for use.

Clock

Setting clock

! Attempting to set the clock while riding the motorcycle can lead to accidents. Set the clock only when the motorcycle is stationary.◀

- Switch on the ignition.



- Repeatedly press button **1** until the odometer reading appears on the display.




- Alternatively, repeatedly press button **2** until the total distance covered reading appears on the display.

with OE On-board computer or with OE Tyre-pressure monitoring (RDC):



- Repeatedly press button **2** until the clock appears on the display.


▶ In this case, the button in the instrument cluster operates only the tripmeters.◀◀



Odometer and tripmeters

Selecting readings

- Switch on the ignition.



- Press button **1**.

- Hold down the button.
 - » Hours reading **3** flashes.
- Press the button.
 - » The hours reading increments by one each time you press the button.
- Hold down the button.
 - » Minutes reading **4** flashes.
- Press the button.
 - » The minutes reading increments by one each time you press the button.
- Hold down the button.
 - » The clock is now set and the time appears on the display.



- Alternatively, press button **2**.




The display starts with the current value and each time the button is pressed it moves one step through the following sequence:

- Total distance covered

- Tripmeter 1 (Trip I)
- Tripmeter 2 (Trip II)
- Residual range (once fuel level is down to reserve)

with OE On-board computer or with OE Tyre-pressure monitoring (RDC):



- Press button **1**.

▶ In this case, the button on the handlebar fitting is for operating the on-board computer or calling up the RDC readings.◀◀

Resetting tripmeter

- Switch on the ignition.
- Select the desired tripmeter.



- Press and hold down button **1**.



- If you prefer, you can use button **2** for this purpose.
- » The tripmeter is reset to zero.

with OE On-board computer or with OE Tyre-pressure monitoring (RDC):



- Press and hold down button **1**.

▶ In this case, the button on the handlebar fitting is for operating the on-board computer or calling up the RDC readings.◀◀

Residual range



Residual-range reading **1** appears accompanied by the word **RANGE** and indicates how far you can ride with the fuel remaining in the tank. This reading is not displayed until fuel level has dropped to reserve. This distance is calculated on the basis of fuel level and average consumption.

When you refuel, the increase in fuel level is not registered unless several litres are added to the fuel already in the tank.

When refuelling after running on reserve, make sure that you top

up the tank to a level above reserve, as otherwise the sensor will not be able to register the new level. If the sensor cannot register the new level neither the fuel-level reading nor the residual-range readout can be updated.

▶ The calculated range is an approximate value. Consequently, BMW Motorrad recommends that you should not try to use the full residual range before refuelling.◀

On-board computer Selecting readings^{OE}

- Switch on the ignition.



- Press button **1**.



The display starts with the current value and each time the button is pressed it moves one step through the following sequence:

- Ambient temperature

- Average speed
- Average consumption
- Range
- Oil level
- Tyre pressures (OE)

Ambient temperature^{OE}



When the motorcycle is at a standstill the heat of the engine can falsify ambient-temperature reading **1**. If the effect of the engine's heat becomes excessive, – temporarily appears on the display.



If ambient temperature drops below 3 °C a warning appears, drawing your attention to the risk of black ice forming. The display automatically switches from any other mode to the temperature reading when the temperature drops below this threshold for the first time.

Average speed^{OE}



Average speed **1** is calculated on the basis of the time elapsed since the last reset. Times during which the engine was stopped are excluded from the calculation.

Resetting average speed^{OE}

- Switch on the ignition.
- Select average speed.



- Press and hold down button **1**.
- » Average speed is reset to zero.

Average consumption^{OE}



Average consumption **1** is calculated by dividing the distance covered since the last reset by the corresponding amount of fuel used.

Resetting average consumption^{OE}

- Switch on the ignition.
- Select average consumption.



- Press and hold down button **1**.
- » Average consumption is reset to zero.

Range^{OE}



The description of the residual-range function (45) also covers the range readout. You can also view range **1** before the fuel level drops to reserve. A special average-consumption figure is used to calculate range; this figure is not necessarily the same as the value you can call up for viewing on the display.

When the motorcycle is propped on its side stand the slight angle of inclination means that the sensor cannot register the fuel level correctly. This is the reason why the range is calculated only

when the motorcycle is on the move.

When refuelling after running on reserve, make sure that you top up the tank to a level above reserve, as otherwise the sensor will not be able to register the new level. If the sensor cannot register the new level neither the fuel-level reading nor the range readout can be updated.

▶ The calculated range is only an approximate reading. Consequently, BMW Motorrad recommends that you should not try to use the full range before refuelling.◀

Oil level^{OE}



Oil-level indicator **1** gives you an indication of the engine oil level. You can call up this reading only when the motorcycle is at a standstill.

The preconditions for the oil level check are as follows:

- Engine at operating temperature.
- Engine idling for at least 10 seconds.
- Side stand retracted.
- Make sure the motorcycle is upright.

The readings mean:

OK: Oil level is correct.

CHECK: Check the oil level the next time you stop for fuel.

- - -: Oil level cannot be measured (conditions as stated above not satisfied).



If you call up another reading on the on-board computer, this symbol remains visible until the sensor again registers a correct oil level.

The most recently measured level is displayed for 5 seconds when you next switch on the ignition.



The oil sensor might be defective if the "Check oil level" message reappears even though the oil level in the oil sight glass is correct. In this case, consult your authorised BMW Motorrad dealer.◀

Tyre pressure monitoring RDC^{OE}

Viewing tyre-pressure readings

- Switch on the ignition.



- Repeatedly press button **1** until the tyre pressures appear on the display.



The tyre pressures are shown, accompanied by the wording **RDC P**. The front tyre pressure is on the left; the reading on the right is the rear tyre pressure.

- - - appears directly after the ignition is switched on, because the sensors do not transmit tyre pressures until the motorcycle accelerates to 30 km/h.

The tyre-pressure readings alternate with the clock. If the motorcycle has an on-board computer the readings alternate with the clock and the values of the on-board computer.

Lights

Side light

The side lights switch on automatically when the ignition is switched on.

▶ The side lights place a strain on the battery. Do not switch the ignition on for longer than absolutely necessary. ◀

Low-beam headlight

The low-beam headlight switches on automatically when you start the engine.

▶ When the engine is not running you can switch on the lights by switching on the ignition and either switching on the high-beam headlight or operating the headlight flasher. ◀

High-beam headlight



- Press the top section of full-beam headlight switch **1**.
 - » High-beam headlight switched on.
- Move full-beam headlight switch **1** to the centre position.
 - » High-beam headlight switched off.
- Press the bottom section of full-beam headlight switch **1**.
 - » The high-beam headlight is switched on until you release the button (headlight flasher).

Switching on parking lights

- Switch off the ignition.



- Immediately after switching off the ignition, press and hold down button **1** for the left turn indicators.
 - » Parking light switches on.

Switching off parking lights

- Switch the ignition on and then off again.
 - » Parking lights switched off.

Turn indicators

Switching on left flashing turn indicators

- Switch on the ignition.

▶ The turn indicators are cancelled automatically after you have ridden for approximately 10 seconds, or covered a distance of about 200 m.◀



- Press button **1** for the left-hand turn indicators.
 - » Left-hand turn indicators switched on.
 - » Telltale light for left-hand turn indicators flashes.

Switching on right flashing turn indicators

- Switch on the ignition.

▶ The turn indicators are cancelled automatically after you have ridden for approximately 10 seconds, or covered a distance of about 200 m.◀



- Press button **2** for the right-hand turn indicators.
 - » Right-hand turn indicators switched on.
 - » Telltale light for right-hand turn indicators flashes.

Cancelling turn indicators



- Press cancel button **3**.
 - » Flashing turn indicators switched off.
 - » Turn indicator telltale lights are off.

Hazard warning flashers


Switching on hazard warning flashers

- Switch on the ignition.

▶ The hazard warning flashers place a strain on the battery. Do not use the hazard

warning flashers for longer than absolutely necessary.◀

▶ If you press a turn-indicator button with the ignition switched on, the turn-indicator function is activated instead of the hazard warning flashers, and remains active until you release the button. The hazard warning flashers recommence flashing as soon as the button is released.◀



- Simultaneously press button **1** for left turn indicators and button **2** for right turn indicators.


- » The hazard warning flashers are switched on.
- » Left and right turn indicator telltale lights flash.
- Switch off the ignition.
- » The hazard warning flashers continue to operate.
- » Left and right turn indicator telltale lights are off.

Switching off hazard warning flashers



- Press cancel button **3**.
- » Hazard warning flashers switched off.


Emergency off switch (kill switch)



- 1** Emergency off switch (kill switch)

 Operating the kill switch when riding can cause the rear wheel to lock and thus cause a fall.
Do not operate the kill switch when riding.◀


The emergency off switch is a kill switch for switching off the engine quickly and easily.



- A** Normal operating position (run)
- B** Engine switched off.

▶ You cannot start the engine unless the kill switch is in the run position.◀


Grip heating^{OE}



- 1** Grip-heating switch

The handlebar grips have two-stage heating. Grip heating can be activated only when the engine is running.

▶ The increase in power consumption caused by the grip heating can drain the battery if you are riding at low engine speeds. If the charge level is low, grip heating is switched off to ensure the battery's starting capability.◀



- 2** Heating off.
- 3** 50 % heat output (one dot visible)
- 4** 100 % heat output (three dots visible)

BMW Motorrad ABS^{OE}

Deactivatable ABS

Under certain circumstances, it can be best to dispense with ABS when you ride on loose surfaces or in practice sessions. Consequently, you have the option of temporarily deactivating this motorcycle's ABS function.

Note the detailed description of the ABS system, which starts on page (80).

Deactivating ABS function

- Switch on the ignition, or bring the motorcycle to a stop.

▶ You can deactivate the ABS function only when the motorcycle is at a standstill.◀



- Press and hold down ABS button **1**.

 ABS warning light starts to show.

- When the ABS warning light comes on, release the ABS button within 5 seconds.

 ABS warning light remains ON.

» The ABS function is deactivated.

Activating ABS function



- Press and hold down ABS button **1**.

 ABS warning light goes out; if self-diagnosis has not completed it starts flashing.

- When the ABS warning light goes out, release the ABS button within 5 seconds.

 The ABS warning light remains off or continues to flash.

» The ABS function is activated.

- Instead of pressing the ABS button, you have the option of switching the ignition off and then on again.

▶ If you switch the ignition off then on again and the ABS light comes back on, there is a fault in the ABS.◀

Clutch

Adjusting clutch lever

 If the position of the clutch fluid reservoir is changed, air can enter the clutch system. Do not twist the handlebar fitting or the handlebars.◀

 Attempting to adjust the clutch lever while riding the motorcycle can lead to accidents. Do not attempt to adjust the clutch lever unless the motorcycle is at a standstill.◀



- Turn adjusting screw **1** clockwise.

 The adjusting screw is indexed and is easier to turn if you push the clutch lever forward.◀

- » Span between handlebar grip and clutch lever increases.

- Turn adjusting screw **1** counter-clockwise.
- » Span between handlebar grip and clutch lever decreases.


Brakes

Adjusting handbrake lever

 Changing the position of the brake-fluid reservoir can allow air to penetrate the brake system.

Do not twist the handlebar fitting or the handlebars.◀

 Attempting to adjust the brake lever while riding the motorcycle can lead to accidents. Do not attempt to adjust the brake lever unless the motorcycle is at a standstill.◀




- Turn adjusting screw **1** clockwise.

 The adjusting screw is indexed and is easier to turn if you push the handbrake lever forward.◀

- » Span between handlebar grip and handbrake lever increases.
- Turn adjusting screw **1** counter-clockwise.
- » Span between handlebar grip and handbrake lever decreases.

Mirrors

Adjusting mirrors



- Pivot the mirror to the correct position by pressing gently at the edge.

Suspension settings

Spring preload

The spring preload of the front suspension can be adjusted to the rider's weight to suit the terrain and the intended use.

It is essential to set spring preload of the rear suspension to suit the load carried by the mo-

torcycle. Increase spring preload when the motorcycle is heavily loaded and reduce spring preload accordingly when the motorcycle is lightly loaded.

Damping

Damping must be adapted to suit spring preload and the surface on which the motorcycle is ridden. An increase in spring preload requires firmer damping, a reduction in spring preload requires softer damping.

Settings, standard suspension

Adjusting spring preload for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



 Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit spring preload.◀

- If you want to increase spring preload, use the tool from the on-board toolkit to turn adjusting ring **1** clockwise.
- If you want to reduce spring preload, use the tool from the on-board toolkit to turn adjusting ring **1** counter-clockwise.



Basic setting of spring preload, rear

- Turn adjusting ring to stage 2. (Motorcycle with full load of fuel, with rider 85 kg)

Adjusting damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



board toolkit to turn adjusting screw **1**.



- If you want a harder damping characteristic, turn adjusting screw **1** in the direction indicated by the H arrow.
- If you want a softer damping characteristic, turn adjusting screw **1** in the direction indicated by the S arrow.




Rear suspension damping, basic setting

- Turn adjusting screw clockwise to limit stop (H), then back it off 3/4 of a turn. (Motorcycle with full load of fuel, with rider 85 kg)

Settings, sport suspension^{OE}


Adjusting spring preload for front wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



! Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit spring preload.◀

- Use adjusting rings **1** and **2** to adjust spring preload.



- Use the tool from the on-board toolkit to release the lock by turning adjusting ring **1** counter-clockwise.
- If you want to increase spring preload, turn adjusting ring **2** clockwise.
- If you want to reduce spring preload, turn adjusting ring **2** counter-clockwise.



Spring preload, basic setting

with OE Sport suspension:


– 184 mm (Spring length (no load on front wheel))◀

- Lock by turning adjusting ring **1** clockwise with the tool from the toolkit until it is locked against adjusting ring **2**.

Adjusting front spring preload at front wheel, motorcycles with activated charcoal filter


On account of the position of the activated charcoal filter, it is not possible to adjust spring preload from the front wheel with the ordinary spanner. This is the reason why this additional spanner is included in the toolkit.

The procedure for adjusting spring preload is as described above; the only difference is that access to the adjuster is from below.




As shown in this illustration, special wrench **1** has to be combined with 3/8" extension **2** and a suitable driver tool **3** (ratchet wrench, bar or similar).

Adjusting damping characteristic for front wheel



! Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit spring preload.◀

- Adjust damping by turning adjusting ring **1**.



- If you want to increase damping, turn adjusting ring **1** counter-clockwise.
- If you want to reduce damping, turn adjusting ring **1** clockwise.




Rebound stage basic setting

with OE Sport suspension:

- Turn bottom knob clockwise to limit stop, then back it off 16 clicks. (Motorcycle with full load of fuel, with rider 85 kg)◀


Adjusting spring preload for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.




! Your motorcycle's handling will suffer if you do not match the spring-preload and damping-characteristic settings. Adjust the damping characteristic to suit spring preload.◀


- Use adjusting rings **1** and **2** to adjust spring preload.



- Release the lock by turning adjusting ring **1** counter-clockwise with the tool from the toolkit, while holding adjusting ring **2** with second tool from the toolkit.



- To turn the adjusting rings, engage tool **1** from above in such a way that all three hooks **2** securely engage the grooves.



- If you want to increase spring preload, turn adjusting ring **2** clockwise.
- If you want to reduce spring preload, turn adjusting ring **2** counter-clockwise.



Basic setting of spring preload, rear

with OE Sport suspension:

- 85 kg (Motorcycle with full load of fuel, with rider)
- 158 mm (Spring length (no load on rear wheel))<

- Lock by turning adjusting ring **1** clockwise with the tool

from the toolkit, while holding adjusting ring **2** with second tool from the toolkit.

Adjusting rebound-stage damping for rear wheel

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Adjust rebound-stage damping by turning adjusting ring **1**.



- If you want to increase rebound-stage damping, turn adjusting ring **1** counter-clockwise.
- If you want to reduce rebound-stage damping, turn adjusting ring **1** clockwise.



Rebound stage basic setting

with OE Sport suspension:


- Turn bottom knob (on piston rod) clockwise to limit stop, then back it off 16 clicks. (Motorcycle with full load of fuel, with rider 85 kg)<

Adjusting compression-stage damping for rear wheel

- Make sure the ground is level and firm and place the motor-cycle on its stand.



- Adjust compression-stage damping by turning adjusting ring **1**.



- If you want to increase compression-stage damping, turn adjusting ring **1** in the H direction.
- If you want to reduce compression-stage damping, turn adjusting ring **1** in the S direction.



Compression stage basic setting

with OE Sport suspension:




Compression stage basic setting

- Turn top knob (on reservoir) clockwise to limit stop, then back it off 14 clicks. (Motor-cycle with full load of fuel, with rider 85 kg)◁

Adjusting spring-strut length

- Remove the rear wheel (101)



- Slacken screws **3** of the spray guard.

- Back off nut **2** by turning it clockwise.
- If you want to increase the length of the spring strut, turn nut **1** counter-clockwise.
- If you want to reduce the length of the spring strut, turn nut **1** clockwise.
- Once you have set the spring strut to the desired length, turn nut **2** counter-clockwise to lock the adjuster.



Spring-strut length

with OE Sport suspension:

- Turn the bottom spring retainer down as far as it will go. (Motorcycle with full load of fuel, with rider 85 kg)◀

- Align the spray guard as shown in the illustration.
- Tighten screws **3** of the spray guard.
- Install the rear wheel (➡ 102)

Tyres

Checking tyre pressure

- Make sure the ground is level and firm and place the motorcycle on its stand.



Incorrect tyre pressures impair the motorcycle's handling characteristics and increase the rate of tyre wear.

Always check that the tyre pressures are correct.◀



At high road speeds, tyre valves have a tendency to open as a result of centrifugal force.

Fit metal valve caps with rubber seals and screw them on firmly to prevent sudden deflation.◀

- Check tyre pressures against the data below.



Tyre pressure, front

- 2.2 bar (one-up, tyre cold)



Tyre pressure, front

- 2.5 bar (two-up and/or with luggage, tyre cold)



Tyre pressure, rear

- 2.5 bar (one-up, tyre cold)

- 2.9 bar (two-up and/or with luggage, tyre cold)

If tyre pressure is too low:

- Correct tyre pressure.

Headlight

Adjusting headlight for driving on left/driving on right

If the motorcycle is ridden in a country where the opposite rule of the road applies, its asymmetric low-beam headlight will tend to dazzle oncoming traffic.

Have the headlight set accordingly by a specialist workshop, preferably an authorised BMW Motorrad dealer.

 Commercially available adhesive tape will damage the plastic lens of the light.


Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, in order to avoid damaging the plastic lens of the light. ◀

Headlight beam throw and spring preload

Headlight beam throw is generally kept constant when spring preload is adjusted to suit load. Spring preload adjustment might not suffice only if the motorcycle is very heavily loaded. Under these circumstances, headlight beam throw has to be adjusted to suit the weight carried by the motorcycle.

 Consult a specialist workshop, preferably an authorised BMW Motorrad dealer, if you are unsure whether the headlight basic setting is correct. ◀


Adjusting headlight beam throw



- 1 Headlight beam-throw adjustment

Spring preload adjustment might not suffice if the motorcycle is very heavily loaded. Moving the pivot lever adjusts headlight

beam throw so as not to dazzle oncoming traffic.



- A Neutral position
B Position for heavy load

Front and rear seats Removing front seat


- Make sure the ground is level and firm and place the motorcycle on its stand.

Removing rear seat


- Remove the front seat (➡ 64)



- Pull and hold loop **1** and pull the rear seat forward to remove.



- Turn key **1** clockwise in the seat lock, while pressing down on the front part of the front seat.



- Raise the seat at the front and lift it off the motorcycle.


Installing rear seat



- Position the rear seat in mounts **1** and push it back.
» The rear seat engages with two audible clicks.
- Install the front seat (➡ 65)

Installing front seat

- Install the rear seat (➡ 65)




! If too much pressure is applied in the forward direction, there is a danger that the motorcycle will be pushed off its stand.

Always make sure that the motorcycle is stable and firmly supported.◀

- Position the front seat in mounts **1** and press it firmly down at the front.
- » The front seat engages with an audible click.


Securing helmet to motorcycle

- Remove the rear seat (➡ 65)



! The helmet catch can scratch the panelling. Make sure the lock is out of the way when you hook the helmet into position.◀

- Use wire rope **1** available as an optional accessory to secure the helmet to the helmet holder.



- Guide the wire rope underneath rear frame **3** and slip the eyes of the wire rope into helmet-holder slot **2**.
- Install the rear seat (➡ 65)

Luggage loops

- Remove the rear seat (➡ 65)
- Turn the rear seat upside down.



- Pull loops **1** out of the holders and to the outside and down.
- Install the rear seat (➡ 65)
 - » You can hook luggage straps into the loops.

Riding

Safety instructions	70
Checklist	71
Starting	72
Running in	74
Brakes	75
Parking your motorcycle	76
Refuelling	77

Safety instructions

Rider's equipment

Do not ride without the correct clothing. Always wear:

- Helmet
- Motorcycling jacket and trousers
- Gloves
- Boots

This applies even to short journeys, and to every season of the year. Your authorised BMW Motorrad dealer will be glad to advise you on the correct clothing for every purpose.

Speed

If you ride at high speed, always bear in mind that various boundary conditions can adversely affect the handling of your motorcycle:

- Settings of the spring-strut and shock-absorber system
- Imbalanced load
- Loose clothing
- Insufficient tyre pressure
- Poor tyre tread
- Etc.

Correct loading



Overloading and imbalanced loads can adversely affect the motorcycle's handling. Do not exceed the permissible gross weight and be sure to comply with the instructions on loading.◀

Alcohol and drugs



Even small amounts of alcohol or drugs will adversely affect your perception and your ability to assess situations and make decisions, and slow down your reflexes. Medication can exacerbate these effects.

Do not ride your motorcycle after consuming alcohol, drugs and/or medication.◀

Risk of poisoning

Exhaust fumes contain carbon monoxide, which is colourless and odourless but highly toxic.



Inhaling the exhaust fumes therefore represents a health hazard and can even cause loss of consciousness with fatal consequences.

Do not inhale exhaust fumes. Do not run the engine in an enclosed space.◀

High voltage



Touching live parts of the ignition system with the engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running.◀

Catalytic converter

If misfiring causes unburned fuel to enter the catalytic converter, there is a danger of overheating and damage.

For this reason, observe the following points:

- Do not run the fuel tank dry.
- Do not attempt to start or run the engine with a spark-plug cap disconnected.
- Stop the engine immediately if it misfires.
- Use only unleaded fuel.
- Comply with all specified maintenance intervals.



Unburned fuel will destroy the catalytic converter. Note the points listed for protection of the catalytic converter.◀

Risk of fire

Temperatures at the exhaust are high.



Flammable materials (e.g. hay, leaves, grass, clothing and luggage, etc.) could ignite if allowed to come into contact with the hot exhaust pipe.

Do not permit flammable materials to come into contact with the hot exhaust system.◀



Cooling would be inadequate if the engine were allowed to idle for a lengthy period with the motorcycle at a standstill: overheating would result. In extreme cases, the motorcycle could catch fire.

Do not allow the engine to idle unnecessarily. Ride away immediately after starting the engine.◀

Tampering with the engine control unit



Tampering with the engine control unit can damage the motorcycle and cause accidents.

Do not tamper with the engine control unit.◀



Tampering with the engine control unit can result in mechanical loads that the motorcycle's components are not designed to withstand. Damage caused in this way is not covered by the warranty.

Do not tamper with the engine control unit.◀

Checklist

Use the following checklist to check important functions, settings and wear limits before you ride off.

- Brakes
- Brake-fluid levels, front and rear
- Clutch
- Clutch fluid level
- Shock absorber setting and spring preload
- Tyre-tread depth and tyre pressures
- Cases correctly installed and luggage secured

At regular intervals:

- Engine oil level (every refuelling stop)
- Brake-pad wear (every third refuelling stop)

Starting

Side stand


You cannot start the motorcycle with the side stand extended and a gear engaged. The engine will switch itself off if you start it with the gearbox in neutral and then

engage a gear before retracting the side stand.

Gearbox

You can start the engine when the gearbox is in neutral or if you pull the clutch with a gear engaged. Do not pull the clutch until after you have switched on the ignition, as otherwise the engine will refuse to start.

Starting engine



- Kill switch in run position **A**.
- Switch on the ignition.

» Pre-ride check is performed.
(73)

with OE Anti-lock braking system (ABS):

- Switch on the ignition.
- » Pre-ride check is performed.
(73)
- » ABS self-diagnosis is performed. (73)◁



- Press starter button **1**.

▶ If ambient temperatures are very low, you might find it necessary to open the throttle slightly when starting the engine. At ambient temperatures below

0 °C, disengage the clutch after switching on the ignition.◀

▶ The start attempt is automatically interrupted if battery voltage is too low. Recharge the battery before you start the engine, or use jump leads and a donor battery to start.◀

- » The engine starts.
- » Consult the troubleshooting chart below if the engine refuses to start. (➡ 122)

Pre-ride check

The instrument cluster runs a test of the 'General' warning light when the ignition is switched on: this is the "Pre-Ride-Check" The 'General' warning light shows first red and then yellow, so that you can check that it is in working order. The test is aborted if you start the engine before it completes.

Phase 1



General warning light shows red.

- **CHECK!** appears on the display.

Phase 2



General warning light shows yellow.

- **CHECK!** appears on the display.

If the 'General' warning light does not show:



Some malfunctions cannot be indicated if the 'General' warning light cannot be displayed.

Check that the 'General' warning light comes on, and that it shows red and yellow.◀

- Have the fault rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

ABS self-diagnosis^{OE}

BMW Motorrad ABS performs self-diagnosis to ensure its operability. Self-diagnosis is performed automatically when you switch on the ignition. The motorcycle has to move forward at a speed above 5 km/h for the wheel sensors to be tested.

Phase 1

- » Test of the diagnosis-compatible system components with the motorcycle at a standstill.



ABS warning light flashes.



Possible national variant of the ABS warning light.

Phase 2

- » Test of the wheel sensors as the motorcycle pulls away from rest.



ABS warning light flashes.



Possible national variant of the ABS warning light.

ABS self-diagnosis completed

» The ABS warning light goes out.

If an indicator showing an ABS fault appears when ABS self-diagnosis completes:

- You can continue to ride. Bear in mind that the ABS function is not available.
- Have the fault rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Running in

The first 1000 km

- While running in the motor-cycle, vary the throttle opening and engine-speed range frequently.
- Try to do most of your riding during this initial period on twisting, fairly hilly roads, avoiding high-speed main roads and highways if possible.



Exceeding the specified engine speeds while running in will lead to increased engine wear.

Keep to the specified engine speeds for running in. ◀

- Do not exceed the rpm limits recommended for running in.



Running-in speed

– <4000 min⁻¹

- No full-load acceleration.

- Avoid low engine speeds at full load.
- Do not omit the first inspection after 500 - 1200 km.

Brake pads

New brake pads must "bed down" and therefore do not achieve their optimum friction levels during the first 500 km. You can compensate for this initial reduction in braking efficiency by exerting greater pressure on the levers.



New brake pads can extend stopping distance by a significant margin.

Apply the brakes in good time. ◀

Tyres

New tyres have a smooth surface. This must be roughened by riding in a restrained manner at various heel angles until the tyres are run in. This running in pro-

cedure is essential if the tyres are to achieve maximum grip.

 Tyres do not have their full grip when new and there is a risk of accidents at extreme angles of heel.

Avoid extreme angles of heel.◀

Brakes

How can stopping distance be minimised?

Each time the brakes are applied, a load distribution shift takes place with the load shifting forward from the rear to the front wheel. The sharper the motorcycle decelerates, the more load is shifted to the front wheel. The higher the wheel load, the more braking force can be transmitted without the wheel locking.

To optimise stopping distance, apply the front brakes rapidly and keep on increasing the force you apply to the brake lever. This

makes the best possible use of the dynamic increase in load at the front wheel. Remember to pull the clutch at the same time. In the "panic braking situations" that are trained so frequently braking force is applied as rapidly as possible and with the rider's full force exerted on the brake levers; under these circumstances the dynamic shift in load distribution cannot keep pace with the increase in deceleration and the tyres cannot transmit the full braking force to the surface of the road. ABS has to intervene to keep the front wheel from locking; this increases stopping distance.

Descending mountain passes

 There is a danger of the brakes fading if you use only the rear brakes when descending mountain passes. Under

extreme conditions, the brakes could overheat and suffer severe damage.

Use both front and rear brakes, and make use of the engine's braking effect as well.◀

Wet brakes

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes might not take effect immediately.

Apply the brakes in good time until the brakes have dried out.◀

Salt on brakes

 The brakes may fail to take effect immediately if the motorcycle was ridden on salt-covered roads and the brakes were not applied for some time. Apply the brakes in good time until the salt layer on the brake

discs and brake pads has been removed.◀

Oil or grease on brakes



Oil and grease on the brake discs and pads considerably diminish braking efficiency.

Especially after repair and maintenance work, make sure that the brake discs and brake pads are free of oil and grease.◀

Dirt or mud on brakes



When riding on loose surfaces or muddy roads, the brakes may fail to take effect immediately because of dirt or moisture on the discs or brake pads.

Apply the brakes in good time until the brakes have been cleaned.◀



The brake pads will wear more rapidly if you ride fre-

quently on unsurfaced tracks or poor roads.

Check the thickness of the brake pads more frequently and replace the brake pads in good time.◀

Parking your motorcycle

Placing motorcycle on side stand



If the ground is soft or uneven, there is no guarantee that the motorcycle will rest firmly on the stand.

Always check that the ground under the stand is level and firm.◀

- Switch off the engine.
- Pull the handbrake lever.
- Hold the motorcycle upright and balanced.
- Use your left foot to extend the side stand fully.



The side stand is designed to support only the weight of the motorcycle.

Do not lean or sit on the motorcycle with the side stand extended.◀

- Slowly lean the motorcycle to the side until its weight is taken by the stand and dismount to the left.



If the motorcycle is on the side stand, the surface of the ground will determine whether it is better to turn the handlebars to the left or right. However, the motorcycle is more stable on a level surface with the handlebars turned to the left than with the handlebars turned to the right.

On level ground, always turn the handlebars to the left to set the steering lock.◀

- Turn the handlebars to full left or right lock.

- Check that the motorcycle is standing firmly.

▶ On a gradient, the motorcycle should always face uphill; select 1st gear.◀

- Lock the steering lock.

Removing motorcycle from side stand

- Unlock the steering lock.
- From the left, grip the handlebars with both hands.
- Pull the handbrake lever.
- Swing your right leg over the seat and lift the motorcycle to the upright position.
- Hold the motorcycle upright and balanced.

⚠ An extended side stand can catch on the ground when the motorcycle is moving and lead to a fall.
Retract the side stand before moving the motorcycle.◀

- Sit on the motorcycle and use your left foot to retract the side stand.

Refuelling

⚠ Fuel is highly flammable. A naked flame close to the fuel tank can cause a fire or explosion.

Do not smoke. Never bring a naked flame near the fuel tank.◀

⚠ Fuel expands when hot. Fuel escaping from an overfilled tank could make its way onto the rear tyre. This could cause a fall.

Do not fill the tank past the bottom edge of the filler neck.◀


⚠ Fuel attacks plastics, which become dull or unsightly. Wipe off plastic parts immediately if they come into contact with fuel.◀

⚠ Fuel can attack the material of the windscreen and the side slipstream deflectors, which become dull or unsightly.

Wipe off the windscreen and slipstream deflectors immediately if they come into contact with fuel.◀


⚠ Leaded fuel will destroy the catalytic converter. Use only unleaded fuel.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Open the protective cap.

- Open the fuel tank cap with the ignition key by turning it counter-clockwise.



- Refuel with fuel of the grade stated below; do not fill the tank past the bottom edge of the filler neck.



Recommended fuel grade

– 98 ROZ/RON (Premium plus unleaded)



Recommended fuel grade

– 95 ROZ/RON (Premium unleaded (fuel grade, usable with power- and consumption-related restrictions))



Usable fuel capacity

– 17 l



Reserve fuel

– ≥ 4 l

- Press the fuel tank cap down firmly to close.
- Remove the key and close the protective cap.

Engineering details

Brake system with BMW Motorrad ABS ^{OE}	80
Tyre pressure monitoring RDC ^{OE}	82

Brake system with BMW Motorrad ABS^{OE}

How does ABS work?

The amount of braking force that can be transferred to the road depends on factors that include the coefficient of friction of the road surface. Loose stones, ice and snow or a wet road all have much lower coefficients of friction than a clean, dry asphalt surface. The lower the coefficient of friction, the longer the braking distance.

If the rider increases braking pressure to the extent that braking force exceeds the maximum transferrable limit, the wheels start to lock and the motorcycle loses its directional stability; a fall is imminent. Before this situation can occur, ABS intervenes and adapts braking pressure to the maximum transferrable braking force, so the wheels continue

to turn and directional stability is maintained irrespective of the condition of the road surface.

What are the effects of surface irregularities?

Humps and surface irregularities can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to the road can drop to zero. If the brakes are applied under these circumstances the ABS has to reduce braking force to ensure that directional stability is maintained when the wheels regain contact with the road surface. At this instant the BMW Motorrad ABS must assume an extremely low coefficient of friction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability. As soon as

it registers the actual circumstances, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

Rear wheel lift

Even under severe braking, a high level of tyre grip can mean that the front wheel does not lock up until very late, if at all. Consequently, ABS does not intervene until very late, if at all. Under these circumstances the rear wheel can lift off the ground, and the outcome can be a high-siding situation in which the motorcycle can flip over.



Severe braking can cause the rear wheel to lift off the ground.

When you brake, bear in mind that ABS control cannot be relied on in all circumstances to prevent the rear wheel from lifting clear of the ground.◀

What is the design baseline for BMW Motorrad ABS?

Within the limits imposed by physics, BMW Motorrad ABS ensures directional stability on any surface. The system is not optimised for special requirements that apply under extreme competitive situations off-road or on the track.

Special situations

The speeds of the front and rear wheels are compared as one means of detecting a wheel's incipient tendency to lock. If the system registers implausible values for a lengthy period the ABS function is deactivated for safety reasons and an ABS fault message is issued. Self-diagnosis has to complete before fault messages can be issued.

In addition to problems with the BMW Motorrad ABS, exceptional

riding conditions can lead to a fault message being issued.

Exceptional riding conditions:

- Riding for a lengthy period with the front wheel lifted off the ground (wheelie).
- Rear wheel rotating with the motorcycle held stationary by applying the front brake (burn-out).
- Heating up with the motorcycle on the centre stand or an auxiliary stand, engine idling or with a gear engaged.
- Rear wheel locked for a lengthy period, for example while descending off-road.

If a fault message is issued on account of exceptional riding conditions as outlined above, you can reactivate the ABS function by switching the ignition off and on again.

What significance devolves on regular maintenance?



Invariably, a technical system cannot perform beyond the abilities dictated by its level of maintenance.

In order to ensure that the BMW Motorrad ABS is always maintained in optimum condition, it is essential for you to comply strictly with the specified inspection intervals. ◀

Reserves for safety

The potentially shorter braking distances which BMW Motorrad ABS permits must not be used as an excuse for careless riding. ABS is primarily a means of ensuring a safety margin in genuine emergencies.

Take care when cornering. When you apply the brakes on a corner, the motorcycle's weight and

momentum take over and even BMW Motorrad ABS is unable to counteract their effects.

Tyre pressure monitoring RDC^{OE}

Function

A sensor integrated into each tyre measures the air temperature and the air pressure inside the tyre and transmits this information to the control unit. Each sensor has a centrifugal-force tripswitch that does not enable transmission of the measured values until the motorcycle has accelerated to about 30 km/h. The display shows - - for each tyre until the tyre-pressure signal is received for the first time. The sensors continue to transmit the measured-value signals for approximately 15 minutes after the motorcycle comes to a stop.

The control unit can administer four sensors, so two different sets of wheels with RDC sensors can be alternated on the motorcycle. An error message is issued if wheels without sensors are fitted to a motorcycle equipped with an RDC control unit.

Temperature compensation

The tyre-pressure readings shown by the multifunction display are temperature-compensated; the reference tyre temperature for these readings is always 20 °C. The air lines available to the public in petrol stations and motorway service areas almost invariably show temperature-dependent tyre pressures, so in most instances these gauge readings will not tally with the readings shown by the multifunction display.

Tyre-pressure ranges

The RDC control unit differentiates between three tyre-pressure ranges, all of which are parameterised for the motorcycle:

- Tyre pressure within permitted tolerance.
- Tyre pressure close to limit of permitted tolerance.
- Tyre pressure outside permitted tolerance.

A warning is also issued if tyre pressure drops sharply but stays within the permitted tolerance.

Accessories

General instructions.....	84
Power socket	84

General instructions

BMW Motorrad recommends the use of parts and accessories for your motorcycle that are approved by BMW for this purpose. Genuine BMW parts and accessories and other products which BMW has approved can be obtained from your authorised BMW Motorrad dealer, together with expert advice on their installation and use.

These parts and products have been tested by BMW for safety, function and suitability. BMW accepts product liability for them. Conversely, BMW is unable to accept any liability whatsoever for parts and accessories which it has not approved.



BMW Motorrad cannot assess each non-BMW product to determine whether it can be used on or in connection with BMW motorcycles

without constituting a safety hazard. Country-specific official authorisation does not suffice as assurance. Tests conducted by these instances cannot make provision for all operating conditions experienced by BMW motorcycles and, consequently, they are not sufficient in some circumstances.

Use only parts and accessories approved by BMW for your motorcycle. ◀

Whenever you are planning modifications, comply with all the legal requirements. Make sure that the motorcycle does not infringe national road-vehicle construction and use regulations.

Power socket Ratings



The supply to socket **1** is cut off automatically if battery voltage is low or the load exceeds the maximum rating.

Operating electrical accessories

You can start using electrical accessories only when the ignition is switched on. The accessory remains operational if the ignition is subsequently switched off. In order to ensure that the drain on the on-board power supply sys-

tem is minimised, the supply to the power socket is cut off approximately 15 minutes after the ignition is switched off, and it is also temporarily interrupted during the start procedure.

Cable routing

The cables from the power socket to the auxiliary device must be routed in such a way that they:

- do not impede the rider
- do not restrict or obstruct the steering angle and handling characteristics
- cannot be trapped



Incorrectly routed cables can impede the rider.

Route the cables as described above.◀

Maintenance

General instructions.....	88
Toolkit	88
Engine oil	89
Brake system, general	91
Brake pads	92
Brake fluid	94
Clutch	95
Tyres	96
Rims	97
Wheels	97
Front-wheel stand	102
Rear-wheel stand	103
Bulbs	104
Jump starting	111
Battery.....	112

General instructions

The Maintenance chapter describes straightforward procedures for checking and replacing certain wear parts.


Special tightening torques are listed as applicable. The tightening torques for the threaded fasteners on your motorcycle are listed in the section entitled "Technical data".

You will find information on more extensive maintenance and repair work in the Repair Manual on DVD/CD-ROM (RepROM) for your motorcycle, which is available from your authorised BMW Motorrad dealer.

Some of the work calls for special tools and a thorough knowledge of motorcycles. If you are in doubt consult a specialist workshop, preferably your authorised BMW Motorrad dealer.

Toolkit

Standard on-board toolkit



1 Extension

- For use with hook wrench

2 Hook wrench

- Adjusting rear spring preload
- Not applicable to motorcycles with sports suspension


3 Tool for oil cap

- Removing and installing plug of oil filler neck

4 Screwdriver with reversible blade

- with cross-head/plain blades
- Replacing turn indicator bulbs

Additional toolkit for sport suspension (OE)



1 Hook wrench

- Adjusting rear spring preload

2 Hook wrench

- Adjusting front spring preload, motorcycles without activated charcoal filter
- Adjusting rear spring preload, holding adjusting ring

3 Hook wrench


- Adjusting front spring preload, motorcycles with activated charcoal filter
- For use with 3/8" driver tool not included in the on-board toolkit

4 Open ring wrench

- Adjust the spring-strut length

On-board toolkit service kit

Your authorised BMW Motorrad dealer can provide the on-board toolkit service kit that you will need if you are considering undertaking more extensive work. You will find information on undertaking work of this nature in the Repair Manual on the DVD/CD-ROM also obtainable from your authorised BMW Motorrad dealer.



1 Extending tool holder

- Adapters to accommodate all tools
- Removing and installing spark plugs

2 1/4" bits

- 5x Torx, for example for removing and installing rear wheel
- 2x cross-head bits
- 1x plain screwdriver bit

3 3/8" adapter for socket-head screws, w/f 22

- Removing and installing front axle

4 Electric torch

- LED bulb

5 Socket

- 3x open-ended spanner, for example for connecting and disconnecting leads to battery terminals

6 Adapter

- Adapter for 1/4" bits
- 9x12 mm and 3/8" swivel adapters

Engine oil

Checking engine oil level



The engine can seize if the oil level is low, and this can lead to accidents.

Always make sure that the oil level is correct. ◀




The oil level varies with the temperature of the oil. The higher the temperature, the higher the level of oil in the sump.

Checking the oil level with the engine cold or after no more than a short ride will lead to misinterpretation; this in turn, means that the engine will be operated with the incorrect quantity of oil.


In order to ensure that the engine oil level is read correctly, check the oil level only after a lengthy trip.◀

- Check that the engine is at operating temperature, make sure that the ground is level and firm and place the motorcycle on its stand.
- Wait five minutes after switching off the engine at operating temperature.
- Hold the motorcycle upright.



- Check the oil level in oil-level indicator **1**.

▶ The insufficient oil pressure warning does not fulfil the function of an oil gauge. The only way of checking whether the oil level is correct is to check the oil sight glass.◀



Engine oil level

– Between MIN and MAX marks

– max 0.5 l (Difference between MIN and MAX)

If the oil level is below the MIN mark:

- Top up the engine oil.

If the oil level is above the MAX mark:

- Have the oil level corrected by a specialist workshop, prefer-

ably an authorised BMW Motorrad dealer.

Topping up engine oil

- Check the engine oil level (→ 89)



 Damage to the engine can result if it is operated without enough oil, but the same also applies if the oil level is too high.

Always make sure that the oil level is correct.◀

- Wipe the area around the filler neck clean.

- Use the tool from the toolkit to remove plug from oil filler neck **1**.
- Top up the engine oil to the specified level.
- Use the tool from the toolkit to install the plug in the engine-oil filler neck.

Brake system, general Dependability of the brake system

A fully functional brake system is a basic requirement for the road safety of your motorcycle.

Do not ride the motorcycle if you have any doubts about the dependability of the brake system. Under these circumstances have the brake system checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.



Incorrect working practices endanger the reliability of the brakes.

Have all work on the brake system performed by a specialist workshop, preferably an authorised BMW Motorrad dealer.◀

Checking operation of brakes

- Pull the handbrake lever.
 - » The pressure point must be clearly perceptible.
- Press the footbrake lever.
 - » The pressure point must be clearly perceptible.

If pressure points are not clearly perceptible:

- Have the brakes checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Brake pads

Checking front brake pad thickness




Brake pads worn past the minimum permissible brake-pad thickness can cause a reduction in braking efficiency and under certain circumstances they can cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible brake-pad thickness.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the left and right brake pads to ascertain their thickness. Viewing direction: Between wheel and fork tube toward the brake caliper.



Brake disc thickness, front

- min 1 mm (Friction pad only, without backing plate)
- The wear indicators (grooves) must be clearly visible.

If the wear indicating marks are no longer clearly visible:

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking rear brake pad thickness



Brake pads worn past the minimum permissible brake-pad thickness can cause a reduction in braking efficiency and under certain circumstances they can cause damage to the brake system.

In order to ensure the dependability of the brake system, do not permit the brake pads to wear past the minimum permissible brake-pad thickness.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.



- Visually inspect the brake pads of the rear brake caliper from the left to ascertain their thickness.



Brake-pad wear limit, rear


- 1 mm (Friction pad only, without backing plate)
- Make sure that the brake disc is not visible through the bore in the inboard brake block.

If the brake disc is visible:

- Have the brake pads replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Brake-pad wear

The rear brake has a mechanical brake-pad wear indicator.



Shaft **1** with three marker rings **2** is between the brake pads.

How to interpret the marks:

- Three rings visible: brake-pad thickness is at least 75 %

- Two rings visible: brake-pad thickness is at least 50 %
- One ring visible: brake-pad thickness is at least 25 %
- No rings visible: brake pads worn to wear limit; check as described above

Brake fluid

Checking brake-fluid level, front brakes



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals. ◀

- Make sure the ground is level and firm and hold the motor-cycle upright.
- Move the handlebars to the straight-ahead position.



- Check the brake fluid level in front reservoir **1**.

▶ Wear of the brake pads causes the brake fluid level in the reservoir to sink. ◀



Brake fluid level, front

- Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably an authorised BMW Motorrad dealer.


Checking brake-fluid level, rear brakes



A low fluid level in the brake reservoir can allow air to penetrate the brake system. This significantly reduces braking efficiency.

Check the brake-fluid level at regular intervals.◀


- Make sure the ground is level and firm and hold the motor-cycle upright.



- Check the brake fluid level in rear reservoir **1**.



Wear of the brake pads causes the brake fluid level in the reservoir to sink.◀



Brake fluid level, rear

- Do not permit the brake fluid level to drop below the MIN mark. (Brake-fluid reservoir horizontal)

If the brake fluid level drops below the permitted level:

- Have the defect rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

Clutch

Checking clutch operation

- Pull the clutch lever.
 - » The pressure point must be clearly perceptible.
- If the pressure point is not clearly perceptible:
- Have the clutch checked by a specialist workshop, preferably an authorised BMW Motorrad dealer.

Checking clutch fluid level

- Make sure the ground is level and firm and hold the motor-cycle upright.
- Move the handlebars to the straight-ahead position.



- Check the clutch fluid level in reservoir **1**.

▶ Wear of the clutch causes the fluid level in the clutch fluid reservoir to rise.◀

▶ The clutch system is filled with a special hydraulic fluid that does not have to be changed.◀



Clutch fluid level

– Do not permit the clutch fluid level to drop.

If the fluid level drops:



Unsuitable hydraulic fluids could cause damage to the clutch system.

Do not attempt to top up the system with fluids of any kind.◀

- Have the defect rectified as quickly as possible by a specialist workshop, preferably

an authorised BMW Motorrad dealer.

Tyres

Measuring tread depth of tyres



Your motorcycle's handling and grip can be impaired even before the tyres wear to the minimum tyre tread depth permitted by law.

Have the tyres changed in good time before they wear to the minimum permissible tread depth.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Measure the tyre tread depth in the main tread grooves with wear marks.



Tyres have wear indicators integrated into the main tread grooves. The tyre is worn out when the tyre tread has worn

down to the level of the marks. The locations of the marks are indicated on the edge of the tyre, e.g. by the letters TI, TWI or by an arrow. ◀

If the tyre tread no longer complies with the minimum legally required tread depth:

- Replace tyre.

Rims

Visual inspection

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Visually inspect the rims for defects.
- Have damaged rims checked and, if necessary, replaced by a specialist workshop, preferably an authorised BMW Motorrad dealer.


Wheels

Recommended tyres

For each size of tyre BMW Motorrad tests and classifies as roadworthy certain makes. BMW Motorrad cannot assess the suitability or provide any guarantee of road safety for other tyres. BMW Motorrad recommends using only tyres tested by BMW Motorrad.

You can obtain detailed information from your authorised BMW Motorrad dealer or on the Internet at www.bmw-motorrad.com.

RDC label^{OE}




 Incorrect tyre-removal procedures can result in damage to the RDC sensors. Be sure to notify the authorised BMW Motorrad dealer or specialist workshop that the wheel is fitted with an RDC sensor. ◀

If the motorcycle is equipped with RDC, each wheel rim bears an adhesive label indicating the position of the RDC sensor. When changing the tyre, take care not to damage the RDC sensor. Be sure to draw the attention of the authorised BMW

Motorrad dealer or specialist workshop to the fact that the wheel is fitted with an RDC sensor.


Remove the front wheel

- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.
- Install the rear-wheel stand (104)



- Remove screws **1** on left and right.


- Lift the mudguard up and forward, pulling the two sides slightly apart.



 Once the calipers have been removed, there is a risk of the brake pads being pressed together to the extent that they cannot be slipped back over the brake disc on reassembly.

Do not operate the handbrake lever when the brake calipers have been removed.◀

- Remove securing screws **2** of the left and right brake calipers.




- Force the brake pads slightly apart by rocking brake calipers **3** back and forth **A** against brake discs **4**.
- Mask off the parts of the wheel rim that could be scratched in the process of removing the brake calipers.
- Carefully pull the brake calipers back and out until clear of the brake discs.

with OE Anti-lock braking system (ABS):

- When removing the left brake caliper, take care not to damage the ABS sensor cable.◀


- Raise front of motorcycle until the front wheel can turn freely. BMW Motorrad recommends the BMW Motorrad front-wheel stand for lifting the motorcycle.
- Install the front-wheel stand (→ 102)



- Release axle clamping screw 5.
- Remove quick-release axle 6, while supporting the wheel.
- Roll the front wheel forward to remove.

with OE Anti-lock braking system (ABS):

- Do not damage the ABS sensor on the left-hand side when rolling out the wheel.◀



- Remove spacing bushing 7 from the left-hand side of the wheel hub.

Installing front wheel

! Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked by a specialist

workshop, preferably an authorised BMW Motorrad dealer.◀

! There is a risk of damaging parts of the front brake, particularly the BMW Motorrad ABS, in the course of the procedure described below.

Take care not to damage the brake system, in particular the ABS sensor with cable and the ABS sensor ring.◀


! The front wheel must be installed right way round to rotate in the correct direction. Note the direction-of-rotation arrows on the tyre or the wheel rim.◀



- Slip spacing bushing **7** into the left-hand side of the wheel hub.
- Roll the front wheel into position between the front forks.

with OE Anti-lock braking system (ABS):

- Do not damage the ABS sensor on the left-hand side when rolling in the wheel.◀



- Raise the front wheel, insert quick-release axle **6** and tighten to specified torque.



Quick-release axle in axle holder

– 50 Nm

- Tighten axle clamping screw **5** to the specified torque.




Clamp screw of quick-release axle

– 19 Nm

- Remove the front-wheel stand.
- Slip the brake calipers onto the brake discs.


with OE Anti-lock braking system (ABS):



The cable of the ABS sensor could chafe through if it comes into contact with the brake disc.

Make sure that the ABS sensor cable is routed snugly along the front suspension.◀

- Route ABS sensor cable **4** as illustrated here.◀




- Install securing screws **2** and tighten to specified torque.



Brake caliper to slider tube

– 30 Nm

- Remove the adhesive tape from the wheel rim.



- Seat the mudguard in holder **1**.
- Install the screws on left and right.
- Operate the brake several times until the brake pads are bedded.
- Remove the rear wheel stand, if installed beforehand.

Removing rear wheel




Parts of the exhaust system can be hot.

Do not touch hot parts of the exhaust system.◀

- Place the motorcycle on an auxiliary stand; BMW Motorrad

recommends the BMW Motorrad rear-wheel stand.


- Install the rear-wheel stand (➡ 104)
- Engage first gear.



- Place a support underneath the rear wheel and remove 5 studs **1**.
- If applicable, remove lock washer **2** of the rear-wheel stand.
- Lower the rear wheel to the ground.
- Roll the rear wheel out toward the rear.

Installing rear wheel

- Check that the wheel adapter and wheel hub are free of grease.
- Place the rear wheel on the wheel adapter.



- If applicable, install lock washer **2** of the auxiliary stand.

 Threaded fasteners not tightened to the specified torque can work loose or their threads can suffer damage. Always have the security of the fasteners checked by a specialist

workshop, preferably an authorised BMW Motorrad dealer. ◀

- Tighten wheel studs **1** until hand-tight and then tighten to specified torque in diagonally opposite sequence.



Rear wheel to wheel carrier

– Tightening sequence: Tighten in diagonally opposite sequence

– 60 Nm

- Remove the auxiliary stand.

Front-wheel stand

Use

A front-wheel stand for simple, safe changing of the front wheel is available from BMW Motorrad. You can obtain the front-wheel stand from your authorised BMW Motorrad dealer.




The BMW Motorrad front wheel stand is not designed to support motorcycles not fitted with a centre stand or without other auxiliary stands. A motorcycle resting only on the front wheel stand and the rear wheel can topple.


Place the motorcycle on its centre stand or another auxiliary stand before lifting the front wheel with the BMW Motorrad front-wheel stand. ◀

Installing front-wheel stand

- Place the motorcycle on an auxiliary stand; BMW Motorrad recommends the BMW Motorrad rear-wheel stand.
- Install the rear-wheel stand ( 104)



- Slacken adjusting screws **1**.
- Push the two pins **2** apart until the front forks fit between them.
- Use locating pins **3** to set the front-wheel stand to the desired height.
- Centre the front-wheel stand relative to the front wheel and push it against the front axle.




- Push both mounting pins **2** through the triangles of the brake caliper anchorages just far enough to allow the front wheel to be rolled between them.

! There is a risk of damaging the ABS sensor ring of the BMW Motorrad ABS.

Push the pin in just far enough to ensure that it clears the sensor ring of the BMW Motorrad ABS.◀

- Tighten adjusting screws **1**.




- Apply uniform pressure to push the front-wheel stand down and raise the motorcycle.

Rear-wheel stand


Rear-wheel stand

BMW Motorrad offers a rear-wheel stand for holding motorcycles (including those without centre stands) securely upright for maintenance work. You can obtain the rear-wheel stand from your authorised BMW Motorrad dealer.

Installing rear-wheel stand



- Use screws **1** to set the rear-wheel stand to the desired height.
- Remove retaining disc **2**. To do so, press release button **3**.



- Push the rear-wheel stand from the right onto the rear axle.
- Push the retaining disc on from the left, while holding the unlock button down.
- Grip the rear grab handle of the motorcycle with your left hand and use your right to grip the lever of the rear-wheel stand **4**.



- Lift the motorcycle upright, simultaneously pressing the lever down until the stand supports the motorcycle in the upright position.
- Press the lever down to the ground.

Bulbs

General instructions

A warning appears in the multi-function display if a bulb is defective.



A defective bulb places your safety at risk because

it is easier for other users to oversee the motorcycle.
Replace defective bulbs as soon as possible; always carry a complete set of spare bulbs if possible.◀

 The bulb is pressurised and can cause injury if damaged.

Wear protective goggles and gloves when changing bulbs.◀

 The types of bulb fitted to your motorcycle are listed in the section entitled "Technical data".◀


 Do not touch the glass of new bulbs with your fingers. Use a clean, dry cloth to hold the bulbs when handling them. Dirt deposits, in particular oil and grease, interfere with heat radiation from the bulb. This leads to overheating and shortens the bulb's operating life.◀

Replacing high-beam/low-beam headlight bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below.


Always make sure that the motorcycle is stable and firmly supported.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.




- Remove cover **2** (low-beam headlight) or cover **3** (high-


beam headlight) by pulling lever **1**.



- Disconnect plug **4**.



- Disengage spring clips **5** from the fastenings and swing them aside.



- Remove bulb **6**.
- Replace the defective bulb.



Bulb for high-beam
headlight

– H7 / 12 V / 55 W




Bulb for low-beam head-
light


– H7 / 12 V / 55 W




- Insert the bulb; make sure that projection **7** is correctly positioned (high-beam headlight down / low-beam headlight up) and make check that the bulb engages correctly.



- Close and lock spring clips **5**.



- Connect plug **4**.



- Install cover **2** (low-beam headlight) or cover **3** (high-beam headlight).


Replacing parking-light bulb

 If it is not standing firmly, the motorcycle could topple in the course of the operations described below.


Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Switch off the ignition.
- ▶ Turn the handlebars to the left to facilitate access. ◀




- Remove cap **1**.



- Disconnect plug **2**.



- Turn bulb socket **3** counter-clockwise to remove.




- Remove bulb **4** from the bulb holder.
- Replace the defective bulb.



Bulb for parking light


– W5W / 12 V / 5 W




- Push bulb **4** into its socket.



- Turn bulb socket **3** clockwise to install.



- Connect plug **2**.



- Install cap **1**.


Replacing front turn indicator bulb



If it is not standing firmly, the motorcycle could topple in the course of the operations described below.

Always make sure that the motorcycle is stable and firmly supported. ◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Switch off the ignition.



- Remove screw **1**.



- Pull the bulb housing out of the mirror housing at the threaded-fastener side.



- Remove the bulb holder **2** from the bulb housing by turning it counter-clockwise.
- Remove bulb **3** from the bulb holder.
- Replace the defective bulb.




Bulbs for flashing turn indicators, front

– W16W / 12 V / 16 W



- Insert bulb **3** into the bulb socket.
- Turn bulb socket **2** clockwise to install it in the bulb housing.
- Seat the bulb housing in the mirror shell.



- Install screw **1**.

Replacing rear turn indicator bulb



If it is not standing firmly, the motorcycle could topple in the course of the operations described below.

Always make sure that the motorcycle is stable and firmly supported. ◀


- Make sure the ground is level and firm and place the motorcycle on its stand.



- Remove screw **1**.



- Pull the glass out of the reflector housing at the threaded-fastener side.




- Turn bulb **2** counter-clockwise and remove it from the bulb housing.
- Replace the defective bulb.



Bulbs for flashing turn indicators, rear

– R10W / 12 V / 10 W



- Turn bulb **2** clockwise to install it in the bulb housing.



- Working from the inboard side, insert the glass into the bulb housing and close the housing.



- Install screw **1**.

Jump starting

! The wires leading to the power socket do not have a load-capacity rating adequate for jump-starting the engine. Excessively high current can lead to a cable fire or damage to the vehicle electronics.

Do not use the on-board socket to jump-start the engine of the motorcycle.◀

! Touching live parts of the ignition system with the

engine running can cause electric shock.

Do not touch parts of the ignition system when the engine is running.◀

! A short-circuit can result if the crocodile clips of the jump leads are accidentally brought into contact with the motorcycle.


Use only jump leads fitted with fully insulated crocodile clips at both ends.◀

! Jump-starting with a donor-battery voltage higher than 12 V can damage the vehicle electronics.

Make sure that the battery of the donor vehicle has a voltage rating of 12 V.◀

- Make sure the ground is level and firm and place the motorcycle on its stand.
- Remove the front seat (➡ 64)

- When jump-starting the engine, do not disconnect the battery from the on-board electrical system.



- Remove the protective cap from the battery's positive terminal **1**.
- Run the engine of the donor vehicle during jump-starting.
- Begin by connecting one end of the red jump lead to the positive terminal of the discharged battery and the other end to the positive terminal of the donor battery.
- Then connect one end of the black jump lead to the negative terminal of the donor battery, and the other end to negative terminal **2** of the discharged battery.
- Start the engine of the vehicle with the discharged battery in the usual way; if the engine does not start, wait a few minutes before repeating the attempt in order to protect the starter motor and the donor battery.
- Allow both engines to idle for a few minutes before disconnecting the jump leads.
- Disconnect the jump lead from the negative terminals **2** first, then disconnect the second jump lead from the positive terminals **1**.
- Seat the protective cap on battery positive terminal **1**.

Do not use proprietary start-assist sprays or other products to start the engine.◀

- Install the front seat (➡ 65)

Battery

Maintenance instructions

Correct upkeep, recharging and storage will prolong the life of the battery and are essential if warranty claims are to be considered.

Compliance with the points below is important in order to maximise battery life:

- Keep the surface of the battery clean and dry
- Do not open the battery
- Do not top up with water
- Be sure to read and comply with the instructions for charging the battery on the following pages
- Do not turn the battery upside down

 If the battery is not disconnected, the on-board electronics (e.g. clock, etc.) gradually drain the battery. This can cause the battery to run flat. If this happens, warranty claims will not be accepted.

If the motorcycle is to be out of use for more than four weeks, disconnect the battery or connect a suitable trickle charger to the battery.◀

 BMW Motorrad has developed a float charger specially designed for compatibility with the electronics of your motorcycle. Using this charger, you can keep the battery charged during long periods of disuse, without having to disconnect the battery from the motorcycle's on-board systems. You can obtain additional information from your authorised BMW Motorrad dealer.◀

Charging battery when connected

 Charging the connected battery directly at the battery terminals can damage the vehicle electronics.

Always disconnect the battery from the on-board circuits before recharging it with a charger connected directly to the battery posts.◀

 Only chargers suitable for this mode of charging can be used to recharge the battery via the on-board socket. Unsuitable chargers could cause damage to the motorcycle's on-board electrics.

Use BMW chargers with the part numbers 71 60 7 688 864 (220 V) or, as applicable, 71 60 7 688 865 (110 V). If you are in doubt, disconnect the battery from the on-board

systems and connect the charger directly to the battery.◀

 If you switch on the ignition and the multifunction display and telltale lights fail to light up, the battery is completely flat. Attempting to charge a completely flat battery via the on-board socket can cause damage to the motorcycle's electronics. If a battery has discharged to the extent that it is completely flat, it has to be disconnected from the on-board circuits and charged with the charger connected directly to the battery posts.◀

- Charge via the power socket, with the battery connected to the motorcycle's on-board electrical system.
- Comply with the operating instructions of the charger.

 The motorcycle's on-board electronics know when the battery is fully charged. The

on-board socket is switched off when this happens.◀

Charging battery when disconnected


- Charge the battery using a suitable charger.
- Comply with the operating instructions of the charger.
- Once the battery is fully charged, disconnect the charger's terminal clips from the battery terminals.

▶ The battery has to be re-charged at regular intervals in the course of a lengthy period of disuse. See the instructions for caring for your battery. Always fully recharge the battery before restoring it to use◀

Removing battery

- Make sure the ground is level and firm and place the motorcycle on its stand.

- Switch off the ignition.
- Remove the front seat (▶ 64)



- Remove diagnosis plug **1** from its holder.

! Disconnection in the wrong sequence increases the risk of short-circuits.

Always proceed in the correct sequence.◀

- Disconnect negative lead **3** first.
- Then pull back protective cap **2** of the positive terminal


and disconnect the positive lead.




- Remove the screw and remove battery retainer **4**.
- Lift the battery up and out; work it slightly back and forth if it is difficult to remove.

Installing battery

- Switch off the ignition.
- Insert the battery into the battery compartment, with the positive terminal on the right in the direction of travel.



- Slip battery retainer **4** over the battery and install the screw.



 Installation in the wrong sequence increases the risk of short-circuits.

Always proceed in the correct sequence.

Never install the battery without the protective cap.◀

- Connect the positive lead to the positive terminal.



If the battery was disconnected from the motorcycle for a prolonged period of time it will be necessary to enter the current date in the instrument cluster, in order to ensure that the service-due indicator functions correctly.

If you want to have the date set consult a specialist workshop, preferably an authorised BMW Motorrad dealer.◀

- Install protective cap **2**.
- Connect negative lead **3** to the negative terminal.
- Seat diagnosis plug **1** in the holder.
- Install the front seat (➡ 65)
- Set the clock (➡ 42)

Care

Care products	118
Washing motorcycle	118
Cleaning easily damaged components.....	118
Paint care	119
Protective wax coating	120
Laying up motorcycle	120
Restoring motorcycle to use	120

Care products

BMW Motorrad recommends that you use the cleaning and care products you can obtain from your authorised BMW Motorrad dealer. The substances in BMW Care Products have been tested in laboratories and in practice; they provide optimised care and protection for the materials used in your vehicle.

 The use of unsuitable cleaning and care products can damage vehicle components. Do not use solvents such as cellulose thinners, cold cleaners, fuel or the like, and do not use cleaning products that contain alcohol.◀

Washing motorcycle

BMW Motorrad recommends that you use BMW insect remover to soften and wash off insects and stubborn dirt on

painted parts prior to washing the motorcycle.

To prevent stains, do not wash the motorcycle immediately after it has been exposed to strong sunlight and do not wash it in the sun.

Make sure that the motorcycle is washed frequently, especially during the winter months.

To remove road salt, clean the motorcycle with cold water immediately after every trip.

 After the motorcycle has been washed, ridden through water or ridden in the rain, the brake discs and pads might be wet and the brakes might not take effect immediately.

Apply the brakes in good time until the brakes have dried out.◀

 Warm water intensifies the effect of salt.

Use only cold water to wash off road salt.◀

 The high pressure of steam cleaners can damage seals, the hydraulic brake system, the electrical system, and the seat. Do not use a steam jet or high-pressure cleaning equipment.◀

Cleaning easily damaged components

Plastics

Clean plastic parts with water and BMW plastic care emulsion. This includes in particular:

- Windscreen and slipstream deflectors
- Headlight lens made of plastic
- Glass cover of the instrument cluster
- Black, unpainted parts

 If plastic parts are cleaned using unsuitable cleaning

agents, the surfaces can be damaged.

Do not use cleaning agents that contain alcohol, solvents or abrasives to clean plastic parts.

Even fly-remover pads or cleaning pads with hard surfaces can produce scratches.◀

▶ Soften stubborn dirt and insects by covering the affected areas with a wet cloth.◀

Windscreen

Clean off dirt and insects with a soft sponge and plenty of water.

⚠ Fuel and chemical solvents attack the material of the windscreen; the windscreen becomes opaque or dull.

Do not use cleaning agents.◀

Chrome

Use plenty of water and BMW shampoo to clean chrome, particularly if it has been exposed to road salt. Use chrome polish for additional treatment.

Radiator

Clean the radiator regularly to prevent overheating of the engine due to inadequate cooling. For example, use a garden hose with low water pressure.



Cooling fins can be bent easily.

Take care not to bend the fins when cleaning the radiator.◀

Rubber

Treat rubber components with water or BMW rubber-care products.



Using silicone sprays for the care of rubber seals can cause damage.

Do not use silicone sprays or other care products that contain silicon.◀

Paint care

Washing the motorcycle regularly will help counteract the long-term effects of substances that damage the paint, especially if your motorcycle is ridden in areas with high air pollution or natural sources of dirt, for example tree resin or pollen.

Remove particularly aggressive substances immediately, however, as otherwise the paint can be affected or become discoloured. Substances of this nature include spilt fuel, oil, grease, brake fluid and bird droppings. We recommend BMW vehicle polish or BMW paint cleaner for this purpose.

Marks on the paintwork are particularly easy to see after the motorcycle has been washed.

Remove stains of this kind immediately, using cleaning-grade benzene or petroleum spirit on a clean cloth or ball of cotton wool. BMW Motorrad recommends BMW tar remover for removing specks of tar. Remember to wax the parts treated in this way.

Protective wax coating

BMW Motorrad recommends applying only BMW car wax or products containing carnauba wax or synthetic wax.

It is time to rewax the paint-work when water "puddles" on the surface, instead of forming beads.

Laying up motorcycle

- Clean the motorcycle.
- Remove the battery.
- Spray the brake and clutch lever pivots, the side stand pivots and the centre stand pivots (if the motorcycle is fit-

ted with a centre stand) with a suitable lubricant.

- Coat bright metal and chrome-plated parts with an acid-free grease (e.g. Vaseline).
- Stand the motorcycle in a dry room in such a way that there is no load on either wheel.

▶ Before laying the vehicle up out of use, have the engine oil and the oil filter element changed by a specialist workshop, preferably an authorised BMW Motorrad dealer. Combine work for laying up/restoring to use with a BMW service or inspection.◀

Restoring motorcycle to use

- Remove the protective wax coating.
- Clean the motorcycle.
- Install a charged battery.

- Before starting: work through the checklist.

Technical data

Troubleshooting chart	122	Riding specifications	137
Threaded fasteners	123		
Engine	125		
Fuel.....	126		
Engine oil	126		
Clutch	127		
Transmission	128		
Rear-wheel drive.....	128		
Running gear	129		
Brakes	130		
Wheels and tyres	131		
Electrics	134		
Frame	135		
Dimensions	136		
Weights.....	136		

Troubleshooting chart

Engine does not start at all or is difficult to start.

Possible cause	Remedy
Kill switch activated	Kill switch in operating position
Side stand extended and gear engaged	Retract the side stand. (➡ 72)
Gear engaged and clutch not disengaged	Select neutral or pull clutch lever (➡ 72)
Clutch pulled when ignition was OFF	Switch on the ignition, then pull the clutch lever
No fuel in tank	Refuelling (➡ 77)
Battery not adequately charged	Charge the battery when connected (➡ 113)

Threaded fasteners

Front wheel	Value	Valid
Brake caliper to slider tube		
M8 x 32	30 Nm	
Clamp screw of quick-release axle		
M8 x 35	19 Nm	
Quick-release axle in axle holder		
M24 x 1.5	50 Nm	
Rear wheel	Value	Valid
Rear wheel to wheel carrier		
M10 x 40 x 1.25	Tighten in diagonally opposite sequence	
	60 Nm	
Locknut for spring basic setting at top spring retainer		
	5 Nm	with OE Sport suspension:

Rear wheel	Value	Valid
Locknut for length adjustment at bottom spring retainer		
	40 Nm	with OE Sport suspension:
Spray guard to spring strut		
	Hand-tight	with OE Sport suspension:

Engine

Engine design	Four-stroke opposed twin, air-cooled with oil-cooled exhaust ports, installed longitudinally, two overhead camshafts, electronic engine management
Displacement	1170 cm ³
Cylinder bore	101 mm
Piston stroke	73 mm
Compression ratio	12.5:1
Nominal output	90 kW, - at engine speed: 8250 min ⁻¹
Torque	112 Nm, - at engine speed: 6800 min ⁻¹
with OE Power reduction:	102 Nm, - at engine speed: 4800 min ⁻¹
Maximum engine speed	max 8800 min ⁻¹
Idle speed	1150±50 min ⁻¹

Fuel

Recommended fuel grade	98 ROZ/RON, Premium plus unleaded 95 ROZ/RON, Premium unleaded (fuel grade, usable with power- and consumption-related restrictions)
Usable fuel capacity	17 l
Reserve fuel	≥4 l

Engine oil

Engine oil, capacity	max 4 l, with filter change
Lubricant	Engine oil, 20W-50
Engine oil, quantity for topping up	max 0.5 l, Difference between MIN and MAX
Oil grades	Engine oils of API classification SF or better. Engine oils of ACEA classification A2 or better. BMW Motorrad recommends not using synthetic oils for the first 10,000 km. Please do not hesitate to contact your authorised BMW Motorrad dealer if you have any questions relating the choice of a suitable engine oil for your motorcycle.

Permissible viscosity classes

SAE 5 W- ≥ 30	-20...20 °C, Operation at low temperatures
SAE 10 W-40	-10...30 °C, Operation at moderate temperatures
SAE 15 W- ≥ 40	≥ 0 °C
SAE 20 W- ≥ 40	≥ 0 °C
SAE 5 W- ≥ 50	≥ -20 °C, High-grade and synthetic oils, operation in all temperature ranges
SAE 10 W- ≥ 50	≥ -20 °C, High-grade and synthetic oils, operation in all temperature ranges

Clutch

Clutch type	Single-plate dry clutch
-------------	-------------------------

Transmission

Gearbox type	Helical 6-speed gearbox with integral reaction damper, claw-action shift by sliding sleeves
Gearbox transmission ratios	1.824 (31:17 teeth), Primary transmission ratio 2.277 (41:18 teeth), 1st gear 1.583 (38:24 teeth), 2nd gear 1.259 (34:27 teeth), 3rd gear 1.033 (31:30 teeth), 4th gear 0.903 (28:31 teeth), 5th gear 0.805 (29:36 teeth), 6th gear

Rear-wheel drive

Type of final drive	Shaft drive with bevel gears
Type of rear suspension	BMW Paralever, consisting of rear wheel swinging arm with central spring strut, reaction link supported by final drive and frame.
Final drive gear ratio	2.62:1

Running gear

Type of front suspension	BMW Telelever, leading link pivot-mounted on engine and telescopic forks, central spring strut supported by pivot mounts in leading link and main frame
with OE Sport suspension:	BMW Telelever, leading link pivot-mounted on engine and telescopic forks, central sports spring strut supported by pivot mounts in leading link and main frame
Spring strut, front, type	Central spring strut with coil spring and twin-tube, gas-filled shock absorber
with OE Sport suspension:	Central spring strut with coil spring and twin-tube, gas-filled shock absorber, adjustable rebound damping and adjustable spring preload
Spring travel, front	110 mm, At wheel
Type of rear suspension	BMW Paralever, consisting of rear wheel swinging arm with central spring strut, reaction link supported by final drive and frame.

Type of rear suspension	Central spring strut with single-tube, gas-filled shock absorber, progressive compression-stage damping, steplessly adjustable rebound-stage damping and adjustable spring preload
with OE Sport suspension:	Central spring strut with single-tube, gas-filled shock absorber, external expansion tank, adjustable rebound-stage and progressive compression-stage damping, steplessly adjustable spring preload and length adjustment
Spring travel at rear wheel	120 mm, At wheel

Brakes

Type of front brake	Hydraulically operated twin disc brake with 4-piston fixed calipers and floating brake discs
Brake-pad material, front	Sintered metal
Type of rear brake	Hydraulically operated disc brake with 2-piston floating caliper and brake disc mounted on final drive
Brake-pad material, rear	Organic material

Wheels and tyres

Tyre combinations recommended at time of going to press (As at: 09.05.2007)	Front: Bridgestone BT014F Radial F, 120/70 ZR17 M/C (58W) Rear: Bridgestone BT014R Radial M, 180/55 ZR17 M/C (73W)
	Front: Bridgestone BT014F Radial F, 120/70 ZR17 M/C (58W) Rear: Bridgestone BT014R Radial F, 190/50 ZR17 M/C (73W)
	Front: Continental Conti Sport Attack, 120/55 ZR17 M/C (73W) Rear: Continental Conti Sport Attack C, 180/55 ZR17 M/C (73W)
	Front: Continental Conti Sport Attack, 120/55 ZR17 M/C (73W) Rear: Continental Conti Sport Attack C, 190/50 ZR17 M/C (73W)
	Front: Dunlop D208F RRT, 120/55 ZR17 M/C (73W) Rear: Dunlop D208 RR, 180/55 ZR17 M/C (73W)
	Front: Dunlop D208F RRT, 120/55 ZR17 M/C (73W) Rear: Dunlop D208 RR, 190/50 ZR17 M/C (73W)

	Front: Metzeler Sporttec M-1/C, 120/70 ZR17 M/C (58W) Rear: Metzeler Sporttec M-1 B, 180/55 ZR17 M/C (73W)
	Front: Metzeler Sporttec M-1/C, 120/70 ZR17 M/C (58W) Rear: Metzeler Sporttec M-1 B, 190/50 ZR17 M/C (73W)
	Front: Michelin Pilot Power B, 120/70 ZR17 M/C (58W) Rear: Michelin Pilot Power B, 180/55 ZR17 M/C (73W)
	Front: Michelin Pilot Power B, 120/70 ZR17 M/C (58W) Rear: Michelin Pilot Power B, 190/50 ZR17 M/C (73W)
	You can obtain an up-to-date list of approved tyres from your authorised BMW Motorrad dealer or on the Internet at "www.bmw-motorrad.com".

Front wheel

Front wheel, type	Cast aluminium wheel with 5 double spokes, MT H2
Front wheel rim size	3.50" x 17"
Tyre designation, front	120/70-17

Rear wheel

Rear wheel type	Cast aluminium wheel with 5 double spokes, MT H2
Rear wheel rim size	5.50" x 17"
with OE Wide tyres:	6.00" x 17"
Tyre designation, rear	180/55-17
with OE Wide tyres:	190/50-17

Tyre pressure

Tyre pressure, front	2.2 bar, one-up, tyre cold 2.5 bar, two-up and/or with luggage, tyre cold
Tyre pressure, rear	2.5 bar, one-up, tyre cold 2.9 bar, two-up and/or with luggage, tyre cold

Electrics

Electrical rating of on-board socket	max 5 A
Fuses	Electronic fuses protect the circuits. If an electronic fuse trips and de-energises a circuit, the circuit is active as soon as the ignition is switched on after the fault has been rectified.

Battery

Battery type	AGM (Absorbent Glass Mat) battery
Battery rated voltage	12 V
Battery rated capacity	14 Ah

Spark plugs

Spark plugs, manufacturer and designation	Bosch YR5LDE
	NGK DCPR 8 EKC
Electrode gap of spark plug	0.8±0.1 mm, When new max 1 mm, Wear limit
Secondary spark plugs, manufacturer and designation	Bosch YR5LDE
	NGK DCPR 8 EKC
Electrode gap of secondary spark plug	0.8±0.1 mm, When new max 1 mm, Wear limit

Lighting

Bulb for high-beam headlight	H7 / 12 V / 55 W
Bulb for low-beam headlight	H7 / 12 V / 55 W
Bulb for parking light	W5W / 12 V / 5 W
Bulbs for flashing turn indicators, front	W16W / 12 V / 16 W
Bulbs for flashing turn indicators, rear	R10W / 12 V / 10 W

Frame

Frame type	Tubular spaceframe with steel front and centre sections, aluminium rear section and load-bearing drive unit
Type plate location	Front panel carrier, inboard, right
VIN location	Front frame top centre

Dimensions

Length of motorcycle	2151 mm
Height of motorcycle	1177 mm, in DIN normal-load position; with mirrors
Width of motorcycle	870 mm, across mirrors
Front-seat height	830 mm, At unladen weight

Weights

Unladen weight	213 kg, DIN unladen weight, ready for road 90 % load of fuel, without optional extras
Permissible gross weight	410 kg
Maximum payload	197 kg

Riding specifications

Top speed	>200 km/h
-----------	-----------

Service

BMW Motorrad service	140
BMW Motorrad service quality	140
BMW Motorrad Service Card: on-the-spot breakdown assistance	140
BMW Motorrad service network ...	141
Maintenance work	141
Confirmation of maintenance work	142
Confirmation of service	147

BMW Motorrad service

Advanced technology requires specially adapted methods of maintenance and repair.



If maintenance and repair work is performed inexpertly, it could result in consequential damage and thus constitute a safety risk.

BMW Motorrad recommends you to have all the associated work on your motorcycle carried out by a specialist workshop, preferably an authorised BMW Motorrad dealer. ◀

Your authorised BMW Motorrad dealer can provide information on BMW services and the work undertaken as part of each service. Have all maintenance and repair work carried out confirmed in the "Service" chapter in this manual. Authorised BMW Motorrad dealers are supplied with the latest technical information and have

the necessary technical know-how. BMW Motorrad recommends that you contact your authorised BMW Motorrad dealer if you have questions regarding your motorcycle.

BMW Motorrad service quality

Along with its reputation for engineering quality and high reliability, BMW Motorrad is a byword for excellent quality of service.

To ensure that your BMW is always in optimum condition, BMW Motorrad recommends that you have the maintenance work required for your motorcycle carried out regularly, preferably by your authorised BMW Motorrad dealer. For generous treatment of claims submitted after the warranty period has expired, evidence of regular maintenance is essential.

Certain signs of wear, moreover, may otherwise not be noticed until it is too late to put them right at moderate cost. Your authorised BMW Motorrad dealer's mechanics know every detail of your motorcycle and can take remedial action if necessary before minor faults develop into serious problems. By having the necessary repairs done properly and in good time, you save time and money in the long run.

BMW Motorrad Service Card: on-the-spot breakdown assistance

In the event of a breakdown, the BMW Motorrad Service Card issued with each new BMW motorcycle enables you to access an extensive range of services such as breakdown assistance, motorcycle transportation etc. (details can differ from country to country). In the event of a break-

down, contact the Mobile Service organisation of BMW Motorrad. The specialists will provide the necessary advice and assistance. You will find important country-specific contact addresses and the after-sales service organisation phone numbers in the "Service Kontakt / Service Contact" brochures, along with information on Mobile Service and the dealership network.

BMW Motorrad service network

BMW Motorrad has an extensive after-sales service network in place to look after you and your motorcycle in more than 100 countries. In Germany alone, you have the best possible access to approximately 200 authorised BMW Motorrad dealers.

All information concerning the international dealership network can be found in the brochure

"Service Contact Europe" or "Service Contact Africa, America, Asia, Australia, Oceania".

Maintenance work

BMW Pre-delivery Check

Your authorised BMW motorcycle dealer conducts the BMW pre-delivery check before handing over the motorcycle to you.

BMW Running-in Check

The BMW running-in check has to be performed when the motorcycle has covered between 500 km and 1,200 km

BMW Service

The BMW Service is carried out once a year; the extent of servicing can vary, depending on the age of the motorcycle and the distance it has covered. Your authorised BMW Motorrad dealer confirms that the service work has been carried out and enters

the date when the next service will be due.

Riders who cover long distances in a year might have to bring in their motorcycles for service before the next scheduled date. It is to allow for these cases that a maximum odometer reading is entered as well in the confirmation of service. Servicing has to be brought forward if this odometer reading is reached before the next scheduled date for the service.

The service-due indicator in the multifunction display reminds you about one month or 1000 km in advance when the time for a service is approaching, on the basis of the programmed values.

Confirmation of maintenance work

BMW Pre-delivery Check

Completed

on _____

Stamp, signature

BMW Running-in Check

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service

at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

BMW Service

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature**BMW Service**

Completed

on _____

Odometer reading _____

Next service
at the latest

on _____

or, if logged beforehand,

Odometer reading _____

Stamp, signature

Confirmation of service

The table is intended as a record of maintenance, warranty and repair work, the installation of optional accessories and, if appropriate, special campaign (recall) work.

Item	Odometer reading	Date

[illegible]

A

Abbreviations and symbols, 6

ABS

Self-diagnosis, 73

Switching off, 54

Switching on, 54

Warning, 30

Accessories

General instructions, 84

Anti-theft alarm, 17

Warning, 35

B

Battery, 14

Charging battery when
connected, 113

Charging battery when
disconnected, 114

Installation, 114

Maintenance instructions, 112

Removal, 114

Warning for battery charge
current, 25

BMW Motorrad service, 140

BMW Motorrad Service

Card, 140

Brake fluid

Checking level, 13, 94

Brake pads

Running in, 74

Test, 92

Brakes

Adjusting handbrake lever, 55

Checking operation, 91

Technical data, 130

Bulbs

General instructions, 104

High-beam headlight, 18

Low-beam headlight, 18

Parking light, 18

Replacing front turn indicator
bulb, 108

Replacing high-beam headlight
bulb, 105

Replacing low-beam headlight
bulb, 105

Replacing parking-light
bulb, 107

Replacing rear turn indicator
bulb, 110

Technical data, 135

Warning for bulb failure, 25, 26

C

Care, 117

Checklist, 71

Cleaning, 117

Clock

Adjusting, 17, 42

Clutch

Adjusting clutch lever, 54

Checking level, 11, 95

Checking operation, 95

Technical data, 127

Confirmation of maintenance
work, 142

Currency, 7

D

Damping

- Adjusting compression-stage damping for rear wheel, 62
- Adjusting for front wheel, 59
- Adjusting for rear wheel, 11, 57
- Adjusting rebound-stage damping for rear wheel, 61
- Setting with sport suspension, 11, 13

E

Electrics

- Technical data, 134

Emergency off switch (kill switch), 16, 52

Engine

- Starting, 72
- Technical data, 125
- Warning for engine electronics, 24

Engine oil

- Checking level, 89
- Temperature gauge, 20
- Topping up, 11, 91
- Warning for engine oil level, 28

- Warning for engine oil pressure, 24
- Equipment, 7
- EWS, 41
- Warning, 24

F

Frame

- Technical data, 135
- Front-wheel stand, 102

Fuel

- Quantity reading, 21
 - Refuelling, 13, 77
 - Warning for fuel down to reserve, 24
- Fuses, 134

G

- Gear indicator, 20
- Grip heating, 16, 53

H

Handlebar fittings

- General view, left side, 15
 - General view, right side, 16
- Hazard warning flashers, 15, 51

Headlight

- Adjustment for driving on left/driving on right, 63
 - Beam throw, 11, 64
- Headlight flasher, 15
- Helmet holder, 66
- High-beam headlight, 15, 18
- Horn, 15

I

Ignition

- Switching off, 40
 - Switching on, 40
- Immobiliser, 41
- Warning, 24
- Instrument cluster
- Overview, 17
 - Sensor for instrument cluster lighting, 17

J

- Jump starting, 111

K

- Keys, 40, 41

L

Laying up, 120

Lights

Headlight flasher, 50

High-beam headlight, 50

Low-beam headlight, 50

Parking light, 50

Side light, 50

Switch on the parking lights, 50

Low-beam headlight, 18

Luggage loops, 66

M**Maintenance**

General instructions, 88

Mirrors

Adjusting, 56

Motorcycle

Care, 117

Cleaning, 117

General view, left side, 11

General view, right side, 13

Laying up, 120

Parking, 76

Restoring to use, 120

O**Odometer and tripmeters**

Resetting, 44

Selecting readings, 43

On-board computer

Ambient temperature, 46

Average consumption, 47

Average speed, 46

Oil level, 48

Range, 48

Selecting readings, 45

P

Power socket, 13, 84

Pre-ride check, 73

R**Rear-wheel drive**

Technical data, 128

Rear-wheel stand, 103

Refuelling, 77

Reserve

Warning, 24

Residual range, 45

Restoring to use, 120

Rev. counter, 17

Running gear

Adjusting treble setting, 62

Technical data, 129

Running in, 74

S

Safety instructions, 70

Seat

Installing front seat, 65

Installing rear seat, 65

Lock, 11

Releasing rear seat, 14

Removing front seat, 64

Removing rear seat, 65

Service, 140

Status indicators on the display, 20

Service Card, 140

Side light, 18

Side stand

For starting, 72

Placing motorcycle on side stand, 76

Removing motorcycle from side stand, 77

- Spark plugs
 - Technical data, 134
- Speedometer, 17
- Spring preload, 56
 - Adjusting for front wheel, 57
 - Adjusting for rear wheel, 56, 60
 - Setting with sport suspension, 11
 - Setting with standard suspension, 11
- Starter, 16
- Starting, 72
- Steering lock
 - Locking, 40

T

- Technical data
 - Brakes, 130
 - Bulbs, 135
 - Clutch, 127
 - Electrics, 134
 - Engine, 125
 - Frame, 135
 - Rear-wheel drive, 128
 - Running gear, 129

- Spark plugs, 134
- Standards, 7
- Transmission, 128
- Wheels and tyres, 131
- Telltale lights, 17
- Toolkit, 14
 - Overview, 88
 - Service kit, 89
- Torques, 123
- Transmission
 - For starting, 72
 - Technical data, 128
- Troubleshooting chart, 122
- Turn indicators
 - Left, 15, 51
 - Right, 16, 51
 - Switching off, 16, 51
- Tyre pressure monitoring RDC
 - Label on wheel rim, 97
 - Status indicators, 49
 - Warning, 33, 34
- Tyres
 - Checking inflation pressure, 63
 - Checking tread depth, 96
 - Recommended tyres, 97

- Running in, 74
- Table of tyre pressures, 14
- Technical data, 131

W

- Warning lights, 17
- Warnings
 - Mode of presentation, 22
- Warnings, overview, 23, 27, 29, 32, 36
- Wheels
 - Installing front wheel, 99
 - Installing rear wheel, 102
 - Remove the front wheel, 98
 - Removing rear wheel, 101
 - Technical data, 131

Details described or illustrated in this booklet may differ from the motorcycle's actual specification as purchased, the accessories fitted or the national-market specification. No claims will be entertained as a result of such discrepancies.

Dimensions, weights, fuel consumption and performance data are quoted to the customary tolerances.

The right to modify designs, equipment and accessories is reserved.

Errors and omissions excepted.

© 2007 BMW Motorrad

Not to be reproduced either wholly or in part without written permission from BMW Motorrad, After Sales.

Printed in Germany.

Important data for refuelling

Fuel

Recommended fuel grade	98 ROZ/RON, Premium plus unleaded 95 ROZ/RON, Premium unleaded (fuel grade, usable with power- and consumption-related restrictions)
Usable fuel capacity	17 l
Reserve fuel	≥4 l

Tyre pressure

Tyre pressure, front	2.2 bar, one-up, tyre cold 2.5 bar, two-up and/or with luggage, tyre cold
Tyre pressure, rear	2.5 bar, one-up, tyre cold 2.9 bar, two-up and/or with luggage, tyre cold

BMW recommends 

Order No. 01 41 7 712 041
07.2007, 3rd edition

