

# 2016 Fat Boy S - Owner's Manual

---

## Safety First

### Safe Operating Rules

---

#### WARNING

**Motorcycles are different from other vehicles. They operate, steer, handle and brake differently. Unskilled or improper use could result in loss of control, death or serious injury. (00556c)**

- Take a rider training course.
- Read owner's manual before riding, adding accessories or servicing.
- Wear a helmet, eye protection and protective clothing.
- Never tow a trailer.

Before operating your motorcycle, read and follow the operating and maintenance instructions in this manual. Follow these basic rules for your personal safety.

- Know and respect the rules of the road. Carefully read and familiarize yourself with the motorcycle safety information provided by your country or state. Read the RIDING TIPS booklet in your owner's kit (in the U.S.) and the MOTORCYCLE HANDBOOK from your state or regional traffic authority. The RIDING TIPS booklet is also available on [www.msf-usa.org](http://www.msf-usa.org). See Rules of the Road.
- Before starting engine, check for proper operation of brake, clutch, shifter, throttle controls, correct fuel and oil supply.

#### WARNING

**Harley-Davidson parts and accessories are designed for Harley-Davidson motorcycles. Using non-Harley-Davidson parts or accessories can adversely affect performance, stability or handling, which could result in death or serious injury. (00001b)**

- Use only Harley-Davidson approved parts and accessories. Use of certain other manufacturer's performance parts may void your new motorcycle warranty, except where prohibited by law. See your Harley-Davidson dealer for details.

#### WARNING

**Stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near gasoline. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00002a)**

When refueling your motorcycle, observe the following rules.

- Refuel in a ventilated area with the engine turned off.
- Remove fuel filler cap slowly.
- Do not smoke or allow open flames or sparks when refueling or servicing the fuel system.
- Do not fill fuel tank above the bottom of the filler neck insert.
- Leave air space to allow for fuel expansion.

**⚠WARNING**

**Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)**

**⚠WARNING**

**Engine exhaust from this product contains chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. (00004f)**

**⚠WARNING**

**Do not run motorcycle in a closed garage or confined area. Inhaling motorcycle exhaust, which contains poisonous carbon monoxide gas, could result in death or serious injury. (00005a)**

**⚠WARNING**

**The jiffy stand locks when placed in the full forward (down) position with vehicle weight on it. If the jiffy stand is not in the full forward (down) position with vehicle weight on it, the vehicle can fall over which could result in death or serious injury. (00006a)**

**⚠WARNING**

**Be sure jiffy stand is fully retracted before riding. If jiffy stand is not fully retracted, it can contact the road surface causing a loss of vehicle control, which could result in death or serious injury. (00007a)**

- A new motorcycle must be operated according to the special break-in procedure. See Break-In Riding Rules.
- Operate motorcycle at moderate speed and out of traffic until you become thoroughly familiar with its operation and handling characteristics under all conditions.

**NOTE:**

*Harley-Davidson recommends that you obtain information and formal training in the correct motorcycle riding technique. In the United States, both the Harley-Davidson Riding Academy (1-414-343-4056) and the Motorcycle Safety Foundation (1-800-446-9227) offer beginning and advanced rider safety courses.*

## **⚠WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

- Do not exceed the legal speed limit or drive too fast for existing conditions. Always reduce speed when poor driving conditions exist. High speed increases the influence of any other condition affecting stability and increases the possibility of loss of control.
- Pay strict attention to road surfaces and wind conditions. Keep both hands on the handlebar grips when riding the motorcycle. Any two-wheeled vehicle may be subject to upsetting forces such as wind blasts from passing trucks, holes in the pavement, rough road surfaces and rider control error. These forces may influence the handling characteristics of your motorcycle. If you experience these conditions, reduce speed and guide the motorcycle with a relaxed grip to a controlled condition. Do not brake abruptly or force the handlebar. This may aggravate an unstable condition.
- Keep cargo weight concentrated close to the motorcycle and as low as possible to minimize the change in the motorcycle's center of gravity. Distribute weight evenly on both sides of the vehicle. Do not load bulky items too far behind the rider or add weight to the handlebars or front forks. Do not exceed maximum specified load in each saddlebag.

### *NOTE:*

*New riders should gain experience under various conditions while riding at moderate speeds.*

- Operate your motorcycle defensively. Remember, a motorcycle does not afford the same protection as an automobile in an accident. One common risk for an accident occurs when another vehicle turns left in front of an on-coming motorcyclist. Operate only with headlamp on.
- Wear an approved helmet, clothing and foot gear suited for motorcycle riding. Bright or light colors are best for greater visibility in traffic, especially at night. Avoid loose, flowing garments and scarves.

## **⚠WARNING**

**Avoid contact with exhaust system and wear protective clothing that completely covers legs while riding. Exhaust pipes and mufflers get very hot when engine is running and remain too hot to touch, even after engine is turned off. Failure to wear protective clothing could result in burns or other serious injury. (00009a)**

- When carrying passengers, it is your responsibility to instruct them on proper riding procedures. See the RIDING TIPS booklet included in your owner's kit (in the U.S.) or available on [www.msf-usa.org](http://www.msf-usa.org).
- Do not allow other individuals, under any circumstances, to operate your motorcycle unless you know that they are experienced and licensed riders. Make sure they are thoroughly familiar with the operation of your particular motorcycle.
- Protect your motorcycle against theft. Using the fork lock immediately after parking your motorcycle will discourage unauthorized use or theft.
- Safe motorcycle operation requires alert mental judgment combined with a defensive driving attitude. Do not allow fatigue, alcohol or drugs to endanger your safety or that of others.

- For vehicles with a sound system, adjust the volume to a non-distracting level before operating vehicle.
- Proper care and maintenance, including tire pressure, tire condition, tread depth and proper adjustment to steering head bearings are important to the stability and safe operation of the motorcycle. Maintain your motorcycle in proper operating condition. Refer to Regular Service Intervals: 2016 Softail Models.

**⚠WARNING**

**Do not operate vehicle with forks locked. Locking the forks restricts the vehicle's turning ability, which could result in death or serious injury. (00035a)**

**⚠WARNING**

**Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)**

**⚠WARNING**

**Do not operate motorcycle with loose, worn or damaged steering or suspension systems. Contact a Harley-Davidson dealer for repairs. Loose, worn or damaged steering or suspension components can adversely affect stability and handling, which could result in death or serious injury. (00011a)**

**⚠WARNING**

**Regularly inspect shock absorbers and front forks. Replace leaking, damaged or worn parts that can adversely affect stability and handling, which could result in death or serious injury. (00012a)**

**⚠WARNING**

**Use Harley-Davidson replacement fasteners. Aftermarket fasteners can adversely affect performance, which could result in death or serious injury. (00013a)**

- See your Harley-Davidson service manual for proper torque values.
- Aftermarket fasteners may not have the specific property requirements to perform properly.

**⚠WARNING**

**Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated,**

overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)

#### **⚠WARNING**

Replace punctured or damaged tires. In some cases, small punctures in the tread area may be repaired from within the removed tire by a Harley-Davidson dealer. Speed should NOT exceed 50 mph (80 km/h) for the first 24 hours after repair, and the repaired tire should NEVER be used over 80 mph (130 km/h). Failure to follow this warning could lead to tire failure and result in death or serious injury. (00015b)

#### **⚠WARNING**

Only install original equipment tire valves and valve caps. A valve, or valve and cap combination, that is too long or too heavy can strike adjacent components and damage the valve, causing rapid tire deflation. Rapid tire deflation can cause loss of vehicle control, which could result in death or serious injury. (00281a)

#### **⚠WARNING**

Do not exceed the motorcycle's Gross Vehicle Weight Rating (GVWR) or Gross Axle Weight Rating (GAWR). Exceeding these weight ratings can lead to component failure and adversely affect stability, handling and performance, which could result in death or serious injury. (00016f)

#### **CAUTION**

When lifting a motorcycle using a jack, be sure jack contacts both lower frame tubes where down tubes and lower frame tubes converge. Never lift by jacking on cross-members, oil pan, mounting brackets, components or housings. Failure to comply can cause serious damage resulting in the need to perform major repair work. (00586d)

- GVWR is the sum of the weight of the motorcycle, accessories and the maximum weight of the rider, passenger and cargo that can be safely carried.
- GAWR is the maximum amount of weight that can be safely carried on each axle.
- The GVWR and GAWR are shown on the information label which is on the frame downtube in some destinations. See Specifications.

#### **⚠WARNING**

Do not tow a disabled motorcycle. Towing can adversely

affect stability and handling, which could result in death or serious injury. (00017a)

**⚠WARNING**

Do not pull a trailer with a motorcycle. Pulling a trailer can cause tire overload, damage and failure, reduced braking performance, and adversely affect stability and handling, which could result in death or serious injury. (00018c)

**⚠WARNING**

Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling. (00019e)

**⚠WARNING**

Do not open storage compartments while riding. Distractions while riding can lead to loss of control, which could result in death or serious injury. (00082a)

**⚠WARNING**

Consult a Harley-Davidson dealer regarding any questions or problems that occur in the operation of your motorcycle. Failure to do so can aggravate an initial problem, cause costly repairs, cause an accident and could result in death or serious injury. (00020a)

**⚠CAUTION**

Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. KEEP OUT OF REACH OF CHILDREN. (00240a)

- Make sure all equipment required by federal, state and local law is installed and in good operating condition.

## **Anti-lock Brake System (ABS)**

---

**⚠WARNING**

If ABS lamp continues flashing at speeds greater than 3 mph (5 km/h) or remains on continuously, the ABS is not

**operating. The standard brake system is operational, but wheel lock up can occur. Contact a Harley-Davidson Dealer to have ABS repaired. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury. (00361b)**

### **⚠WARNING**

**ABS cannot prevent lockup of rear wheel due to engine braking. ABS will not aid in cornering or on loose/uneven surfaces. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury. (00362a)**

To operate motorcycles equipped with an anti-lock brake system, see Brake System.

## **Rules of the Road**

---

- Always sound your horn, use your turn signals and exercise caution when passing other vehicles going in the same direction. Never pass going in the same direction at street intersections, on curves or when going up or down a hill.
- At street intersections, give the right-of-way. Do not presume you have the right-of-way, as the other driver may not know that it is your turn.
- Always signal when preparing to stop, turn or pass.
- Promptly obey all traffic signs, including those signs used for the control of traffic at intersections. Always obey traffic signs near schools and at railroad crossings.
- When intending to turn, signal at least 100 ft 30.5 m before reaching the turning point. If turning across an intersection, move over to the centerline of the street (unless local rules require otherwise). Slow down when entering the intersection and turn carefully.
- Never anticipate a traffic light. When a change is indicated from GO to STOP (or STOP to GO), slow down and wait for the light to change. Never run through a yellow or red traffic light.
- While turning, watch for pedestrians, animals, as well as vehicles.
- Do not leave the curb or parking area without signaling. Make sure that your way is clear to enter moving traffic. A moving line of traffic always has the right-of-way.
- Make sure that your license plate is installed in the position specified by law. Make sure that your license plate is always clearly visible. Keep the license plate clean.
- Ride at a safe speed that is consistent with the type of highway you are on. Pay strict attention to whether the road is dry, oily, icy or wet.
- Watch for debris such as leaves or loose gravel.
- Weather and traffic conditions on the highway dictate adjusting your speed and driving habits accordingly.

## **Accessories and Cargo**

---

Harley-Davidson Motor Company cannot test and make specific recommendations concerning every accessory or combination of accessories sold. Therefore, the rider must be responsible for safe operation when installing accessories or carrying extra weight.

### **⚠WARNING**

**See the Accessories and Cargo section in your owner's manual. Improper cargo loading or accessory installation**

can cause component failure and adversely affect stability, handling and performance, which could result in death or serious injury. (00021b)

#### **⚠ WARNING**

**Do not exceed the motorcycle's Gross Vehicle Weight Rating (GVWR) or Gross Axle Weight Rating (GAWR). Exceeding these weight ratings can lead to component failure and adversely affect stability, handling and performance, which could result in death or serious injury. (00016f)**

- GVWR is the sum of the weight of the motorcycle, accessories and the maximum weight of the rider, passenger and cargo that can be safely carried.
- GAWR is the maximum amount of weight that can be safely carried on each axle.
- The GVWR and GAWR are shown on the information label which is on the frame downtube in some destinations. Refer to weight tables. See Specifications.

#### **⚠ WARNING**

**Do not pull a trailer with a motorcycle. Pulling a trailer can cause tire overload, damage and failure, reduced braking performance, and adversely affect stability and handling, which could result in death or serious injury. (00018c)**

## **Accessories and Cargo Guidelines**

---

Follow the following guidelines when equipping a motorcycle, carrying passengers and/or cargo.

#### **⚠ WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

- Do not exceed the legal speed limit or drive too fast for existing conditions. Always reduce speed when poor driving conditions exist. High speed increases the influence of any other condition affecting stability and increases the possibility of loss of control.
- Pay strict attention to road surfaces and wind conditions, and always keep both hands on the handlebar grips when riding. Two-wheeled vehicles are subject to upsetting forces such as wind blasts from passing trucks, holes in the pavement, rough road surfaces, rider control error. These forces may influence the handling characteristics of your motorcycle. If you experience these conditions, reduce speed and guide the motorcycle with a relaxed grip to a controlled condition. Do not brake abruptly or force the handlebar. This may aggravate an unstable condition.
- Keep cargo weight concentrated close to the motorcycle and as low as possible. This position minimizes the change in the motorcycle's center of gravity.
- Distribute weight evenly on both sides of the vehicle.
- Do not load bulky items too far behind the rider or add weight to the handlebars or front

forks.

- If equipped, do not exceed maximum specified load in each saddlebag.
- If equipped, do not overload luggage racks. Luggage racks are designed for lightweight items.
- Make sure cargo is secure and will not shift while riding and recheck the cargo periodically. Accessories that change the operator's riding position may increase reaction time and affect handling.
- Extra electrical equipment can overload the motorcycle's electrical system. This overload can result in electrical system and/or component failure.

#### **WARNING**

**Front and/or rear guard(s) can provide limited leg and cosmetic vehicle protection under unique circumstances. (Fall over while stopped, very slow speed slide.) It is not made or intended to provide protection from bodily injury in a collision with another vehicle or any other object. (00022b)**

- Large surfaces such as fairings, windshields, backrests and luggage racks can have an adverse effect on stability and handling.
- Install only Genuine Harley-Davidson accessories designed specifically for your motorcycle.
- Pay particular attention to the weights of accessories, cargo, riding gear, passenger and rider. These weights affect the loading requirements of your motorcycle.

#### **WARNING**

**Harley-Davidson parts and accessories are designed for Harley-Davidson motorcycles. Using non-Harley-Davidson parts or accessories can adversely affect performance, stability or handling, which could result in death or serious injury. (00001b)**

#### **WARNING**

**Do not add sidecar to this motorcycle. Operating motorcycle with sidecar can cause loss of vehicle control, which could result in death or serious injury. (00590d)**

## **Noise Control System**

---

### **Tampering**

---

Removal or replacement of any noise control system component may be prohibited by law. This prohibition includes modifications made prior to vehicle sale or delivery to the ultimate purchaser. Use of a vehicle on which noise control system components have been removed or rendered inoperative may also be prohibited by law.

## **Labels**


---

See Labels. The safety and maintenance labels on your motorcycle indicate compliance to market regulations. Refer to Labels.

NOTE:

*Some labels are available in different languages for destinations outside the United States.*

If removed or damaged, replacement labels can be purchased. See a Harley-Davidson dealer for all available labels.



Labels

Labels

| ITEM | PART NO.                                                      | DESCRIPTION           | LOCATION                           | TEXT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------|---------------------------------------------------------------|-----------------------|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | 14000347<br>(all except FLSTFBS)<br><br>14000377<br>(FLSTFBS) | General warnings      | Top of air cleaner cover           | <p><b>WARNING:</b> Motorcycles are different from other vehicles. They operate, steer, handle and brake differently. Unskilled or improper use could result in loss of control, death or serious injury.</p> <ul style="list-style-type: none"> <li>• Take a rider training course.</li> <li>• Read Owner's Manual before riding, adding accessories or servicing.</li> <li>• Wear a helmet, eye protection and protective clothing.</li> <li>• Never tow a trailer.</li> </ul> <p>For a manual, find nearest dealer at 1-414-343-4056 or <a href="http://www.harley-davidson.com">www.harley-davidson.com</a></p> |
| 2    | 15368-01A                                                     | Battery warning       | On frame, left of battery          | <p><b>WARNING:</b> A connected battery can cause a spark or motorcycle startup while servicing. Death or serious injury could occur.</p> <ul style="list-style-type: none"> <li>• Disconnect negative cable before servicing.</li> <li>• Keep cable away from terminal while servicing.</li> </ul>                                                                                                                                                                                                                                                                                                                 |
| 3    | 14000069                                                      | Saddlebag load limits | Inside saddlebag (equipped models) | <p><b>WARNING:</b> Too much weight in saddlebags can cause loss of control. Death or serious injury could occur.</p> <ul style="list-style-type: none"> <li>• Do not put more than 15 pounds in each saddlebag.</li> <li>• Put equal weight in each saddlebag.</li> <li>• See Accessories and Cargo section of</li> </ul>                                                                                                                                                                                                                                                                                          |

|   |                     |                      |                    |                                                                                                                                                                                                                                                                                                                                         |
|---|---------------------|----------------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   |                     |                      |                    | Owner's Manual for more information.                                                                                                                                                                                                                                                                                                    |
| 4 | Not sold separately | Shock absorber label | On shock absorbers | WARNING: This assembly contains high-pressure nitrogen gas. Any attempt to disassemble or refill this shock assembly may result in an explosion, causing serious injury. Exposure to flame or puncture may also result in an explosion, causing serious injury. Replacement and disposal should only be done by your authorized dealer. |

## Identification

### Vehicle Identification Number (VIN)

---

#### General

---

See Typical Harley-Davidson VIN: 2016 Softail Models. A unique 17-digit serial or Vehicle Identification Number (VIN) is assigned to each motorcycle. Refer to Harley-Davidson VIN Breakdown: 2016 Softail Models.

#### Location

---

See VIN Locations. The full 17-digit VIN is stamped on the right side of the frame near the steering head. In some destinations, a printed VIN label is also attached on the front downtube.



#### Abbreviated VIN

---

An abbreviated VIN showing the vehicle model, engine type, model year, and sequential number is stamped on the left side of the crankcase between the engine cylinders.

*NOTE:*

*Always give the full 17-digit Vehicle Identification Number when ordering parts or making any inquiry about your motorcycle.*



**Harley-Davidson VIN Breakdown: 2016 Softail Models**

| POSITION | DESCRIPTION                   | POSSIBLE VALUES                                                                                                                                                                                                             |
|----------|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1        | World manufacturer identifier | 1HD=Originally manufactured in the United States<br>5HD=Originally manufactured in the United States for sale outside of the United States<br>932=Originally manufactured in Brazil<br>MEG=Originally manufactured in India |
| 2        | Motorcycle type               | 1=Heavyweight motorcycle (901 cm <sup>3</sup> or larger)                                                                                                                                                                    |
| 3        | Model                         | See VIN model table                                                                                                                                                                                                         |
| 4        | Engine type                   | 9=Twin Cam 110B™ (1802 cm <sup>3</sup> ) air-cooled, fuel-injected, balanced                                                                                                                                                |

|   |                                         |                                                                                                                                                                                                  |                                                                                                                                                                                                                     |
|---|-----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   |                                         | V=Twin Cam 103B™ (1690 cm <sup>3</sup> ) air-cooled, fuel-injected, balanced                                                                                                                     |                                                                                                                                                                                                                     |
| 5 | Calibration/configuration, introduction | <b>Normal Introduction</b><br>1=Domestic (DOM)<br>3=California (CAL)<br>A=Canada (CAN)<br>C=HDI<br>E=Japan (JPN)<br>G=Australia (AUS)<br>J=Brazil (BRZ)<br>L=Asia Pacific (APC)<br>N=India (IND) | <b>Mid-year or Special Introduction</b><br>2, 4=Domestic (DOM)<br>5, 6=California (CAL)<br>B=Canada (CAN)<br>D=HDI<br>F=Japan (JPN)<br>H=Australia (AUS)<br>K=Brazil (BRZ)<br>M=Asia Pacific (APC)<br>P=India (IND) |
| 6 | VIN check digit                         | Can be 0-9 or X                                                                                                                                                                                  |                                                                                                                                                                                                                     |
| 7 | Model year                              | G=2016                                                                                                                                                                                           |                                                                                                                                                                                                                     |
| 8 | Assembly plant                          | B=York, PA U.S.A.<br>C=Kansas City, MO U.S.A.<br>D=H-D Brazil-Manaus, Brazil (CKD)<br>N=Haryana India (Bawal District Rewari)                                                                    |                                                                                                                                                                                                                     |
| 9 | Sequential number                       | Varies                                                                                                                                                                                           |                                                                                                                                                                                                                     |

**VIN Model Codes: 2016 Softail Models**

| CODE | MODEL                           | CODE | MODEL                                                                          |
|------|---------------------------------|------|--------------------------------------------------------------------------------|
| BF   | FXSB Breakout®                  | JN   | FLSTFB Fat Boy® Lo<br><br>FLSTFB Fat Boy® Special (some international markets) |
| BW   | FLSTC Heritage Softail® Classic | JR   | FLS Softail® Slim™                                                             |
| BX   | FLSTF Fat Boy®                  | JS   | FLSS Softail® Slim™ S                                                          |
| JD   | FLSTN Softail® Deluxe           | JT   | FLSTFBS Fat Boy® S                                                             |

## Specifications

### Specifications

---

**Engine: Twin Cam 103B**

| ITEM                | SPECIFICATION                                      |                      |
|---------------------|----------------------------------------------------|----------------------|
| Number of cylinders | 2                                                  |                      |
| Type                | 4-cycle, 45 degree<br>V-twin, balanced, air cooled |                      |
| Compression ratio   | 9.6:1                                              |                      |
| Bore                | 3.87 in                                            | 98.4 mm              |
| Stroke              | 4.374 in                                           | 111.1 mm             |
| Displacement        | 103.1 in <sup>3</sup>                              | 1690 cm <sup>3</sup> |
| Lubrication system  | Pressurized dry sump                               |                      |

**Engine: Twin Cam 110B**

| ITEM                | SPECIFICATION                            |                      |
|---------------------|------------------------------------------|----------------------|
| Number of cylinders | 2                                        |                      |
| Type                | 4-cycle, 45 degree<br>V-Type, air-cooled |                      |
| Compression ratio   | 9.2-1                                    |                      |
| Bore                | 4.00 in                                  | 101.6 mm             |
| Stroke              | 4.374 in                                 | 111.1 mm             |
| Displacement        | 110.0 in <sup>3</sup>                    | 1801 cm <sup>3</sup> |

**NOTE:**

*Specifications in this publication may not match those of official certification in some markets due to timing of publication printing, variance in testing methods, and/or vehicle differences. Customers seeking officially recognized regulatory specifications for their vehicle should refer to certification documents and/or contact their respective dealer or distributor.*

**Electrical**

| COMPONENT         | SPECIFICATION                                                                   |              |
|-------------------|---------------------------------------------------------------------------------|--------------|
| Ignition timing   | Not adjustable                                                                  |              |
| Battery           | 12 V, 19 Ah, 315 CCA<br>sealed and maintenance-free                             |              |
| Charging system   | Three-phase, 38 A system<br>(439 W @ 13 V, 2000 rpm,<br>489 W max power @ 13 V) |              |
| Spark plug size   | 12 mm                                                                           |              |
| Spark plug gap    | 0.038-0.043 in                                                                  | 0.97-1.09 mm |
| Spark plug torque | 12-18 ft-lbs                                                                    | 16.3-24.4 Nm |

#### Transmission

| TRANSMISSION | SPECIFICATION             |
|--------------|---------------------------|
| Type         | Constant mesh, foot shift |
| Speeds       | 6 forward                 |

#### Sprocket Teeth

| DRIVE   | ITEM         | NUMBER OF TEETH |
|---------|--------------|-----------------|
| Primary | Engine       | 34              |
|         | Clutch       | 46              |
| Final   | Transmission | 32              |
|         | Rear wheel   | 66              |

#### Overall Drive Ratios

| GEAR   | RATIO                      |                 |
|--------|----------------------------|-----------------|
|        | DOMESTIC AND INTERNATIONAL | JAPANESE MODELS |
| First  | 9.311                      | 9.029           |
| Second | 6.454                      | 6.259           |
| Third  | 4.793                      | 4.648           |
| Fourth | 3.882                      | 3.764           |
| Fifth  | 3.307                      | 3.207           |
| Sixth  | 2.790                      | 2.706           |

#### Capacities

| ITEM                                                                                                 | U.S.    | L    |
|------------------------------------------------------------------------------------------------------|---------|------|
| Fuel tank (total)                                                                                    | 5.0 gal | 18.9 |
| Low fuel warning light on                                                                            | 1.0 gal | 3.8  |
| Oil tank with filter *                                                                               | 3.0 qt  | 2.8  |
| Transmission (approximate) **                                                                        | 1.0 qt  | 0.95 |
| Primary chaincase (approximate)                                                                      | 1.0 qt  | 0.95 |
| * When refilling, initially add 2.0 qt 1.90 L and add as needed to bring level within specification. |         |      |
| ** When refilling, initially add 28 oz 0.83 L and add as needed to bring level within specification. |         |      |

 **WARNING**

**Do not exceed the motorcycle's Gross Vehicle Weight Rating (GVWR) or Gross Axle Weight Rating (GAWR). Exceeding these weight ratings can lead to component failure and adversely affect stability, handling and performance, which could result in death or serious injury. (00016f)**

- GVWR is the sum of the weight of the motorcycle, accessories and the maximum weight of the rider, passenger and cargo that can be safely carried.
- GAWR is the maximum amount of weight that can be safely carried on each axle.
- The GVWR and GAWR are shown on the information plate, located on the frame downtube.

NOTE:

*The maximum additional weight allowed on the motorcycle equals the Gross Vehicle Weight Rating (GVWR) minus the running weight. For example, a motorcycle with GVWR of 1200 lb 544 kg having a running weight of 800 lb 363 kg, would allow a maximum of an additional 400 lb 181 kg combined weight of the rider, passenger, riding gear, cargo and installed accessories.*

**Weights: FLSTC, FLSTF, FLSTFB, FLSTFBS and FLSTN**

| ITEM                                                                                                     | FLSTC |     | FLSTF |     | FLSTFB |     | FLSTFBS |     | FLSTN |     |
|----------------------------------------------------------------------------------------------------------|-------|-----|-------|-----|--------|-----|---------|-----|-------|-----|
|                                                                                                          | lb    | kg  | lb    | kg  | lb     | kg  | lb      | kg  | lb    | kg  |
| Running weight*                                                                                          | 755   | 342 | 730   | 331 | 733    | 332 | 739     | 335 | 730   | 331 |
| Maximum added weight allowed**                                                                           | 405   | 181 | 430   | 195 | 427    | 191 | 421     | 191 | 430   | 195 |
| GVWR                                                                                                     | 1160  | 526 | 1160  | 526 | 1160   | 526 | 1160    | 526 | 1160  | 526 |
| GAWR front                                                                                               | 430   | 195 | 430   | 195 | 430    | 195 | 430     | 195 | 430   | 195 |
| GAWR rear                                                                                                | 730   | 331 | 730   | 331 | 730    | 331 | 730     | 331 | 730   | 331 |
| * The total weight of the motorcycle as delivered with all oil/fluids and approximately 90% of fuel.     |       |     |       |     |        |     |         |     |       |     |
| ** The total weight of accessories, cargo, riding gear, passenger and rider must not exceed this weight. |       |     |       |     |        |     |         |     |       |     |

**Weights: FLS, FLSS and FXSB**

| ITEM                                                                                                     | FLS  |     | FLSS |     | FXSB |     |
|----------------------------------------------------------------------------------------------------------|------|-----|------|-----|------|-----|
|                                                                                                          | lb   | kg  | lb   | kg  | lb   | kg  |
| Running weight*                                                                                          | 706  | 320 | 712  | 323 | 707  | 321 |
| Maximum added weight allowed**                                                                           | 454  | 206 | 448  | 203 | 468  | 212 |
| GVWR                                                                                                     | 1160 | 526 | 1160 | 526 | 1175 | 533 |
| GAWR front                                                                                               | 430  | 195 | 430  | 195 | 415  | 188 |
| GAWR rear                                                                                                | 730  | 331 | 730  | 331 | 760  | 345 |
| * The total weight of the motorcycle as delivered with all oil/fluids and approximately 90% of fuel.     |      |     |      |     |      |     |
| ** The total weight of accessories, cargo, riding gear, passenger and rider must not exceed this weight. |      |     |      |     |      |     |

**Dimensions: FLSTC, FLSTF, FLSTFB, FLSTFBS and FLSTN**

| ITEM                                | FLSTC |      | FLSTF |      | FLSTFB |      | FLSTFBS |      | FLSTN |      |
|-------------------------------------|-------|------|-------|------|--------|------|---------|------|-------|------|
|                                     | in    | mm   | in    | mm   | in     | mm   | in      | mm   | in    | mm   |
| Length                              | 94.7  | 2405 | 93.9  | 2385 | 94.1   | 2390 | 94.1    | 2390 | 94.9  | 2410 |
| Overall width                       | 38.2  | 970  | 38.8  | 985  | 39.0   | 990  | 39.0    | 990  | 37.2  | 945  |
| Overall height                      | 54.9  | 1395 | 43.9  | 1115 | 42.7   | 1085 | 42.7    | 1085 | 43.3  | 1110 |
| Wheelbase                           | 64.4  | 1635 | 64.4  | 1635 | 64.2   | 1630 | 64.2    | 1630 | 64.4  | 1635 |
| Road clearance                      | 4.7   | 120  | 5.1   | 130  | 4.7    | 120  | 4.7     | 120  | 4.3   | 110  |
| Seat height*                        | 27.0  | 685  | 25.0  | 635  | 24.3   | 616  | 24.3    | 616  | 24.5  | 622  |
| * With 180 lb 81.6 kg rider on seat |       |      |       |      |        |      |         |      |       |      |

Dimensions: FLS, FLSS and FXSB

| ITEM                                 | FLS  |      | FLSS |      | FXSB |      |
|--------------------------------------|------|------|------|------|------|------|
|                                      | in   | mm   | in   | mm   | in   | mm   |
| Length                               | 92.3 | 2345 | 92.3 | 2345 | 95.7 | 2430 |
| Overall width                        | 38.2 | 970  | 38.2 | 970  | 37.0 | 940  |
| Overall height                       | 42.5 | 1080 | 42.5 | 1080 | 41.1 | 1045 |
| Wheelbase                            | 64.4 | 1635 | 64.4 | 1635 | 67.3 | 1710 |
| Road clearance                       | 4.9  | 125  | 4.9  | 125  | 4.3  | 110  |
| Seat height*                         | 23.8 | 605  | 23.8 | 605  | 24.7 | 627  |
| * With 180 lb 81.6 kg rider on seat. |      |      |      |      |      |      |

Specified Tires

| MODEL                    | MOUNT | SIZE  | SPECIFIED TIRE         | PRESSURE (COLD) |     |
|--------------------------|-------|-------|------------------------|-----------------|-----|
|                          |       |       |                        | psi             | kPa |
| FLSTC, FLS, FLSS         | front | 16 in | Dunlop D402F MT90B16   | 36              | 248 |
| FLSTN, FLSTC (whitewall) | front | 16 in | Dunlop D402F MT90B16   | 36              | 248 |
| FLSTF, FLSTFB, FLSTFBS   | front | 17 in | Dunlop D408F 140/75R17 | 36              | 248 |
| FXSB                     | front | 21 in | Dunlop D408F 130/60B21 | 36              | 248 |
| FLSTC                    | rear  | 16 in | Dunlop D401 150/80B16  | 40              | 276 |
| FLSTN, FLSTC (whitewall) | rear  | 16 in | Dunlop D402 MU85B16    | 40              | 276 |
| FLS, FLSS                | rear  | 16 in | Dunlop D402 MU85B16    | 40              | 276 |
| FLSTF, FLSTFB, FLSTFBS   | rear  | 17 in | Dunlop D407 200/55R17  | 42              | 290 |
| FXSB                     | rear  | 18 in | Dunlop D407 240/40R18  | 42              | 290 |

## Tire Data

### WARNING

Match tires, tubes, rim strips or seals, air valves and caps

to the correct wheel. Contact a Harley-Davidson dealer. Mismatching can lead to tire damage, allow tire slippage on the wheel or cause tire failure, which could result in death or serious injury. (00023c)

**⚠ WARNING**

Only install original equipment tire valves and valve caps. A valve, or valve and cap combination, that is too long or too heavy can strike adjacent components and damage the valve, causing rapid tire deflation. Rapid tire deflation can cause loss of vehicle control, which could result in death or serious injury. (00281a)

**⚠ WARNING**

Use only Harley-Davidson specified tires. See a Harley-Davidson dealer. Using non-specified tires can adversely affect stability, handling or braking, which could result in death or serious injury. (00024b)

Refer to Specified Tires for specified tires and recommended pressures.

**⚠ WARNING**

Install new seal before mounting tire. Riding motorcycle without seal in place can sever valve stem causing rapid air loss leading to the loss of control, which could result in death or serious injury. (00622b)

Softail motorcycles with profile laced wheels (wire spoked wheels with smooth round rims) are fitted with a special rim seal, a rim strip and a tubeless tire. An inner tube is not used. These rims are unique and identified by the letters MTM and the word TUBELESS etched into the rim. Never install a tire with an inner tube on these type wheels. Install a **new** rim seal and rim strip each time a tire is mounted on a profile laced wheel with the MTM and TUBELESS markings.

Steel-laced rims use an inner tube and rim strip. Tubeless tires fitted with the correct size inner tubes may be used with these wheels. Install a **new** inner tube and rim strip each time a **new** tire is installed on a steel-laced wheel.

Tubeless tires are used on all Harley-Davidson cast and disc wheels.

**⚠ WARNING**

Harley-Davidson front and rear tires are not the same. Interchanging front and rear tires can cause tire failure, which could result in death or serious injury. (00026a)

**⚠ WARNING**

Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and

**see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)**

Always maintain proper tire pressure. Refer to Specified Tires. Do not load tires beyond GAWR specified in Weights: FLSTC, FLSTF, FLSTFB, FLSTFBS and FLSTN and Weights: FLS, FLSS and FXSB. Under-inflated, over-inflated or overloaded tires can fail.

#### **⚠ WARNING**

**Replace tire immediately with a Harley-Davidson specified tire when wear bars become visible or only 1/32 in (0.8 mm) tread depth remains. Riding with a worn tire could result in death or serious injury. (00090c)**

Harley-Davidson tires have wear bars that run horizontally across the tread. When a tire is worn to the point that the wear bars are visible, or 1/32 in 0.8 mm tread depth remains, the tire can:

- Be more easily damaged leading to tire failure.
- Provide reduced traction.
- Adversely affect stability and handling.

Harley-Davidson does not perform testing with only nitrogen in tires. Harley-Davidson neither recommends nor discourages the use of pure nitrogen to inflate tires.

**India Tire Compliance Statement:** Harley-Davidson Motor Company declares that the tires listed in the specifications section (India Only) meet the Indian Standard 15627 requirement of the Bureau of Indian Standards (as amended from time to time) required for registration of vehicles assembled/manufactured in India. These tires also comply with the Central Motor Vehicle Rules requirements, 1989.

## **Gasoline Blends**

---

Your motorcycle was designed to get the best performance and efficiency using unleaded gasoline. Most gasoline is blended with alcohol and/or ether to create oxygenated blends. The type and amount of alcohol or ether added to the fuel is important.

#### **CAUTION**

**Do not use gasoline that contains methanol. Doing so can result in fuel system component failure, engine damage and/or equipment malfunction. (00148a)**

- Gasoline/METHYL TERTIARY BUTYL ETHER (MTBE) blends are a mixture of gasoline and as much as 15 percent MTBE. Gasoline/MTBE blends use in your motorcycle is approved.
- ETHANOL fuel is a mixture of ethanol (grain alcohol) and unleaded gasoline and can have an impact on fuel mileage. Fuels with an ethanol content of up to 10 percent may be used in your motorcycle without affecting vehicle performance. U.S. EPA regulations currently indicate that fuels with 15 percent ethanol (E15) are restricted from use in motorcycles at the time of this publication. Some motorcycles are calibrated to operate with higher ethanol concentrations to meet the fuel standards in certain countries.

- REFORMULATED OR OXYGENATED GASOLINES (RFG) describes gasoline blends that are specifically designed to burn cleaner than other types of gasoline. This results in fewer tailpipe emissions. They are also formulated to evaporate less when filling the tank. Reformulated gasolines use additives to oxygenate the gas. Your motorcycle will run normally using this type of fuel. Harley-Davidson recommends using it whenever possible as an aid to cleaner air in our environment.
- Do not use racing fuel or fuel containing methanol. Use of these fuels will damage the fuel system.
- Using fuel additives other than those approved for use by Harley-Davidson may damage the engine, fuel system and other components.

Some gasoline blends might adversely affect starting, driveability or fuel efficiency. If any of these problems are experienced, try a different brand of gasoline or gasoline with a higher octane blend.

## Fuel

---

Always use a good quality unleaded gasoline. Octane ratings are usually found on the pump. Refer to Octane Rating.

### WARNING

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

### WARNING

**Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00029a)**

Modern service station pumps dispense a high flow of gasoline into a motorcycle fuel tank. This can cause air entrapment and pressurization.

Octane Rating

| SPECIFICATION       | RATING      |
|---------------------|-------------|
| Pump Octane (R+M)/2 | 91 (95 RON) |

## Catalytic Converter

---

### CAUTION

**Do not operate catalytic converter-equipped vehicle with engine misfire. If you operate the vehicle under this condition, the exhaust will become abnormally hot, which can cause vehicle damage, including emission control**

loss. (00149c)

### CAUTION

**Use only unleaded fuel in catalytic converter-equipped motorcycles. Using leaded fuel will damage the emission control system. (00150b)**

Your motorcycle has catalytic converters except in Australia.

## Controls and Indicators

### General: Controls and Indicators

---

#### ⚠ WARNING

**Read the CONTROLS AND INDICATORS section before riding your motorcycle. Failure to understand the operation of the motorcycle could result in death or serious injury. (00043a)**

Some features explained are unique to certain models. These features may be available as accessories for your Harley-Davidson motorcycle. See a Harley-Davidson dealer for a complete list of accessories that will fit your specific motorcycle.

### Primary Controls

---

### Clutch Hand Lever

---

#### ⚠ WARNING

**Do not position fingers between hand control lever and handlebar grip. Improper hand positioning can impair control lever operation and cause loss of vehicle control, which could result in death or serious injury. (00032a)**

The clutch hand lever is located on the left handlebar and is operated with the fingers of the left hand.

A clutch switch is incorporated into the left handlebar switch assembly. It enables the rider to start the vehicle in any gear (or in neutral) as long as the clutch lever is pulled in. If the clutch is not disengaged and the vehicle is in gear, the vehicle will not start.

### Gear Shift Lever

---

The gear shift lever is located in front of the left rider footboard or footrest. The gear shift is operated with the left foot.

Neutral is found between first and second gear in a six speed shift pattern. See Shifting Gears.

## Front Brake Lever

---

The front brake lever operates the front brake. Operate the hand lever with the fingers of the right hand. See Brake System.

## Throttle Control Grip

---

The throttle control grip is located on the right handlebar control and is operated with the right hand.

To reduce rider fatigue on long trips, a spring-loaded throttle friction adjustment screw (10) is located at the bottom of the throttle grip clamp on non-cruise equipped models.

1. Slowly turn throttle control grip clockwise (toward the front) to close the throttle (decelerate).
2. Slowly turn throttle control grip counterclockwise (toward rear of motorcycle) to open the throttle (accelerate).

### WARNING

**Do not tighten throttle friction adjustment screw to the point where the engine will not return to idle automatically. Over-tightening can lead to loss of vehicle control, which could result in death or serious injury. (00031b)**

3. Loosen the throttle friction adjustment screw so the throttle returns to the idle position when the hand is removed from the grip.

#### NOTE:

*The throttle adjustment screw should not be used under normal stop and go operating conditions.*

4. Screw the throttle adjustment screw in to increase friction on the grip. This friction provides a damping effect on throttle motion.

## Rear Brake Pedal

---

The rear brake pedal operates the brake on the rear wheel. Operate the rear brake pedal with the right foot. See Brake System.

## Left Hand Control Switches

---

### Trip

---

See Left Hand Switch Module (typical). The trip switch (1) activates the trip odometers. The trip switch also is used to scroll through the optional screens of the odometer display. With the ignition off, the trip switch can activate time or odometer displays. Refer to Left-Hand Control Switches.

## Horn

---

See Left Hand Switch Module (typical). The horn is operated by pressing the horn switch (2). The horn can be activated for up to 10 seconds at a time. If the horn switch is held for a longer period, the horn automatically deactivates. Refer to Left-Hand Control Switches.

## High Beam

---

See Left Hand Switch Module (typical). Press the high beam switch (3) to activate the high beam. The (blue) high beam indicator lamp is lit when the high beam is on. Refer to Left-Hand Control Switches.

## Low Beam/Flash to Pass

---

**Low beam:** See Left Hand Switch Module (typical). Press the bottom of the switch to (4) activate the low beam.

**Flash to pass:** When the low beam switch is on, press and release the flash to pass switch (4) to flash the high beam before passing another vehicle. The high beam indicator lamp in the speedometer face is illuminated as long as the flash to pass switch is pressed.

When in accessory, press the flash to pass switch to activate the headlamp. Refer to Left-Hand Control Switches.

## Left Turn Signal


---

**Activate:** See Left Hand Switch Module (typical). Press the left turn signal switch (5) to activate the left turn signal. Refer to Left-Hand Control Switches.

**Cancel:** Press the left turn signal switch to cancel the left turn signal. For detailed operation, see Turn Signal Switch Operation.

*NOTE:*

*Front turn signal lamps also function as running lamps. This feature may not be available in all markets.*



**Left-Hand Control Switches**

| SWITCH | NAME                       | FUNCTION                                                                                                                                             |
|--------|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | Trip                       | Press the switch to alternate odometer displays.                                                                                                     |
|        | Horn                       | Press the switch to sound the horn.                                                                                                                  |
|        | High beam                  | Press the switch to switch the headlamp to high beam.                                                                                                |
|        | Low beam/<br>flash to pass | Press the switch to switch the headlamp to low beam.<br><br>Press and release to flash the high beam.<br><br>In ACC, press to activate the headlamp. |
|        | Left turn                  | Press the switch to signal a left turn.                                                                                                              |

## Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN


See Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN. The cruise control switch automatically controls the speed. Refer to Cruise Control Switch: FLSS, FLSTC, FLSTFBS, FLSTN. See Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN.

**Cruise:** Press the cruise switch straight in to enable cruise control. The cruise control indicator

lights orange. Pressing the switch again turns off cruise control.

**SET/-:** With cruise control enabled, press SET/- to set the cruising speed. The cruise control indicator lights green. While at cruising speed, press SET/- to decrease the regulated speed.

**RES/+:** If cruise control is disengaged (such as a braking event or rolling the throttle through the roll-off switch), press RES/+ to resume the previous cruising speed. While at cruising speed, press RES/+ to increase speed.



Cruise Control Switch: FLSS, FLSTC, FLSTFBS, FLSTN

| SWITCH | NAME   | FUNCTION                                                                                              |
|--------|--------|-------------------------------------------------------------------------------------------------------|
|        | Cruise | Press the switch to turn on cruise.                                                                   |
|        | Set    | Press the switch to set the cruise speed.<br><br>Tap the switch down to decrease speed in increments. |
|        | Resume | Press the switch to resume cruise.<br><br>Tap the switch up to increase set speed in increments.      |

### Right-Hand Control Switches

### Hazard Warning 4-Way Flasher

See Right Hand Control Module. The hazard switch (1) is used to leave a stranded motorcycle in the 4-way flashing mode. With the flashers, the motorcycle can be left with the ignition locked

until help is found. Refer to Right Hand Control Switches.

1. With the ignition switch in the IGNITION or ACC position, press on the hazard warning triangle to activate the 4-way flashers.

*NOTE:*

**Security models:** *The fob must be present when turning on the 4-way flashers and when canceling the flashers.*

2. Turn ignition off. The 4-way flashers continue for 2 hours or until cancelled by the rider.
3. To cancel, turn the ignition to ACC or IGNITION. Press the warning triangle above the start switch.

## Start

---

See Right Hand Control Module. The start switch (5) is on the right handlebar control module. Refer to Right Hand Control Switches.

1. Switch the off/run switch to the run position. Shift the transmission to neutral. The neutral (green) indicator should be illuminated. See Starting the Engine.
2. Turn ignition on. Press the start switch to operate the starter motor.

*NOTES:*

- *When the starter is activated, the headlamp is momentarily turned off to reduce battery load.*
- *If the engine does not start, the starter motor runs for five seconds and then stops. Release the start switch. Press the start switch to try again. After several unsuccessful attempts to start the engine, see a Harley-Davidson dealer.*

## Engine Off

---

See Right Hand Control Module. Press the engine off switch (2) to shut off the engine. Refer to Right Hand Control Switches.

After turning off the engine. Turn the ignition switch to OFF to disconnect the electric power.

## Engine Run

---

See Right Hand Control Module. Push the engine run switch (3) to enable engine start and run. The engine run switch must be in the run position to start or operate the engine. Refer to Right Hand Control Switches.

## Right Turn Signal


---

**Activate:** See Right Hand Control Module. Press the right turn signal switch (4) to activate the right turn signal. Refer to Right Hand Control Switches.

**Cancel:** Press the right turn signal switch to cancel the right turn signal. For detailed operation, see Turn Signal Switch Operation.

NOTE:

Front turn signal lamps also function as running lamps. This feature may not be available in all markets.



Right Hand Control Switches

| SWITCH | NAME       | FUNCTION                                                         |
|--------|------------|------------------------------------------------------------------|
|        | Hazard     | Press to activate the 4-way flashers.                            |
|        | Start      | Press to start the engine.                                       |
|        | Off        | Press to stop the engine or to prevent the engine from starting. |
|        | Run        | Press to allow the engine to start.                              |
|        | Right turn | Press to signal a right turn.                                    |

### Turn Signal Switch Operation

### Operating

Press and release the left or right turn signal switch to activate the turn signal lamps. The lamps flash until they are automatically canceled or manually canceled by the rider.

NOTE:

*If a turn signal indicator flashes rapidly, a turn signal is not operating. Exercise caution. Use hand signals. Immediately replace defective components.*

## Automatic Canceling

---

The turn signal lamps automatically cancel when a full turn has been detected based on speed, acceleration and turn completion.

The lamps also cancel if the turn signal has been activated for a prolonged period (20 flashes) while the motorcycle speed is greater than 7 mph 11 km/h . If the motorcycle is stopped or moving slower than this speed, the turn signal continues flashing.

## Manual Canceling

---

To cancel the turn signal, press and release the turn signal switch a second time.

To activate the opposite turn signal, press and release the turn signal switch for the new direction. The first turn signal cancels and the opposite turn signal lamps begin flashing.

## Ignition Switch

---

### Ignition Key

---

The ignition key locks the ignition switch to prevent unauthorized use or theft of your motorcycle.

See Ignition/Fork Lock Key. If lost, a Harley-Davidson dealer can replace the key based on a unique key number. The key number (2) is stamped on the top of the key under the plastic cover (1). Record your key number on the line provided on the Personal Information and Dealer Information page in the front of this Owner's Manual.

NOTE:

*The lamps work when the switch is in the IGNITION (IGN) position, as required by law in some localities.*

The ignition switch controls the motorcycle electrical functions. Refer to Ignition Switch Positions.

### WARNING

**The automatic-on headlamp feature provides increased visibility of the rider to other motorists. Be sure headlamp is on at all times. Poor visibility of rider to other motorists can result in death or serious injury. (00030b)**

### CAUTION

**Turn the ignition switch to the OFF position before locking the motorcycle. Leaving the switch in the ACC position will keep the instrument lights on and result in a discharged**


battery. (00492b)

### CAUTION

Protect your vehicle against theft. Failure to lock the motorcycle after parking could result in theft and/or equipment damage. (00151b)

### CAUTION

Do not lubricate barrel locks with petroleum based lubricants or graphite. Inoperative locks may result. (00152a)



#### Ignition Switch Positions

| SWITCH POSITION                                                                              | FUNCTION                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OFF                                                                                          | Ignition, lamps and accessories are off.                                                                                                                                                   |
| ACCESSORY (ACC)*                                                                             | Accessories are on. Hazard warning flashers can be operated. Instrument lamps are on. The headlamp switch can be switched between high and low beam. Brake lamp and horn can be activated. |
| IGNITION (IGN)*                                                                              | Ignition, lamps and accessories are on.                                                                                                                                                    |
| *International models have an additional function - position lamp and tail lamp are also on. |                                                                                                                                                                                            |
| NOTE: Leaving the motorcycle in ACC for an extended                                          |                                                                                                                                                                                            |

amount of time can discharge the battery. If in ACC, the motorcycle will be automatically turned OFF after two hours to prevent battery from complete discharge. To resume normal operation turn the ignition switch back to OFF and then to the desired position.


## All except FXSB

See Ignition Switch: All except FXSB. The ignition switch is on the instrument panel on top of the tank.

**Unlock:** To unlock the switch, insert key and turn clockwise to unlock position. Remove the key from ignition switch before operating motorcycle. If you do not remove key, it can fall out while riding.

**Operate:** Rotate switch to desired position. Refer to Ignition Switch Positions.

**Lock:** The switch can be locked in the OFF or ACC position. To lock the switch, raise the switch cover, insert key, and turn counterclockwise to LOCK position.




## FXSB

See Ignition Switch: FXSB. The ignition switch is on the left side of the vehicle between the engine cylinders.

**Unlock:** Insert key and turn clockwise to unlock the thumb lever. Remove the key from ignition switch before operating motorcycle. If you do not remove key, it can fall out while riding.

**Operate:** Use the thumb lever to select the ACC or IGN positions. Refer to Ignition Switch Positions.

**Lock:** Turn the thumb lever to OFF. Insert the key and turn counterclockwise to lock the thumb lever. Remove the key.



## Instruments

---

### Fuel: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FLS, FLSS

---

See Instruments: All except FXSB. The fuel gauge (1) uses a sweep indicator on a scale from F (full) to E (empty). The red end of the scale indicates a low fuel level in the tank.

## Speedometer

---

### **⚠ WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could**

## **result in death or serious injury. (00008a)**

See Instruments: All except FXSB or Instruments: FXSB. The speedometer (2) registers miles per hour (U.S. models only), kilometers per hour (international models only) or is dimensioned in both mph and km/h for required markets.

Instrument backlighting activates after a slight delay. Changes to ambient lighting, such as going through a tunnel, may briefly change backlighting.

## **Odometer**

---

Pressing the trip switch with the ignition switch in any position activates the odometer reading.

The odometer window (3) in the speedometer face also provides the following selectable displays:

- Odometer
- Trip odometer A
- Trip odometer B
- Fuel range
- Time
- Gear number
- Tachometer

Press and release the trip switch to cycle through the displays.

## **Trip Odometers A and B**

---

See Trip Odometers, Tachometer/Gear Selection. To check mileage or to reset trip odometers, the ignition switch must be in the ACC or IGN position. Press and release the trip switch (1) until the desired trip odometer register, A (2) or B (3) is displayed. An A or B in the upper left of the display window identifies the trip odometer.



To reset or zero trip odometers, have desired (A or B) odometer in display window. Press the trip switch and hold for approximately three seconds. The trip odometer resets to zero.


## **Tachometer/Gear Selection**

---

See Trip Odometers, Tachometer/Gear Selection. Press and release the trip switch to cycle through the odometer displays to select the gear number and the tachometer display. The odometer shows the current gear (1-6) and the engine speed in revolutions per minute (rpm).

When the transmission is in neutral or the clutch lever is pulled in, the gear number is blank.





## Odometer Window Displays

---

### Time

---

Press and release the trip switch to cycle through the odometer window displays to the time display. To set the time:


1. Turn ignition switch to IGNITION (IGN) or ACCESSORY (ACC).
2. See Time Displays. Press and release the trip switch (1) until time (hour and minutes) is displayed. Press and hold the trip switch until 12H (2) begins to blink in the speedometer display window. Release the switch.
3. Press and release the trip switch once to advance to a blinking 24H or military style time display. Each time you press and release the switch, the display switches between 12H and 24H.
4. When the desired time style is displayed, press and hold the trip switch until the hours display (3) is blinking.
5. Press and release the trip switch repeatedly to advance the hours.
6. When the correct hour is displayed, press and hold the trip switch until the minutes display (4) starts blinking.
7. Press and release the trip switch repeatedly to advance the minutes display.

8. When the correct minutes are displayed (5), press and hold the trip switch until the display advances to the selection of AM or PM (6).

NOTE:

*AM or PM does not appear in the regular time display. The motorcycle uses the selection for diagnostic purposes.*

9. In the 12H display, AM or PM flashes. Select AM or PM with the trip switch. Press and hold the switch for five seconds.
10. Turn ignition switch OFF.



## Fuel Range

See Odometer Window Displays. The fuel range display (1) shows the approximate mileage available with the amount of fuel left in the fuel tank.

With ignition switch in the ACC or IGN position, press the trip switch until fuel range is displayed, as indicated by the letter "R" in the left side of the display. The calculated remaining distance (miles or kilometers) to empty is displayed, based on the amount of fuel in tank. Range can be accessed at any time using the trip switch.

## Low Fuel Warning

When the low fuel warning lamp illuminates, the fuel range feature automatically displays in the odometer window. The rider can press the trip switch to return to the cycle of odometer displays. The fuel range warning is not repeated until the ignition switch is cycled off and back on.

See Odometer Window Displays. After the fuel range drops to 10 miles or 10 kilometers remaining, the fuel range display will scroll "LO RNG" (2) to indicate that the motorcycle will shortly run out of fuel.

Resetting the low fuel warning lamp and range requires an ignition cycle change. Always turn the ignition switch to OFF when fueling.

**Disable:** To disable this function while riding, press and hold the trip switch while in the fuel range display mode. The automatic range pop-up feature indicates that it is disabled when it blinks twice.

**Enable:** To enable the automatic low fuel warning range display, press and hold the trip switch. The low fuel range blinks once when the automatic feature is enabled.

*NOTE:*

- *When the low fuel warning lamp turns on, the fuel level is low. Refuel as soon as possible.*
- *The range display is only updated when the vehicle is moving.*
- *The automatic fuel range display is enabled after the ignition is turned OFF-IGN.*

## Tip Indicator

### WARNING

**If tip occurs, check all controls for proper operation. Restricted control movement can adversely affect the performance of the brakes, clutch or ability to shift, which could result in loss of vehicle control and death or serious injury. (00350a)**

See Odometer Window Displays. Should motorcycle be tipped over, the word "tIP" (3) appears in the odometer window. The engine can not start until reset.

**Reset:** To reset, set the motorcycle upright and turn the ignition switch OFF-IGN.

## No Fob Message

See Odometer Window Displays. If the motorcycle has a security system and is driven off leaving the fob behind, "NO FOB" (4) temporarily displays in the odometer window.

With the motorcycle separated from its assigned fob, the motorcycle can only be started with a manual PIN entry to disarm the security system. See Arming and Disarming.

## Sidestand Message

See Odometer Window Displays. On international (HDI) models, a "SidE StAnd" (5) message is displayed if the motorcycle is placed into gear while the jiffy stand is down. See Jiffy Stand Interlock: International Models.



1. Fuel range
2. Low range
3. Tip over
4. No fob
5. Jiffy stand down

**Odometer Window Displays**

## Instrument Lamps

---

### Sixth Gear

---

See Instrument Lamps. The sixth gear lamp (1) indicates when the transmission is in sixth gear.

### Security System

---

See Instrument Lamps. On motorcycles equipped with a security system, the security system lamp (2) illuminates when the security system is armed. See Security System.

If the security lamp remains lit after the security system is disarmed, see a Harley-Davidson dealer.

### Battery Discharge

---

See Instrument Lamps. The battery discharge lamp (3) indicates either overcharging or undercharging of the battery. See Battery Maintenance.

## Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN

---

**Solid:** See Instrument Lamps. The cruise control lamp (4) illuminates amber when cruise control is on. The lamp turns green when the cruise speed has been set and the motorcycle is at cruise speed. The lamp returns to amber if cruise is disengaged and is waiting for a resume command. See Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN.

## Low Fuel

---

**Solid:** See Instrument Lamps. The amber low fuel warning lamp (5) illuminates when the gasoline in the tank reaches the low fuel level. Refer to Capacities.

**Flashing:** If the low fuel lamp flashes continuously, it indicates the presence of a fault in the fuel level circuitry. See a Harley-Davidson dealer.

## Anti-Lock Brake System (ABS)

---

### WARNING

**If ABS lamp continues flashing at speeds greater than 3 mph (5 km/h) or remains on continuously, the ABS is not operating. The standard brake system is operational, but wheel lock up can occur. Contact a Harley-Davidson Dealer to have ABS repaired. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury. (00361b)**

**Flashing:** See Instrument Lamps. On vehicles with ABS, the ABS lamp (6) begins flashing when the vehicle is turned on. The flashing lamp indicates that the system is in self-diagnosis mode. It continues to flash until motorcycle speed exceeds 3 mph 5 km/h . ABS is not operational until the lamp turns off.

**Solid:** Continuous illumination of the lamp indicates a malfunctioning ABS system. The ABS is disabled and the brakes are operating as if they were non-ABS brakes. See a Harley-Davidson dealer for service.


## Check Engine

---

See Instrument Lamps. The check engine lamp (7) is located inside the instrument cluster. Its purpose is to indicate whether or not the engine/engine management system is operating normally. The check engine lamp color is amber.

The check engine lamp normally comes on when the ignition is first turned on and remains on for approximately 4 seconds, as the engine management system runs a series of self-diagnostics.

If the check engine lamp comes on at any other time, see a Harley-Davidson dealer.



## Indicator Lamps

See Indicator Lamps. Five indicator lamps are provided in the instrument panel.

## Turn Indicator Lamps

The turn indicators (1, 5) flash when a turn signal is activated. When the 4-way hazard flashers are operating, both turn indicators flash simultaneously.

## Headlamp High Beam Indicator Lamp

The headlamp high beam indicator lamp (2) is lit when the high beam or flash to pass switch is activated.

## Neutral Indicator Lamp

The neutral indicator lamp (3) is lit when the transmission is in neutral.

## Oil Pressure Indicator Lamp

The oil pressure indicator lamp (4) is lit when sufficient oil is not circulating through the engine.


The lamp is lit when the ignition is turned on before starting the engine. With engine running, lamp should be off when engine speed is above idle.

Circumstances that could cause the oil indicator lamp to illuminate:

- Low oil level. Stop engine immediately. Add oil.
- Diluted oil. Change oil as soon as possible.
- Incorrect oil for the operating temperature. Change oil as soon as possible.
- For further information, see Troubleshooting.

### CAUTION

**If the oil pressure indicator lamp remains lit, always check the oil supply first. If the oil supply is normal and the lamp is still lit, stop the engine at once and do not ride further until the trouble is located and the necessary repairs are made. Failure to do so may result in engine damage. (00157a)**



### Cruise Control: FLSS, FLSTC, FLSTFBS, FLSTN

### ⚠ WARNING

**Do not use the cruise control system in heavy traffic, on roads with sharp or blind curves or on slippery roads of any kind. Using the cruise control in these circumstances can cause loss of control, which could result in death or serious injury. (00083a)**

## WARNING

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

## Turn Cruise On

---

*NOTE:*

*Cruise control only works at speeds between 30-90 mph 48-90 km/h in third gear or higher.*

See Cruise Control. Press the cruise switch in to turn on cruise (1). When on, the cruise icon in the speedometer face glows amber.

## Set Cruise Speed

---

See Cruise Control. When the motorcycle reaches your intended speed, press the SET/- switch down to set the cruise speed (2). The amber cruise icon changes to green.

If necessary, adjust the cruise speed to match the speed limit or traffic conditions:

## Increase/Decrease Cruise

---

Tapping the RES/+ switch up increases speed by 1 mph 1.6 km/h . Holding up the RES/+ switch gradually increases cruise speed.

Tapping the SET/+ switch down decreases speed by 1 mph 1.6 km/h . Holding the switch down gradually decreases cruise speed.

## Disengage Cruise

---

See Cruise Control. To drop out of cruise speed, roll the throttle closed through the roll-off switch (3).

Cruise also disengages, if the rider:

- Squeezes the front brake lever or presses the rear brake pedal.
- Squeezes the clutch lever.
- Rolls the throttle open more than 10 mph 16 km/h above the set speed.

## Resume Cruise

---

*NOTE:*


*If the current speed is more than 15 mph 24 km/h below the cruise speed, cruise will not resume.*

See Cruise Control. If cruise has been disengaged yet the cruise indicator is amber, pressing the RES/+ switch up resumes cruise (4). The icon glows green. The motorcycle automatically resumes cruise at the set speed.

## Turn Cruise Off

---

Press the cruise switch in to turn off cruise control. The cruise icon goes blank.



## Electronic Throttle Control (ETC)

---

The motorcycle has an Electronic Throttle Control (ETC). Instead of using a mechanical cable connection to the throttle body, this technology uses redundant grip sensors to indicate rider requested throttle position to the Electronic Control Module (ECM). The ECM then regulates proper fuel/air intake and ignition timing based on the rider's actions.

The Electronic Control Module (ECM) monitors the status of the grip sensors, throttle plate actuation and airflow. If Trouble Codes are detected, the ECM disables cruise control, illuminates the check engine lamp and will transition to one of the following modes.

### ETC Limited Performance Mode

---

The rider experiences near-normal operation. The motorcycle operates with provisions to guard against unintended acceleration.

### ETC Power Management Mode

---

The throttle plate actuator returns to an "idle detent" or "limp-home" position, which provides enough torque to achieve speed of about 25 mph 40 km/h . The motorcycle's response to grip sensor input is reduced.

### ETC Forced Idle Mode

---

The throttle plate actuator is forced to a "fast idle" position, which provides enough torque to crawl, but not enough torque to operate at traffic speeds.

### ETC Forced Shut Down Mode

---

The engine is forced to shut down.

## Heel-Toe Shift Lever

---

See Heel-Toe Foot Shift Lever. Some motorcycles have a heel-toe shift lever. Upshifts can be made with the heel of the left foot. Upshifts and downshifts can be made with the toe.

**Downshift (toe):** Push toe shift lever all the way down (full stroke).


**Upshift (toe):** Lift the toe shift lever all the way up (full stroke).

**Upshift (heel):** Push the heel shift lever all the way down (full stroke).

Release the heel-toe shift lever after each gear change to allow the lever to return to its center position before another gear change.

*NOTE:*

*The height of the heel-toe shift lever can be adjusted for rider preference. Verify that full lever movement is available after adjustment. See the service manual.*



## Gear Shift Lever

---

### Location

---

See Shift Lever and Shift Pattern. The gear shift lever is located on the left side of the motorcycle and is operated with the left foot. The shift lever changes gears in a sequential six-speed transmission.

## Shift Pattern

---

### CAUTION


The clutch must be fully disengaged before attempting a gear shift. Failure to fully disengage the clutch can result in equipment damage. (00182a)

See Shift Lever and Shift Pattern. Each gear must be engaged in sequence. Lift the gear shift lever to upshift and press the lever to downshift. After each gear change, release the gear shift lever to allow it to return to its resting position. See Shifting Gears.

## Neutral

---

Neutral is located between first and second gear. The transmission can be shifted to neutral from either first or second gear. Lift or press the gear shift lever one-half of its stroke. In neutral, the indicator lamp will light.



## Brake System

---

## Front Brake Lever

---

### ⚠ WARNING

Do not position fingers between hand control lever and handlebar grip. Improper hand positioning can impair control lever operation and cause loss of vehicle control,


**which could result in death or serious injury. (00032a)**

See Brake Controls. The front brake hand lever (1) controls the front wheel brake. The brake lever is located on the right handlebar. Operate the hand lever with the fingers of the right hand.

## Rear Brake Pedal

---

See Brake Controls. The rear brake pedal (2) controls the rear wheel brake. The brake pedal is located on the right side. Operate the rear brake pedal with the right foot.



## Non-ABS Brake System

---

Apply brakes uniformly and evenly to prevent wheels from locking. Use front and rear brakes equally for best results.

### **⚠ WARNING**


**Do not apply brake strongly enough to lock the wheel. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury.**

## Anti-lock Brake System (ABS)

---

Harley-Davidson's anti-lock brake system assists the rider in maintaining control when braking in a straight-line emergency situation. ABS operates independently on front and rear brakes to keep the wheels rolling and prevent uncontrolled wheel lock-ups either on dry pavement or on slick surfaces such as gravel, leaves or when riding in wet conditions.

See ABS Module (HCU). Models with ABS have ABS module (HCU).



## How ABS Works

---

The ABS monitors sensors at the front and rear wheels to determine wheel speed. If the system detects one or both wheels are slowing down too quickly, which indicates they are close to locking, the ABS reacts. If the deceleration rate does not match a criteria stored in memory, the ABS also reacts. The system rapidly opens and closes valves to modulate the brake caliper pressure utilizing only the brake lever/pedal pressure being applied by the rider. During ABS activation, the system provides the electronic equivalent of manually pumping the brakes. ABS is capable of cycling up to seven times per second.

The rider recognizes ABS activation by the slight pulsing sensation in the hand lever or the rear brake pedal. The pulsing sensation may also be accompanied by a clicking sound from the ABS module. Both are the result of normal operation. Refer to ABS Symptoms and Conditions.

## How To Use ABS

While an advantage in emergency braking, ABS is not a substitute for safe riding. The safest way to stop a motorcycle is upright with both wheels straight.

Harley-Davidson ABS is a manual assist system. When stopping in an emergency stopping situation, maintain pressure on the brakes through all ABS events. Do not modulate or "pump" the brake controls. The wheels do not lock until the end of the stop when motorcycle speed reaches approximately 4 mph 6 km/h and ABS is no longer needed.

### **⚠ WARNING**

**ABS cannot prevent lockup of rear wheel due to engine braking. ABS will not aid in cornering or on loose/uneven surfaces. A locked wheel will skid and can cause loss of vehicle control, which could result in death or serious injury. (00362a)**

## **ABS: Tires and Wheels**

Motorcycles equipped with ABS must always use Harley-Davidson tires and wheels. The ABS monitors the rotational speed of the wheels through individual wheel speed sensors. Changing to different diameter wheels or different-sized tires can alter the rotational speed. This can upset the calibration of the ABS and have an adverse effect on its ability to detect and prevent uncontrolled wheel lockups. Operating at tire pressures other than those specified in ABS Symptoms and Conditions can reduce ABS braking performance.

**ABS Symptoms and Conditions**

| <b>SYMPTOM</b>                                   | <b>CONDITION</b>                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ABS lamp continuously lit                        | ABS malfunction detected. See a Harley-Davidson dealer for service.                                                                                                                                                                                                                                                                                                                                       |
| ABS lamp flashing                                | This indicates a normal self-diagnostics process when the motorcycle is first turned on and the speed is under 3 mph 5 km/h . ABS is not operational until the lamp turns off. If the lamp continues flashing at speeds greater than 3 mph 5 km/h , see a Harley-Davidson dealer for service.                                                                                                             |
| Pulsing brake lever or pedal during an ABS event | Normal condition.                                                                                                                                                                                                                                                                                                                                                                                         |
| Clicking sound during an ABS event               | Normal condition.                                                                                                                                                                                                                                                                                                                                                                                         |
| "Surge" sensation while braking                  | Normal condition. This is most noticeable when braking with one brake (front only or rear only). Result of a reduction in deceleration which can be caused by cracks or bumps in road, engine braking (high engine RPMs causing the rear wheel to slow down), hard braking at slow speeds, and other conditions. This is due to ABS modulating caliper brake pressure to prevent uncontrolled wheel lock. |
| Temporarily stiff rear                           | Normal condition. Engine braking (high engine RPMs causing the rear wheel to slow down) or down shifting can activate ABS. If applying the rear brake at the                                                                                                                                                                                                                                              |

|                         |                                                                                                                                                                                                |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| brake pedal             | same time or immediately after, the ABS may be closing a valve to prevent pressure to the rear brake. This is due to ABS modulating caliper brake pressure to prevent uncontrolled wheel lock. |
| Tire chirp              | Normal condition. Depending on surface, tire can chirp without locking the wheel.                                                                                                              |
| Black mark on pavement  | Normal condition. Depending on surface, tire can leave a black mark without locking the wheel.                                                                                                 |
| Wheel lock at low speed | Normal condition. ABS does not activate on front wheel below 3 mph 5 km/h or on rear wheel below 5 mph 8 km/h .                                                                                |

## Jiffy Stand

---

### **⚠ WARNING**

**Always park motorcycle on a level, firm surface. An unbalanced motorcycle can fall over, which could result in death or serious injury. (00039a)**

The jiffy stand is located on the left side of the motorcycle. The stand swings outward to support the motorcycle for parking.

### **⚠ WARNING**

**The jiffy stand locks when placed in the full forward (down) position with vehicle weight on it. If the jiffy stand is not in the full forward (down) position with vehicle weight on it, the vehicle can fall over which could result in death or serious injury. (00006a)**

### **⚠ WARNING**

**Be sure jiffy stand is fully retracted before riding. If jiffy stand is not fully retracted, it can contact the road surface causing a loss of vehicle control, which could result in death or serious injury. (00007a)**

## Jiffy Stand Interlock: International Models

---

Some international models have a jiffy stand interlock.

The motorcycle will start and run with the jiffy stand down while the transmission is in neutral. If the jiffy stand is down, the transmission is in gear and the clutch is released, the vehicle will stall. The message "SidE StAnd" will scroll across the odometer to indicate this to the rider. Raising the jiffy stand (or putting the transmission in neutral) will permit the engine to run and clear the message.

If the jiffy stand falls out of the fully retracted position while riding at speeds greater than 10 mph 15 km/h , then the jiffy stand interlock will maintain engine operation and alert the rider about this

by illuminating the indicators (flash twice) and scroll the message "SidE StAnd" across the odometer. The message will remain until the system detects the jiffy stand in the fully retracted position.

If the motorcycle is in a safe condition, the rider can clear the text message by pressing the TRIP switch once while the motorcycle is powered up.

## Rear View Mirrors

---

### WARNING

**Objects in mirrors are closer than they appear. Use caution when judging distance of objects in mirrors. Failure to judge correct distances could result in death or serious injury. (00033a)**

Your motorcycle has two convex rear view mirrors.

This type of mirror is designed to give a much wider view to the rear than a flat mirror. However, cars and other objects seen in this type of mirror look smaller and farther away than they actually are.

- Use caution when judging the size or relative distance of objects seen in rear view mirrors.
- Always adjust the rear view mirrors to reflect the area behind the motorcycle before riding.

#### NOTE:

*Adjust mirrors so you can see a small portion of your shoulders in each mirror. This will help you establish the relative distance of vehicles to the rear of your motorcycle.*

## Fuel Filler Cap

---

## Fuel Gauge

---

See Fuel Tank. Some models have a fuel gauge on the left side of the tank. The fuel gauge is not removable.

The fuel range feature can also be used to determine the remaining fuel. See Instruments.

## Fuel Filler Cap

---

### WARNING

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

See Fuel Tank. Turn fuel filler cap counterclockwise to remove. The cap turns approximately three-quarters of a turn before it begins to loosen.

Turn fuel filler cap clockwise until it clicks to install. The ratchet action of the cap prevents over-tightening.

See SAFE OPERATING RULES section and review the following safety alerts.

**⚠ WARNING**

**Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)**

**⚠ WARNING**


**Do not use aftermarket fuel caps. Aftermarket fuel caps may fit improperly and leak, which could lead to death or serious injury. See a Harley-Davidson dealer for approved fuel caps. (00034a)**

**CAUTION**

**Do not spill fuel onto the motorcycle while refueling. Immediately wipe up fuel spills on your motorcycle. Fuel can cause damage to cosmetic surfaces. (00147b)**

**CAUTION**

**Use only unleaded fuel in catalytic converter-equipped motorcycles. Using leaded fuel will damage the emission control system. (00150b)**



## Locking Fuel Filler Cap (Japan and Asia Pacific)

---

## Replacement Keys

---

Find the four-digit key number stamped on the back of the key opposite the H-D logo. Write the ignition key number in the space provided at the front of this manual. With that number, your Harley-Davidson dealer can order a replacement.

## Removal

---

1. See Locking Fuel Filler Cap. Rotate the lock cover to access the key lock.
2. Insert the key.
3. Hold the fuel filler cap in place. Turn the key counterclockwise until it stops.
4. Turn key back to its original position. Remove the key.
5. Turn cap counterclockwise until resistance is felt. Continue to turn cap counterclockwise to remove cap.

## Installation

---


1. See Locking Fuel Filler Cap. Insert the key into the lock.
2. To make sure that the cap is unlocked, firmly, hold the cap. Turn the key counterclockwise until it stops.

3. Allow the key to return to a neutral position. Remove the key.

NOTE:

*When installing the fuel cap, rotate the cap one full turn past the audible click.*

4. Turn the cap clockwise to install the fuel cap.
5. Close the lock cover.



## Fork Lock

### ⚠ WARNING

Do not operate vehicle with forks locked. Locking the forks restricts the vehicle's turning ability, which could result in death or serious injury. (00035a)

### CAUTION

Protect your vehicle against theft. Failure to lock the motorcycle after parking could result in theft and/or equipment damage. (00151b)

### CAUTION

Do not lubricate barrel locks with petroleum based lubricants or graphite. Inoperative locks may result. (00152a)


See Fork Lock. The fork lock is located in the steering head on the right side. The fork is locked with the ignition key.

Using the fork lock immediately after parking your motorcycle will discourage unauthorized use or theft.

## To Lock Fork

---

1. Turn fork to full left position.
2. Insert key into fork lock.
3. Push in on fork lock and turn to left position.
4. Remove key.



## Shock Absorbers

---

### Calculate Number of Preload Turns

---

The rear shock spring preload is pre-set to the total load. It can be varied to suit your own personal comfort.

*NOTE:*

*To determine the motorcycle configuration for an FLS or FLSTFB, check the configuration/calibration character stamped on the VIN. Refer to Harley-Davidson VIN Breakdown: 2016 Softail Models.*

1. Identify the number of preload turns for the weight of the rider.

- a. **FLSTC, FLSTF, FLS (APC, AUS), FLSTFB (HDI, ENG, IND, BRZ):** Refer to Shock Preload: FLSTC, FLSTF, FLS (APC, AUS), FLSS (AUS), FLSTFB (HDI, ENG, IND, BRZ), FLSTFBS (HDI, ENG).
- b. **FXSB, FLSTN, FLS (all except APC/AUS), FLSTFB (all except HDI, ENG, IND, BRZ):** Refer to Shock Preload: FXSB, FLSTN, FLS (all except APC, AUS), FLSS (all except AUS), FLSTFB (all except HDI, ENG, IND, BRZ), FLSTFBS (all except (HDI, ENG)).

2. Calculate the number of turns for the intended passenger and cargo.

3. Add the number of turns for the rider to the number of turns required for the total weight of the passenger and/or cargo.

**Shock Preload: FLSTC, FLSTF, FLS (APC, AUS), FLSS (AUS), FLSTFB (HDI, ENG, IND, BRZ), FLSTFBS (HDI, ENG)**

| RIDER WEIGHT*                                                                                                                             | TURNS** |
|-------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Less than 165 lb 75 kg                                                                                                                    | 0       |
| 165-220 lb 75-100 kg                                                                                                                      | 1       |
| 220-275 lb 100-125 kg                                                                                                                     | 2       |
| 275-335 lb 125-152 kg                                                                                                                     | 3       |
| 335-395 lb 152-179 kg                                                                                                                     | 4       |
| 395 lb 179 kg to maximum added weight allowed (refer to Weights: FLSTC, FLSTF, FLSTFB, FLSTFBS and FLSTN and Weights: FLS, FLSS and FXSB) | 5       |
| * <b>Passenger/Cargo:</b> For every 40 lb 18.1 kg increase preload one turn.                                                              |         |
| ** Turns out (counterclockwise) from minimum preload.                                                                                     |         |

**Shock Preload: FXSB, FLSTN, FLS (all except APC, AUS), FLSS (all except AUS), FLSTFB (all except HDI, ENG, IND, BRZ), FLSTFBS (all except (HDI, ENG))**


| RIDER WEIGHT*                                                                                                                             | TURNS** |
|-------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Less than 185 lb 84 kg                                                                                                                    | 0       |
| 185-235 lb 84-107 kg                                                                                                                      | 1       |
| 235-285 lb 107-129 kg                                                                                                                     | 2       |
| 285-340 lb 129-154 kg                                                                                                                     | 3       |
| 340 lb 154 kg to maximum added weight allowed (refer to Weights: FLSTC, FLSTF, FLSTFB, FLSTFBS and FLSTN and Weights: FLS, FLSS and FXSB) | 4       |
| * <b>Passenger/Cargo:</b> For every 35 lb 15.8 kg increase preload one turn.                                                              |         |
| ** Turns out (counterclockwise) from minimum preload.                                                                                     |         |

## Adjustment

---

### NOTES:

- *Adjust the shocks with the motorcycle resting on the jiffy stand.*
  - *Adjust both shocks the same number of turns.*
1. See Shock Absorber Adjustment. Hold the shaft with a wrench on the flats (3) and loosen the jamnut (1).
  2. Use the tangs of the SHOCK ADJUSTMENT SPANNER 94448-82B (4) in the holes (2) in the rear shock canister to turn the canister clockwise until it stops. This position is the minimum rider weight position.
  3. Mark the face of the canister for reference.
  4. Turn the canister counterclockwise the number of turns calculated for the total load.
  5. Tighten the jamnut.



## Saddlebag Operation: FLSTC

---

### Open

---

See Saddlebag Quick Disconnect. To use the quick disconnect strap feature:

1. Lift the strap end to expose the quick release buckle.
2. Press on the lock tabs as shown.

*NOTE:*

*The straps can also be opened and closed using the buckle in a conventional manner.*


## Close

---

1. Insert the male strap end into the receptacle on the bag.
2. Push until a positive click is heard.

### CAUTION

**Check that saddlebag frame(s) are fully seated and tightly secured with mounting hardware. Failure to do so could result in the saddlebags becoming detached and/or damaged. (00171b)**



## Saddlebags: FLSTC

---

### ⚠ WARNING

**See the Accessories and Cargo section in your owner's manual. Improper cargo loading or accessory installation can cause component failure and adversely affect stability, handling and performance, which could result in death or serious injury. (00021b)**

### **CAUTION**

**Check that saddlebag frame(s) are fully seated and tightly secured with mounting hardware. Failure to do so could result in the saddlebags becoming detached and/or damaged. (00171b)**

## **Removal**

---

1. See Saddlebag Assembly: FLSTC. Unbuckle the saddlebag straps.
2. Use one hand to support the saddlebag and another hand to remove the flanged locknuts and washers (1) from the saddlebag mounting studs (2).
3. Remove acorn nut and washer (5) and the saddlebag from the saddlebag mounting bracket (4).
4. If operating the motorcycle without the saddlebags, remove and store the nylon retaining washer (6) and the carriage bolt (7) from the saddlebag mounting bracket.

## **Installation**


---

1. See Saddlebag Assembly: FLSTC. If removed, install the saddlebag mount carriage bolt (7) and retaining washer (6).
2. Align the saddlebag with the mounting holes on the fender support.
3. Push the mounting studs (2) through the saddlebag mounting holes.
4. Install fasteners:
  - a. Install flanged locknuts and washers (1).
  - b. Install washer and acorn nut (5) over the saddlebag mounting bracket.
  - c. Tighten to 15-18 ft-lbs (20.3-24.4 Nm).
5. Buckle saddlebag straps.

### **⚠ WARNING**

**Do not allow passenger to use saddlebags as grab handles. Failure to use a grab strap, designed for passengers to hold onto when riding, could result in death or serious injury. (00081a)**

For proper saddlebag maintenance, see Leather and Vinyl Care.



## Windshield: FLSTC

### Removal


1. See Windshield Assembly. Insert your fingers into the wireform latch springs (2) at either side of the windshield (1) and move the top of the windshield assembly forward, until the top bracket notches slide away from the grommets (3).
2. Carefully lift the windshield bracket bottom notches off the bottom grommets. Remove windshield.

### Installation

1. See Windshield Assembly. Insert your fingers into the wireform latch springs at either side of the windshield and slide the bottom windshield bracket notches onto the bottom grommets.
2. Slide the top bracket notches onto the top grommets.

NOTE:


*For proper windshield maintenance, see Windshield Care.*



### **Auxiliary/Fog Lamps: FLSTC, FLSTN**

See Auxiliary/Fog Lamp Switch. The auxiliary/fog lamp switch is on the left steering head panel. Turn on the auxiliary/fog lamps as needed.

Based on legal requirements, an authorized Harley-Davidson dealer can configure the auxiliary/fog lamps to turn on or off with the high beam.




## Side-Mounted License Plate

---

See Side-Mounted License Plate Assembly. Some models have a side-mounted license plate assembly. The license plate must be in the extended position during operation. This feature may not be available in all markets.

The side-mounted license plate assembly includes an LED lamp module. If the LED lamp fails, see a Harley-Davidson dealer for assembly replacement.



## Security System

### Security System

---

### Components

---

The security system consists of a control module, a hands-free antenna and a hands-free fob carried by the rider/passenger.

After parking the motorcycle, turn the ignition to OFF or ACCESSORY and the security system will automatically **arm** within five seconds. While armed, the starter and ignition are disabled and the rider can leave the motorcycle knowing that the module disables the ignition if someone tampers with the ignition switch or activates an alarm if someone attempts to move the motorcycle.

If the fob is present, the module automatically **disarms** when the ignition is turned to IGNITION or ACCESSORY.

#### NOTES:

- If disconnecting the battery, see *Disconnecting Power* to prevent the optional security system siren from sounding.
- Do not relocate the module or the antenna.

### Options

---

See a Harley-Davidson dealer or [www.harley-davidson.com](http://www.harley-davidson.com) for security system options.

- Smart Siren II.
- Security Pager and Security Pager Receiver II.
- Replacement fobs.

## FCC Regulations

---

FCC ID: L2C0027TR IC ID: 3432A-0027TR

FCC ID: L2C0028TR IC ID: 3432A-0028TR

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

*NOTE:*

*Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

## Security System Fob

---

## Fob Assignment

---

See Fob: Security System. Fobs are electronically assigned to the security system by a Harley-Davidson dealer. Up to two fobs can be assigned at any one time.

*NOTES:*

- *The reusable label found on the fob packaging lists the serial number of the fob. For reference, affix the label to a blank "NOTES" page in this Owner's Manual.*
- *The serial number of the fob is also found on the inside of the fob. See Fob Battery.*
- *The module will arm only if the fob has been assigned by a Harley-Davidson dealer and a personal identification number (PIN) has been entered in the system. Write the PIN on the personal information page in the front of this owner's manual and on the removable wallet card.*
- *If the fob is misplaced or the fob fails, refer to the wallet card and use the PIN to manually disarm the system. See Arming and Disarming and Troubleshooting.*
- *The rider can change the PIN at any time. See Personal Identification Number (PIN).*

## Riding with a Fob

---


- Always carry the fob when riding, loading, fueling, moving, parking or servicing the motorcycle. Carry the fob in a convenient pocket.
- Do not leave the fob attached to the handlebars or store the fob in a luggage compartment. Unintentionally leaving the fob with the motorcycle when it is parked prevents the system from activating the alarm.
- Do not ride with the fob stored in a metal case or with the fob closer than 3.0 in 76 mm to a

mobile phone, display or other electronic device. Any electromagnetic interference may prevent the fob from disarming the system.

- For added security, always lock the fork and remove the key when parked. If the fob is within range and the motorcycle is unlocked, tampering with the motorcycle will not activate the alarm.

## Riding without a Fob

If the motorcycle is ridden off without the fob, the odometer window temporarily displays "NO FOB." To restart a motorcycle without a fob, disarm the security system with the PIN.



## Personal Identification Number (PIN)

The personal identification number (PIN) is a number that can be used to disarm the security system. Use the PIN in case the assigned fob is misplaced, fails or if the fob cannot communicate with the motorcycle because of electromagnetic interference.

A PIN is a five-digit number (1-9, no zeros).

## Changing the PIN

The rider can change the PIN at any time. Refer to Changing the PIN.

Changing the PIN

| STEP | ACTION | WAIT FOR CONFIRMATION | NOTES |
|------|--------|-----------------------|-------|
|------|--------|-----------------------|-------|

| NO. |                                                                                                                                         |                                                                                                             |                                                                                |
|-----|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
| 1   | Select a 5-digit (1 thru 9) PIN and record on the wallet card from owner's manual.                                                      |                                                                                                             |                                                                                |
| 2   | With an assigned fob present, turn the engine stop switch to <b>OFF</b> .                                                               |                                                                                                             |                                                                                |
| 3   | Turn the ignition switch to <b>IGN</b> .                                                                                                |                                                                                                             |                                                                                |
| 4   | Cycle the OFF/RUN switch twice:<br><b>RUN - OFF - RUN - OFF - RUN</b> .                                                                 |                                                                                                             |                                                                                |
| 5   | Press <b>left</b> turn signal switch <b>two times</b> .                                                                                 | ENTER PIN will scroll through the odometer window.                                                          |                                                                                |
| 6   | Press <b>right</b> turn signal switch <b>one time</b> and release.                                                                      | Turn signals will flash three times. Current PIN will appear in odometer. The first digit will be flashing. |                                                                                |
| 7   | Enter first digit of new PIN by pressing and releasing the <b>left</b> turn signal switch until the selected digit appears.             |                                                                                                             |                                                                                |
| 8   | Press <b>right</b> turn signal switch <b>one time</b> and release.                                                                      | The new digit will replace the current in odometer window.                                                  |                                                                                |
| 9   | Enter second digit of selected PIN by pressing and releasing the <b>left</b> turn signal switch until the selected digit is present.    |                                                                                                             |                                                                                |
| 10  | Press <b>right</b> turn signal switch <b>one time</b> and release.                                                                      | The new digit will replace the current in odometer window.                                                  |                                                                                |
| 11  | Enter third digit of the selected PIN by pressing and releasing the <b>left</b> turn signal switch until the selected digit is present. |                                                                                                             |                                                                                |
| 12  | Press <b>right</b> turn switch <b>one time</b> and release.                                                                             | The new digit will replace the current in odometer window.                                                  |                                                                                |
| 13  | Enter fourth digit of new PIN by pressing and releasing the <b>left</b> turn signal switch until the selected digit is present.         |                                                                                                             |                                                                                |
| 14  | Press <b>right</b> turn switch <b>one time</b> and release.                                                                             | The new digit will replace the current in odometer window.                                                  |                                                                                |
| 15  | Enter fifth digit of the new PIN by pressing and releasing the <b>left</b> turn signal switch until the selected digit is present.      |                                                                                                             |                                                                                |
| 16  | Press <b>right</b> turn switch <b>one time</b> and release.                                                                             | The new digit will replace the current in odometer window.                                                  |                                                                                |
| 17  | Turn the engine stop switch <b>OFF</b> , then turn the ignition switch to <b>OFF</b> .                                                  |                                                                                                             | Pushing the engine stop switch to <b>OFF</b> stores the new PIN in the module. |

## Security Status Indicator

---

See Instrument Lamps. The security lamp in the speedometer face indicates the status of the security system.

- **Armed:** A lamp that blinks approximately every three seconds indicates that the system is armed.
- **Disarmed:** After the system disarms and the ignition is on, the lamp will remain illuminated for approximately four seconds and then turn off.
- **Service:** A lamp that remains illuminated longer than four seconds when the system is disarmed indicates that service of the module is required.

## Arming and Disarming

---

### Arming

---

When the motorcycle is parked and the ignition is turned to OFF or ACCESSORY, the security system arms automatically within five seconds if no motion is detected. Even when the fob is present, the system arms.

On arming, the turn signals flash twice and the optional siren chirps twice if the siren is in the chirp mode. While armed, the indicator lamp in the speedometer face flashes every three seconds.

*NOTE:*

**International models:** *The system must be in the chirp mode for the siren to chirp on arming or disarming. See Siren Chirp Mode (Confirmation).*

### Disarming

---

With the fob present, the rider may ride or move the motorcycle for parking, storage or service without setting off the alarm. Disarming is automatic as long as the fob is within range.

**Fob:** An armed security system is automatically disarmed when the fob is present and the motorcycle is moved or the ignition switch is turned to IGNITION or ACCESSORY. The range of the fob is 5 ft 1.5 m .

When the system disarms, the optional siren chirps once and the security indicator lamp illuminates for a solid four seconds and then turns off.

*NOTE:*

*On any motion, like lifting the motorcycle up off its jiffy stand or turning the ignition to ON, the system will electronically "poll" for the presence of the fob. If the fob is present, the system disarms.*

**Personal identification number (PIN):** If the fob is misplaced or if the present fob fails to communicate, the system can be disarmed with the personal identification number (PIN). Refer to Entering a PIN to Disarm Security System.

### Disarming with a PIN

Disarm the security system manually using the PIN if the fob is lost, the fob battery is discharged or if where you parked there is a strong electromagnetic interference.

Do not turn handlebars, straddle seat or lift motorcycle off the jiffy stand. During a PIN disarm, if the security system detects motorcycle motion the system will activate the alarm.

**NOTES:**

- *If a mistake is made while entering PIN, turn the ignition switch to OFF before entering the last digit and then start the procedure from the beginning.*
- *If the procedure fails to disarm the security system, wait two minutes before attempting another PIN disarm.*
- *The security system remains disarmed until the ignition is turned to OFF.*
- *At any time during a PIN disarm if the fob is brought within range, the security system disarms as the module receives the coded signal from the fob.*

**Entering a PIN to Disarm Security System**

| STEP NO. | ACTION                                                                                                           | WAIT FOR CONFIRMATION                                                                                                                           | NOTES                              |
|----------|------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| 1        | If necessary, verify the current 5-digit PIN.                                                                    |                                                                                                                                                 | Should be recorded on wallet card. |
| 2        | Turn ignition to <b>IGN</b> .                                                                                    | If armed, the odometer window display will read: ENTER PIN and the security lamp will be flashing at a fast rate. The headlight will not be on. |                                    |
| 3        | Press and release the left turn signal switch.                                                                   | In the odometer window, a flashing 1 will appear.                                                                                               |                                    |
| 4        | Advance the digit by tapping the left turn signal until the odometer window displays the first digit of the PIN. | The first digit in the odometer will be the first digit in the PIN.                                                                             |                                    |
| 5        | Press <b>right</b> turn switch <b>1 time</b> .                                                                   | The first digit is stored and the next digit will flash.                                                                                        | Serves as enter key.               |
| 6        | Advance the second digit using the left turn switch until the digit reaches the second digit of the PIN.         | The second digit in the odometer will be the second digit in the PIN.                                                                           |                                    |
| 7        | Press <b>right</b> turn switch <b>1 time</b> .                                                                   | The second digit is stored and the next dash will flash.                                                                                        | Serves as enter key.               |
| 8        | Advance the third digit using the left turn switch until it reaches the third digit of the PIN.                  | The third digit in the odometer will be the third digit in the PIN.                                                                             |                                    |
| 9        | Press <b>right</b> turn switch <b>1 time</b> .                                                                   | The third digit is stored and the next dash will flash.                                                                                         | Serves as enter key.               |
| 10       | Advance the fourth digit using the left turn switch until it reaches the fourth digit of the PIN.                | The fourth digit in the odometer will be the fourth digit in the PIN.                                                                           |                                    |
| 11       | Press <b>right</b> turn switch <b>1 time</b> .                                                                   | The fourth digit is stored and the next dash                                                                                                    | Serves as                          |

|    |                                                                                                 |                                                                               |                              |
|----|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|------------------------------|
|    |                                                                                                 | will flash.                                                                   | enter key.                   |
| 12 | Advance the fifth digit using the left turn switch until it reaches the fifth digit of the PIN. | The fifth digit in the odometer will be the fifth digit in the PIN.           |                              |
| 13 | Press <b>right</b> turn switch <b>1 time</b> .                                                  | The fifth digit is stored. The security system indicator lamp stops blinking. | Security System is disarmed. |

## Alarm

---

## Ignition Disabled

---

When the fob is not present and the system is armed, if the ignition switch is turned to IGNITION or ACCESSORY, the security lamp will flash at a fast rate and the odometer window display will scroll "ENTeR PIN". The headlamp will not turn on.

After approximately 10 seconds, if the system does not receive a left turn signal switch input, the display will go blank. The ignition system will remain disabled until the fob is present or the current PIN is entered.

## Warnings

---

Once armed, if the motorcycle is moved or lifted up off of its jiffy stand and the fob is not present, the alarm will warn the operator with three alternate flashes of the turn signals and a chirp of the optional siren.

Within four seconds, if the motorcycle is back on its jiffy stand and no further motion is detected and/or the ignition is turned to OFF, the system will remain armed without activating the alarm.

If the motorcycle motion continues, the system will issue a second warning four seconds after the first.

*NOTE:*

*During warnings and alarms, the starter motor and the ignition circuits are disabled.*

## Alarm Activation

---

If the security system is still detecting motion and/or if the ignition has not been turned back to OFF after a second warning, the system will activate the alarm.

When activated, the security system will:

- Alternately flash the four turn signals.
- Sound the optional siren.

**Duration:** The alarm will stop within 30 seconds and if no motion is detected, the alarm will not restart.

However, if motorcycle motion continues, the system will repeat the 30 second alarm and recheck

for motion. The alarm will repeat this 30 second alarm cycle for five minutes (10 cycles) or until the alarm is deactivated.

*NOTE:*

*The alarm will also activate the LED, vibration or audible modes of a Harley-Davidson security pager. A pager can operate either in silent or in combination with an optional siren. The range of a pager can be up to 0.5 mi 0.8 km . See a Harley-Davidson dealer for details.*

## Deactivate Alarm

---

- **Key fob:** Bring the fob to within 5 ft 1.5 m of the motorcycle. After the module identifies that the fob is present, the system will terminate the alarm.
- **PIN entry:** Enter the PIN to deactivate the alarm. If an error is made while entering the PIN, wait until the alarm is between cycles to enter the PIN.

## Siren Chirp Mode (Confirmation)

---

### Chirp Mode

---

In chirp mode, the siren sounds two chirps when arming, and a single chirp when disarming.

### Chirpless Mode

---

In chirpless mode, the siren does not chirp on arming or disarming.

The siren still provides warning chirps and sounds the alarm if motorcycle is moved or ignition switch is turned on without the fob present.

## Switching Modes

---

Quickly cycling ignition switch ON-OFF-ON-OFF-ON switches the system from one mode to the other.

1. With the fob present, turn the ignition switch to IGNITION.
2. When the security lamp turns off, turn the ignition switch to OFF.
3. When the security lamp turns off (but before the turn signals flash twice), immediately turn the ignition switch to IGNITION.
4. When the security lamp turns off, immediately turn the ignition switch to OFF.
5. When the security lamp turns off (but before the turn signals flash twice), immediately turn the ignition switch to IGNITION.

## Transport Mode

---

When transporting the motorcycle, place the system in the transport mode. Otherwise, the alarm activated by motion detection can discharge the battery.

In the transport mode, the security system is armed without enabling the motion detector for one ignition cycle. This allows the vehicle to be picked up and moved in an armed state. However, any attempt to start the engine when the fob is not within range will trigger the alarm.

## To Enter Transport Mode

---

1. With an assigned fob within range, turn the ignition switch to IGNITION.
2. Before the security lamp goes out, turn the ignition switch to OFF.
3. Within three seconds, simultaneously press both the left and the right turn signal switches.
4. After the turn signals flash once, the system enters the transport mode. With the fob removed, the motorcycle can be moved without setting off the alarm.

## To Exit Transport Mode

---

With the fob present, turn the ignition switch to IGNITION to disarm the system.

## Storage and Service Departments

---

### Long-Term Parking

---

To maintain arming, store the fob beyond the range of the antenna. The antenna range is approximately 5 ft 1.5 m . Have the fob present before moving parked motorcycle.

If the motorcycle will not be operated for several months, such as during the winter season, see Motorcycle Storage.

### Service Departments

---

When the motorcycle is left at a Harley-Davidson dealer, there are two options:

1. Leave an assigned fob with the dealer.
2. To maintain possession of the fob, ask the dealer to disable the system for service (service mode) before leaving the dealership.

### Fob Battery

---


### Replacing the Battery

---

Replace the fob battery every year.

1. See Fob Battery. Slowly turn a thin blade in the thumbnail slot (1) on the side of the fob to separate the two halves.
2. Remove the battery (2) and discard.
3. Install a **new** battery (Panasonic 2032 or equivalent) with the positive side down.

4. Align the two halves of the fob. Snap the halves together.



## Disconnecting Power

---

## Siren Equipped Models

---

When disconnecting the battery or removing the main fuse, perform the following steps to prevent the optional siren from sounding.

1. Verify that the fob is present.
2. Turn the ignition switch to IGNITION.
3. Pull the main fuse from its holder or disconnect the battery.

*NOTE:*

*Place the ignition switch in the OFF position before installing the main fuse.*

## Troubleshooting

---

## Security System Indicator

---

If the system indicator lamp stays illuminated while riding, see a Harley-Davidson dealer.

## Fob

---

If the security system continues to actuate warnings and alarms with the fob present, check for:

1. **Electromagnetic interference:** Other electronic devices, power lines or other electromagnetic sources can cause the security system to operate inconsistently.
  - a. Verify that the fob is not in a metal enclosure or within 3.0 in 76 mm of any other electronic devices.
  - b. Place the fob on the seat and turn the ignition to IGN. After the system disarms, return the fob to a convenient location.
  - c. Move motorcycle at least 15 ft 5 m from the spot of interference.
  - d. Use the PIN to disarm the system.

NOTE:

*Leaving a fob next to a computer monitor can run down the battery.*

2. **Discharged fob battery:** Use the PIN to disarm the system. Replace the battery. See Fob Battery.
3. **A damaged fob:** Use the PIN to disarm the motorcycle. Replacement fobs are available for purchase from a Harley-Davidson dealer.

## Siren

---

- If the siren does not chirp two or three times on a valid arming command from the security module, the siren is either in the chirpless mode, not connected, not working, or the siren wiring was opened or shorted while the siren was disarmed.
- If the siren is armed and the internal siren battery is dead, shorted, disconnected, or has been charging for a period longer than 24 hours, the siren will respond with three chirps on arming instead of two.
- The internal siren battery may not charge if the vehicle's battery is less than 12.5 volts.
- If the siren enters the self-driven mode where it is powered from the siren's internal 9 volt battery, the turn signal lamps may or may not alternately flash. If the security module activates the siren, the turn signal lamps will alternately flash. If the siren has been armed and a security event occurs, and the siren is in self-driven mode, the siren will alarm for 20-30 seconds and then turn off for 5-10 seconds. This alarm cycle will be repeated ten times if the siren is in the self-driven mode.

## Operation

### Operating Recommendations

---

#### WARNING

**Motorcycles are different from other vehicles. They operate, steer, handle and brake differently. Unskilled or improper use could result in loss of control, death or**

**serious injury. (00556c)**

- Take a rider training course.
- Read owner's manual before riding, adding accessories or servicing.
- Wear a helmet, eye protection and protective clothing.
- Never tow a trailer.

**⚠ WARNING**

**Travel at speeds appropriate for road and conditions and never travel faster than posted speed limit. Excessive speed can cause loss of vehicle control, which could result in death or serious injury. (00008a)**

**CAUTION**

**Do not run the engine at extremely high RPM with clutch disengaged or transmission in neutral. Running an engine at high RPM can result in engine damage. (00177a)**

**CAUTION**

**Do not exceed the maximum safe RPM specified below under any conditions. Exceeding the maximum safe engine RPM can result in equipment damage. (00248a)**

- The maximum recommended safe engine speed is 5500 rpm.
- Do not idle engine unnecessarily for more than a few minutes with motorcycle standing still.

**CAUTION**

**Air-cooled engines require air movement over the cylinders and heads to maintain proper operating temperature. Extended periods of idling or parade duty can overheat the engine, resulting in serious engine damage. (00178a)**

An engine running long distances at high speed must be given closer than ordinary attention to avoid overheating and possible engine damage.

This applies particularly to a motorcycle equipped with windshield and fairing.

**⚠ WARNING**

**When riding on wet roads, brake efficiency and traction are greatly reduced. Failure to use care when braking, accelerating or turning on wet roads can cause loss of control, which could result in death or serious injury. (00041a)**

## WARNING

**Continuous use of brake causes overheating and reduced efficiency, which could result in death or serious injury. (00042a)**

## WARNING

**Do not tow a disabled motorcycle. Towing can adversely affect stability and handling, which could result in death or serious injury. (00017a)**

### NOTES:

- *Have the engine checked regularly and keep it well tuned.*
- *When descending a long, steep grade, downshift and use engine compression together with intermittent application of both brakes to slow the motorcycle.*

## Break-In Riding Rules

---

### The First 500 Miles (800 Kilometers)

---

The sound design, quality materials and workmanship that are built into your new Harley-Davidson gives you optimum performance right from the start.

To allow your engine to wear-in its critical parts, we recommend that you observe the riding rules for the first 500 mi 800 km .

1. During the first 50 mi 80 km of riding, keep the engine speed below 3000 rpm in any gear. Do not lug the engine by running or accelerating at low rpm, or by running at high rpm longer than needed for shifting or passing.
2. Up to 500 mi 800 km , vary the engine speed and avoid operating at any steady engine speed for long periods. Engine speed up to 3500 rpm in any gear is permissible.
3. Drive slowly and avoid fast starts at wide open throttle until the engine has warmed up.
4. Avoid lugging the engine by not running the engine at low speeds in higher gears.
5. Avoid hard braking. Break in new brakes with moderate use for the first 200 mi 300 km .

## Pre-Riding Checklist

---

## WARNING

**Read the CONTROLS AND INDICATORS section before riding your motorcycle. Failure to understand the operation of the motorcycle could result in death or serious injury. (00043a)**

Always inspect motorcycle condition before riding.

### **⚠WARNING**

**Stop the engine when refueling or servicing the fuel system. Do not smoke or allow open flame or sparks near gasoline. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00002a)**

### **⚠WARNING**

**Avoid spills. Slowly remove filler cap. Do not fill above bottom of filler neck insert, leaving air space for fuel expansion. Secure filler cap after refueling. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00028a)**

### **⚠WARNING**

**Use care when refueling. Pressurized air in fuel tank can force gasoline to escape through filler tube. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00029a)**

1. Check fuel level. Add fuel if necessary.
2. Adjust mirrors to proper riding positions.
3. Check engine oil level. Add oil if necessary.
4. Check controls to make sure that they operate properly. Operate the front and rear brakes, throttle, clutch and shifter. All controls should operate freely without binding.
5. Check steering for proper operation by turning the handlebars through the full operating range. Handlebars should turn smoothly without binding.

### **⚠WARNING**

**Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)**

6. Check tire condition, pressure and motorcycle loading. Incorrect pressure and excessive loading can lead to tire or wheel failure, and can affect handling and stability. For correct tire pressures, refer to Specified Tires.

### **⚠WARNING**

**Be sure headlamp, tail and stop lamp and turn signals are**

**operating properly before riding. Poor visibility of rider to other motorists can result in death or serious injury. (00478b)**

7. Test all switches and lights for proper operation.
8. Check for any fuel, oil or hydraulic fluid leaks. Check for coolant leaks on applicable vehicles.
9. Check drive belt for wear or damage.
10. Service your motorcycle as necessary.

## **Starting the Engine**

---

### **General**

---

#### **CAUTION**

**The engine should be allowed to run slowly for 15-30 seconds. This will allow the engine to warm up and let oil reach all surfaces needing lubrication. Failure to comply can result in engine damage. (00563b)**

Do not roll the throttle before starting. Rolling the throttle before starting the motorcycle is unnecessary.

### **Starting**

---

#### **⚠ WARNING**

**Shift transmission to neutral before starting engine to prevent accidental movement, which could result in death or serious injury. (00044a)**

1. Turn the ignition switch to IGN. Do not roll the throttle.
2. See Right Handlebar Control Switches. Turn the off/run switch to run position (1).

*NOTE:*

*The engine lamp lights for approximately 4 seconds and you hear the fuel pump purr for approximately two seconds as it operates to fill the fuel lines with gasoline.*

3. Pull in clutch lever.

*NOTE:*

*To activate the starting system, the clutch interlock circuitry requires that the clutch be disengaged. The clutch lever must be pulled in against the left handlebar grip and/or the transmission must be shifted to the neutral position (with the green neutral lamp lit).*


4. Raise the jiffy stand (required on international models).

5. Press the start switch (2) to start the motorcycle.

NOTE:

*If the engine does not start, the starter operates for 5 seconds and stop. Release the start switch and reapply. If after two 5 second starting attempts, the motorcycle still will not start, see a Harley-Davidson dealer.*

6. When the engine has started, you can operate your motorcycle as you normally would after raising the jiffy stand.



## Starting after Tipover

### **⚠ WARNING**

**If tip occurs, check all controls for proper operation. Restricted control movement can adversely affect the performance of the brakes, clutch or ability to shift, which could result in loss of vehicle control and death or serious injury. (00350a)**

After a tipover, reset the ignition before starting the engine.

NOTE:

*The word "tIP" appears in the odometer window.*

1. Set the motorcycle upright.
2. Reset the ignition by turning the ignition switch OFF-IGNITION.

## Engine Idle Temperature Management System (EITMS)

---

The Engine Idle Temperature Management System (EITMS) can provide limited cooling of the rear cylinder for riders who frequently find themselves in prolonged idle conditions or traffic congestion.

### Operation

---

When engine temperature reaches a predetermined point, the EITMS turns off the rear cylinder fuel injector. The rear cylinder becomes an "air pump" which works to cool the engine.

EITMS activates (rear cylinder turns off) when **all** of the following conditions are met:

- Ambient temperature or engine temperature exceeds temperature threshold
- Throttle control is at idle
- Vehicle speed under 1 mph 2 km/h
- Engine speed under 1200 rpm

*NOTE:*

*EITMS does not activate within the first four minutes after starting the vehicle.*

EITMS disables (rear cylinder begins firing again) if **any one** of the following occurs:

- Ambient temperature or engine temperature falls below temperature threshold
- Throttle control is above idle
- Vehicle speed exceeds 2 mph 3 km/h
- Engine speed exceeds 1350 rpm
- Clutch is released with vehicle in gear

When the engine is in EITMS operation, you may notice a difference in idle cadence. Additionally, there may be a unique exhaust odor. These are both considered to be normal conditions.

### Enabling/Disabling EITMS

---

**Enabled:** The EITMS engine cooling feature automatically activates whenever the vehicle comes to a complete stop and is idling during elevated temperature conditions. When the feature is enabled, it may not activate under cool riding conditions.

**Disabled:** The EITMS feature is not active under any conditions.

EITMS can be enabled or disabled by performing the following procedure.

1. Turn the ignition switch on. Push the engine off/run switch on the right handlebar to the run position (the motorcycle may be running or not running).
2. Push the throttle to roll-off position and hold.
3. See Instrument Lamps. After approximately 3 seconds, the cruise indicator lamp will either flash green (EITMS enabled) or orange (EITMS disabled).
4. Repeat the procedure as necessary to enable or disable EITMS.

*NOTES:*

- *A flashing cruise lamp indicates the EITMS setting. A solid (non-flashing) lamp indicates the*

*cruise control setting.*

- *The EITMS setting remains in effect until it is changed by the rider or dealer. There is no need to reconfigure EITMS at each startup.*

## Stopping the Engine

---

1. Stop the engine by turning the engine off/run switch on the right handlebar to off.
2. Turn the ignition switch to off. If the engine should be stalled or stopped in any way, turn the ignition switch to OFF at once to prevent battery discharge.

## Shifting Gears

---

### CAUTION

**The clutch must be fully disengaged before attempting a gear shift. Failure to fully disengage the clutch can result in equipment damage. (00182a)**

## Stopped, Engine Off

---

Squeeze in the clutch lever to fully disengage the clutch. Gears may not engage because the transmission shafts are not turning and shifter components are not lined up. Rock the motorcycle backward and forward while lightly pressing on the shift lever.

## Starting from a Stop

---

*NOTE:*

*Always start the engine with the transmission in neutral. Always start forward motion in first gear.*

1. With the engine running and the jiffy stand retracted, pull the clutch hand lever in against the handlebar grip to fully disengage the clutch.
2. Press the gear shift lever down to the end of its travel and release. The transmission is now in first gear.
3. Ease out the clutch lever and at the same time, gradually open the throttle.

## Upshift (Acceleration)

---

See Shifting Sequence: Upshift. Engage the next higher gear when the motorcycle reaches the shifting speed. Refer to Recommended Upshift Speeds.


**Recommended Upshift Speeds**

| GEAR CHANGE     | mph | km/h |
|-----------------|-----|------|
| First to second | 15  | 25   |
| Second to third | 25  | 40   |
| Third to fourth | 35  | 55   |
| Fourth to fifth | 45  | 70   |

1. Close the throttle.
2. Squeeze in the clutch lever to fully disengage the clutch.
3. Lift the gear shift lever up to the end of its travel and release.
4. Ease out the clutch lever and gradually open the throttle.
5. Repeat the previous steps to engage remaining gears.

**NOTES:**

- *Disengage the clutch completely before each gear change.*
- *Partially open the throttle so the engine does not drag when the clutch lever is released.*



## Downshift (Deceleration)

### ⚠ WARNING

**Do not downshift at speeds higher than those listed. Shifting to lower gears when speed is too high can cause the rear wheel to lose traction and lead to loss of vehicle control, which could result in death or serious injury. (00045b)**

See Shifting Sequence: Downshift. When speed decreases, as when climbing a hill or slowing for a turn, shift to the next lower gear. Refer to Recommended Downshift Speeds.

#### Recommended Downshift Speeds

| GEAR CHANGE | mph | km/h |
|-------------|-----|------|
|-------------|-----|------|

| GEAR CHANGE     | mph | kph |
|-----------------|-----|-----|
| Sixth to fifth  | 50  | 80  |
| Fifth to fourth | 40  | 65  |
| Fourth to third | 30  | 50  |
| Third to second | 20  | 30  |
| Second to first | 10  | 15  |

**NOTE:**

*The shifting points shown in the table are recommendations. Vehicle owners may determine that their individual shifting patterns may differ from those stated and are appropriate for individual riding styles.*

1. Close the throttle.
2. Squeeze in the clutch lever to fully disengage the clutch.
3. Press the gear shift lever down to the end of its travel and release.
4. Ease out the clutch lever and gradually open the throttle.
5. Repeat the previous steps to engage remaining gears.


**NOTES:**

- *Disengage the clutch completely before each gear change.*
- *Partially open the throttle so the engine does not drag when clutch lever is released.*

**CAUTION**

**Shift to neutral before stopping engine. Shifting mechanism can be damaged by shifting gears while engine is stopped. (00183a)**

The gear shifter mechanism permits shifting the transmission to neutral from either first or second gear.



Shifting Sequence: Downshift

## Maintenance and Lubrication

### Safe Operating Maintenance

#### ⚠ WARNING

Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)

#### ⚠ WARNING

If you operate your motorcycle under adverse conditions (severe cold, extreme heat, very dusty environment, very bad roads, through standing water, etc.), you should perform the regular maintenance intervals more frequently to ensure the safe operation of your motorcycle. Failure to maintain your motorcycle could result in death or serious injury. (00094a)

Good maintenance leads to safe motorcycling. A careful check of certain equipment must be made after periods of storage. Also, frequently inspect the motorcycle between the regular service intervals to determine if additional maintenance is necessary.

Check the following items:

1. Tires for correct pressure, excessive wear or any signs of tire damage.
2. Drive belt for proper tension, wear or damage.

3. Brakes, steering and throttle for responsiveness and freedom from binding.
4. Brake fluid level and condition. Hydraulic lines and fittings for leaks. Also, check brake pads and discs for wear.
5. Cables for fraying or crimping and free operation.
6. Engine oil and primary chaincase/transmission fluid levels.
7. Headlamp, tail lamp, brake lamp and turn signals for proper operation.

## Break-In Maintenance

---

### NOTE:

*The performance of new motorcycle initial service is required to keep your new motorcycle warranty in force and for proper emissions system operation.*

After a new motorcycle has been ridden 1000 mi 1600 km , visit an authorized Harley-Davidson dealer for initial service. Refer to Regular Service Intervals: 2016 Softail Models.

## Disposal and Recycling

---

Help protect our environment! Many communities maintain facilities for recycling used fluids, plastics and metals. Dispose of or recycle used oil, lubricants, fuel, coolant, brake fluid and batteries in accordance with local regulations. Many Harley-Davidson parts and accessories are made of plastics and metals which can also be recycled.

## Engine Lubrication

---

### ⚠CAUTION

**Prolonged or repeated contact with used motor oil may be harmful to skin and could cause skin cancer. Promptly wash affected areas with soap and water. (00358b)**

### ⚠CAUTION

**If engine oil is swallowed, do not induce vomiting. Contact a physician immediately. In case of contact with eyes, immediately flush with water. Contact a physician if irritation persists. (00357d)**

### CAUTION

**Do not switch lubricant brands indiscriminately because some lubricants interact chemically when mixed. Use of inferior lubricants can damage the engine. (00184a)**

Engine oil is a major factor in the performance and service life of the engine. Use the proper grade of oil for the lowest temperature expected before the next oil change. Refer to Recommended Engine Oils.

**FLSS, FLSTFBS:** These models came filled with SCREAMIN' EAGLE SYN3 FULL SYNTHETIC MOTORCYCLE LUBRICANT.

**All except FLSS, FLSTFBS:** These models were originally filled with GENUINE HARLEY-DAVIDSON H-D 360 MOTORCYCLE OIL 20W50.

These oils are the preferred oil under normal operating conditions. If operation under extreme cold or heat are expected, refer to Recommended Engine Oils for alternative choices.

If SYN3 or H-D 360 is not available, add oil certified for diesel engines. Acceptable designations include: CH-4, CI-4 and CJ-4. The preferred viscosities, in descending order are: 20W50, 15W40 and 10W40.

At the first opportunity, see an authorized dealer to change back to 100 percent Harley-Davidson oil.

**Recommended Engine Oils**

| TYPE                                                     | VISCOSITY | RATING | LOWEST<br>AMBIENT<br>TEMPERATURE | COLD-<br>WEATHER<br>STARTS<br>BELOW<br><br>50 °F (10 °C) |
|----------------------------------------------------------|-----------|--------|----------------------------------|----------------------------------------------------------|
| Screamin' Eagle SYN3 Full Synthetic Motorcycle Lubricant | SAE 20W50 | HD 360 | Above 30 °F -1 °C                | Excellent                                                |
| Genuine Harley-Davidson H-D 360 Motorcycle Oil           | SAE 20W50 | HD 360 | Above 40 °F 4 °C                 | Good                                                     |
| Genuine Harley-Davidson H-D 360 Motorcycle Oil           | SAE 50    | HD 360 | Above 60 °F 16 °C                | Poor                                                     |
| Genuine Harley-Davidson H-D 360 Motorcycle Oil           | SAE 60    | HD 360 | Above 80 °F 27 °C                | Poor                                                     |
| Genuine Harley-Davidson H-D 360 Motorcycle Oil           | SAE 10W40 | HD 360 | Below 40 °F 4 °C                 | Excellent                                                |

## Engine Oil

---

Check engine oil level during pre-ride inspection.

Refer to Regular Service Intervals: 2016 Softail Models. Change engine oil at scheduled service intervals. Change oil more frequently in severe riding conditions. Also, change oil more frequently in cold weather. See Winter Lubrication.

## Checking and Adding Oil

---

### CAUTION

Oil level cannot be accurately measured on a cold engine. For pre-ride inspection, with motorcycle leaning on jiffy stand on level ground, oil should register on dipstick between arrows when engine is cold. Do not add oil to

bring the level to the FULL mark on a COLD engine.  
(00185a)

### CAUTION

Do not allow hot oil level to fall below Add/Fill mark on dipstick. Doing so can result in equipment damage and/or equipment malfunction. (00189a)

### CAUTION


Do not overfill oil. Doing so can result in oil carryover to the air cleaner leading to equipment damage and/or equipment malfunction. (00190b)

1. Run motorcycle until engine oil reaches at least 200 °F 93 °C .
2. Idle motorcycle on jiffy stand for 1-2 minutes.
3. Shut off motorcycle and leave motorcycle **resting on jiffy stand**.

*NOTE:*

*Add engine oil only when oil is at normal operating temperature. Otherwise, excessive oil can enter the air cleaner.*

4. See Engine Oil Level. Check engine oil level. If necessary, add oil until oil level is at the FULL HOT mark on the dipstick.



om00107



1. FULL HOT
2. FILL

Engine Oil Level

## Changing Oil and Oil Filter

### NOTES:

- Change engine oil at shorter intervals if ridden extremely hard, used in competition or driven on dusty roads.
- Twin Cam equipped vehicles require the premium oil filter, available in chrome (Part No. 63798-99A) or black (Part No. 63731-99A).

1. Run motorcycle until engine is at normal operating temperature. Turn off engine.
2. See Checking Oil Tank Level. Remove the oil filler plug/dipstick.
3. See Oil Tank Drain Plug: Softail Models. Remove the oil tank drain plug and O-ring (2). Drain engine oil.

### CAUTION

**Use Harley-Davidson oil filter wrench for filter removal.  
This tool can prevent damage to crankshaft position  
sensor and/or sensor cable. (00192b)**

4. See Oil Filter Wrenches. Remove the oil filter using the OIL FILTER WRENCH HD-42311 or OIL FILTER WRENCH HD-44067 . Clean the oil filter mounting surface of any old gasket material.
5. See Lubricating New Oil Filter Gasket. Install **new** oil filter.
  - a. Lubricate gasket with clean engine oil.
  - b. Install **new** oil filter on filter mount.

- c. Hand-tighten oil filter one-half to three-quarters of a turn after gasket first contacts filter mounting surface. Do NOT use oil filter wrench for installation.

6. See Oil Tank Drain Plug: Softail Models. Install oil tank drain plug (2).

- a. Inspect O-ring for tears or damage. Replace if necessary. Clean magnetic drain plug.
- b. Install drain plug. Tighten to 14-21 ft-lbs (19.0-28.5 Nm).

NOTE:

*Use the proper grade of oil for the lowest temperature expected before the next oil change. Refer to Recommended Engine Oils.*

7. Refer to Engine Oil Capacity. Add an initial volume of engine oil.

**Engine Oil Capacity**

| ITEM       | CAPACITY |      |
|------------|----------|------|
|            | qt       | L    |
| Engine oil | 3.0      | 2.84 |


8. See Checking Oil Tank Level. Fully install oil filler plug/dipstick in oil tank.

NOTE:

*Add engine oil only when oil is at normal operating temperature. Filling the engine oil tank to the FULL HOT mark when the oil is below operating temperature can lead to excessive oil in the air cleaner.*


9. See Engine Oil Level. Verify that oil level is above the FILL mark on the dipstick.

- a. Start engine and carefully check for oil leaks around drain plug and oil filter.
- b. Run motorcycle until engine oil reaches at least 200 °F 93 °C .
- c. Allow to idle on jiffy stand for 1-2 minutes. Turn off engine.
- d. If necessary, add oil to bring oil level to the FULL HOT mark on the dipstick. Do not overfill oil tank.




1. Frame connection for oil tank drain hose
2. Oil tank drain plug and O-ring

**Oil Tank Drain Plug: Softail Models**



**Oil Filter Wrenches**



## Winter Lubrication

---

Change engine oil often in colder climates. If motorcycle is frequently used for trips less than 15 mi 24 km , in ambient temperatures below 60 °F 16 °C , reduce oil change intervals to 1500 mi 2400 km .

*NOTE:*

*Lower ambient temperatures require more frequent oil changes.*

Water vapor is a normal by-product of combustion. During cold-weather operation, some water vapor condenses to liquid form on the cool surfaces inside the engine. In freezing weather this water becomes slush or ice. If the engine is not warmed to operating temperature, accumulated slush or ice blocks the oil lines and causes engine damage. Over time, water will accumulate, mix with the engine oil and form a sludge that is harmful to the engine.

If the engine is allowed to warm to normal operating temperature, most of the water evaporates and exits through the crankcase breather.

## Check Transmission Lubricant

---

*NOTE:*

*Check transmission fluid with the motorcycle at ambient temperature.*



1. Park motorcycle on a level surface on jiffy stand.
2. See Transmission Filler Plug/Dipstick Location. Remove transmission filler plug/dipstick. Wipe dipstick clean.
3. Install filler plug/dipstick until O-ring contacts the case. Do not tighten.
4. See Transmission Lubricant Level. Remove filler plug/dipstick. Check lubricant level on dipstick.

### CAUTION

**Mixing mineral-based lubricants with SYN-3 in the**

**transmission can damage the transmission. (00452b)**

5. Proper oil level is between the Add (A) (1) and Full (F) (2) marks. Add only enough lubricant to bring level to between the A mark and the F marks. Refer to Transmission Lubricant.
6. Install filler plug/dipstick. Tighten to 25-75 in-lbs (2.8-8.5 Nm).



**Transmission Lubricant**

| MODEL                          | LUBRICANT                                                       |
|--------------------------------|-----------------------------------------------------------------|
| FLSS,<br>FLSTFBS               | SCREAMIN' EAGLE SYN3 FULL<br>SYNTHETIC MOTORCYCLE<br>LUBRICANT. |
| All except<br>FLSS,<br>FLSTFBS | FORMULA+ TRANSMISSION AND<br>PRIMARY CHAIN LUBRICANT            |

## Change Transmission Lubricant

---

1. See Transmission Filler Plug/Dipstick Location. Remove transmission filler plug/dipstick.

### **⚠ WARNING**


**Be sure that no lubricants or fluids get on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047d)**

2. See Transmission Drain Plug (bottom view). Remove transmission drain plug. Drain transmission.
3. Clean and inspect drain plug and O-ring.

### **CAUTION**

**Do not over-tighten filler or drain plug. Doing so could result in a lubricant leak. (00200b)**

4. Install drain plug with O-ring. Tighten to 14-21 ft-lbs (19.0-28.5 Nm). Do not over-tighten.
5. Fill the transmission with 28 oz 0.83 L of recommended Harley-Davidson lubricant. Refer to Transmission Lubricant.
6. Check lubricant level. Add enough lubricant to bring the level between the add (A) and full (F) marks. See Check Transmission Lubricant.
7. Install filler plug/dipstick. Tighten to 25-75 in-lbs (2.8-8.5 Nm).



## Change Primary Chaincase Lubricant

**NOTE:**


*Drain and refill the primary chaincase with fresh lubricant at proper intervals. Refer to Regular Service Intervals: 2016 Softail Models.*

1. Run motorcycle until engine is at normal operating temperature. Turn off engine.

### **⚠WARNING**

**Be sure that no lubricants or fluids get on tires, wheels or brakes when changing fluid. Traction can be adversely affected, which could result in loss of control of the motorcycle and death or serious injury. (00047d)**

2. Secure motorcycle upright (not leaning on jiffy stand) on a level surface.
3. See Removal/Installation of Chaincase Drain Plug. Drain primary chaincase.
4. Clean drain plug magnet. If plug has excessive debris, inspect the condition of chaincase components.
5. Install **new** O-ring on drain plug.
6. Install drain plug. Tighten to 14-21 ft-lbs (19.0-28.5 Nm).



7. See Clutch Cover. Remove screws with washers (3) and clutch inspection cover (2).
8. Remove seal (1). Wipe oil from groove in chaincase cover and mounting surface.

### CAUTION

**Do not overfill the primary chaincase with lubricant. Overfilling can cause rough clutch engagement, incomplete disengagement, clutch drag and/or difficulty in finding neutral at engine idle. (00199b)**


9. Pour specified amount of lubricant through clutch inspection cover opening. Refer to Primary Chaincase Lubricant Refill Capacity.
  - a. **FLSS, FLSTFBS:** SCREAMIN' EAGLE SYN3 FULL SYNTHETIC MOTORCYCLE LUBRICANT
  - b. **All except FLSS, FLSTFBS:** FORMULA+ TRANSMISSION AND PRIMARY CHAINCASE LUBRICANT


**Primary Chaincase Lubricant Refill Capacity**

| CONDITION                              | CAPACITY |     |
|----------------------------------------|----------|-----|
|                                        | fl oz    | L   |
| Wet                                    | 34       | 1.0 |
| Dry *                                  | 38       | 1.1 |
| * Quantity after complete disassembly. |          |     |

10. Install clutch inspection cover and **new** seal:

- a. Thoroughly wipe all lubricant from cover mounting surface and groove in chaincase cover.
- b. See Clutch Cover. Position **new** seal (1) in groove in clutch inspection cover (2). Press each of the nubs on seal into the groove.
- c. Secure clutch inspection cover (2) with screws with captive washers (3).
- d. See Clutch Cover Torque Sequence. Tighten in sequence shown to 84-108 in-lbs (9.5-12.2 Nm).





## Drive Belt Deflection

### NOTE:

*Always use BELT TENSION GAUGE HD-35381-A to measure belt deflection. Failure to use tension gauge may cause under-tensioned belts. Loose belts can fail due to "ratcheting" (jumping a tooth) which causes tensile cord crimping and breakage.*

Check deflection:

- As part of pre-ride inspection.
- At every scheduled service interval.
- With transmission in neutral.
- With motorcycle at ambient temperature.
- With motorcycle upright or on jiffy stand with rear wheel on the ground.
- With the vehicle unladen: no rider, passenger or cargo.


### **⚠ WARNING**


**To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse before proceeding. (00251b)**

1. Disarm security system. Remove main fuse. See Fuses.
2. See Belt Tension Gauge. Measure belt deflection using H-D BELT TENSION GAUGE HD-35381-A :
  - a. Slide O-ring (4) to 0 lb 0 kg mark (3).
  - b. Fit belt cradle (2) against bottom of drive belt halfway between drive pulleys.
  - c. Press upward on knob (6) until O-ring slides down to 10 lb 4.5 kg mark (5) and hold

steady.

3. See Checking Belt Deflection. Measure belt deflection (4) while holding gauge steady.
4. If the measurement is not within specification, see a Harley-Davidson dealer for service. Refer to Drive Belt Deflection.
5. Install main fuse.





1. Transmission sprocket
2. Rear wheel sprocket
3. 10 lb (4.5 kg) of force
4. Amount of deflection

#### Checking Belt Deflection

#### Drive Belt Deflection

| MODEL                                                                                                                                                                                                                                                                                                                                                                                                                  | DEFLECTION |           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|-----------|
|                                                                                                                                                                                                                                                                                                                                                                                                                        | in         | mm        |
| FLS*, FLSS**, FLSTFB***, FLSTFBS****, FLSTN, FXSB                                                                                                                                                                                                                                                                                                                                                                      | 1/4-5/16   | 6.4-7.9   |
| FLSTC, FLSTF                                                                                                                                                                                                                                                                                                                                                                                                           | 9/16-5/8   | 14.3-15.9 |
| <p>* FLS (AUS/APC configurations) uses FLSTC, FLSTF specification.</p> <p>** FLSS (AUS/ configuration) uses FLSTC, FLSTF specification.</p> <p>*** FLSTFB (BRZ/HDI/IND/ENG configurations) uses FLSTC, FLSTF specification.</p> <p>**** FLSTFBS (HDI/ENG configurations) uses FLSTC, FLSTF specification.</p> <p>To determine configuration from VIN, refer to Harley-Davidson VIN Breakdown: 2016 Softail Models.</p> |            |           |

## Chassis Lubrication

Refer to Regular Service Intervals: 2016 Softail Models for all maintenance schedules.

*NOTE:*

*Use recommended SPECIAL PURPOSE GREASE for steering head bearings. Use a multipurpose chassis grease for other applications.*

1. Lubricate clutch control cable with HARLEY LUBE.
2. Lubricate front brake hand lever and clutch control hand lever only if necessary.
3. Inspect rear fork pivot shaft bearings.
4. Pack the steering head bearings with SPECIAL PURPOSE GREASE at recommended service intervals.
5. Lubricate the jiffy stand mechanism with SILVER GRADE ANTI-SEIZE.

*NOTE:*

*For model specific information regarding the chassis lubrication, see the service manual or a Harley-Davidson dealer.*

## Front Fork Oil

---

Have a Harley-Davidson dealer service the front fork at the specified intervals. If fork does not appear to be working properly or an appreciable amount of oil leakage develops, see a Harley-Davidson dealer. If there is insufficient oil in either side of fork, the rebound action will be incorrect. Refer to Regular Service Intervals: 2016 Softail Models.

## Hydraulic Clutch: FLSS, FLSTFBS

---

Check clutch fluid level at specified intervals. Refer to Regular Service Intervals: 2016 Softail Models.

*NOTE:*

*Clutch fluid should never need to be added or removed as the result of normal wear.*

1. Place vehicle on a flat level surface. Level the master cylinder by turning the handlebar and/or standing the motorcycle upright (not leaning on jiffy stand).
2. See Clutch Reservoir Sight Glass. View reservoir sight glass. Verify fluid presence. Sight glass appears dark if fluid is present. If the entire sight glass is not dark, then proceed to the next step.

### CAUTION

**Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. KEEP OUT OF REACH OF CHILDREN. (00240a)**

### CAUTION

**Do not allow dirt or debris to enter the master cylinder reservoir. Dirt or debris in the reservoir can cause improper operation and equipment damage. (00205c)**

### CAUTION

**D.O.T. 4 brake fluid will damage painted and body panel surfaces it comes in contact with. Always use caution and protect surfaces from spills whenever brake work is performed. Failure to comply can result in cosmetic damage. (00239b)**

*NOTE:*

*If DOT 4 brake fluid contacts painted surfaces, IMMEDIATELY flush area with clear water.*

3. Clean all dirt and debris from the clutch master cylinder cover. Remove the two clutch master cylinder cover screws. Remove the cover.

### CAUTION


**D.O.T. 4 hydraulic brake fluid is used in the hydraulic clutch. Do not use other types of fluids as they are not compatible and could cause equipment damage. (00353a)**

*NOTES:*

- *Do not exceed FILL LEVEL. Clutch fluid volume increases with clutch wear. Over-filling can damage seals and damage clutch system.*
  - *If fluid level is substantially above the FILL level, a worn clutch can be the cause.*
  - *Check that clutch hand lever returns completely. If lever does not return completely, problems similar to over-filling can result.*
4. Verify that the fluid level in the clutch master cylinder reservoir is at the FILL level mark at the top of the ledge on the rear inside wall of the reservoir. If the fluid level is low, add DOT 4 BRAKE FLUID which is approved for clutch system use and available from a Harley-Davidson dealer.
  5. Inspect the clutch master cylinder cover gasket for rips, cuts, cracks or other signs of damage. Replace the gasket if necessary. Carefully place the cover and cover gasket on the master cylinder reservoir. Secure with the two cover screws. Tighten the screws to 8-10 in-lbs (0.9-1.1 Nm).

*NOTE:*

*If the fluid level is correct but the clutch does not operate properly, refer to the service manual or see a Harley-Davidson dealer for service.*



## Mechanical Clutch

---

### CAUTION

**The clutch control cable must be oiled and adjusted periodically to compensate for lining wear. See MAINTENANCE SCHEDULING in this manual. Failure to oil and adjust the clutch control cable can result in equipment damage. (00203b)**

Adjust the clutch control cable at specified intervals. Refer to Regular Service Intervals: 2016 Softail Models.

If the clutch slips under load or drags when released, the control cable may need to be adjusted or clutch service may need to be performed. See a Harley-Davidson dealer for service.

## Hydraulic Lifters

---

The hydraulic lifters are self-adjusting. They automatically adjust length to compensate for engine expansion and valve mechanism wear. This keeps the valve mechanism free of lash when the engine is running.

When starting an engine which has been turned off even for a few minutes, the valve mechanism may be slightly noisy until the hydraulic units completely refill with oil. If at any time the valve mechanism becomes abnormally noisy, other than for a short period immediately after engine is started, it is an indication that one or more of the hydraulic units may not be functioning properly.

Always check the engine oil level first since normal circulation of oil through the engine is necessary for proper operation of the hydraulic lifters.

If engine oil is at the proper level, the lifters may not be functioning properly because of dirt in the oil supply passages leading to the lifter units. See a Harley-Davidson dealer for service.

## Steering Head Bearings

---

### **⚠ WARNING**

**Adjustments to steering head bearings should be performed by a Harley-Davidson dealer. Improperly adjusted bearings can adversely affect handling and stability, which could result in death or serious injury. (00051b)**

Check for proper steering head bearing adjustment and lubricate bearings using SPECIAL PURPOSE GREASE at proper intervals. Refer to Regular Service Intervals: 2016 Softail Models.

With motorcycle front end raised off the floor, be sure front fork turns freely without any binding or interference and that there is no appreciable front to rear fork movement indicating excessive bearing looseness. Steering head bearings should be adjusted according to service manual procedure, if necessary.

## Brakes

---

Inspect brake fluid level and check brake pads and discs for wear at proper intervals. Refer to Regular Service Intervals: 2016 Softail Models.

## Brake Fluid

---

### **⚠ WARNING**

**Clean reservoir filler cap or cover before removing. Use only DOT 4 brake fluid from a sealed container. Contaminated fluid can adversely affect braking or clutch disengagement, which could result in death or serious injury. (00504d)**

### **⚠ CAUTION**

**Direct contact of D.O.T. 4 brake fluid with eyes can cause irritation. Avoid eye contact. In case of eye contact flush with large amounts of water and get medical attention. Swallowing large amounts of D.O.T. 4 brake fluid can cause digestive discomfort. If swallowed, obtain medical attention. Use in well ventilated area. KEEP OUT OF REACH OF CHILDREN. (00240a)**

### **CAUTION**

**D.O.T. 4 brake fluid will damage painted and body panel surfaces it comes in contact with. Always use caution and protect surfaces from spills whenever brake work is performed. Failure to comply can result in cosmetic**

damage. (00239b)


### CAUTION

**Do not allow dirt or debris to enter the master cylinder reservoir. Dirt or debris in the reservoir can cause improper operation and equipment damage. (00205c)**

#### NOTES:

- *If the brake system is not leaking, there should never be a need to add fluid. If the fluid level is low, the pads are probably worn. By replacing the pads, the fluid level will return to its normal level.*
  - *Use only DOT 4 brake fluid and replace the brake fluid every two years. See a Harley-Davidson dealer.*
1. Position vehicle on a flat, level surface.
    - a. **Front brake:** Level the master cylinder by turning the handlebar and/or standing the motorcycle upright (not leaning on jiffy stand).
    - b. **Rear brake:** Position the motorcycle so the master cylinder reservoir is level.
  2. See Brake Fluid Reservoirs. View reservoir sight glass.
    - a. **Front:** Verify that fluid is visible in the sight glass (1). If the fluid level is below the minimum mark (2) or not present, see a Harley-Davidson dealer.
    - b. **Rear:** Verify fluid presence. The sight glass (3) appears dark if fluid is present. If the sight glass is clear, see a Harley-Davidson dealer.
  3. Verify front brake hand lever and rear brake foot pedal have a firm feel when applied. If brakes are not firm, the brake system must be bled. See a Harley-Davidson dealer.

om01938



1. Front reservoir sight glass
2. Minimum mark
3. Rear reservoir sight glass

**Brake Fluid Reservoirs**

## Brake Pads

### **⚠ WARNING**

Inspect brake pads for wear at service maintenance intervals. If you ride under adverse conditions (steep hills, heavy traffic, etc.), inspect more frequently. Excessively worn brake pads can lead to brake failure, which could result in death or serious injury. (00052a)

### **⚠ WARNING**

Always replace brake pads in complete sets for correct and safe brake operation. Improper brake operation could result in death or serious injury. (00111a)

### **⚠ WARNING**

Brakes are a critical safety component. Contact a Harley-Davidson dealer for brake repair or replacement. Improperly serviced brakes can adversely affect brake performance, which could result in death or serious injury. (00054a)

### **⚠ WARNING**

Perform routine scheduled brake maintenance. Lack of

**Perform routine scheduled brake maintenance. Lack of maintenance at recommended intervals can adversely affect brake performance, which could result in death or serious injury. (00055a)**

**⚠ WARNING**


**Be sure wheel and brake caliper are aligned. Riding with a misaligned wheel or brake caliper can cause the brake disc to bind and lead to loss of control, which could result in death or serious injury. (00050a)**

Harley-Davidson's brake pad friction material is selected to give the best performance possible under dry, wet and high operating temperature conditions. It exceeds all regulatory requirements currently in effect. However, during some braking conditions you can hear a brake noise. This noise is normal for this friction material.

**Minimum Brake Pad Friction Material Thickness**

| <b>MODEL</b> | <b>in</b> | <b>mm</b> |
|--------------|-----------|-----------|
| All          | 0.040     | 1.02      |

1. See Brake Friction Material. Check the brake disc as it spins. The disc should run true in the brake caliper.
2. Measure the thickness of the brake pad friction material. The pads do not necessarily wear evenly. Check each pad. The grooves on the brake pads are no longer visible when the pads are near the end of service life.
3. If the brake pad friction material is at the minimum thickness or less, replace the pads. Always replace brake pads in pairs. See a Harley-Davidson dealer. Refer to Minimum Brake Pad Friction Material Thickness.



1. Front, from below
2. Rear, from above

**Brake Friction Material**

## Tires

Refer to Specified Tires for tires and pressures.

- Keep tires properly inflated.
- Follow tire data for correct cold tire inflation pressure.
- Check tire pressures when tires are cold.

### **⚠ WARNING**

**Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)**

### **⚠ WARNING**

**Match tires, tubes, rim strips or seals, air valves and caps to the correct wheel. Contact a Harley-Davidson dealer. Mismatching can lead to tire damage, allow tire slippage on the wheel or cause tire failure, which could result in death or serious injury. (00023c)**

### WARNING

**Only install original equipment tire valves and valve caps. A valve, or valve and cap combination, that is too long or too heavy can strike adjacent components and damage the valve, causing rapid tire deflation. Rapid tire deflation can cause loss of vehicle control, which could result in death or serious injury. (00281a)**

Check tires for correct pressure, excessive wear or any signs of tire damage at least weekly if in daily use. Check before each ride if only ridden occasionally.

Use only Harley-Davidson specified tires. Other tires may not fit correctly and could adversely affect stability, handling and performance. Refer to Specified Tires.

### WARNING

**Tires are a critical safety component. Contact a Harley-Davidson dealer for tire repair or replacement. Improper tire service can adversely affect stability and handling, which could result in death or serious injury. (00057a)**

### WARNING

**Replace punctured or damaged tires. In some cases, small punctures in the tread area may be repaired from within the removed tire by a Harley-Davidson dealer. Speed should NOT exceed 50 mph (80 km/h) for the first 24 hours after repair, and the repaired tire should NEVER be used over 80 mph (130 km/h). Failure to follow this warning could lead to tire failure and result in death or serious injury. (00015b)**

### WARNING

**Striking an object, such as a curb or pothole can cause internal tire damage. If an object is struck, have the tire inspected immediately inside and out by a Harley-Davidson dealer. A damaged tire can fail while riding and adversely affect stability and handling, which could result in death or serious injury. (00058b)**

## Rim Seals

---

Some Softail motorcycles with Profile laced wheels (wire spoked wheels with smooth round rims) are fitted with a special rim seal, a rim strip and a tubeless tire. An inner tube is not used. These rims are unique and identified by the letters MTM and the word TUBELESS etched into the rim. Never install a tire with an inner tube on these type wheels. Install a **new** rim seal and rim strip each time a **new** tire is mounted on a Profile laced wheel with MTM and TUBELESS markings.

Steel-laced rims use an inner tube and rim strip. Tubeless tires fitted with the correct size inner tubes may be used with these wheels. Install a **new** inner tube and rim strip each time a tire is

installed on a steel-laced wheel.

## Tire Replacement

---

### Inspection

---

#### WARNING

Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)

#### WARNING

Replace tire immediately with a Harley-Davidson specified tire when wear bars become visible or only 1/32 in (0.8 mm) tread depth remains. Riding with a worn tire could result in death or serious injury. (00090c)

Harley-Davidson tires have tread wear indicator bars that run horizontally across the tread. When a tire is worn to the point the tread wear indicator bars become visible on the tread surfaces, or 1/32 in 0.8 mm tread depth remains, the tire can:

- Be more easily damaged leading to tire failure.
- Provide reduced traction.
- Adversely affect stability and handling.

See Dunlop Sidewall Tread Wear Indicator Bar Locator. Arrows on tire sidewalls pinpoint location of tread wear indicator bars.

See Dunlop Tread Wear Indicator Bar Appearance. Always replace tires before the tread wear indicator bars appear.

### When To Replace Tires

---

#### WARNING

Use only Harley-Davidson specified tires. See a Harley-Davidson dealer. Using non-specified tires can adversely affect stability, handling or braking, which could result in death or serious injury. (00024b)


NOTE:


*Always replace tires with the specified tires. Refer to Specified Tires.*

**New** tires are needed if:

- Tread wear indicator bars become visible on the tread surfaces.
- Tire cords or fabric become visible through cracked sidewalls, snags or deep cuts.
- Bumps, bulges or slits in the tire.
- Punctures, cuts or other damage to the tire that cannot be repaired.

When installing tires on rims, do not rely on tread design to determine direction of rotation. Always make sure that the rotational arrows molded into the sidewalls point in the direction of rotation when the vehicle is moving forward.





## Shock Absorbers

---

Inspect shock absorbers and rubber bushings for leaks and bushing deterioration at proper intervals.

### **⚠ WARNING**

**Shock absorber cannot be serviced. Attempting service can cause an explosion, which could result in death or serious injury. (00602d)**

- Do not refill, disassemble, puncture or expose shock to flames.
- Replacement and disposal should only be done by an authorized Harley-Davidson dealer.

## Spark Plugs

---

### **⚠ WARNING**

**Disconnecting spark plug cable with engine running can result in electric shock and death or serious injury. (00464b)**

### **⚠ CAUTION**

**Do NOT pull on any electrical wires. Pulling on electrical wires may damage the internal conductor causing high resistance, which may result in minor or moderate injury. (00168a)**

Check the spark plugs at the specified service intervals. Refer to Regular Service Intervals: 2016 Softail Models.

1. Disconnect spark plug cables from plugs by pulling up on the molded connector caps.
2. Remove the spark plugs.

*NOTE:*

*Use only specified Harley-Davidson spark plugs.*

3. Use a wire-type feeler gauge to gauge the spark plug gap.
  - a. Select the gauge with a wire size that is within gap specifications. Refer to Electrical.
  - b. Pass the wire gauge between the center and the outer electrodes.
  - c. If necessary, use a gapping tool to bring the gap to within specification.
4. Apply ANTI-SEIZE LUBRICANT to the spark plug threads.

*NOTES:*

- *Spark plugs must be tightened to the torque specified for proper heat transfer.*
- *If a torque wrench is not available, tighten **new** spark plugs finger-tight. Then tighten an extra one-quarter turn with a spark plug wrench.*

5. Install the spark plugs. Tighten to 12-18 ft-lbs (16.3-24.4 Nm).
6. Connect each molded connector cap until the cap snaps firmly into place over the spark plug.

## **Air Cleaner: FLSS**

---

### **Removal**

---

1. See Air Cleaner: FLSS. Remove the air cleaner cover screw (6). Remove air cleaner cover (1), cover adapter (5) and spacer (1).
2. Remove the filter screws (4) and the filter element (3).
3. Inspect and clean the filter element. Replace if necessary. See Cleaning Filter Element.

### **Installation**


---

*NOTE:*

*When servicing the air cleaner, apply LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue) to the threads of all fasteners.*

1. See Air Cleaner: FLSS. Secure filter element (3) to air cleaner mounting studs with screws (4). Tighten to 55-60 in-lbs (6.2-6.8 Nm).
2. Insert spacer (2) into adapter (5).
3. Align adapter with filter element channel and mounting screws. Seat adapter ribs into element channel.

4. Secure cover (1) to the adapter (5) with the cover screw (6). Tighten to 36-60 in-lbs (4.1-6.8 Nm).



## Air Cleaner: FLSTFBS

---

## Rain Sock

---

See Air Cleaner: FLSTFBS. In wet or rainy conditions, because the filter element is exposed, water can enter the engine. When parked, water can cause internal engine corrosion or damage. When running, water can cause the engine to misfire.

In wet or rainy conditions, install the rain sock (8) over the air cleaner assembly to prevent water intrusion.

## Removal

---


1. See Air Cleaner: FLSTFBS. Remove two screws (1). Remove trim insert (2).
2. Remove screw (3) to release cover (4). Remove cover.
3. Remove three screws (5) to release filter element (6). Remove filter element.

4. Inspect and clean the filter element. Replace if necessary. See Cleaning Filter Element.

## Installation

---

1. See Air Cleaner: FLSTFBS. Place filter element (6) onto backplate (7).
2. Install the filter element screws (5). Tighten to 55-60 in-lbs (6.2-6.8 Nm).
3. Place air cleaner cover (4) onto backplate. Apply a drop of LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue) to the threads of each screw. Tighten to 36-60 in-lbs (4.0-6.8 Nm).
4. Install trim insert (2). Install trim insert screws (1). Tighten to 27-32 in-lbs (3.1-3.6 Nm).



## Air Cleaner: All except FLSS, FLSTFBS

---

## Removal

---

### NOTE:

*When removing insert, only pull on the front edge without pushing in the middle. Otherwise the insert could be damaged.*

1. **Models without screw access:** See Air Cleaner Assembly. Pull on front edge of insert

(7) to remove.

2. Remove screw (8) and air cleaner cover (9) with rubber seal (1).
3. Remove three screws (5) to release cover bracket (2) from filter element (4).
4. Remove filter element pulling breather tube (3) from hole on inboard side.
5. Remove breather tube from breather bolts.
6. Inspect the breather tube and fittings for damage. Replace if necessary.
7. Inspect and clean the filter element. Replace if necessary. See Cleaning Filter Element.


## Installation

---

### NOTE:

*Air cleaner mounting without installation of the breather tubes allows crankcase vapors to vent into the atmosphere. Lack of breather tubes violates emissions regulations.*

1. See Air Cleaner Assembly. Install breather tube (3) onto breather bolts.
2. Insert breather tube into hole on inboard side of filter element.
3. Place filter element (4) onto backplate with the flat side at the four o'clock position.
4. Install cover bracket (2) with screws (5). Tighten to 108-132 in-lbs (12.2-14.9 Nm).
5. Verify that rubber seal (1) is not damaged and is properly seated around perimeter of air cleaner cover (9).
6. Place air cleaner cover onto backplate. Apply a drop of LOCTITE 243 MEDIUM STRENGTH THREADLOCKER AND SEALANT (blue) to the threads of each screw. Install screw. Tighten to 36-60 in-lbs (4.1-6.8 Nm).
7. **Models without screw access:** Secure insert (7).



## Cleaning Filter Element

### **⚠ WARNING**

**Do not use gasoline or solvents to clean filter element. Flammable cleaning agents can cause an intake system fire, which could result in death or serious injury. (00101a)**

*NOTE:*

*Do NOT strike filter element on a hard surface to dislodge dirt.*

1. Wash the paper/wire mesh air filter element and breather hoses in lukewarm water with a mild detergent.

*NOTE:*

*Do NOT use air cleaner filter oil on the Harley-Davidson paper/wire mesh air filter element.*

### **⚠ WARNING**

**Compressed air can pierce the skin and flying debris from compressed air could cause serious eye injury. Wear safety glasses when working with compressed air. Never use your hand to check for air leaks or to determine air flow rates. (00061a)**

2. Allow filter element to air dry or use low-pressure compressed air blowing from the inside.
3. Hold the filter element up to a strong light source. The element is sufficiently clean when light is uniformly visible through the media.
4. Replace the filter element if damaged or if filter media cannot be adequately cleaned.

## Headlamp Bulb Replacement

### WARNING

Handle bulb carefully and wear eye protection. Bulb contains gas under pressure, which, if not handled carefully, could cause serious eye injury. (00062b)

### CAUTION

When replacement is required, use only the specified sealed beam unit or bulb, available from a Harley-Davidson dealer. An improper wattage sealed beam or bulb, can cause charging system problems. (00209a)

Replace burned out bulbs.

## Bulb Removal

---

### WARNING

To prevent accidental vehicle start-up, which could cause death or serious injury, remove main fuse before proceeding. (00251b)

#### NOTE:

*Make note of components during disassembly to aid in assembly.*

1. Remove main fuse. See Fuses.
2. See Headlamp Bulbs. Remove trim ring hardware (1). Remove trim ring (2).
3. Remove mounting ring (3) and bumper, if equipped.
4. Disconnect headlamp connector (8) from bulb (5).
5. Remove rubber boot (6), if equipped, from back of headlamp lens (4).
6. Remove wire retaining clip (7) from headlamp base.
7. Remove bulb from headlamp assembly.
8. **For International Models Only:** Rotate boot (10) one-quarter turn and remove bulb assembly from housing. Pull position bulb (9) to remove from boot.

## Bulb Installation

---

### CAUTION

Never touch the quartz bulb. Fingerprints will etch the glass and decrease bulb life. Handle the bulb with paper or a clean, dry cloth. Failure to do so could result in bulb

## damage. (00210b)

NOTE:


When installing a **new** bulb, make sure connector contacts are clean for good electrical contact.

1. Install **new** bulb and assemble the headlamp components.
2. **For International Models Only:** Install **new** bulb in boot. Install boot in housing. Rotate one-quarter turn.
3. Verify slots and tabs in headlamp and trim ring are aligned.
4. Install rubber boot with word TOP at the top of the headlamp lens assembly.
5. Connect the headlamp connector.
6. Install bumper, if equipped.
7. Install trim ring and hardware.
8. Install main fuse.

### WARNING

**Be sure that all lights and switches operate properly before operating motorcycle. Low visibility of rider can result in death or serious injury. (00316a)**

9. Turn ignition on. Check operation of all lamps.
10. If necessary, align headlamp assembly. See Headlamp Alignment.



# Headlamp Alignment

---

NOTE:

*Adjust headlamp beams to converge into one pattern.*

1. Check tire pressure.
2. Adjust the suspension to the weight of the rider.
3. Fill fuel tank or add an equal amount of ballast.

NOTE:


*See Headlamp Alignment. Draw a perpendicular line (1) on the floor. For best results, choose an area with minimum light.*

4. Draw a vertical line (2) on the wall.
5. Position the front axle 25 ft 7.6 m from wall.

NOTE:


*Because a riders weight compresses the suspension slightly, have a person whose weight is approximately the same as that of the rider sit on the motorcycle.*

6. With the vehicle laden and upright, point the front wheel straight forward at wall. Measure the distance (4) from the floor to the center of the high beam bulb.
7. Draw a horizontal line (5) through the vertical line on the wall 2.1 in 53.3 mm lower than the measured bulb centerline.
8. Align headlamp. With the ignition on, set the headlamp switch to high beam.
  - a. Center the center of the hot spot (brightest area of light beam) on the two intersecting lines.
  - b. Adjust headlamp alignment if necessary.



## Headlamp Adjustment

1. See Headlamp Adjustment. Loosen horizontal adjustment fastener (2). Tilt headlamp horizontally to direct light beam straight ahead.
2. Tighten horizontal adjustment fastener (2) to 30-35 ft-lbs (40.7-47.5 Nm).
3. Loosen vertical adjustment fastener (1). Tilt headlamp vertically until beam centers on horizontal line.
4. Tighten vertical adjustment fastener (1) to:
  - a. **FXSB:** 25-30 ft-lbs (33.9-40.7 Nm).
  - b. **All except FXSB:** 35-45 ft-lbs (47.5-61.0 Nm).



## LED Rear Turn Signal/Tail Lamps: International FLS, FLSS, FXSB

---

On FLS, FLSS and FXSB models (except Domestic and Canada configurations), the rear turn signal/tail lamps are LED assemblies with no replaceable bulbs. Caps on rear turn signals are not removable. See an authorized Harley-Davidson dealer for assembly replacement.

## Turn Signal Bulb Replacement: Bullet Style

---

*NOTE:*


*Models with LED lamps do not contain replacement bulbs. Replace the LED assembly.*

1. See Remove Lens. Insert a coin or the blade of a small screwdriver into the notch at the bottom of the lens cap. Carefully twist until the lens cap pops out of the lamp housing.
2. Push bulb in and rotate counterclockwise. Pull bulb from socket.
3. Inspect condition of electrical contacts in socket. If necessary, clean with a small wire brush and electrical contact cleaner.
4. Apply ELECTRICAL CONTACT LUBRICANT to contacts in socket and at bottom of **new** bulb.
5. Align pins on **new** bulb with pin guides in bulb socket. Push bulb in and turn clockwise to lock in place.
6. Snap lens cap onto the lamp housing with notch at bottom.

## ⚠ WARNING

**Be sure that all lights and switches operate properly before operating motorcycle. Low visibility of rider can result in death or serious injury. (00316a)**

7. Check operation of all lamps.




### Turn Signal Bulb Replacement: Flat Lens Style

1. See Turn Signal Lamp Assembly: Flat Lens Style. Remove two screws (1) to release lens (2) from lamp housing (4).
2. While pushing bulb (3) in, rotate counterclockwise to remove.
3. Inspect condition of electrical contacts in socket. If necessary, clean with a small wire brush and electrical contact cleaner.
4. Apply ELECTRICAL CONTACT LUBRICANT to contacts in socket and at bottom of **new** bulb.
5. Align pins on **new** bulb with guides in bulb socket. Push and rotate new bulb clockwise into socket.
6. Secure lens (2) to lamp housing (4) with two screws (1).

## ⚠ WARNING

**Be sure that all lights and switches operate properly before operating motorcycle. Low visibility of rider can result in death or serious injury. (00316a)**

7. Check operation of all lamps.



- 1. Screws (2)
- 2. Lens
- 3. Bulb
- 4. Lamp housing

**Turn Signal Lamp Assembly: Flat Lens  
Style**

## Tail Lamp Bulb Replacement

1. See Tail Lamp Assembly. Turn ignition switch OFF.

2. Remove two screws and lens (1) from base (2).

*NOTE:*

*Disconnect 4-pin multilock connector from circuit board to simplify bulb removal.*

3. Remove bulb assembly from lens. Remove bulb.

4. Coat base of **new** bulb with ELECTRICAL CONTACT LUBRICANT (Part No. 11300004).  
Install **new** bulb.

5. Install bulb assembly to lens (1).


6. If removed, connect 4-pin multilock connector (3) to circuit board.

7. Install lens (1) to base (2) with two screws. Tighten to 20-24 in-lbs (2.3-2.7 Nm).

### **⚠ WARNING**

**Be sure that all lights and switches operate properly before operating motorcycle. Low visibility of rider can result in death or serious injury. (00316a)**

8. Turn ignition on. Check operation of all lamps.




### Tail Lamp Bulb Replacement: Tombstone Style

1. See Tail Lamp Assembly: Tombstone Style. Turn ignition switch OFF.
2. Remove three screws (1) to detach the tail lamp assembly (2) from base.
3. Push bulb (3) into socket. Rotate one-quarter turn counterclockwise. Pull bulb from socket.
4. Inspect condition of electrical contacts in socket. If necessary, clean with a small wire brush and electrical contact cleaner.
5. Coat base of **new** bulb with ELECTRICAL CONTACT LUBRICANT (Part No. 11300004).
6. Orient index pins on **new** bulb (3) with pin guides inside bulb socket. Push and rotate **new** bulb clockwise into socket.
7. Install tail lamp assembly (2) to base with three screws (1). Tighten screws to 20-24 in-lbs (2.3-2.7 Nm).

#### **⚠ WARNING**

**Be sure that all lights and switches operate properly before operating motorcycle. Low visibility of rider can result in death or serious injury. (00316a)**

8. Turn ignition on. Check operation of all lamps.



## Battery Maintenance

### Type

Your motorcycle uses an Absorbed Glass Mat (AGM) battery. The AGM battery is permanently sealed, valve regulated, maintenance-free, lead/calcium and sulfuric acid battery. All batteries are shipped precharged and ready for service. Do not attempt to open the battery for any reason.

#### Antidotes for Battery Acid

| CONTACT  | TREATMENT                                                                                                                             |
|----------|---------------------------------------------------------------------------------------------------------------------------------------|
| External | Flush with water.                                                                                                                     |
| Internal | Drink large quantities of milk or water, followed by milk of magnesia, vegetable oil or beaten eggs. Get immediate medical attention. |
| Eyes     | Flush with water. Get immediate medical attention.                                                                                    |

#### **⚠ WARNING**

**Batteries contain sulfuric acid, which could cause severe burns to eyes and skin. Wear a protective face shield, rubberized gloves and protective clothing when working with batteries. KEEP BATTERIES AWAY FROM CHILDREN.**

(00063a)

**⚠ WARNING**

Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)


**⚠ WARNING**

Batteries, battery posts, terminals and related accessories contain lead and lead compounds, and other chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling. (00019e)

**⚠ WARNING**

Never remove warning label attached to top of battery. Failure to read and understand all precautions contained in warning, could result in death or serious injury. (00064a)

om01163



Battery Warning Label



## Voltmeter Test

The voltmeter test provides a general indicator of battery condition. Check the voltage of the battery to verify that it is in a 100 percent fully charged condition. If the open circuit (disconnected) voltage reading is below 12.7 V, charge the battery. Recheck the voltage after the battery has set for one to two hours. Refer to Voltmeter Test.

Voltmeter Test

| READING IN VOLTS | PERCENT OF CHARGE |
|------------------|-------------------|
| 12.7             | 100               |
| 12.6             | 75                |
| 12.3             | 50                |
| 12.0             | 25                |
| 11.8             | 0                 |

## Cleaning and Inspection

Battery top must be clean and dry. Dirt and electrolyte on top of the battery can cause battery to self-discharge.

1. Clean battery top.
2. Clean cable connectors and battery terminals using a wire brush or fine grit sandpaper to remove any oxidation.
3. Inspect and clean the battery screws, clamps and cables. Check for breakage, loose connections and corrosion.

4. Check the battery posts for melting or damage caused by over-tightening.
5. Inspect the battery for discoloration, a raised top or a warped or distorted case. These conditions might indicate that the battery has been frozen, overheated or overcharged.
6. Inspect the battery case for cracks or leaks.

## Charging

---

An automatic, constant monitoring battery charger/tender with a charging rate of 5 amps or less at less than 14.6 volts is recommended. The use of constant current chargers (including trickle chargers) to charge sealed AGM batteries is not recommended. Any overcharge will cause dry-out and premature battery failure. Never charge a battery without first reviewing the instructions for the charger being used. In addition to the manufacturer's instructions, follow these general safety precautions.

Charge the battery if any of the following conditions exist:

- Vehicle lamps appear dim.
- Electric starter sounds weak.
- Battery has not been used for an extended time.

### WARNING

**Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)**

### WARNING

**Batteries contain sulfuric acid, which could cause severe burns to eyes and skin. Wear a protective face shield, rubberized gloves and protective clothing when working with batteries. KEEP BATTERIES AWAY FROM CHILDREN. (00063a)**

1. Perform a voltmeter test to determine the state of charge. If battery needs to be charged, proceed to the next step.
2. Place the battery on a level surface.

### WARNING

**Unplug or turn OFF battery charger before connecting charger cables to battery. Connecting cables with charger ON can cause a spark and battery explosion, which could result in death or serious injury. (00066a)**

### WARNING

**Connect positive (+) battery cable first. If positive (+) cable**

should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)

### **⚠ WARNING**

**Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00049a)**

### **CAUTION**

**Do not reverse the charger connections described in the following steps or the charging system of the motorcycle could be damaged. (00214a)**

*NOTES:*

- *Do not use chargers with excessively high voltage designed for flooded batteries or excessively high current designed for much larger batteries. Do not charge at more than 5 amps or more than 14.6 volts.*
- *Most automatic, constant monitoring battery chargers are completely automatic and can be left connected to both AC power and to the battery that is being charged. When leaving this type of charger connected for extended periods of time, periodically check the battery to see if it is unusually warm. This is an indication that the battery may have a weak cell or internal short. Read the manufacturer's instructions for the charger being used.*

3. Connect the red battery charger lead to positive terminal of the battery.
4. Connect the black battery charger lead to negative terminal of the battery.

*NOTE:*

*If the battery is still in the vehicle, connect the negative lead to the chassis ground. Make sure that the ignition and all electrical accessories are turned off.*

5. Step away from the battery and turn on the charger.

### **⚠ WARNING**

**Unplug or turn OFF battery charger before disconnecting charger cables from battery. Disconnecting clamps with charger ON can cause a spark and battery explosion, which could result in death or serious injury. (00067a)**

6. After the battery is fully charged, turn OFF the charger. Disconnect the black battery charger lead from the negative terminal of the battery.
7. Disconnect the red battery charger lead from the positive terminal of the battery.
8. Mark the charging date on the battery.


## Storage

If the motorcycle will not be operated for several weeks, such as during the winter season, remove the battery from the motorcycle and fully charge.

If the motorcycle will be stored with the battery installed, connect an automatic, constant monitoring charger/tender to maintain charge. See an authorized Harley-Davidson dealer for more information.

A battery that is removed from the vehicle is affected by self-discharge. A battery that is stored in the vehicle is affected by both self-discharge and, more significantly, parasitic loads.

- Batteries self-discharge at a faster rate at higher ambient temperatures.
- To reduce the self-discharge rate, store battery in a cool, dry place.
- Charge the battery every two weeks if stored in the vehicle.
- Charge the battery once per month if stored out of the vehicle.



## Battery Disconnection and Removal


### ⚠ WARNING

Disconnect negative (-) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery

**explosion, which could result in death or serious injury.**  
**(00049a)**

**Security siren:** To prevent the optional siren from sounding, turn on the ignition with the hands-free fob present to disarm the security system.

1. Remove seat.
2. See Battery: Softail Models. Remove battery negative cable (black) from battery negative terminal.
3. Remove battery positive cable (red) from battery positive terminal.
4. Remove battery.



## Battery Installation and Connection

### **⚠ WARNING**

**Be sure rubber boot covers starter solenoid terminal connected to positive (+) battery cable. An uncovered terminal can short and cause sparks, which could result in a battery explosion and death or serious injury. (00463c)**

1. See Battery Caddy. Place battery caddy into position and install battery caddy clip (1) under front of battery tray (3). Make sure tabs (2) of battery caddy fit over rear of battery tray.
2. See Battery Caddy Wire Routing. Install positive battery cable (1) into clip in caddy. Place an S-shaped bend in the positive battery cable at the starter end of the cable. This

properly positions the terminal end for battery installation.

3. Route rear O2 sensor harness (2) through clip (3).

#### **⚠WARNING**

**Connect positive (+) battery cable first. If positive (+) cable should contact ground with negative (-) cable connected, the resulting sparks can cause a battery explosion, which could result in death or serious injury. (00068a)**

#### **CAUTION**

**Connect the cables to the correct battery terminals. Failure to do so could result in damage to the motorcycle electrical system. (00215a)**


4. See Battery: Softail Models. Install battery. Tighten positive battery terminal fastener to 60-72 in-lbs (6.8-8.1 Nm).
5. Install negative battery cable at battery frame ground (1) before any accessory ground wires.
6. Install negative battery cable (2) at battery. Tighten negative battery terminal fastener to 60-72 in-lbs (6.8-8.1 Nm).

#### **⚠WARNING**

**After installing seat, pull upward on seat to be sure it is locked in position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070b)**

7. Install seat.


sm03812b



1. Clip
2. Tabs
3. Battery tray


**Battery Caddy**

om02169



1. Positive battery cable
2. Rear oxygen sensor harness
3. Clip

**Battery Caddy Wire Routing**



## Jump Starting

Jump starting a motorcycle is not recommended. However, in circumstances when a jump-start is necessary, use the following procedure.

### **⚠ WARNING**

Be sure jumper cables touch only appropriate battery terminals or ground. Allowing jumper cables to touch each other can result in sparks and a battery explosion, which could result in death or serious injury. (00072a)

### **⚠ WARNING**

Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. **KEEP BATTERIES AWAY FROM CHILDREN.** (00065a)

### **CAUTION**

Be sure both vehicles have the same battery voltage when jump starting. Connecting vehicles with different system voltages can result in vehicle damage. (00220c)

#### NOTES:

- *DO NOT jump-start from a running BOOSTER vehicle. The high output charging systems on*

*some vehicles can damage the motorcycle's electrical components.*

- *Make sure the motorcycle and the BOOSTER vehicle are not touching one another.*

## Connection

---

1. Turn off all unnecessary lamps and accessories.
2. See Jump-Start Cable Connections. Connect one end of a jumper cable to the motorcycle DISCHARGED battery positive terminal (1).
3. Connect the other end of the same cable to the BOOSTER vehicle battery positive terminal (2).

### **⚠WARNING**

**Do not connect negative (-) cable to or near the discharged battery negative (-) terminal. Doing so could cause a spark and explosion, which could result in death or serious injury. (00073a)**

4. Connect one end of a jumper cable to the BOOSTER vehicle battery negative terminal (3).

### **CAUTION**


**Do not connect the negative (-) cable to painted or chrome parts. Doing so could result in discoloration at the attachment point. (00221a)**

5. Connect other end of the same cable (4) to a safe motorcycle ground away from the DISCHARGED battery.
6. Start the motorcycle.

## Disconnection

---

1. See Jump-Start Cable Connections. With the motorcycle continuing to run, remove the negative jumper cable motorcycle ground (4).
2. Remove the negative jumper cable from the BOOSTER vehicle battery negative terminal (3).
3. Remove the positive jumper cable from the BOOSTER vehicle battery positive terminal (2).
4. Remove the positive jumper cable from the DISCHARGED motorcycle battery positive terminal (1).



1. Discharged battery positive terminal
2. Booster battery positive terminal
3. Booster battery negative terminal
4. Ground

**Jump-Start Cable Connections**

## Fuses

## Fuses

See Fuse Block. The electrical circuits are protected by three fuses. Individual vehicle circuits are protected by the body control module (BCM).

- Main (1): A 40 A fuse that protects all the circuits including those protected by the 15 A Battery fuse. Failure of this fuse will cause the motorcycle to stop running. See a Harley-Davidson dealer.
- P&A (2): A 15 A fuse protects the circuits of any installed accessories.
- Battery (3): A 15 A fuse that protects all the circuits. If the battery fuse fails while the engine is running, the engine will continue to run and critical circuits like the ABS brakes will continue to function. The failure of this fuse will trigger a diagnostic code. See a Harley-Davidson dealer.

## Removal

1. If equipped with security system siren, turn the ignition to ON with the fob present to disarm the security system.
2. Remove the seat. See Seats.

3. See Fuse Block Location. Pull cover off fuse block.

4. See Fuse Block. Remove suspect fuse.

## Installation

---

### CAUTION

**Always use replacement fuses that are of the correct type and amperage rating. Use of incorrect fuses can result in damage to electrical systems. (00222a)**


1. Install **new** fuse.


2. Place cover on fuse block.

### ⚠WARNING

**After installing seat, pull upward on seat to be sure it is locked in position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070b)**

3. Install seat. See Seats.





## Seats


---

## General

---


See Seat Tongue (typical) and Frame Back. The seat has a tongue which engages a slot in the back end of the frame. Follow the appropriate procedure for your model motorcycle to remove or install the seat.

om01308



Seat Tongue (typical)

om00134



Frame Back

**Seats: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FXSB**

## Removal


## ⚠ WARNING


**After installing seat, pull upward on seat to be sure it is locked in position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070b)**

1. See Seat: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FXSB. Remove the thumbscrew (1).
2. Remove the passenger pillion (2).
3. Remove mounting nuts (4).
4. Raise the rear of the seat (5, 6, 7, or 8) off the mounting posts and slide seat tongue out of the frame.
5. Remove grab strap (3).

## Installation

1. See Seat: FLSTC, FLSTF, FLSTFB, FLSTFBS, FLSTN, FXSB. Install seat strap (3) on the mounting posts on rear fender.
2. Insert tongue at front of seat into the channel in the frame.
3. Install rear of seat on the mounting posts on rear fender. Install mounting nuts (4) and tighten.
4. Slide slots on passenger pillion (2) to engage the seat mounting nuts.
5. Install thumbscrew (1) and tighten.





**Seats: FLS, FLSS**

## Removal

1. See Seat: FLS, FLSS. Remove seat mounting screw (1) from top of rear fender.
2. See Seat Tongue (typical). Push seat rearward to free tongue (2) at front of seat from slot or bracket in frame back.
3. Remove seat.


## Installation

1. See Seat: FLS, FLSS. Place seat on frame back.
2. Slide seat toward front of motorcycle until the tongue (2) locks into the bracket or slot in the frame back.
3. Push seat forward to center rear fender seat retention nut in hole of mounting bracket.
4. Hand-tighten the seat mounting screw (1).

### **⚠WARNING**

**After installing seat, pull upward on seat to be sure it is locked in position. While riding, a loose seat can shift causing loss of control, which could result in death or serious injury. (00070b)**

5. Pull up on seat to verify that it is properly secured.



1. Mounting screw
2. Tongue

Seat: FLS, FLSS

## Motorcycle Storage

### Placing Motorcycle in Storage

#### CAUTION

Proper storage is important for the trouble-free operation of your motorcycle. See your Owner's Manual for storage recommendations or see a Harley-Davidson dealer. Improper storage procedures can lead to equipment damage. (00046a)

If the motorcycle is not to be ridden for several months, such as during the winter season, there are several tasks which must be performed. These steps protect parts against corrosion, preserve the battery and prevent the build-up of gum and varnish in the fuel system.

If possible, store the motorcycle in a dry area with a stable temperature. Keep the motorcycle away from harsh chemicals or other substances such as fertilizers or salt.

#### ⚠ WARNING

Do not store motorcycle with gasoline in tank within the home or garage where open flames, pilot lights, sparks or electric motors are present. Gasoline is extremely flammable and highly explosive, which could result in death or serious injury. (00003a)

NOTE:

*Make a list of everything you do and fasten it to a hand grip. When you take the motorcycle out of storage, this list is your reference/checklist to get your motorcycle in operating condition.*

1. Fill fuel tank. Add fuel stabilizer following manufacturer's instructions.
2. Warm motorcycle to operating temperature. Change oil and turn engine over to circulate the **new** oil.
3. Check and adjust belt if necessary.
4. Check tire pressure. Refer to Specified Tires for specified pressure.
5. Protect the body panels, engine, chassis and wheels from corrosion. Follow the cosmetic care procedures described in the Care and Cleaning section before storage.
6. Prepare battery for storage. See Battery Maintenance.

**⚠ WARNING**

**Explosive hydrogen gas, which escapes during charging, could cause death or serious injury. Charge battery in a well-ventilated area. Keep open flames, electrical sparks and smoking materials away from battery at all times. KEEP BATTERIES AWAY FROM CHILDREN. (00065a)**

NOTES:

- *If the motorcycle is being stored with the security system armed, connect a 750mA SUPERSMART BATTERY TENDER 66000038 to maintain battery charge.*
  - *If the motorcycle is being stored with the security system disarmed, turn on the motorcycle while the hands-free fob is present. This operation prevents the optional siren from sounding. Disconnect the negative battery cable and prepare battery for storage. See Battery Maintenance.*
7. Use a material such as light canvas that can breathe to cover the motorcycle. Plastic materials that do not breathe promote the formation of condensation.
  8. Remove the antennas or allow them to protrude through the cover, if equipped. Do not bend or tuck antennas under the cover.

## Removing Motorcycle from Storage

---

**⚠ WARNING**

**The clutch failing to disengage can cause loss of control, which could result in death or serious injury. Prior to starting after extended periods of storage, place transmission in gear and push vehicle back and forth several times to assure proper clutch disengagement. (00075a)**

NOTE:

*Lubricants contaminated with water have a milky white appearance. Replace contaminated*

*lubricants with the appropriate **new** Harley-Davidson lubricant.*

1. Charge the battery.
2. Install battery. See Battery Maintenance.
3. Run motorcycle until engine is at normal operating temperature. Turn off engine.
4. Check engine oil level.
5. Check lubricant level.
6. Check controls to make sure that they are operating properly. Operate the front and rear brakes, throttle, clutch and shifter.
7. Check steering for smoothness by turning the handlebars through the full operating range.

#### **⚠ WARNING**

**Be sure tires are properly inflated, balanced, undamaged, and have adequate tread. Inspect your tires regularly and see a Harley-Davidson dealer for replacements. Riding with excessively worn, unbalanced, improperly inflated, overloaded or damaged tires can lead to tire failure and adversely affect stability and handling, which could result in death or serious injury. (00014b)**

8. Check tire pressure. Refer to Specified Tires for specified pressure.
9. Check overall tire condition. See Tire Replacement.
10. Test all switches and lights for proper operation.
11. Check for any fluid leaks.

#### **CAUTION**

**Turn engine over a few times to be sure there is no oil in the crankcase and that all oil has been pumped back into the oil tank. Stop engine and re-check oil level. Failure to do so can result in engine damage. (00071a)**

## **Care and Cleaning**

### **Cleaning and General Care**

---

Clean and protect the cosmetic surfaces on your motorcycle as often as possible to inhibit rust and corrosion. After the motorcycle is cleaned, polish and seal the motorcycle to create a barrier of protection against the weather and harsh substances.

Harley-Davidson cleaning products are tested extensively for use on vehicle surfaces. These products are formulated to be compatible with one another. See a Harley-Davidson dealer to purchase recommended cleaning products. Refer to Recommended Cleaning and Care

Products and Recommended Surface Care Products.

NOTES:

- Use recommended surface care products. Do not use paper towels, terry cloths, cloth diapers or other materials with nylon fibers which can create fine scratches to surfaces.
- Dirty cleaning materials can scratch finished surfaces. Use only clean sponges and detailing cloths to prevent damage to the motorcycle.
- For repair of scratched surfaces, see a Harley-Davidson dealer.

**⚠WARNING**

Observe warnings on labels of cleaning compounds.  
Failure to follow warnings could result in death or serious injury. (00076a)

**⚠WARNING**

Do not wash brake discs with cleaners containing chlorine or silicone. Cleaners containing chlorine and silicone can impair brake function, which could result in death or serious injury. (00077a)

**CAUTION**

Do not use a pressure washer to clean motorcycle. Using a pressure washer can result in equipment damage. (00489c)

**CAUTION**

Use of abrasive products or powered buffing equipment will cause permanent cosmetic damage to body panels. Use only recommended products and techniques outlined in this manual to avoid damaging body panels. (00245b)

Recommended Cleaning and Care Products

| PRODUCT<br><br>PART NO.                                           | PURPOSE                                                                           | FRAME         | BODY<br><br>PANELS | WHEELS | DENIM<br><br>FINISH | OTHER              |
|-------------------------------------------------------------------|-----------------------------------------------------------------------------------|---------------|--------------------|--------|---------------------|--------------------|
| BARE ALUMINUM WHEEL PROTECTANT - INDIVIDUAL WIPES<br><br>93600063 | Corrosion control for bare aluminum surfaces.                                     | No            | No                 | Yes    | No                  | "Burst" collection |
| BARE METAL POLISH<br><br>93600028 (U.S.)<br><br>93600083 (Non-    | Polishes non-clear coated polished aluminum or polished stainless steel surfaces. | As applicable |                    |        |                     |                    |

|                                                                     |                                                                                                      |               |     |               |     |                       |
|---------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|---------------|-----|---------------|-----|-----------------------|
| U.S.)                                                               |                                                                                                      |               |     |               |     |                       |
| BLACK LEATHER REJUVENATOR<br>93600033 (U.S.)<br>93600081 (Non-U.S.) | Rejuvenates black leather products so they look brand new.                                           | No            | No  | No            | No  | Black leather goods   |
| BOOT MARK REMOVER<br>93600001 (U.S.)<br>93600069 (Non-U.S.)         | Removes boot marks from chrome exhaust components.                                                   | No            | No  | No            | No  | Exhaust system        |
| BUG REMOVER<br>93600022 (U.S.)<br>93600075 (Non-U.S.)               | Removes bugs from metal, plastic or painted surfaces. Also available as individual wipes (93600065). | Yes           | Yes | Yes           | Yes |                       |
| CHROME CLEAN & SHINE<br>93600031 (U.S.)<br>93600082 (Non-U.S.)      | Shines chrome-plated surfaces and cleans brushed aluminum or stainless steel surfaces.               | As applicable |     |               |     |                       |
| DENIM PAINT CLEANER<br>93600064 (U.S.)<br>93600078 (Non-U.S.)       | Waterless quick cleaner and detailer.                                                                | Yes           | Yes | Yes           | Yes |                       |
| ENGINE BRIGHTENER<br>93600002 (U.S.)<br>93600068 (Non-U.S.)         | Rejuvenates wrinkle black engine finish.                                                             | No            | No  | No            | No  | Wrinkle black engines |
| GLAZE POLY SEALANT<br>93600026 (U.S.)<br>93600079 (Non-U.S.)        | Provides a protective barrier for glossy paint surfaces and chrome.                                  | Yes           | Yes | As applicable | No  |                       |
| GLOSS DETAILER<br>93600062 (U.S.)                                   | Produces high gloss with UV protection. Allows chrome to breathe, unlike wax. Good for               | Yes           | Yes | Yes           | No  |                       |

|                                                                  |                                                                                                                   |     |     |     |     |                                         |
|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|-----|-----|-----|-----|-----------------------------------------|
| 93600073 (Non-U.S.)                                              | windshields. Also available as individual wipes (97401-10).                                                       |     |     |     |     |                                         |
| HARLEY TRAVEL CARE KIT<br>93600007                               | Travel size cleaning and care products.                                                                           | Yes | Yes | Yes | Yes |                                         |
| LEATHER PROTECTANT<br>93600034 (U.S.)<br>93600080 (Non-U.S.)     | Weatherproofs and preserves leather products.                                                                     | No  | No  | No  | No  | Leather goods                           |
| QUICK WASH<br>93600012 (U.S.)<br>93600071 (Non-U.S.)             | A quick wash for a lightly soiled motorcycle. Cleans all surfaces, sheeting action prevents spots.                | Yes | Yes | Yes | Yes |                                         |
| SCRATCH & SWIRL REPAIR<br>93600025 (U.S.)<br>93600074 (Non-U.S.) | Removes fine scratches and swirls.                                                                                | Yes | Yes | No  | No  |                                         |
| SEAT, SADDLEBAG & TRIM CLEANER<br>93600010                       | Cleans and conditions vinyl, leather and plastic. Use on seats, saddlebags, inner fairings and any other trim.    | No  | No  | No  | No  | Seats, saddlebags and trim              |
| SPRAY CLEANER & POLISH<br>93600029 (U.S.)<br>93600084 (Non-U.S.) | Aerosol quick cleaner and detailer. Reduces static attraction to dust. Works great for removing bugs.             | Yes | Yes | Yes | No  |                                         |
| SUNWASH BIKE SOAP<br>93600023 (U.S.)<br>93600077 (Non-U.S.)      | Thorough washing of all surfaces with a wash mitt. Reduces hard water spots when washing a motorcycle in the sun. | Yes | Yes | Yes | Yes |                                         |
| WHEEL & TIRE CLEANER<br>93600024 (U.S.)<br>93600076 (Non-U.S.)   | Removes brake dust and road grime from wheels, tires and whitewalls. Do not use on frames or anodized parts.      | No  | No  | Yes | No  | Black-coated exhaust pipes and mufflers |

|                                                                  |                                                               |     |     |    |    |            |
|------------------------------------------------------------------|---------------------------------------------------------------|-----|-----|----|----|------------|
| WINDSHIELD<br>CLEANER<br><br>93600067                            | Quick windshield cleaner<br>in convenient single use<br>wipe. | Yes | Yes | No | No | Windshield |
| WINDSHIELD<br>WATER<br><br>REPELLENT<br><br>93600032<br>(Global) | Allows water to bead and<br>dissipate from the<br>windshield. | No  | No  | No | No | Windshield |

**Recommended Surface Care Products**

| <b>PRODUCT<br/><br/>PART NO.</b>                                                   | <b>PURPOSE</b>                                                                                                              |
|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| BUG EATER<br>SPONGE<br><br>93600110                                                | When paired with water and BUG REMOVER, the BUG EATER SPONGE breaks down and dissolves baked on bugs and road grime.        |
| CLEANING BRUSH<br>KIT<br><br>94844-10                                              | Brush kit for detailing your motorcycle.                                                                                    |
| DETAILING SWABS<br><br>93600107                                                    | Large cotton swabs for cleaning crevices and detailed surfaces.                                                             |
| DISPOSABLE<br>DETAILING SOFT<br>CLOTH<br><br>93600114                              | Non-absorbent cloth for applying and buffing SWIRL & SCRATCH REPAIR and GLAZE POLY SEALANT to painted surfaces or chrome.   |
| HARLEY WASH<br>BUCKET<br><br>94811-10                                              | Wash bucket with apron to hold your supplies. Includes GRIT GUARD insert.                                                   |
| HOG BLASTER<br>MOTORCYCLE<br>DRYER<br><br>94651-09 (120 V)<br><br>94865-09 (220 V) | Blows a stream of warm dry filtered air. Reduces streaks and water spots.                                                   |
| MICROFIBER<br>DETAILING CLOTH<br><br>94663-02                                      | Highly absorbent detailing cloth for polishing and sealing. Contains no nylon fibers.                                       |
| SYNTHETIC DRYING<br>CHAMOIS<br><br>94791-01                                        | Extra-absorbent, non-streaking synthetic towel for drying. Dampen towel and wring out before using for greatest absorbency. |
| WASH MITT                                                                          | Absorbent wool-blended washing mitten.                                                                                      |

|                        |                                     |
|------------------------|-------------------------------------|
| 94760-99               |                                     |
| WHEEL & SPOKE<br>BRUSH | Cone-shaped scrub brush for wheels. |
| 43078-99               |                                     |

## Washing the Motorcycle

---

Use only recommended cleaning and care products. Refer to Recommended Cleaning and Care Products and Recommended Surface Care Products.

*NOTE:*

*During rinsing and washing, avoid direct spray on electrical components and any luggage or saddlebag sealing areas (if equipped). Avoid spraying water under leather saddlebag covers (if equipped).*

## Preparation

---

1. Allow motorcycle to cool before rinsing or washing. Spraying water on hot surfaces can leave water spots and mineral deposits.
2. Rinse the motorcycle from the bottom up.
3. To loosen dried bugs or hardened dirt, allow surfaces to soak under a damp towel.

## Cleaning Wheels and Tires

---

1. Rinse wheel and tire surfaces. Avoid splashing brake dust on chrome or painted parts.
2. Apply WHEEL & TIRE CLEANER. Allow cleaner to set for one minute.
3. Clean the wheel with a BUG EATER SPONGE or WHEEL & SPOKE BRUSH. Thoroughly scrub all brake dust and other sediments off the wheel. Accumulated brake dust can trap moisture and dirt, which leads to wheel corrosion.
4. Rinse well.

## Washing the Motorcycle

---

*NOTE:*

*See the appropriate instructions in this section for cleaning leather, denim (flat) finishes, windshields or other special surfaces.*

1. If necessary, use BUG REMOVER to remove bug splatters.
  - a. Rinse the affected surfaces during preparation.
  - b. Spray the area with BUG REMOVER.

- c. Wait one minute while the BUG REMOVER penetrates the bug splatters.
  - d. Use the BUG EATER SPONGE while washing to easily remove bugs.
2. Prepare the wash.
  - a. Fill a HARLEY WASH BUCKET with clean water.
  - b. Add SUNWASH BIKE SOAP, following the directions on the package.
  - c. Soak the WASH MITT and/or a BUG EATER SPONGE in the SUNWASH solution.
3. Wash all surfaces starting at the top working down toward the ground.
4. Rinse the motorcycle twice in both directions:
  - a. Rinse from the bottom up.
  - b. Rinse from the top down.

## Drying the Motorcycle

---

1. Dry the surfaces from the top down using a SYNTHETIC DRYING CHAMOIS or a HOG BLASTER MOTORCYCLE DRYER. Avoid using any type of forced air on speakers or other sensitive components.
2. Dampen chamois in clean water and wring out the excess. The chamois is more absorbent when wet.
3. Wipe across the vehicle surface.
4. Repeat as necessary until surface is dry.

## Polishing and Sealing

---

NOTE:

*If motorcycle has denim finish, skip the Polishing and Sealing procedure.*

1. Apply GLAZE POLY SEALANT with a DISPOSABLE DETAILING SOFT CLOTH or MICROFIBER DETAILING CLOTH, following the instructions on the package.
2. Buff with a DISPOSABLE DETAILING SOFT CLOTH.
3. Polish and seal the wheels to prevent corrosion.

## Denim Finish Care

---

Some motorcycles have a denim (flat or matte) finish. The denim finish has qualities which differ from high gloss finishes on all other Harley-Davidson motorcycles. Like denim fabric, denim paint burnishes or mars with age and use that adds character and personality to the finish. Refer to Recommended Cleaning and Care Products for recommended products.

- If scratched, the color coat of paint does nick/scuff and these marks cannot be rubbed out.
- If polished, the finish will become less matte and more glossy over time.

## How to Clean

---

**For light deposits:** Use DENIM PAINT CLEANER and a MICROFIBER DETAILING CLOTH. This treatment helps remove finger prints and light soil.

**For heavier deposits:** Use either SUNWASH BIKE SOAP and a clean WASH MITT or QUICK WASH. Rinse thoroughly with clean water.

## Leather and Vinyl Care

---

### CAUTION

**Do not use bleach or detergents containing bleach on saddlebags, seats, tank panels or painted surfaces. Doing so can result in equipment damage. (00229a)**

Do not use ordinary soap to clean leather or fur. It could dry or remove the oils from the leather.

Leather, vinyl and other synthetic surfaces must be periodically cleaned and treated to maintain its appearance and extend its life. Clean and treat these surfaces once a season or more frequently under adverse conditions.

These surfaces are not designed for long-term exposure to inclement weather. Protect these surfaces with an HARLEY-DAVIDSON SEAT RAIN COVER or MOTORCYCLE STORAGE COVER (sold separately).

1. Vacuum or blow dust off surface.
2. Thoroughly clean surfaces with SEAT, SADDLEBAG & TRIM CLEANER, following directions on the bottle.
3. Allow the material to dry naturally and completely at room temperature before applying other products to the material. Do not use artificial means to dry the material quickly.
4. For leather only, rejuvenate faded black surfaces with BLACK LEATHER REJUVENATOR. Apply LEATHER PROTECTANT to weatherproof and preserve the leather.

#### NOTE:

*Many Harley-Davidson accessories and seats are made of either treated or untreated leather or have leather inserts. Natural materials age differently and require different care than man-made materials. Seat covers and panels made of leather gain "character", such as wrinkles, with age. Leather is porous and organic and each leather product settles into its own distinct form with use. Your leather product matures into its own custom shape and style from the sun, rain and time. This maturing is natural and enhances the custom quality of your Harley-Davidson motorcycle.*

## Wheel Care

---

Wheels can corrode or be cosmetically damaged if they are not properly cleaned, polished and preserved. Cleaning and sealing wheels with the proper treatment guards against pitting, corrosion, spots and stains. Harley-Davidson recommends that wheels be cared for weekly. Corrosion to wheels is not considered a defect in materials or workmanship.

#### NOTE:

*Bare aluminum wheels do not have a protective coating and corrode unless properly treated. Apply BARE ALUMINUM WHEEL PROTECTANT when purchasing the motorcycle and at least twice per year to prevent cosmetic damage.*

Keep wheels clean from harsh chemicals, acid-based wheel cleaners, salt and accumulated brake dust. After washing wheels with WHEEL & TIRE CLEANER, use the polish and sealing products according to the type of wheels. Refer to Wheel Polish and Sealing Products.

#### Wheel Polish and Sealing Products

| WHEELS                               | PRODUCT                        | DESCRIPTION                                                                                                         |
|--------------------------------------|--------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Anodized                             | GLAZE POLY SEALANT             | Cleans surface, removes fine scratches. Provides a breathable sealant against acid, chemicals, salt and brake dust. |
|                                      | GLOSS DETAILER                 | Seals and protects against harsh chemicals, salt and other sediments to prevent corrosion.                          |
| Bare aluminum                        | BARE ALUMINUM WHEEL PROTECTANT | Creates a protective coating for bare aluminum wheels to prevent oxidation. Individual wipe.                        |
| Chrome                               | CHROME CLEAN & SHINE           | Non-abrasive cleaner to brighten chrome wheels.                                                                     |
|                                      | GLOSS DETAILER                 | Seals and protects against harsh chemicals, salt and other sediments to prevent oxidation.                          |
| Polished aluminum or stainless steel | BARE METAL POLISH              | Microabrasive polish to refurbish polished wheels. Do not use on chrome.                                            |

## Windshield Care

### CAUTION

**Polycarbonate windscreens/windshields require proper attention and care to maintain. Failure to maintain polycarbonate properly can result in damage to the windscreen/windshield. (00483d)**

### CAUTION

**Use only Harley-Davidson recommended products on Harley-Davidson windshields. Do not use harsh chemicals or rain sheeting products, which can cause windshield surface damage, such as dulling or hazing. (00231c)**

- Powdered, abrasive or alkaline cleanser can damage windscreen/windshields. Ammonia-based window cleaners cause permanent yellow effects to windshields.
- Do not use gas station windshield cleaner as finish can be damaged.
- Do not use a brush or squeegee as finish can be damaged.
- Do not clean in hot sun or high temperature.

Windshields require special care. However, windshields can be washed with WINDSHIELD

CLEANER - INDIVIDUAL WIPES, SUNWASH BIKE SOAP or QUICK WASH when washing the entire motorcycle. Refer to Recommended Cleaning and Care Products.

NOTES:

- To treat windshields with water repellent use WINDSHIELD WATER REPELLENT.
- Use BUG REMOVER to soft bug splatters. Wipe clean with a BUG EATER SPONGE.
- Covering windshields with a clean, wet cloth for approximately 15-20 minutes before washing makes dried bug removal easier.

1. Use WINDSHIELD CLEANER to detail windshields.
2. Wipe dry with a clean MICROFIBER DETAILING CLOTH.

NOTE:

To minimize swirl marks, clean windshield when the motorcycle is cool and parked in the shade. Faint swirl marks are normal. Swirl marks are more visible on tinted windshields.

## Troubleshooting

### Troubleshooting: General

---

#### WARNING

The troubleshooting section of the Owner's Manual is a guide to diagnose problems. Read the service manual before performing any work. Improper repair and/or maintenance could result in death or serious injury. (00080a)

Use the following checklists for troubleshooting. Carefully check each cause because more than one condition can cause trouble.

### Engine

---

#### Starter Does Not Operate or Does Not Turn Engine Over

---

1. Engine OFF/RUN switch off.
2. Ignition switch off.
3. Discharged battery or loose or corroded connections (solenoid chatters).
4. Clutch lever not squeezed against handlebar or transmission not in neutral.
5. Jiffy stand not in retracted position (for models equipped with jiffy stand interlock).
6. Blown fuse.

#### Engine Turns Over But Does Not Start

---

1. Fuel tank empty.
2. Fuel filter clogged.
3. Discharged battery or loose or damaged battery terminal connections.
4. Fouled spark plugs.
5. Spark plug cable connections loose or in bad condition and shorting.
6. Loose or corroded wire or cable connection at coil or battery.
7. Fuel pump inoperative.
8. Blown fuse.

## **Starts Hard**

---

1. Spark plugs in bad condition, have improper gap or are partially fouled.
2. Spark plug cables in bad condition and leaking.
3. Battery nearly discharged.
4. Loose wire or cable connection at one of the battery terminals or at coil.
5. Engine oil too heavy (cold weather).
6. Fuel tank vent plugged or fuel line closed off, restricting fuel flow.
7. Water or dirt in fuel system or filter.
8. Fuel pump inoperative.

## **Starts But Runs Irregularly or Misses**

---

1. Spark plugs in bad condition or partially fouled.
2. Spark plug cables in bad condition and leaking.
3. Spark plug gap too close or too wide.
4. Battery nearly discharged.
5. Damaged wire or loose connection at battery terminals or coils.
6. Intermittent short circuit due to damaged wire insulation.
7. Water or dirt in fuel system or filter.
8. Fuel vent system plugged. See dealer.
9. One or more injectors fouled.

## **A Spark Plug Fouls Repeatedly**

---

1. Fuel mixture too rich.
2. Incorrect spark plug for service

## **Pre-ignition or Detonation (Knocks or Pings)**

---

1. Incorrect fuel.
2. Incorrect spark plug for service

## **Overheats**

---

1. Insufficient oil supply or oil not circulating.
2. Heavy carbon deposit from lugging engine. See dealer.
3. Insufficient air flow over cylinder heads during extended periods of idling or parade duty.

## **Excessive Vibration**

---

1. Rear fork pivot shaft loose. See dealer.
2. Front engine mounting bolts loose. See dealer.
3. Front chain or links tight as a result of insufficient lubrication or belt badly worn.
4. Engine to transmission mounting bolts loose (applicable models). See dealer.
5. Damaged frame. See dealer.
6. Wheels and/or tires damaged. See dealer.
7. Vehicle not properly aligned. See dealer.

## **Engine Oil Not Circulating (Oil Pressure Lamp Lit)**

---

1. Insufficient or diluted oil supply.
2. Oil feed clogged with ice and sludge in freezing weather.
3. Grounded oil signal switch wire or faulty signal switch. See dealer.
4. Damaged or improperly installed check valve. See dealer.
5. Oil pump problem. See dealer.

## **Electrical System**

---

### **Alternator Does Not Charge**

---

1. Regulator not grounded. See dealer.

2. Engine ground wire loose or damaged. See dealer.
3. Loose or damaged wires in charging circuit. See dealer.

## **Alternator Charge Rate is Below Normal**

---

1. Weak battery.
2. Excessive use of add-on accessories.
3. Loose or corroded connections.
4. Extensive periods of idling or low speed riding.

## **Transmission**

---

### **Transmission Shifts Hard**

---

1. Bent shifter rod. See dealer.

### **Transmission Jumps Out of Gear**

---

1. Worn shifter dogs in transmission. See dealer.

## **Clutch Slips**

---

1. Clutch controls improperly adjusted. See dealer.
2. Worn friction discs. See dealer.
3. Insufficient clutch spring tension. See dealer.

## **Clutch Drags or Does Not Release**

---

1. Clutch controls improperly adjusted. See dealer.
2. Primary chaincase overfilled.
3. Clutch discs warped. See dealer.

## **Clutch Chatters**

---

1. Friction discs or steel discs worn or warped. See dealer.

## **Brakes**

---

### **Brakes Do Not Hold Normally**

---

1. Master cylinder low on fluid. See dealer.
2. Brake line contains air bubbles. See dealer.
3. Master cylinder piston worn. See dealer.
4. Brake pads contaminated with grease or oil. See dealer.
5. Brake pads badly worn. See dealer.
6. Brake disc badly worn or warped. See dealer.
7. Brake fades because of heat build up. Excessive braking or brake pads dragging. See dealer.
8. Brake drags. Insufficient hand lever free play. See dealer.

## Accessories

### Genuine Motor Parts and Accessories

---

Stop at your Harley-Davidson dealer to pick up a copy of the Genuine Motor Parts and Accessories catalog or go to [www.harley-davidson.com](http://www.harley-davidson.com) to view thousands of Genuine Motor Accessories that are available for Harley-Davidson motorcycles.

The website includes the following tools and resources for accessorizing and personalizing your motorcycle.

### Online Catalog

---

The full Genuine Motor Parts and Accessories catalog is available online in PDF format. The catalog includes hundreds of pages of Harley-Davidson accessories and maintenance products. For performance parts, check out the Screamin' Eagle Pro Racing Parts catalog.

*NOTE:*

*Performance parts may not be available in some countries due to local restrictions. See your Harley-Davidson dealer for more information.*

### Shop for Your Bike

---

Browse through categories of accessories and options available specifically for your motorcycle. View product descriptions, pricing, fitment and online instruction sheets for many of the available products.

### Customizer

---

Virtually redesign your motorcycle with parts and accessories using the Customizer. This tool allows you to experiment with different accessory and color combinations and shows how your motorcycle would look with the accessories installed. You can easily create a custom list of accessories to print out for your dealer.

## Fit Shop

---

Learn how to customize your motorcycle to fit you personally. See how making changes to the suspension, seat, handlebars or foot controls can enhance the ergonomics and comfort of your motorcycle.

## Custom Seats

---

Create a custom seat using selected designs, colors and textured materials. Custom seat specifications can be easily printed out for your dealer.

## Custom Coverage

---

## Add Accessories to Your New Motorcycle

---

*NOTE:*

*Custom Coverage is not offered in some regions. See an authorized Harley-Davidson dealer to determine the parts and accessories warranty policies, terms and conditions in your area.*

Harley-Davidson offers the Custom Coverage extended limited warranty for parts and accessories that are purchased and installed at an authorized Harley-Davidson dealer within 60 days after retail purchase of the motorcycle.

This limited warranty provides coverage for eligible *street legal* Genuine Harley-Davidson Motor Parts and Genuine Harley-Davidson Motor Accessories. This extended coverage on parts and accessories remains in effect for the remainder of the Harley-Davidson Motorcycle Limited Warranty for the vehicle. See Limited Motorcycle Warranty.

Purchases qualifying for Custom Coverage must be made at an authorized Harley-Davidson dealership within 60 days after retail purchase. Additional parts and accessories may be purchased and installed as often as desired within 60 days after retail purchase of the motorcycle.

Parts and accessories must be purchased and installed at an authorized Harley-Davidson dealership to qualify for Custom Coverage. Parts and accessories purchased via the internet are not eligible.

## Warranties and Responsibilities

### Warranty and Maintenance

---

This owner's manual contains your new motorcycle limited warranty and your owner's maintenance record.

It is your responsibility as the owner to follow the maintenance schedule at the mileage intervals as specified in the owner's manual. All of the specified maintenance services must be performed on schedule to keep your limited warranty valid.

Some countries, states or other locations may require all regular maintenance and service work to be done by an authorized Harley-Davidson dealer for your limited warranty to remain in effect. Check with your authorized Harley-Davidson dealer for local requirements.

1. Make an appointment with a Harley-Davidson dealer for inspection and service prior to the first 1000 mi 1600 km , and as soon as possible after any issue arises.
2. Bring this owner's manual with you when you visit your authorized Harley-Davidson dealer to have your motorcycle inspected and serviced.
3. Have the dealer technician sign the maintenance record in the owner's manual at the proper mileage interval. These records should be retained by the owner as proof of proper maintenance.
4. Keep receipts covering any parts, service or maintenance performed.

These records should be transferred to each subsequent owner.

Use only Harley-Davidson approved parts and accessories that have been designed, tested and approved for your model and model year motorcycle.

Use of aftermarket performance parts may void all or parts of your limited warranty. See an authorized Harley-Davidson dealer for details.

Harley-Davidson authorized dealerships are independently owned and operated and may sell and install parts and accessories that are not manufactured or approved by Harley-Davidson for use on your motorcycle. Therefore, you should understand that Harley-Davidson is not and cannot be responsible for the quality, suitability, or safety of any non-Harley-Davidson part, accessory or design modification, including labor, which may be sold and/or installed by authorized Harley-Davidson dealerships.

## **Keeping It All Harley-Davidson**

---

Genuine Harley-Davidson parts are engineered and tested specifically for use on your motorcycle. Insist that your authorized Harley-Davidson dealer uses only genuine Harley-Davidson replacement parts and accessories to keep your Harley-Davidson motorcycle and its limited warranty intact. Not all Harley-Davidson parts and accessories are appropriate for your model or model year motorcycle.

### **CAUTION**

**It is possible to overload your vehicle's charging system by adding too many electrical accessories. If the combined electrical accessories operating at any one time consume more electrical current than the vehicle's charging system can produce, the electrical consumption can discharge the battery and cause damage to the vehicle's electrical system. See an authorized Harley-Davidson dealer for advice about the amount of current consumed by additional electrical accessories or for necessary wiring changes. (00211c)**

#### **NOTE:**

*Installing off-road or competition parts to enhance performance may void all or parts of your limited warranty. See the Harley-Davidson Motorcycle Limited Warranty in this owner's manual or an authorized Harley-Davidson dealer for details.*

## **EPA Noise Regulations in the United States**

---

EPA noise regulations require that the following statements be included in the Owner's Manual.

## **EPA Regulations**

---

**TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED:** Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE FOLLOWING:

1. Replacing the muffler(s) and/or the entire exhaust system with parts not certified to be noise legal for street use.
2. Removing or modifying the muffler internal baffles in any way.
3. Replacing the air intake/cleaner assembly with one not certified to be noise legal for street use.
4. Modifying the air intake/cleaner assembly in such a way as to make the vehicle no longer noise legal for street use.

Harley-Davidson recommends that any and all noise related maintenance be done by an authorized Harley-Davidson dealer using Genuine Harley-Davidson parts.

## **California and Select International Markets Evaporative Emission Controls: 2016 Models**

---

All new 2016 Harley-Davidson motorcycles sold in the State of California and select international markets have an evaporative emission control system. This system is designed to meet CARB and local regulations in effect at the time of manufacture.

The system requires a small amount of maintenance. Periodically inspect system to verify that hoses are properly routed, not kinked or blocked and that all fittings are secure. Periodically check mounting hardware for tightness.

## **Warranty/Service Information**

---

Any authorized Harley-Davidson dealer may provide warranty repair work on your motorcycle. The fact that an authorized Harley-Davidson dealership performs warranty repairs does not create an agency relationship between Harley-Davidson and the authorized dealership. If you have any questions regarding warranty obligations contact your authorized Harley-Davidson dealer.

For normal service work or warranty work under the above conditions, you may obtain the name and location of your nearest U.S. authorized Harley-Davidson dealer by calling 1-800-258-2464 (U.S. only). To find dealers worldwide, see [www.harley-davidson.com](http://www.harley-davidson.com).

## **Reporting Safety Defects in the United States**

---

Safety defects must be reported to the National Highway Traffic Safety Administration (NHTSA) and Harley-Davidson.

## NHTSA Statement

---

If you believe that your motorcycle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Harley-Davidson.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of motorcycles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your authorized Harley-Davidson dealer, or Harley-Davidson.

You can contact NHTSA through the following means. Additional information about motor vehicle safety is available through the website.

**Telephone:** Vehicle Safety Hotline (toll-free) at 1-888-327-4236 (TTY: 1-800-424-9153).

**Website:** [www.safercar.gov](http://www.safercar.gov)

**Address:** Administrator, NHTSA, 400 Seventh Street SW, Washington, DC 20590

## Required Documentation for Imported Motorcycles

---

If a Harley-Davidson motorcycle is imported into the United States, additional documentation is required for that motorcycle to be eligible for the United States Harley-Davidson Motorcycle Limited Warranty. An authorized Harley-Davidson dealer can provide a form explaining the requirements.

## Owner Contact Information

---

If you move from your present address, sell your motorcycle, or purchase a pre-owned Harley-Davidson motorcycle, see an authorized Harley-Davidson dealer to update your owner contact information.

This will provide Harley-Davidson with an accurate registration (as required by law in some countries), and will allow Harley-Davidson to notify you in the event of a recall or product program.

The rights and benefits conferred upon you and the obligations of Harley-Davidson as set forth herein are separate and distinct from any rights and duties set forth in any service contract you may have purchased from a dealership and/or third-party insurance company. Harley-Davidson does not authorize any entity to expand Harley-Davidson's warranty obligations in connection with your motorcycle or this limited warranty.

When updating your contact information, your authorized Harley-Davidson dealer will need your Vehicle Identification Number (VIN), odometer mileage, and date of vehicle transfer (if applicable).

## Questions and Concerns

---

If you have questions or concerns regarding the performance of your motorcycle or the application of the limited warranty described here, or are not satisfied with the service you are receiving from an authorized Harley-Davidson dealership, do the following:

1. Contact the selling and/or servicing dealership and speak to the sales and/or service manager.

2. If your concern cannot be addressed to your satisfaction by the dealership, contact the Harley-Davidson Customer Support Center by mailing your concern to the following address or calling the phone number below.

In the U.S., state warranty laws, often referred to as lemon laws, may provide you with certain rights not specifically mentioned here. To the extent allowed by your state, Harley-Davidson requests that you first send written notification of any defect or warranty non-conformity that you have experienced with your motorcycle to Harley-Davidson. Harley-Davidson appreciates the opportunity to investigate your concerns and restore your satisfaction in your motorcycle by making the necessary repairs consistent with the terms of Harley-Davidson's limited warranty. Harley-Davidson requests that you send your complaint to the Harley-Davidson Customer Support Center.

- Harley-Davidson Motor Company
- Attention: Harley-Davidson Customer Support Center
- P.O. Box 653
- Milwaukee, Wisconsin 53201
- 1-800-258-2464 (U.S. only)
- 1-414-343-4056

This warranty does not mean that each Harley-Davidson motorcycle is free from defects. Defects may be unintentionally introduced into motorcycles during the design and manufacturing processes and such defects could result in the need for repairs. For this reason, Harley-Davidson provides the Limited Warranty in order to remedy any such defects that result in a component malfunction or failure during the warranty period. The remedy under this written warranty, and any implied warranty, is limited to repair, replacement or adjustment of the defective part. This exclusive remedy shall not be deemed to have failed its essential purpose so long as Harley-Davidson, through its authorized dealers, is willing and able to repair, replace or adjust defective parts in the prescribed manner. Harley-Davidson's liability, if any, shall in no event exceed the cost of correcting any defect as herein provided and upon expiration of this warranty, any such liability shall terminate.

## **Limited Motorcycle Warranty**

### **2016 Harley-Davidson Motorcycle Limited Warranty**

---

#### **24 Months/Unlimited Miles**

---

Harley-Davidson warrants for any new 2016 Harley-Davidson motorcycle that an authorized Harley-Davidson dealer will repair or replace without charge any parts found under normal use to be defective in factory materials or workmanship. Such repair or replacement of defective parts will be Harley-Davidson's sole obligation and your sole and exclusive remedy under this limited warranty. This limited warranty applies only for the duration identified below.

No person, including Harley-Davidson dealers, may modify, extend or waive any part of this warranty.

As a condition of this warranty, you are responsible for properly using, maintaining, and caring for your motorcycle as outlined in your Owner Manual. Harley-Davidson recommends that you maintain copies of all maintenance records and receipts.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE EMISSIONS, NOISE, AND RADIO LIMITED WARRANTIES) ON THE MOTORCYCLE. Any implied warranty of merchantability or fitness for particular purpose is limited to the duration of the express warranty,

or to the duration set forth in your state's warranty statutes, whichever is shorter. Any implied warranty is not transferred to subsequent purchasers/buyers of the motorcycle.

The implied warranty of fitness for a particular purpose does not apply if your motorcycle is used for racing, even if the motorcycle is equipped for racing.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

TO THE FULLEST EXTENT ALLOWED BY LAW, NEITHER HARLEY-DAVIDSON NOR ITS AUTHORIZED DEALERS SHALL BE LIABLE FOR LOSS OF TIME, INCONVENIENCE, LOSS OF MOTORCYCLE USE, COMMERCIAL LOSS OR ANY OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Harley-Davidson and your dealer are not responsible for any time or income that you lose, any inconvenience, the loss of your transportation or use of your motorcycle, the cost of a rental motorcycle, fuel, travel, meals, or lodging, or for any other incidental or consequential damages you may have.

Punitive, exemplary, or multiple damages may not be recovered unless applicable law prohibits their disclaimer. You may not bring any warranty-related claim as a class representative, a private attorney general, a member of a class of claimants or in any other representative capacity. Harley-Davidson shall not be liable for any damages caused by delay in delivery or furnishing of any products and/or services.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

The following terms and conditions apply to this limited warranty:

## **Duration**

---

1. The duration of this limited warranty is twenty-four months, starting from the earlier of (a) the date of initial retail purchase and delivery of the motorcycle from an authorized Harley-Davidson dealer, or (b) the third anniversary of the last day of the model year of the motorcycle. Your authorized Harley-Davidson dealer will submit an electronic Sales and Warranty Registration form to initiate your limited warranty.
2. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the limited warranty period.

## **Owner's Obligations**

---

To obtain warranty service, return your motorcycle at your expense within the limited warranty period to an authorized Harley-Davidson dealer. The authorized Harley-Davidson dealer should be able to provide warranty service during normal business hours, depending upon the workload of the authorized dealer's service department and the availability of necessary parts.

## **Exclusions**

---

This limited warranty will not apply to any motorcycle.

1. Which has not been operated or maintained as specified in the owner's manual.
2. Which has been abused, neglected, misused, improperly stored, used "off the highway," or used for racing or competition of any kind.
3. Which is not manufactured to comply with the laws of the market in which it is registered.
4. Which has off-road or competition parts installed to enhance performance, a trailer hitch, or has other unapproved modifications (even if these modifications include genuine Harley-Davidson parts and accessories that are not approved for use on your motorcycle). These modifications may void all or parts of your new motorcycle limited warranty. See an authorized Harley-Davidson dealer for details.
5. Which has been subjected to an act of God, war, riot, insurrection, nuclear contamination, natural disasters, including, but not limited to, lightning, forest fires, dust storms, hail storms, ice storms, earthquakes, or floods, or other circumstances out of Harley-Davidson's control.
6. Which has been in an accident or collision or has been dropped or struck.

## Other Limitations

---

This limited warranty does not cover:

1. Parts and labor for normal maintenance as recommended in the owner's manual, or the replacement of parts due to normal wear and tear including, but not limited to, the following: tires, lubrication, oil and filter change, fuel system cleaning, battery maintenance, engine tune-up, spark plugs, brake, clutch, chain/belt adjustment and chain replacement.
2. Cosmetic concerns that arise as a result of owner abuse, lack of proper maintenance or environmental conditions (except concerns that result from defects in factory materials or workmanship, which are covered by this limited warranty for the duration of the limited warranty period).
3. Any cosmetic condition existing at the time of retail delivery that has not been documented by the authorized Harley-Davidson selling dealer prior to retail delivery.
4. Defects or damage to the motorcycle caused by alterations outside of Harley-Davidson's factory specifications or caused by alterations or use of parts or accessories not approved for the make and model year of your motorcycle.
5. Damage caused by installation or use of non-Harley-Davidson components, even those installed by an authorized Harley-Davidson dealership, that cause a Harley-Davidson part to fail. Examples include, but are not limited to performance-enhancing powertrain components or software, exhaust systems, trailer hitches, non-approved tires, lowering kits, handlebars, and add-ons connected to the factory electrical system.

## Important: Read Carefully

---

1. Authorized Harley-Davidson dealers are independently owned and operated and may sell non-Harley-Davidson products. Because of this, HARLEY-DAVIDSON IS NOT RESPONSIBLE FOR THE SAFETY, QUALITY, OR SUITABILITY OF ANY NON-HARLEY-DAVIDSON PART, ACCESSORY OR DESIGN MODIFICATION INCLUDING, BUT NOT LIMITED TO, LABOR WHICH MAY BE SOLD AND/OR INSTALLED BY AUTHORIZED

## HARLEY-DAVIDSON DEALERS.

2. This limited warranty is a contract between you and Harley-Davidson. It is separate and apart from any warranty you may receive or purchase from an authorized Harley-Davidson dealer. An authorized Harley-Davidson dealer is not authorized to alter, modify, expand, or in any way change the terms and conditions of this limited warranty.
3. Any warranty work or parts replacement authorized by Harley-Davidson will not preclude Harley-Davidson from later relying on any exclusion where applicable.
4. Harley-Davidson and its authorized dealers reserve the right to modify or service motorcycles designed and manufactured by Harley-Davidson at any time without incurring any additional obligation to make the same alteration or change to a motorcycle previously built and sold. Harley-Davidson reserves the right to provide post-warranty repairs, conduct repair campaigns, offer good-will or customer satisfaction repairs or extend the warranty coverage for certain motorcycles at its sole discretion. Said repairs or extensions of warranty coverage in no way obligates Harley-Davidson to provide similar accommodations to other owners of similar motorcycles. Sometimes Harley-Davidson may offer a special adjustment program to pay all or part of the cost of certain repairs beyond the terms of your limited warranty. Check with your authorized Harley-Davidson dealer to learn whether such programs are available to you. Your state may prohibit these types of offers, in which case, they may not be available to you.
5. The fact that a part is labeled or branded Harley-Davidson does not necessarily make it appropriate or warranted for the make and model of your motorcycle. The use of parts not designed and tested for your motorcycle may have negative consequences on the performance of your motorcycle and may create conditions not covered by this limited warranty.

## **Limited Motorcycle Warranty (Australia)**

### **2016 Australia/New Zealand Harley-Davidson Motorcycle Manufacturer's Limited Warranty**

---

### **24 Months/Unlimited Miles**

---

**This motorcycle limited warranty, referred to below as the "H-D Motorcycle Warranty" applies to all persons who purchase a new 2016 or prior-model Harley-Davidson motorcycle in Australia and New Zealand only after 1st January 2016.**

### **Your Consumer Rights**

---

The benefits given to you under this H-D Motorcycle Warranty are additional to, and do not detract from, other rights and remedies that you may have in respect of the motorcycle under Australian and New Zealand laws, including consumer protection laws.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand, our goods also come with guarantees that cannot be excluded under the New Zealand Consumer Guarantees Act.

## Warranty

---

This H-D Motorcycle Warranty, is provided by **Harley-Davidson, Motor Company**, P.O. Box 653, Milwaukee, Wisconsin 53201, U.S.A, phone: +1 (414) 343-4056, ("Harley-Davidson").

Harley-Davidson warrants for any new 2016 Harley-Davidson motorcycle that an authorised Harley-Davidson dealer will repair or replace without charge any parts found to be defective in factory materials or workmanship under normal use during the warranty period set out below.

Such repair or replacement of parts will be Harley-Davidson's sole obligation and your sole remedy under this H-D Motorcycle Warranty, however you may have other rights under Australian and New Zealand laws, as described above.

**Note:** Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair goods.

The following terms and conditions apply to this H-D Motorcycle Warranty:

## Warranty Period

---

The duration of this H-D Motorcycle Warranty is twenty-four months, starting from the earlier of:

- (a) the date of delivery by an authorised Harley-Davidson dealer to the first retail purchaser; or
- (b) the third anniversary of the last day of the model year of the motorcycle (if not sold to a retail purchaser before that date).

Your authorised Harley-Davidson dealer will submit an electronic Sales and Warranty Registration form to initiate your H-D Motorcycle Warranty.

**Note:** If the motorcycle was used as a demonstrator or company motorcycle, then the warranty period may have started and/or expired prior to the initial retail sale. See an authorised Harley-Davidson dealer for details.

Any unexpired portion of this H-D Motorcycle Warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the warranty period. See the OWNER CONTACT INFORMATION section of the Owner's Manual for information regarding notification of ownership changes.

## Obtaining Warranty Service

---

To obtain warranty service, return your motorcycle at your expense within the warranty period to an authorised dealer. Harley-Davidson's network of authorised dealers is large, and continues to expand. To find current contact information for your nearest authorised dealer, visit our website at [www.h-d.com.au](http://www.h-d.com.au).

The authorised Harley-Davidson dealer should be able to provide warranty service during normal business hours and as soon as possible, depending upon the workload of the authorised dealer's service department and the availability of necessary parts

You are responsible for collecting the motorcycle from the authorized dealer once the warranty service has been completed, at your expense.

## Exclusions

---

This H-D Motorcycle Warranty will not apply to any motorcycle (or part or accessory):

1. Which has not been operated or maintained as specified in the Owner's Manual.
2. Which has been abused, neglected, misused, improperly stored, used "off the highway," or used for racing or competition of any kind.
3. Which was not originally manufactured for use or sold in Australia and New Zealand and/or does not comply with Australian and New Zealand homologation requirements.
4. Which has off-road or competition parts installed to enhance performance, or has unapproved modifications. These modifications may void all or part of your new H-D Motorcycle Warranty. See an authorised Harley-Davidson dealer for details.
5. Where damage is caused by, or Harley-Davidson is unable to honour this H-D Motorcycle Warranty due to, acts of God, war, riot, insurrection, natural disasters, including, but not limited to, nuclear contamination, lightning, forest fires, dust storms, hail storms, ice storms, earthquakes, floods, or other circumstances out of Harley-Davidson's control.
6. Which has been in an accident, collision, dropped or struck.

**Note:** Even though this H-D Motorcycle Warranty does not apply in the circumstances set out above, you may still have rights under Australian and New Zealand laws, including the Australian Consumer Law in such circumstances.

## Other Limitations

---

This H-D Motorcycle Warranty does not cover:

1. Parts and accessories not manufactured by Harley-Davidson, or any damage caused to the motorcycle by the installation of such parts and accessories, even if such parts and accessories are installed on the motorcycle at the date of initial retail purchase. A separate third party warranty may apply to such parts and accessories. See an authorised Harley-Davidson dealer for details.
2. Parts and labour for normal maintenance as recommended in the Owner's Manual, or the replacement of parts due to normal wear and tear including, but not limited to, the following: tyres, lubrication, oil and filter change, fuel system cleaning, battery maintenance, engine tune-up, spark plugs, brake, clutch, chain/belt adjustment and chain replacement.
3. Cosmetic or other concerns that arise as a result of owner abuse, lack of proper maintenance or environmental conditions (except concerns that result from defects in factory materials or workmanship, which are covered by this H-D Motorcycle Warranty for the duration of the warranty period).
4. Any cosmetic condition existing at the time of retail delivery that has not been documented by the authorised Harley-Davidson selling dealer prior to retail delivery.
5. Defects or damage to the motorcycle caused by alterations outside of Harley-Davidson's factory specifications, including the installation of competition or closed course parts and

accessories and the addition of loads and stresses to the motorcycle above those recommended by Harley-Davidson.

6. Damage caused by installation or use of non-Harley-Davidson components, even those installed by an authorised dealership, that cause a Harley-Davidson part to fail. Examples include, but are not limited to performance-enhancing powertrain components or software, exhaust systems, non-approved tyres, lowering kits, handlebars, add-ons connected to the factory electrical system, tow bars, etc.

**Note:** Even though this H-D Motorcycle Warranty does not cover the circumstances set out above, you may still have rights under Australian and New Zealand laws, including the Australian Consumer Law.

## **Important: Read Carefully**

---

1. Authorised Harley-Davidson dealers are independently owned and operated and may sell non-Harley-Davidson products. Because of this, HARLEY-DAVIDSON IS NOT RESPONSIBLE FOR THE SAFETY, QUALITY, OR SUITABILITY OF ANY NON-HARLEY-DAVIDSON PART, ACCESSORY OR DESIGN MODIFICATION WHICH MAY BE SOLD AND/OR INSTALLED BY AUTHORISED HARLEY-DAVIDSON DEALERS OR LABOUR CARRIED OUT BY DEALERS.
2. This H-D Motorcycle Warranty is a contract between you and Harley-Davidson. It is separate and apart from any warranty you may receive or purchase from an authorised Harley-Davidson dealer. An authorised Harley-Davidson dealer is not authorised to alter, modify, or in any way change the terms and conditions of this H-D Motorcycle Warranty.

Any warranty work or parts replacement authorised by Harley-Davidson will not preclude Harley-Davidson from later relying on any exclusion where Harley-Davidson later becomes aware that an exclusion applied or the warranty claim did not otherwise comply with the terms of this H-D Motorcycle Warranty.

## **Limited Noise Warranty**

### **2016 Harley-Davidson Motorcycle Noise Control System Limited Warranty**

---

The following limited warranty applies to the noise control system, is in addition to the MOTORCYCLE LIMITED WARRANTY and EMISSION CONTROL SYSTEM LIMITED WARRANTY, and applies only to Harley-Davidson motorcycles sold in the U.S.

Harley-Davidson warrants to the first owner and each subsequent owner that this motorcycle is designed and built so as to conform at the time of sale with applicable regulations of the U.S. Environmental Protection Agency (as tested following F-76 Drive-By test procedure) and that it is free from defects in factory materials and workmanship which can cause this motorcycle not to meet U.S. Environmental Protection Agency Standards within one (1) year from initial retail purchase and delivery from an authorized Harley-Davidson dealer or one (1) year from the [second] anniversary of the last day of the model year of the motorcycle, or 3,730 miles 6,000 kilometers whichever occurs first. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the limited warranty period. If the motorcycle was used as a demonstrator or company motorcycle, then the limited warranty period may have started and/or expired prior to the initial retail sale. See an authorized Harley-Davidson dealer for details.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE

MOTORCYCLE AND EMISSIONS LIMITED WARRANTIES) ON THE MOTORCYCLE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The limited warranty period shall begin on the date the motorcycle is delivered to the first retail purchaser or, if the motorcycle is placed in service as a demonstrator or company motorcycle prior to sale at retail, on the date it is first placed in service.

#### THE FOLLOWING ITEMS ARE NOT COVERED BY THE NOISE CONTROL SYSTEM LIMITED WARRANTY

1. Failures which arise as a result of misuse, alteration, or non-performance of maintenance as specified in the Owner's Manual.
2. Replacing, removing, or modifying any portion of the NOISE CONTROL SYSTEM (consisting of the exhaust system and air intake/cleaner assembly) with parts not certified to be noise legal for street use.
3. Any motorcycle on which the odometer mileage has been changed so that the mileage cannot be determined.
4. TO THE FULLEST EXTENT ALLOWED BY LAW, NEITHER HARLEY-DAVIDSON NOR ITS AUTHORIZED DEALERS SHALL BE LIABLE FOR LOSS OF TIME, INCONVENIENCE, LOSS OF MOTORCYCLE USE, COMMERCIAL LOSS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

## Other Rights

---

This limited warranty gives you specific legal rights, and you may have other rights which vary from state to state.

## Recommendations for Required Maintenance

---

It is recommended that any noise system maintenance be performed by an authorized Harley-Davidson dealer using genuine Harley-Davidson replacement parts. The maintenance, replacement or repair of the noise control system may be performed by any other qualified service outlet or individual. Non-genuine Harley-Davidson parts may be used only if such parts are certified to comply with U.S. Environmental Protection Agency Standards.

## Limited Emission Warranty

### 2016 Harley-Davidson Emission Control System Limited Warranty

---

The following limited warranty applies to the emission control system, is in addition to the MOTORCYCLE LIMITED WARRANTY and NOISE CONTROL SYSTEM LIMITED WARRANTY, and applies only to Harley-Davidson motorcycles certified for sale, registered, and normally operated in the U.S. Refer to the CALIFORNIA EMISSIONS CONTROL WARRANTY

STATEMENT for additional warranty provisions applicable to California motorcycles.

Harley-Davidson Motor Company warrants to the first owner and each subsequent owner that this vehicle is designed, built, and equipped so as to conform at the time of sale with applicable regulations under section 7521 of Title 42 of the United States Code, and that it is free from defects in materials and workmanship which would cause this motorcycle to fail to conform with applicable regulations for five (5) years from the initial retail purchase and delivery from an authorized Harley-Davidson dealer (or five (5) years from the date the motorcycle is first placed in service, if it is first placed in service as a "demonstrator" or "company" motorcycle prior to delivery), or 18,641 miles 30,000 kilometers, whichever occurs first. Any unexpired portion of this limited warranty will be transferred to subsequent owners, upon the resale of the motorcycle during the warranty period.

THERE IS NO OTHER EXPRESS WARRANTY (OTHER THAN THE SEPARATE MOTORCYCLE AND NOISE LIMITED WARRANTIES) ON THE MOTORCYCLE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The limited warranty period shall begin on the date the motorcycle is delivered to the first retail purchaser or, if the motorcycle is placed in service as a demonstrator or company motorcycle prior to sale at retail, on the date it is first placed in service.

THE FOLLOWING ITEMS ARE NOT COVERED BY THE EMISSION CONTROL SYSTEM LIMITED WARRANTY

1. Failures which arise as a result of misuse, tampering, alterations, accident, acts of nature, or improper or inadequate maintenance as specified in the Owner's Manual.
2. Required maintenance services (as specified in the Owner's Manual) and the replacement of parts (such as spark plugs, fuel and oil filters, etc.) used in required maintenance.
3. Any motorcycle on which the odometer mileage has been changed so that the mileage cannot be determined.
4. TO THE FULLEST EXTENT ALLOWED BY LAW, NEITHER HARLEY-DAVIDSON NOR ITS AUTHORIZED DEALERS SHALL BE LIABLE FOR LOSS OF TIME, INCONVENIENCE, TOWING OF THE VEHICLE, LOSS OF MOTORCYCLE USE, COMMERCIAL LOSS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

## **Items Covered by this Emission Warranty**

---

The emission control system warranty may cover the following parts if the defect is deemed to be emissions-related:

- Air cleaner assembly
- Cam shaft
- Spark plug
- Ignition coil
- Ignition wires
- Vapor valve

- Catalytic converter
- Crankcase breather
- MAP sensor
- TMAP sensor
- Intake air temperature sensor
- Throttle position sensor
- Fuel injectors
- Induction module or throttle body
- Engine temperature sensor
- Electronic control unit
- Regulator/fuel pump (for leaks and/or high and low-pressure failures)
- Fuel filter
- Oxygen sensors

#### **Fuel Tank** (non-cosmetic failures only)

- Leaks
- Fuel vapor separator
- Fuel cap

If used on the above: hoses, clamps, fittings, tubing, sealing gaskets and mounting hardware.

Detailed instructions for proper maintenance and use of this motorcycle, including the time and/or mileage intervals at which such maintenance is to be performed, may be found in this Owner's Manual under Service Records.

## **Other Rights**

---

This limited warranty gives you specific legal rights, and you may have other rights which vary from state to state.

## **Recommendations for Required Maintenance**

---

It is recommended that any emission system maintenance be performed by an authorized Harley-Davidson dealer using genuine Harley-Davidson replacement parts. However the maintenance, replacement or repair of the emissions control system may be performed by any other qualified service outlet or individual. Non-genuine Harley-Davidson parts may be used only if such parts are certified to comply with U.S. Environmental Protection Agency Standards.

## **California Emissions Control Warranty**

### **California Emissions Control Warranty Statement**

---

## **Your Warranty Rights and Obligations**

---

The California Air Resources Board and Harley-Davidson Motor Company are pleased to explain the emission control system warranty on your 2016 model year motorcycle. In California, new motor vehicles must be designed, built and equipped to meet the State's stringent anti-smog standards. Harley-Davidson Motor Company must warrant the emission control system on your motorcycle for the periods of time listed below provided there has been no abuse, unapproved modification, neglect or improper maintenance of your motorcycle.

Your emission control system may include parts such as the carburetor or fuel-injection system, the ignition system, catalytic converter, and engine computer. Also included may be hoses, connectors and other emission-related assemblies.

Where a warrantable condition exists, within the warranty period noted below, your authorized Harley-Davidson dealer will repair your motorcycle at no cost to you including diagnosis, parts and labor.

## **Manufacturer's Warranty Coverage**

---

For a period of use of five years or 18,641 miles 30,000 kilometers , whichever first occurs, beginning on the date the motorcycle is delivered to the ultimate purchaser or, if the motorcycle is placed in service as a demonstrator or company motorcycle prior to sale at retail, the date it is first placed in service.

If any emission related part on your motorcycle is defective, the part will be repaired or replaced by Harley-Davidson Motor Company. This is your emission control system DEFECTS WARRANTY.

## **Owner's Warranty Responsibilities**

---

As the motorcycle owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. Harley-Davidson recommends that you retain all receipts covering maintenance on your motorcycle, but Harley-Davidson cannot deny emissions warranty coverage solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your motorcycle to an authorized Harley-Davidson dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

As the motorcycle owner, you should also be aware that Harley-Davidson may deny you warranty coverage if your motorcycle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact Harley-Davidson Customer Service Department at 1-800-258-2464 (U.S. only) or 1-414-343-4056, or the California Air Resources Board at 9528 Telstar Ave., El Monte, California 91731.

## **Additional Warranty Terms**

---

The warranty period starts the date the motorcycle is delivered to the ultimate purchaser or, if the motorcycle is placed in service as a demonstrator or company motorcycle prior to sale at retail, the date it is first placed in service.

The emission control system of each new Harley-Davidson motorcycle was designed, built and tested using only Genuine Harley-Davidson parts and with these parts the motorcycle is certified as being in conformity with California emission control regulations.

We recommend that you take your motorcycle to an authorized Harley-Davidson dealer for repairs under this warranty. The dealer has factory-trained mechanics and genuine Harley-Davidson parts. However, in the case of an "emergency" (as defined below), you could have repairs performed at any available service establishment or by the owner, using any replacement part. An

authorized Harley-Davidson dealer not being reasonably available, or a part not being available within a reasonable time period (not to exceed 30 days from the time the motorcycle is initially presented to a Harley-Davidson dealer for repair) constitutes an emergency. Harley-Davidson will reimburse the owner for such repairs, including diagnosis, only if it is established that the repairs are covered under this emission warranty. Harley-Davidson's parts reimbursement, however, will not exceed our suggested retail price for all warranted parts replaced and our labor reimbursement will be limited to our recommended time allowances for emission system repairs at the geographically appropriate hourly labor rate.

To obtain reimbursement from Harley-Davidson for such emergency repairs, you must keep all failed parts and original receipts, so you can present them to an authorized Harley-Davidson dealer for inspection. Harley-Davidson recommends that you bring your motorcycle to an authorized dealer for inspection to ensure that the emergency repairs were done properly.

**Remember:** Use of non-Harley-Davidson replacement parts may impair the effectiveness of the emission control system or otherwise damage your motorcycle. If other than genuine Harley-Davidson parts are used for maintenance, replacement or repair of components affecting emission control, you should obtain written assurances that such non-Harley-Davidson parts are warranted by their manufacturer to be equal in quality to Genuine Harley-Davidson parts in both performance and durability. The use of non-Harley-Davidson replacement parts does not invalidate the existing warranty, if any, on other Harley-Davidson components unless the non-Harley-Davidson parts cause damage to warranted parts or result in the creation of an emissions non-compliant motorcycle. However, HARLEY-DAVIDSON ASSUMES NO LIABILITY UNDER THIS WARRANTY WITH RESPECT TO ANY PARTS WHICH ARE NOT GENUINE HARLEY-DAVIDSON PARTS, unless Harley-Davidson parts cause damage to non-genuine Harley-Davidson parts.

## What Is Covered by this Emission Warranty

---

The emission control system warranty covers the following "warranted parts" only:

- Air cleaner assembly
- Cam shaft
- Spark plug
- Ignition coil
- Ignition wires
- Vapor valve
- Catalytic converter
- Crankcase breather
- MAP sensor
- TMAP sensor
- Intake air temperature sensor
- Throttle position sensor
- Fuel injectors
- Induction module or throttle body
- Engine temperature sensor
- Electronic control unit
- Regulator/fuel pump (for leaks and/or high and low pressure failures)
- Fuel filter
- Oxygen sensors
- Carbon canister
- Purge control valve

**Fuel Tank** (non-cosmetic failures only)

- Leaks
- Fuel vapor separator
- Fuel cap

If used on the above: hoses, clamps, fittings, tubing, sealing gaskets and mounting hardware.

## What Is Not Covered by this Emission Warranty

---

The emission control system warranty does not cover:

Malfunctions in any "warranted parts" caused by any of the following: abuse, misuse, unapproved modification or alteration, tampering, disconnection, or improper or inadequate maintenance. The warranty also does not cover replacement of listed parts in the event that the vehicle has been rendered emissions non-compliant in the state of California through actions noted above.

Damage resulting from accident, acts of nature or other events beyond the control of Harley-Davidson.

The repair or replacement of "warranted parts" which are scheduled for replacement prior to 18,641 mi 30,000 km , once these parts have been replaced at the first replacement interval as part of required maintenance services.

Repairs and services performed by anyone other than an authorized Harley-Davidson Dealer (except in case of emergency as defined above).

Loss of time, inconvenience, loss of use of the motorcycle, towing of the vehicle, or commercial loss and/or consequential damages.

Repairs on any motorcycle of which odometer mileage has been changed so that mileage cannot be readily determined.

## Maintenance Scheduling

### Service Records

---

### Regular Service Intervals

---

#### WARNING

**Perform the service and maintenance operations as indicated in the regular service interval table. Lack of regular maintenance at the recommended intervals can affect the safe operation of your motorcycle, which could result in death or serious injury. (00010a)**

#### WARNING

**If you operate your motorcycle under adverse conditions (severe cold, extreme heat, very dusty environment, very bad roads, through standing water, etc.), you should perform the regular maintenance intervals more frequently to ensure the safe operation of your motorcycle. Failure to**

**maintain your motorcycle could result in death or serious injury. (00094a)**

Regular maintenance must be performed at specified intervals to help keep your new Harley-Davidson motorcycle operating at peak performance and keep your new motorcycle limited warranty in force. Your authorized Harley-Davidson dealer knows best how to service your motorcycle with factory approved methods and equipment assuring you of thorough and competent workmanship.

Some maintenance items are scheduled at least once per year, even if the next mileage interval has not been reached. In severe riding conditions, some maintenance items need to be performed more frequently. Refer to Regular Service Intervals: 2016 Softail Models.

NOTES:

- *The use of parts and service procedures other than Harley-Davidson approved parts and service procedures may void the limited warranty. Any alterations to the emission system components, such as the intake and exhaust system, may be in violation of motor vehicle laws.*
- *Some countries, such as Brazil, may require all regular maintenance to be performed by an authorized Harley-Davidson dealer for your limited warranty to remain in effect. Check with your authorized Harley-Davidson dealer.*
- *Some countries, such as Brazil, require additional annual (or semi-annual) regular maintenance steps to keep your limited warranty in effect and/or comply with vehicle regulations. Check with your authorized Harley-Davidson dealer and the motorcycle regulations in your country for local requirements.*
- *After completing the final service interval, repeat the service schedule starting at the 5000 mi 8000 km interval. Refer to Regular Service Intervals: 2016 Softail Models.*
- *Whenever a vehicle is in for maintenance, always check for and complete open recalls and product programs.*
- *Whenever a vehicle is in for maintenance, always verify that the latest calibration is installed.*

### Regular Service Intervals: 2016 Softail Models

[illegible]

|                                                                     |   |   |   |   |   |   |   |   |   |   |   |         |
|---------------------------------------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---------|
| (hydraulic operated)                                                |   |   |   |   |   |   |   |   |   |   |   |         |
| Check front brake and hydraulic clutch reservoir cover screw torque | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Adjust steering head bearings                                       | X |   | X |   | X |   | X |   | X |   | X | 2       |
| Lubricate steering head bearings                                    |   |   | X |   | X |   | X |   | X |   | X | 2, 7    |
| Check lower fork bracket pinch bolt torque                          | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Check upper fork bracket pinch bolt torque                          | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Inspect windshield bushings (if applicable)                         |   |   | X |   | X |   | X |   | X |   | X |         |
| Check upper and lower switch housing screw torque                   | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Check clutch lever handlebar clamp screw torque                     | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Check master cylinder handlebar clamp screw torque                  | X |   | X |   | X |   | X |   | X |   | X | 1, 2, 6 |
| Inspect air cleaner, service as required                            |   | X | X | X | X | X | X | X | X | X | X | 4       |
| Replace engine oil and filter                                       | X | X | X | X | X | X | X | X | X | X | X | 1, 4    |
| Replace                                                             | X |   | X |   | X |   | X |   | X |   | X | 4       |

[illegible]

[illegible]

|                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |   |   |   |   |   |   |   |   |   |   |  |
|----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|---|---|---|---|---|---|---|---|---|--|
| every<br>100,000 mi<br>160,000 km                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |   |   |   |   |   |   |   |   |   |   |  |
| Road test to<br>verify<br>component<br>and system<br>functions | X                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | X | X | X | X | X | X | X | X | X | X |  |
| <b>NOTES:</b>                                                  | <p>1. Perform annually or at specified intervals, whichever comes first.</p> <p>2. Should be performed by an authorized Harley-Davidson dealer, unless you have the proper tools, service data and are mechanically qualified.</p> <p>3. Perform spoke tension check at the 1000 mi 1600 km , 5000 mi 8000 km , 20,000 mi 32,000 km services and every 15,000 mi 24,000 km interval thereafter. Not all vehicles are equipped with spoke wheels. Consult appropriate topic in service manual.</p> <p>4. Perform maintenance more frequently in severe riding conditions (such as extreme temperatures, dusty environments, mountainous or rough roads, long storage conditions, short runs, heavy stop/go traffic or poor fuel quality).</p> <p>5. Replace DOT 4 brake fluid and flush system every two years.</p> <p>6. For torque instructions, see Shop Practices in the service manual.</p> <p>7. Disassemble, lubricate and inspect every 30,000 mi 48,000 km .</p> <p>8. Clutch fluid will rise as clutch wears.</p> |   |   |   |   |   |   |   |   |   |   |  |

## Maintenance Records

Maintain a record of all service. Refer to Owner's Maintenance Records.

Owner's Maintenance Records

| SERVICE MILE INTERVAL | DATE | DEALER<br>NUMBER | TECHNICIAN<br>NAME | TECHNICIAN<br>SIGNATURE |
|-----------------------|------|------------------|--------------------|-------------------------|
| 1,000 mi 1,600 km     |      |                  |                    |                         |
| 5,000 mi 8,000 km     |      |                  |                    |                         |
| 10,000 mi 16,000 km   |      |                  |                    |                         |
| 15,000 mi 24,000 km   |      |                  |                    |                         |
| 20,000 mi 32,000 km   |      |                  |                    |                         |
| 25,000 mi 40,000 km   |      |                  |                    |                         |
| 30,000 mi 48,000 km   |      |                  |                    |                         |
| 35,000 mi 56,000 km   |      |                  |                    |                         |
| 40,000 mi 64,000 km   |      |                  |                    |                         |
| 45,000 mi 72,000 km   |      |                  |                    |                         |
| 50,000 mi 80,000 km   |      |                  |                    |                         |

---

## Service Literature

---

Visit any Harley-Davidson dealer to purchase a service or parts manual for your motorcycle. Factory authorized manuals are the most complete and detailed source of information outside of your Harley-Davidson dealer. Refer to Service Literature: 2016 Softail Models.

### Service Literature: 2016 Softail Models

| DOCUMENT                                                                                                                     | PART<br>NUMBER |
|------------------------------------------------------------------------------------------------------------------------------|----------------|
| Softail Models Service Manual                                                                                                | 99482-16       |
| Softail Models Electrical Diagnostic Manual                                                                                  | 99498-16       |
| Softail Models Parts Catalog                                                                                                 | 99455-16       |
| Publication numbers listed are English language manuals.<br><br>Other languages are available from a Harley-Davidson dealer. |                |

## H-D U.S.A., LLC Trademark Information

---

Bar & Shield, Boom!, Cross Bones, Cruise Drive, CVO, Digital Tech, Digital Technician, Digital Technician II, Dyna, Electra Glide, Evolution, Fat Bob, Fat Boy, Forty-Eight, Glaze, Gloss, H-D, H-Dnet.com, Harley, Harley-Davidson, HD, Heritage Softail, Iron 883, Low Rider, Night Rod, Nightster, Night Train, Profile, Reflex, Revolution, Road Glide, Road King, Road Tech, Rocker, Screamin' Eagle, Seventy-Two, Softail, Sportster, Street Glide, Street Rod, Sun Ray, Sunwash, Super Glide, SuperLow, Supersmart, Switchback, SYN3, TechLink, TechLink II, Tour-Pak, Tri Glide, Twin Cam 88, Twin Cam 88B, Twin Cam 96, Twin Cam 96B, Twin Cam 103, Twin Cam 103B, Twin Cam 110, Twin Cam 110B, Twin-Cooled, Ultra Classic, V-Rod, VRSC and Harley-Davidson Genuine Motor Parts and Genuine Motor Accessories are among the trademarks of H-D U.S.A., LLC.

## Product Registered Marks

---

Apple, Alcantara S.p.A., Allen, Amp Multilock, Bluetooth, Brembo, City Navigator, Delphi, Deutsch, Dunlop, Dynojet, Fluke, G.E. Versilube, Garmin, Gunk, Hydroseal, Hylomar, iPhone, iPod, Kevlar, Lexan, Loctite, Lubriplate, Keps, K&N, Magnaflux, Marson Thread-Setter Tool Kit, MAXI fuse, Molex, Michelin, MPZ, Multilock, nano, NGK, Novus, Packard, Pirelli, Permatex, Philips, PJ1, Pozidriv, Road Tech, Robinair, S100, Sems, SiriusXM, Snap-on, Teflon, Threadlocker, Torca, Torco, TORX, Tufoil, Tyco, Ultratorch, Velcro, X-Acto, XM Satellite Radio, and zumo are among the trademarks of their respective owners.