



SERVICE STATION MANUAL

**665333 IT-665334 EN-665335 FR-665336 DE-665337
ES-665339 PT-665340 NL**



Vespa LXV 125 i.e.



SERVICE STATION MANUAL

Vespa LXV 125 i.e.

The descriptions and images in this publication are given for illustrative purposes only and are not binding. While the basic characteristics as described and illustrated in this booklet remain unchanged, Piaggio & C. S.p.A. reserves the right, at any time and without being required to update this publication beforehand, to make any changes to components, parts or accessories, which it considers necessary to improve the product or which are required for manufacturing or construction reasons.

Not all versions/models shown in this publication are available in all countries. The availability of each model should be checked at the official PIAGGIO sales network.

© Copyright 2013 - Piaggio & C. S.p.A. All rights reserved. Reproduction of this publication in whole or in part is prohibited.

Piaggio & C. S.p.A. Viale Rinaldo Piaggio, 25 - 56025 PONTEDERA (PI), Italy
www.piaggio.com

SERVICE STATION MANUAL

Vespa LXV 125 i.e.

This service station manual has been drawn up by Piaggio & C. Spa to be used by the workshops of Piaggio dealers. It is assumed that the user of this manual for maintaining and repairing Piaggio vehicles has a basic knowledge of mechanical principles and vehicle repair technique procedures. Any significant changes to vehicle characteristics or to specific repair operations will be communicated by updates to this manual. Nevertheless, no mounting work can be satisfactory if the necessary equipment and tools are unavailable. It is therefore advisable to read the sections of this manual concerning special tools, along with the special tool catalogue.

N.B. Provides key information to make the procedure easier to understand and carry out.

CAUTION Refers to specific procedures to carry out for preventing damages to the vehicle.

WARNING Refers to specific procedures to carry out to prevent injuries to the repairer.



Personal safety Failure to completely observe these instructions will result in serious risk of personal injury.



Safeguarding the environment Sections marked with this symbol indicate the correct use of the vehicle to prevent damaging the environment.



Vehicle intactness The incomplete or non-observance of these regulations leads to the risk of serious damage to the vehicle and sometimes even the invalidity of the guarantee.



INDEX OF TOPICS

CHARACTERISTICS

CHAR

TOOLING

TOOL

MAINTENANCE

MAIN

TROUBLESHOOTING

TROUBL

ELECTRICAL SYSTEM

ELE SYS

ENGINE FROM VEHICLE

ENG VE

ENGINE

ENG

INJECTION

INJEC

SUSPENSIONS

SUSP

BRAKING SYSTEM

BRAK SYS

CHASSIS

CHAS

PRE-DELIVERY

PRE DE

INDEX OF TOPICS

CHARACTERISTICS

CHAR

Rules

This section describes general safety rules for any maintenance operations performed on the vehicle.

Safety rules

- If work can only be done on the vehicle with the engine running, make sure that the premises are well ventilated, using special extractors if necessary; never let the engine run in an enclosed area. Exhaust fumes are toxic.
 - The battery electrolyte contains sulphuric acid. Protect your eyes, clothes and skin. Sulphuric acid is highly corrosive; in the event of contact with your eyes or skin, rinse thoroughly with abundant water and seek immediate medical attention.
 - The battery produces hydrogen, a gas that can be highly explosive. Do not smoke and avoid sparks or flames near the battery, especially when charging it.
 - Fuel is highly flammable and it can be explosive given some conditions. Do not smoke in the working area, and avoid naked flames or sparks.
 - Clean the brake pads in a well-ventilated area, directing the jet of compressed air in such a way that you do not breathe in the dust produced by the wear of the friction material. Even though the latter contains no asbestos, inhaling dust is harmful.
-

Maintenance rules

- Use original PIAGGIO spare parts and lubricants recommended by the Manufacturer. Non-original or non-conforming spares may damage the vehicle.
 - Use only the appropriate tools designed for this vehicle.
 - Always use new gaskets, sealing rings and split pins upon refitting.
 - After removal, clean the components using non-flammable or low flash-point solvents. Lubricate all the work surfaces, except tapered couplings, before refitting these parts.
 - After refitting, make sure that all the components have been installed correctly and work properly.
 - Use only equipment with metric sizes for removal, service and reassembly operations. Metric bolts, nuts and screws are not interchangeable with coupling members using English measurements. Using unsuitable coupling members and tools may damage the vehicle.
 - When carrying out maintenance operations on the vehicle that involve the electrical system, make sure the electrical connections have been made properly, particularly the ground and battery connections.
-

Vehicle identification


VEHICLE IDENTIFICATION

vehicle identification

Specification	Desc./Quantity
Chassis prefix	ZAPM4430000 to 100001
Engine prefix	M444Mto 1001



Dimensions and mass



WEIGHTS AND DIMENSIONS

Specification	Desc./Quantity
Kerb weight	118 ± 6 kg
Maximum height	1225 mm
Width	740 mm
Wheelbase	1280 mm
Length	1770 mm

Engine

ENGINE

Specification	Desc./Quantity
ENGINE	Single cylinder 4-stroke
Timing system	Single overhead camshaft (SOHC) with 2 valves
Valve clearance	intake 0.10 exhaust 0.15
Bore x stroke	57 x 48.6 mm
Engine capacity	124 cm ³
Compression ratio	10.6 ± 0.5 to 1
Engine idle speed	1,750 ± 50 rpm
Air filter	sponge, impregnated with mixture (50% petrol and 50% oil)
Fuel system	Electronic injection with electric fuel pump.
Starting system	electric starter motor with freewheel
Lubrication	with lobe pump (inside the crankcase) chain-driven and double filter: mesh and paper
Minimum lubrication pressure (100° C)	0.8 bar
Lubrication pressure	3.5 to 4 bar
Max. power	7.9 kW at 8250 rpm
MAX. torque	9.6 Nm at 6500 rpm
Cooling	Forced-circulation air cooling.

Transmission

TRANSMISSION

Specification	Desc./Quantity
Transmission	With continuously variable expandable pulley transmission with torque server, V belt, automatic clutch, gear reduction unit and transmission housing with forced air circulation cooling.
Final reduction gear	Gear reduction unit in oil bath.

Capacities

CAPACITY

Specification	Desc./Quantity
Engine oil	1100 cc (67.13 cu.in)
Rear hub oil	~ 100 cm ³
Fuel tank capacity	8.2 litres (2 l of them for reserve)

Electrical system

ELECTRICAL COMPONENTS

Specification	Desc./Quantity
Spark plug	NGK CR8EB or DENSO U24ESR-NB
Battery	12V - 10 Ah Sealed battery
Fuses	1 of 20A - 1 of 15A - 4 of 7.5A
Alternator	alternating current
Ignition/advance	Electronic with inductive discharge and variable advance

CHECKING RELAYS «A» OPERATING AS CIRCUIT BREAKERS

- 1) Check that, given regular conditions, there is no continuity between terminals 30 and 87.
- 2) Apply 12V voltage to power terminals 85 and 86 of the relay.
- 3) With the relay powered, check that there is continuity between terminals 30 and 87.
- 4) If these conditions are not fulfilled, the relay is damaged and must be replaced.



To check buttons and switches, check that, according to their position, the continuity of contacts is correct as indicated in the following charts.

TURN INDICATOR SWITCH

	Ro	Bl-Ne	Bi-Bi
↩			
↔ STOP ↔			
↪			


HORN BUTTON

	Gr-Ne	Bi


LIGHT SWITCH

	Ma-Bi	Bi	Vi-Bi


ENGINE STOP SWITCH

	Ve-Ne	Gr-Ve
RUN		
OFF		

STARTER BUTTON


	Bi-Ne	Ar-Bi
		

IGNITION SWITCH

	Ar	Rs-Ne	Gr	Bi-Ne
0 LOCK				
1 OFF				
2 ON				

FUEL INJECTOR

Type: 3 holes
Conicity of the nozzle: 20°
Resistance at terminals: 13.7 - 15.2 Ohm




FUEL PUMP UNIT

Mechanical type pressure regulator operating at a pressure of 2.5 BAR


Pump winding resistance: ~ 1.5 Ohm

Input current during regular functioning: 1.4 - 1.8 A



SPEED/PHASE SENSOR

Resistance at the component ends: 100 to 150 Ohm at approx. 20°



ENGINE TEMPERATURE SENSOR

0° = 9440 Ohm

+10° = 5660 Ohm

+20° = 3500 Ohm

+30° = 2265 Ohm

+80° = 357 Ohm




MINIMUM OIL PRESSURE SENSOR

Normally closed switch

Activation threshold: 0.3 - 0.6 BAR

With the engine off: continuity between muffler and ground



HV COIL


<DIV class=O v:shape="_x0000_s3074">

- Resistance of the primary = 0.5 Ohm ± 8%

- Resistance between primary and ground = infinite

- Resistance between primary and H.V. output = 3.1KOhm ± 9%


- Presence of battery voltage at component ends when key is ON and for 2 sec



STATOR

Power: 450 W

Resistance between terminals: 0.2 - 1 Ohm
terminal insulation from ground



Frame and suspensions

CHASSIS AND SUSPENSION

Specification	Desc./Quantity
Chassis	Stamped plate body with welded structural reinforcements.
Front suspension	Single arm with helical spring and single double-acting hydraulic shock absorber.
Front suspension travel	70.3 mm
Rear suspension	Double-acting shock absorber, adjustable to four positions at preloading.
Rear suspension travel	83 mm

Brakes

BRAKES

Specification	Desc./Quantity
Front brake	Ø 200-mm disc brake with hydraulic control activated by handlebar right-side lever.
Rear brake	Ø 110-mm drum brake with mechanical control activated by handlebar left-side lever.

Wheels and tyres

WHEELS AND TYRES

Specification	Desc./Quantity
Front wheel rim	Die-cast aluminium alloy; 2.50 x11"
Front tyre	Tubeless, 110/70-11" 45L

Specification	Desc./Quantity
Rear wheel rim	Die-cast aluminium alloy; 3.00 x 10"
Rear tyre	Tubeless, 120/70-10" 54L
Front tyre pressure	1.6 bar
Rear tyre pressure	2 bar
Rear wheel pressure (rider and passenger):	2.3 bar

N.B.

CHECK AND ADJUST TYRE PRESSURE WITH TYRES AT AMBIENT TEMPERATURE. REGULATE PRESSURE ACCORDING TO THE WEIGHT OF BOTH RIDER AND ACCESSORIES

Tightening Torques

LUBRICATION

Name	Torque in Nm
Hub oil drainage cap	15 to 17
Minimum oil pressure sensor	12 to 14
Oil filter	4 to 6
Oil pump cover screws	5 to 6
Screws fixing oil pump to the crankcase	5 to 6
Oil pump command sprocket screws	10 to 14
Chain cover screws	4 to 6
Oil sump screws	10 to 14
Minimum oil pressure sensor	12 to 14
Blow-by recovery duct fixing screws	3 - 4
Engine oil drainage plug / mesh filter	24 to 30

MUFFLER

Name	Torque in Nm
Silencer heat guard fixing screw	4 to 5
Screws fixing silencer to the crankcase	24 ÷ 27
Lambda probe tightening on exhaust manifold	40 to 50

HEAD AND CYLINDER

Name	Torque in Nm
Ignition spark plug	12 to 14
Head cover screws	11 - 13
Nuts fixing head to cylinder (*)	28 to 30
Head fixing screws (external)	11 to 13
Starter ground screw	7 to 8.5
Flywheel cover screw	1 to 2
Flywheel air duct screw	3 - 4
Pressure reducer counterweight retainer	7 - 8.5
Camshaft sprocket screw	12 to 14
Timing chain tensioner slider screw	10 to 14
Starter counterweight support screw	11 to 15
Tensioner screws	11 to 13
Timing chain tensioner central screw	5 - 6
Camshaft retention plate screw	4 to 6
Nut fixing silencer to cylinder head	16 to 18
Head intake manifold screw	11 to 13

(*) Lubricate the retainer threads before fitting and lock in a crossed sequence and repeat tightening 2 or 3 times.

TRANSMISSION

Name	Torque in Nm
Drive pulley nut	75 - 83
Transmission cover screw	11 to 13
Driven pulley shaft nut	54 - 60
Rear hub cap screw	24 to 27
Clutch unit nut on driven pulley	45 to 50
Hub oil drainage screw	15 to 17

FLYWHEEL

Name	Torque in Nm
Flywheel fan screws	3 to 4
Stator assembly screws (°)	3 to 4
Flywheel nut	52 - 58
Pick-up screw	3 to 4

(°) Apply LOCTITE 242 threadlock

CRANKCASE AND CRANKSHAFT

Name	Torque in Nm
Internal engine crankcase bulkhead (transmission-side half shaft) screws	4 to 6
Oil filter on crankcase fitting	27 - 33
Rear brake cam tightening screw	11 to 13
Engine-crankcase coupling screws	11 ÷ 13
Pre-filter cap	24 to 30
Starter motor fixing screw	11 to 13

STEERING ASSEMBLY

Name	Torque in Nm
Steering upper ring nut	35 to 40
Steering lower ring nut	12 to 14
Handlebar fixing screw	50 to 55

CHASSIS ASSEMBLY

Name	Torque in Nm
Swinging arm - chassis pin	44 to 52
Engine-swinging arm bolt	33 - 41
Stand bolt	32 to 40
Swinging arm silent-block containment bolt	33 to 41

FRONT SUSPENSION

Name	Torque in Nm
Shock absorber upper nut	20 to 30
Front wheel axle nut	75 to 90
Shock absorber upper bracket bolts	20 to 25
Wheel screw	20 to 25
Shock absorber lower bolts (°)	20 to 27

(°) Apply LOCTITE 242 threadlock

FRONT BRAKE

Name	Torque in Nm
Brake fluid pump-hose fitting	8 to 12
Brake fluid pipe-calliper fitting	20 ÷ 25
Screw tightening calliper to support	20 - 25
Brake disc screw (°)	5 to 6.5
Oil bleed valve (on the calliper)	10 to 12
Handlebar pump	7 ÷ 10
Brake pump reservoir screw	15 to 20

(°) Apply LOCTITE 242 threadlock

REAR SUSPENSION

Name	Torque in Nm
Rear wheel axle	104 ÷ 126
Shock absorber lower clamping	33 to 41
Shock-absorber/chassis nut	20 to 25

Overhaul data

Assembly clearances

Cylinder - piston assy.

COUPLING BETWEEN PISTON AND ALUMINIUM CYLINDER WITH CAST-IRON LINER

Name	Initials	Cylinder	Piston	Play on fitting
Coupling	A	56.980 to 56.987	56.933 to 56.940	0.040 - 0.054
Coupling	B	56.987 to 56.994	56.940 to 56.947	0.040 - 0.054
Coupling	C	56.994 to 57.001	56.947 to 56.954	0.040 - 0.054
Coupling	D	57.001 to 57.008	56.954 to 56.961	0.040 - 0.054
Coupling 1st oversize	A1	57.180 to 57.187	57.133 to 57.140	0.040 - 0.054
Coupling 1st oversize	B1	57.187 to 57.194	57.140 to 57.147	0.040 - 0.054
Coupling 1st oversize	C1	57.194 to 57.201	57.147 to 57.154	0.040 - 0.054
Coupling 1st oversize	D1	57.201 to 57.208	57.154 to 57.161	0.040 - 0.054
Coupling 2nd oversize	A2	57.380 to 57.387	57.333 to 57.340	0.040 - 0.054
Coupling 2nd oversize	B2	57.387 to 57.394	57.340 to 57.347	0.040 - 0.054
Coupling 2nd oversize	C2	57.394 to 57.401	57.347 to 57.354	0.040 - 0.054
Coupling 2nd oversize	D2	57.401 to 57.408	57.354 to 57.361	0.040 - 0.054
Coupling 3rd oversize	A3	57.580 to 57.587	57.533 to 57.540	0.040 - 0.054
Coupling 3rd oversize	B3	57.587 to 57.594	57.540 to 57.547	0.040 - 0.054
Coupling 3rd oversize	C3	57.594 to 57.601	57.547 to 57.554	0.040 - 0.054
Coupling 3rd oversize	D3	57.601 to 57.608	57.554 to 57.561	0.040 - 0.054

PISTON TO CAST IRON CYLINDER COUPLING

Name	Initials	Cylinder	Piston	Play on fitting
Coupling	M	56.997 - 57.004	56.944 - 56.951	0.046 - 0.060
Coupling	N	57.004 - 57.011	56.951 - 56.958	0.046 - 0.060
Coupling	O	57.011 - 57.018	56.958 - 56.965	0.046 - 0.060
Coupling	P	57.018 - 57.025	56.965 - 56.972	0.046 - 0.060
coupling 1st oversize	M1	57.197 - 57.204	57.144 - 57.151	0.046 - 0.060
coupling 1st oversize	N1	57.204 - 57.211	57.151 - 57.158	0.046 - 0.060
coupling 1st oversize	O1	57.211 - 57.218	57.158 - 57.165	0.046 - 0.060
coupling 1st oversize	P1	57.218 - 57.225	57.165 - 57.172	0.046 - 0.060
Coupling 2nd oversize	M2	57.397 - 57.404	57.344 - 57.351	0.046 - 0.060
Coupling 2nd oversize	N2	57.404 - 57.411	57.351 - 57.358	0.046 - 0.060
Coupling 2nd oversize	O2	57.411 - 57.418	57.358 - 57.365	0.046 - 0.060
Coupling 2nd oversize	P2	57.418 - 57.425	57.365 - 57.372	0.046 - 0.060
Coupling 3rd oversize	M3	57.597 - 57.604	57.544 - 57.551	0.046 - 0.060
Coupling 3rd oversize	N3	57.604 - 57.611	57.551 - 57.558	0.046 - 0.060
Coupling 3rd oversize	O3	57.611 - 57.618	57.558 - 57.565	0.046 - 0.060
Coupling 3rd oversize	P3	57.618 - 57.625	57.565 - 57.572	0.046 - 0.060


Piston rings

SEALING RINGS

Name	Description	Dimensions	Initials	Quantity
Compression ring		57 x 1	A	0.15 - 0.30
Oil scraper ring		57x1	A	0.10 - 0.30
Oil scraper ring		57x2.5	A	0.10 - 0.35
Compression ring 1st oversize		57.2 x 1	A	0.15 - 0.30
Oil scraper ring 1st oversize		57.2x1	A	0.10 - 0.30
Oil scraper ring 1st oversize		57.2x2.5	A	0.10 - 0.35

Name	Description	Dimensions	Initials	Quantity
Compression ring 2nd oversize		57.4x1	A	0.15 - 0.30
Oil scraper ring 2nd oversize		57.4x1	A	0.10 - 0.30
Oil scraper ring 2nd oversize		57.4x2.5	A	0.10 - 0.35
Compression ring 3rd oversize		57.6x1	A	0.15 - 0.30
Oil scraper ring 3rd oversize		57.6x1	A	0.10 - 0.30
Oil scraper ring 3rd oversize		57.6x2.5	A	0.10 - 0.35

Maximum clearance after use: 1 mm



Crankcase - crankshaft - connecting rod


AXIAL CLEARANCE BETWEEN CRANKSHAFT AND CONNECTING ROD

Name	Description	Dimensions	Initials	Quantity
Half-shaft, transmission side		16.6 +0-0.05	A	D = 0.20 - 0.50
Flywheel-side half shaft		16.6 +0-0.05	B	D = 0.20 - 0.50
Connecting rod with PP		18 -0.10 -0.15	C	0.20 to 0.50
Crank pin width		51.400	E	

AXIAL CLEARANCE BETWEEN CRANKSHAFT AND CRANKSHAFT HALF-BEARINGS

Name	Description	Dimensions	Initials	Quantity
Crankshaft			Category 1	28.998 - 29.004
Crankshaft			Category 2	29.004 - 29.010
Crankcase			Category 1	32.953 - 32.959
Crankcase			Category 2	32.959 - 32.965
Crankshaft half-bearing			Category B - blue	1.973 - 1.976
Crankshaft half-bearing			Category C - yellow	1.976 - 1.979
Crankshaft half-bearing			Category E - green	1.979 - 1.982
Crankshaft category 1 - Crankcase category 1			E - E	
Crankshaft category 1 - Crankcase category 2			C - C	
Crankshaft category 2 - Crankcase category 1			C - C	
Crankshaft category 2 - Crankcase category 2			B - B	

Crankshaft/crankcase axial clearance: 0.15 to 0.40



Slot packing system

- Provisionally fit the piston into the cylinder, without any base gasket.
- Assemble a dial gauge on the specific tool
- Set the dial gauge to zero at a contrast plane with an average preload, for example 5 mm. Keeping the zero setting position, fit the tool on the cylinder and lock it with 2 nuts, as shown in the figure.
- Rotate the crankshaft up to the TDC (the inversion point of the dial gauge rotation)
- Calculate the difference between the two measurements: use the chart below to identify the thickness of the cylinder base gasket to be used for refitting. Correctly identify the cylinder base gasket thickness to keep the correct compression ratio.
- Remove the special tool and the cylinder.


Characteristic

Compression ratio

10.6 ± 0.5 to 1

SHIMMING SYSTEM

Specification	Desc./Quantity
Value measured	0 - 0.1
Thickness	0.8 ± 0.05
Value measured	0.1 - 0.3
Thickness	0.6 ± 0.05
Value measured	0.3 - 0.4
Thickness	0.4 ± 0.05



Products

RECOMMENDED PRODUCTS TABLE

Product	Description	Specifications
AGIP GEAR SAE 80W-90	Lubricant for gearboxes and transmissions.	API GL-4
AGIP BRAKE 4	Brake fluid.	Synthetic fluid SAE J 1703 -FMVSS 116 - DOT 3/4 - ISO 4925 - CUNA NC 956 DOT 4
eni i-Ride PG 5W-40	Synthetic based lubricant for high-performance four-stroke engines.	JASO MA, MA2 - API SL - ACEA A3
AGIP FILTER OIL	Special product for the treatment of foam filters.	-
AGIP GREASE MU3	Yellow-brown, lithium-base, medium-fibre multipurpose grease.	ISO L-X-BCHA 3 - DIN 51 825 K3K -20
AGIP GP 330	Water repellent stringy calcium spray grease.	R.I.D./A.D.R. 2 10°b) 2 R.I.Na. 2.42 - I.A.T.A. 2 - I.M.D.G. class 2 UN 1950 Page 9022 EM 25-89




INDEX OF TOPICS


TOOLING

TOOL



SPECIFIC TOOLS


Stores code	Description	
001330Y	Tool for fitting steering seats	
001467Y009	Bell for OD 42-mm bearings	
001467Y013	Calliper to extract Ø 15-mm bearings	
001467Y014	Calliper to extract Ø 15-mm bearings	
001467Y017	Bell for bearings, OD 39 mm	
002465Y	Calliper for circlips	

Stores code	Description	
005095Y	Engine support	
006029Y	Punch for fitting steering bearing seat on steering tube	
008564Y	Flywheel extractor	
020004Y	Punch for removing steering bearings from headstock	
020021Y	Front suspension service tool	

Stores code	Description	
020036Y	Punch	
020037Y	Punch	
020038Y	Punch	
020055Y	Wrench for steering tube ring nut	
020074Y	Support base for checking crankshaft alignment	
020150Y	Air heater mounting	
020151Y	Air heater	


Stores code	Description	
020193Y	Oil pressure check gauge	
020262Y	Crankcase splitting plate	
020263Y	Driven pulley assembly sheath	
020287Y	Clamp to fit piston on cylinder	
020306Y	Punch for assembling valve seal rings	
020325Y	Pliers for brake-shoe springs	

Stores code	Description	
020329Y	Mity-Vac vacuum-operated pump	
020330Y	Stroboscopic light to check timing	
020331Y	Digital multimeter	
020332Y	Digital rpm indicator	
020333Y	Single battery charger	

Stores code	Description	
020334Y	Multiple battery charger	
020335Y	Magnetic mounting for dial gauge	
020357Y 020359Y	32 x 35-mm Adaptor 42 x 47-mm Adaptor	
020360Y	52 x 55-mm Adaptor	
020363Y	20-mm guide	

Stores code	Description	
020364Y	25-mm guide	
020365Y	22 mm guide	
020368Y	driving pulley lock wrench	
020375Y	28 x 30 mm adaptor	
020376Y	Adaptor handle	
020382Y 020382Y011	Tool to extract valve cotters adapter for valve removal tool	

Stores code	Description	
020412Y	15-mm guide	
020414Y	28-mm guide	
020423Y	Driven pulley lock wrench	
020424Y	Driven pulley roller casing fitting punch	
020425Y	Punch for flywheel-side oil seal	
020426Y	Piston fitting fork	
020456Y	Ø 24 mm adaptor	

Stores code	Description	
020427Y	Piston assembly band	
020428Y	Piston position check mounting	
020430Y	Pin lock fitting tool	
020431Y	Valve oil seal extractor	
020434Y	Oil pressure check fitting	
020441Y	26 x 28 mm adaptor	

Stores code	Description	
020439Y	17-mm guide	
020444Y	Tool for fitting/ removing the driven pulley clutch	
020480Y	Petrol pressure check kit	
020481Y	Control unit interface wiring	
020565Y	Flywheel lock calliper spanner	
020622Y	Transmission-side oil seal punch	
020922Y	Diagnosis Tool	

INDEX OF TOPICS

MAINTENANCE

MAIN

Maintenance chart

MAINTENANCE TABLE

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE, IF NECESSARY

C: CLEAN, **R:** REPLACE, **A:** ADJUST, **L:** LUBRICATE

* Check level every 3,000 km

** Replace every 2 years

Km x 1,000	1	6	12	18	24	30	36	42	48	54	60
Safety fasteners	I		I		I		I		I		I
Centre stand bracket		L	L	L	L	L	L	L	L	L	L
Drive belt		I	R	I	R	I	R	I	R	I	R
Throttle control	A		A		A		A		A		A
Air filter		C	C	C	C	C	C	C	C	C	C
Oil filter		R	R	R	R	R	R	R	R	R	R
Mesh oil filter	C	C	C	C	C	C	C	C	C	C	C
Valve clearance		A		A			A			A	
Electrical system and battery	I	I	I	I	I	I	I	I	I	I	I
Cylinder ventilation system					C				C		
Brake levers	L		L		L		L		L		L
Brake fluid **	I	I	I	I	I	I	I	I	I	I	I
Engine oil *	R	R	R	R	R	R	R	R	R	R	R
Hub oil	R	I	I	I	R	I	R	I	R	I	I
Headlight direction adjustment			A		A		A		A		A
Brake pads	I	I	I	I	I	I	I	I	I	I	I
Sliding shoes / CVT rollers		I	R	I	R	I	R	I	R	I	R
Tyre pressure and wear	I	I	I	I	I	I	I	I	I	I	I
Vehicle road test	I	I	I	I	I	I	I	I	I	I	I
Odometer gear			L		L		L		L		L
Suspension			I		I		I		I		I
Steering	A		A		A		A		A		A
Transmission			L		L		L		L		L
Operation time	80'	150'	160'	150'	175'	95'	270'	95'	175'	150'	160'

Spark plug

- Position the vehicle on the stand
- Open the saddle and remove the helmet compartment.
- Remove the spark plug external inspection door by undoing the indicated screw




- Disconnect spark plug HV cable hood and, acting on the engine compartment, release the cable from the retaining bracket.
- Slide the internal cover upwards.



- Unscrew the spark plug using the wrench supplied.



- Check the conditions of the spark plug, make sure the insulation is intact, that the electrodes are not excessively worn or sooty, the conditions of the washer, and measure the distance between the electrodes using the appropriate feeler gauge.
- Adjust the distance, if necessary, by bending the side electrode very carefully. In case of anomaly (as described before), replace the spark plug with another of the recommended type.



- Fit the spark plug with the correct inclination and manually screw it all the way down, then use the special spanner to tighten it.
- Refit the cover.
- Place the cap fully over the spark plug, and tie down the cable to the bracket.
- Carry out refit operations.

CAUTION

THE SPARK PLUG MUST BE REMOVED WHEN THE MOTOR IS COLD. THE SPARK PLUG MUST BE REPLACED EVERY 20,000 KM. THE USE OF NON CONFORMING ELECTRONIC IGNITION CONTROL UNITS OR SPARK PLUGS OTHER THAN THOSE PRESCRIBED CAN SERIOUSLY DAMAGE THE ENGINE.

Characteristic**Electrode gap**

0.7 to 0.8 mm

Spark plug

NGK CR8EB or DENSO U24ESR-NB

Locking torques (N*m)

Spark plug 12 ÷ 14


Hub oil

Check

- Park the vehicle on flat ground and rest it on the centre stand.
- Unscrew the oil dipstick/cover, dry it with a cloth and reinsert it **screwing it in thoroughly**.



- Remove the dipstick/cover and check that the oil level is between MIN and MAX.
- If the level is below the MIN value, restore the proper amount of oil in the hub.
- Screw the oil dipstick back and check it is locked.



Replacement

- Remove the oil dipstick/cover.



- Remove the rear wheel.
- Prepare an adequately sized container.
- Unscrew the oil drainage plug and drain out all the oil.



- Screw in the drainage cap again and fill the hub with the prescribed oil.

Recommended products

AGIP GEAR SAE 80W-90 Lubricant for gearboxes and transmissions.

API GL-4

Characteristic

Rear hub oil

Capacity ~ 100cc

Locking torques (N*m)

Hub oil drainage screw 15 to 17 Nm


Air filter

Proceed as follows:

- Undo the indicated fixing screws.
- Remove the left side fairing.



- Remove the helmet compartment.
- Undo the six screws and remove the air-box cover.
- Remove the filtering element and clean it with water and shampoo; then dry it with a clean cloth and short blasts of compressed air. Finally, immerse it in a mixture of 50% oil of the recommended type and 50% petrol. Then gently squeeze the



filter element between your hands, allow it to drip and then refit it. Possible oil or water deposits can be eliminated by removing the rubber lower cap.

CAUTION

IF THE VEHICLE IS USED ON DUSTY ROADS IT IS NECESSARY TO CARRY OUT MAINTENANCE CHECKS OF THE AIR FILTER MORE OFTEN TO AVOID DAMAGING THE ENGINE.

Recommended products

AGIP FILTER OIL Special product for the treatment of foam filters.

-



Engine oil

In four stroke engines, the engine oil is used to lubricate the timing elements, the bench bearings and the thermal group. **An insufficient quantity of oil can cause serious damage to the engine.**

In all four stroke engines, the deterioration of the oil characteristics, or a certain consumption should be considered normal, especially if during the run-in period. Consumption levels in particular can be influenced by the conditions of use (e.g.: oil consumption increases when driving at "full throttle").

Replacement

Change oil and replace filter as indicated in the scheduled maintenance table. The engine must be emptied by draining off the oil through the drainage plug of the mesh pre-filter, flywheel side; furthermore to facilitate oil drainage, loosen or remove the cap/dipstick. Once all the oil has drained through the drainage hole, unscrew the oil cartridge filter and remove it.

Make sure the pre-filter and drainage plug O-rings are in good conditions.

Lubricate them and refit the mesh filter and the oil drainage plug, screwing them up to the prescribed torque.

Refit the new cartridge filter being careful to lubricate the O-ring before fitting it.

Change the engine oil.



Since a certain quantity of oil still remains in the circuit, oil must be filled from oil dipstick/cover. Then start up the vehicle, leave it running for a few minutes and switch it off: after five minutes check the level and if necessary top up without exceeding the **MAX** level. The cartridge filter must be replaced every time the oil is changed. Use new oil of the recommended type for topping up and changing purposes.

N.B.

THE ENGINE MUST BE HOT WHEN THE OIL IS CHANGED.

Recommended products

eni i-Ride PG 5W-40 Synthetic based lubricant for high-performance four-stroke engines.

JASO MA, MA2 - API SL - ACEA A3



Check

This operation must be carried out with the engine cold and following the procedure below:


- Place the vehicle on its centre stand and on flat ground.
- Undo cap/dipstick, dry it off with a clean cloth and reinsert it, **screwing down completely**.
- Remove the cap/dipstick again and check that the level is between the MIN and MAX reference marks; top up if necessary.


The MAX level mark indicates a quantity of around 1100 cc of oil in the engine. If the check is carried out after the vehicle has been used, and therefore with a hot engine, the level will be lower; in order to carry out a correct check it is necessary to wait at least 10 minutes after the engine has been stopped, so as to get the correct level.

Engine oil top-up

The oil should be topped up after having checked the level and in any case by adding oil **without ever exceeding the MAX. level**.

Restoration of the level from **MIN** to **MAX** requires approximately **200 cc**.





Engine oil filter

Change oil and replace filter as indicated in the scheduled maintenance table. Use new oil of the recommended type for topping up and changing purposes.

Make sure the pre-filter and drainage plug O-rings are in good conditions. Lubricate them and refit the mesh filter and the oil drainage plug, screwing them up to the specified torque. Refit the new cartridge filter being careful to lubricate the O-ring before fitting it. Change the engine oil.

Recommended products

eni i-Ride PG 5W-40 Synthetic based lubricant for high-performance four-stroke engines.

JASO MA, MA2 - API SL - ACEA A3

Oil pressure warning light

The vehicle is equipped with a telltale light on the dashboard that lights up when the key is turned to the «ON» position. However, this light should switch off once the engine has started.

If the light turns on during braking, at idling speed or while turning a corner, it is necessary to check the oil level and the lubrication system.




Checking the ignition timing

- Remove the flywheel fan.
- Rotate the flywheel until the reference (arrow) matches the crankcase operation end as shown in the figure (TDC). Make sure that the 2V reference point on the camshaft control pulley is aligned with the reference point on the head as shown in the second figure. If the reference mark is opposite the indicator on the head, make the crankshaft turn once more.
- The TDC reference mark is repeated also between the flywheel cooling fan and the flywheel cover.

To use this reference mark, remove the spark plug and turn the engine in the opposite direction to the normal direction of rotation using a compass spanner applied to the camshaft drive sprocket housing.

N.B.

TIME THE TIMING SYSTEM UNIT IF IT IS NOT IN PHASE.



Checking the valve clearance

- To check valve clearance, centre the reference marks of the timing system.
- Use a feeler gauge to check that the clearance between the valve and the register corresponds with the indicated values. When the valve clearance values, intake and exhaust respectively, are different from the ones indicated below, adjust them by loosening the lock nut and operate on the set screw with a screwdriver.

Characteristic

Valve clearance

Intake: 0.10 mm (when cold)

Exhaust: 0.15 mm (when cold)

Braking system

Level check

Proceed as follows:

- Rest the vehicle on its centre stand with the handlebars perfectly horizontal;
- Check the level of liquid with the related warning light «A».

A certain lowering of the level is caused by wear on the brake pads.



Top-up

Proceed as follows:

- Remove the reservoir cap by loosening the two screws, remove the gasket and top-up using only the fluid specified without exceeding the maximum level.

CAUTION

ONLY USE DOT 4-CLASSIFIED BRAKE FLUID.

CAUTION



AVOID CONTACT OF THE BRAKE FLUID WITH YOUR EYES, SKIN, AND CLOTHING. IN CASE OF ACCIDENTAL CONTACT, WASH WITH WATER.

CAUTION

BRAKING CIRCUIT FLUID IS HIGHLY CORROSIVE; DO NOT LET IT COME INTO CONTACT WITH PAINTED PARTS.

CAUTION

BRAKE FLUID IS HYGROSCOPIC; THAT IS, IT ABSORBS MOISTURE FROM THE SURROUNDING AIR. IF THE CONTENT OF MOISTURE IN THE BRAKE FLUID EXCEEDS A CERTAIN VALUE, BRAKING WILL BE INEFFICIENT. NEVER USE BRAKE FLUID FROM OPEN OR PARTIALLY USED CONTAINERS.

UNDER NORMAL CLIMATIC CONDITIONS, REPLACE FLUID AS INDICATED IN THE SCHEDULED MAINTENANCE TABLE.

N.B.

SEE THE BRAKING SYSTEM CHAPTER WITH REGARD TO THE CHANGING OF BRAKE FLUID AND THE BLEEDING OF AIR FROM THE CIRCUITS.


Recommended products

AGIP BRAKE 4 Brake fluid.

Synthetic fluid SAE J 1703 - FMVSS 116 - DOT 3/4

- ISO 4925 - CUNA NC 956 DOT 4

Locking torques (N*m)



Brake pump reservoir screws 15 to 20


Headlight adjustment

Proceed as follows:

1. Position the vehicle in running order and with the tyres inflated to the prescribed pressure, onto a flat surface 10 m away from a half-lit white screen; ensure that the longitudinal axis of the vehicle is perpendicular to the screen;
2. Turn on the headlight and check that the boundary of the light beam projected onto the screen is not higher than $\frac{9}{10}$ or lower than $\frac{7}{10}$ of the distance between the centre of the headlight and the ground;
3. Otherwise loosen the rear screw on just one side, press or pull the point of the headlight slightly to adjust its position.

N.B.

THE ABOVE PROCEDURE COMPLIES WITH THE EUROPEAN STANDARDS REGARDING MAXIMUM AND MINIMUM HEIGHT OF LIGHT BEAMS. REFER TO THE STATUTORY REGULATIONS IN FORCE IN EVERY COUNTRY WHERE THE VEHICLE IS USED.



INDEX OF TOPICS

TROUBLESHOOTING

TROUBL

Engine

See also

[Troubleshooting procedure](#)

Poor performance

POOR PERFORMANCE

Possible Cause	Operation
Air filter blocked or dirty	Remove the sponge, wash with water and car shampoo, then soak it in a mixture of 50% petrol and 50% specific oil. Press with your hand without squeezing, allow it to drip dry and refit.
Excessive drive belt wear	Check it and replace, if necessary
Lack of compression: parts, cylinder and valves worn	Replace the worn parts
Oil level exceeds maximum	Check for causes and fill to reach the correct level
Excess of scales in the combustion chamber	Descalc the cylinder, the piston, the head and the valves
Incorrect timing or worn timing system elements	Time the system again or replace the worn parts
Muffler obstructed	Replace
Inefficient automatic transmission	Check the rollers and the pulley movement, replace the damaged parts and lubricate the movable guide of the driven pulley with grease.
Wrong valve adjustment	Adjust the valve clearance properly
Overheated valves	Remove the head and the valves, grind or replace the valves
Valve seat distorted	Replace the head unit
Worn cylinder, Worn or broken piston rings	Replace the piston cylinder assembly or just the piston rings

Starting difficulties

DIFFICULTY STARTING UP

Possible Cause	Operation
Flat battery	Check the state of the battery. If it shows signs of sulphation, replace it and bring the new battery into service by charging it for not more than ten hours at a current of 1/10 of the capacity of the battery itself.
Faulty spark plug	Replace the spark plug
Incorrect valve sealing or valve adjustment	Inspect the head and/or restore the correct clearance
Starter motor and start-up system fault	Check starter motor.
Altered fuel characteristics	Drain off the fuel no longer up to standard; then, refill
Air filter obstructed or dirty.	Remove the sponge, wash with water and car shampoo, then soak it in a mixture of 50% petrol and 50% specific oil. Press with your hand without squeezing, allow it to drip dry and refit.
Fuel pump fault	Check the pump.

Excessive oil consumption/Exhaust smoke

EXCESSIVE CONSUMPTION

Possible Cause	Operation
Wrong valve adjustment	Adjust the valve clearance properly
Overheated valves	Remove the head and the valves, grind or replace the valves
Misshapen/worn valve seats	Replace the head unit
Worn cylinder, Worn or broken piston rings	Replace the piston cylinder assembly or piston rings
Worn or broken piston rings or piston rings that have not been fitted properly	Replace the piston cylinder unit or just the piston rings
Oil leaks from the couplings or from the gaskets	Check and replace the gaskets or restore the coupling seal
Worn valve oil guard	Replace the valve oil seal
Worn valve guides	Check and replace the head unit if required

Insufficient lubrication pressure

POOR LUBRICATION PRESSURE

Possible Cause	Operation
By-Pass remains open	Check the By-Pass and replace if required. Carefully clean the By-Pass area.
Oil pump with excessive clearance	Perform the dimensional checks on the oil pump components
Oil filter too dirty	Replace the cartridge filter
Oil level too low	Restore the level adding the recommended oil type

Transmission and brakes

Clutch grabbing or performing inadequately

IRREGULAR CLUTCH PERFORMANCE OR SLIPPAGE

Possible Cause	Operation
Slippage or irregular functioning	Check that there is no grease on the masses. Check that the faying surface between the clutch masses and the clutch housing is mainly in the middle and with equivalent specifications on the three masses. Check that the clutch housing is not scored or worn abnormally

Insufficient braking

INEFFICIENT OR NOISY BRAKING

Possible Cause	Operation
Worn brake pads or shoes	Replace the brake pads or shoes and check for brake disk or drum wear conditions.
Front brake disk loose or deformed	Check the brake disc screws are locked; use a dial gauge and a wheel mounted on the vehicle to measure the axial shift of the disc.
Air bubbles inside the hydraulic braking system	Carefully bleed the hydraulic braking system, (there must be no flexible movement of the brake lever).
Fluid leakage in hydraulic braking system	Failing elastic fittings, plunger or brake pump seals, replace
Excessive clearance in the rear brake control cable	Adjust the clearance with the appropriate adjuster located on the back part of the crankcase.

Brakes overheating

BRAKES OVERHEATING

Possible Cause	Operation
Rubber gaskets swollen or stuck	Replace gaskets.
Compensation holes on the pump clogged	Clean carefully and blast with compressed air
Brake disc slack or distorted	Check the brake disc screws are locked; use a dial gauge and a wheel mounted on the vehicle to measure the axial shift of the disc.
Defective piston sliding	Check calliper and replace any damaged part.

Electrical system

Battery

BATTERY

Possible Cause	Operation
Battery	The battery is the electrical device in the system that requires the most frequent inspections and thorough maintenance. If the vehicle is not used for some time (1 month or more) the battery needs to be recharged periodically. The battery runs down completely in the course of 5 to 6 months. If the battery is fitted on a motorcycle, be careful not to invert the connections, keeping in mind that the black ground wire is connected to the negative terminal while the red wire is connected to the terminal marked+. Follow the instructions in the ELECTRICAL SYSTEM chapter for the recharging of the batteries.

Steering and suspensions

Heavy steering

STEERING HARDENING

Possible Cause	Operation
Steering hardening	Check the tightening of the top and bottom ring nuts. If irregularities continue in turning the steering even after making the above adjustments, check the seats in which the ball bearings rotate: if they are recessed or if the balls are squashed, replace them.

Excessive steering play

EXCESSIVE STEERING CLEARANCE

Possible Cause	Operation
Excessive steering clearance	Check the tightening of the top ring nut. If irregularities continue in turning the steering even after making the above adjustments, check the seats in which the ball bearings rotate: replace if they are recessed.

Noisy suspension

NOISY SUSPENSION

Possible Cause	Operation
NOISY SUSPENSION	If the front suspension is noisy, check: that the front shock absorber works properly and the ball bearings are good condition. Finally, check the locking torque of the wheel axle nut, the brake calliper and the disc. Check that the swinging arm connecting the engine to the chassis and the rear shock absorber work properly.

Suspension oil leakage


OIL LEAKAGE FROM SUSPENSION

Possible Cause	Operation
Faulty or broken seals	Replace the shock absorber Check the condition of wear of the steering covers and the adjustments.

INDEX OF TOPICS

ELECTRICAL SYSTEM

ELE SYS

**Key:**


1. Magneto flywheel
2. Voltage regulator
3. Battery 12V-10 Ah
4. Starter relay
5. Starter motor
6. Starter button
7. Fuse No.1 - 20A
8. Fuse No.2 - 7.5A
9. Stop light bulb
10. ignition key contacts
11. Low beam light solenoid
12. Stop buttons
13. Light switch
14. Fuse No.5 - 7.5A
15. Fuse No.6 - 15A
16. Fuse No.4 - 7,5A
17. Front and rear daylight running light bulbs and license plate light
18. Headlight with twin-filament bulb
19. Pre-installation for anti-theft device

-
20. Turn indicator bulbs
 21. Turn indicator switch
 22. Turn indicator control device
 23. Instrument panel bulb
 24. Fuel level transmitter
 25. Oil pressure sensor
 26. Fuse No.3 - 7.5A
 27. Immobilizer aerial
 28. Injection electronic control unit
 29. Fuel system pump
 30. Diagnostics socket
 31. Engine temperature sensor
 32. Fuel injector
 33. HV coil
 34. Engine speed sensor
 35. Lambda probe
 36. Horn button
 37. Horn
 38. Injection load solenoid
 39. High-beam light solenoid
 40. Turn indicator warning light bulb
 41. Bulb for oil pressure warning light
 42. Fuel gauge
 43. Low fuel warning light bulb
 44. Bulb for engine control telltale light
 45. Immobilizer
 46. Bulb for high beam headlight warning light
 47. Engine stop switch
 48. Ground on the chassis
 49. Earth braid
 50. Ground on the engine
 51. Condenser
 52. Resistance
 53. Immobilizer LED warning light
 54. Resistance

KEY

Ar: Orange **Az:** Light blue **Bi:** White **Bl:** Blue **Gi:** Yellow **Gr:** Grey **Ma:** Brown **Ne:** Black **Ro:** Pink **Rs:** Red **Ve:** Green **Vi:** Purple

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Key:

1. Left turn indicator bulbs
2. Right turn indicator bulbs
3. Turn indicator warning light bulb
4. Turn indicator switch
5. Turn indicator control device
6. Pre-installation for anti-theft device
7. Headlight with twin-filament bulb
8. Bulb for high beam headlight warning light
9. Front daylight running light bulb
10. Rear tail light bulb
11. License plate bulb
12. Instrument panel lighting bulbs
13. engine stop switch
14. Fuses No. 3- 7.5A; No. 4- 7.5A; No. 5- 7.5A; No. 6- 15A;
15. High-beam light solenoid

-
16. Low beam light solenoid
 17. Light switch
 18. Stop buttons
 19. Ignition switch contacts
 20. Fuse No.2 - 7.5A
 21. Earth braid
 22. Starter motor
 23. Starter remote control switch
 24. Starter button
 25. Fuse No.1 - 20A
 26. 12v-10Ah battery
 27. Magneto flywheel
 28. Voltage regulator
 29. Stop light bulb
 30. Injection load relay
 31. Horn button
 32. Horn
 33. Lambda probe
 34. Engine speed sensor
 35. HV coil
 36. Fuel injector
 37. Engine temperature sensor
 38. Fuel system pump
 39. Diagnostics socket
 40. Injection electronic control unit
 41. Immobilizer antenna
 42. Bulb for engine control telltale light
 43. Fuel level transmitter
 44. Fuel gauge
 45. Low fuel warning light bulb
 46. Oil pressure sensor
 47. Bulb for oil pressure warning light
 48. Immobilizer LED warning light


KEY

Ar: Orange **Az:** Light blue **Bi:** White **Bl:** Blue **Gi:** Yellow **Gr:** Grey **Ma:** Brown **Ne:** Black **Ro:** Pink **Rs:** Red **Ve:** Green **Vi:** Purple

Components arrangement




1. Magneto flywheel - Remove the flywheel cover, as described in the «Engine» chapter, to reach it. To get access to the connectors, remove the helmet compartment.




2. Voltage regulator - Remove the front central cover to reach it.





3. Battery - Lift the saddle and remove the cover to reach them.



4. Starter remote control - Remove the battery to reach it.



7 - 8 - 14 - 15 - 16 -26. Fuses - Remove the battery cover and/or the front central cover to reach them.




11 - 38 - 39. Remote controls - Remove the front central cover to reach it.




29 - 24. Pump and fuel lever transmitter - They are fitted on the tank, remove the fuel tank to reach them.



25 - 34. Oil pressure sensor - engine speed sensor - To reach it, remove the fan cover cap, as described in ENGINE chapter.




27. Immobilizer aerial- Remove the shield back plate to reach it.



28. Injection ECU - Remove the helmet compartment to reach it.





30. Diagnosis connector - Remove the helmet compartment to reach it.



31 - 32. Engine temperature sensor - fuel injector - Remove the helmet compartment to reach it.



33. H.V. coil - Remove the helmet compartment and undo the two screws indicated to reach it.




Ground points


On the vehicle there is a chassis ground point, marked with letter "A", on the right side of the battery compartment.




There is another ground point **"B"** on the starter motor.




On the left side of the chassis, under the footrest, there is the chassis-engine ground lead **"C"**.




Electrical system installation

Back side

1. To the front part
2. To the magneto flywheel
3. To HV coil
4. To the rear lighting devices
5. Chassis ground
6. Start-up remote control switch
7. Fuel level transmitter
8. Battery
9. Diagnostic socket
10. Generator connector
11. Pick-up connector



1. Rear right turn indicator
2. License plate light
3. To rear light
4. Rear left turn indicator
5. Fuel pump
6. To the fuel level transmitter
7. Diagnostic socket
8. Generator connector
9. Pick-up connector
10. HV coil
11. Lambda sensor
12. Lambda probe connector




1. Fuse box
2. Start-up remote control switch
3. Battery
4. Fuel pump
5. Fuel level transmitter
6. Injector
7. Engine temperature sensor
8. Injection ECU
9. Start-up motor ground
10. Start-up motor positive terminal
11. Diagnostic socket
12. HV coil
13. Generator connector
14. Pick-up connector

- 15.To the spark plug
- 16.chassis - engine ground lead
- 17.To the front part

Conceptual diagrams

Ignition




Key:

- 3. Battery 12V-10 Ah
- 7. Fuse No.1 - 20A
- 8. Fuse No.2 - 7,5A
- 10. ignition key contacts
- 13. Light switch
- 15. Fuse No.6 - 15A
- 26. Fuse No.3 - 7.5A
- 27. Immobilizer aerial
- 28. Injection electronic control unit
- 29. Fuel system pump
- 30. Diagnostics socket
- 32. Fuel injector

- 33. HV coil
- 38. Injection load solenoid
- 44. Bulb for engine control telltale light
- 45. Immobilizer
- 51. Condenser
- 52. Resistance
- 53. Immobilizer LED warning light
- 54. Resistance


THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Key:


- 14. Fuse No.6 - 15A
- 19. Ignition switch contacts
- 20. Fuse No.2 - 7.5A
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 30. Injection load relay
- 35. HV coil
- 40. Injection electronic control unit
- 41. Immobilizer antenna

48. Immobilizer LED warning light

Battery recharge and starting**Key:**

1. Magneto flywheel
2. Voltage regulator
3. Battery 12V-10 Ah
4. Starter relay
5. Starter motor
6. Starter button
7. Fuse No.1 - 20A
8. Fuse No.2 - 7.5A
9. Stop light bulb
10. ignition key contacts
12. Stop buttons
15. Fuse No.6 - 15A
26. Fuse No.3 - 7.5A
28. Injection electronic control unit


THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Key:


- 14. Fuses No. 3- 7.5A;
- 18. Stop buttons
- 19. Ignition switch contacts
- 22. Starter motor
- 23. Starter remote control switch
- 24. Starter button
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 27. Magneto flywheel
- 28. Voltage regulator
- 29. Stop light bulb
- 40. Injection electronic control unit

Level indicators and enable signals section

**Key:**

- 7. Fuse No.1 - 20A
- 8. Fuse No.2 - 7.5A
- 10. ignition key contacts
- 15. Fuse No.6 - 15A
- 24. Fuel level transmitter
- 25. Oil pressure sensor
- 26. Fuse No.3 - 7.5A
- 28. Injection electronic control unit
- 31. Engine temperature sensor
- 32. Fuel injector
- 34. Engine speed sensor
- 35. Lambda probe
- 38. Injection load solenoid
- 41. Bulb for oil pressure warning light
- 42. Fuel gauge
- 43. Low fuel warning light bulb
- 44. Bulb for engine control telltale light


THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Key:

- 13. engine stop switch
- 14. Fuses No. 3- 7.5A; No. 6- 15A
- 19. Ignition switch contacts
- 20. Fuse No.2 - 7.5A
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 40. Injection electronic control unit
- 41. Immobilizer antenna
- 43. Fuel level transmitter
- 44. Fuel gauge
- 45. Low fuel warning light bulb
- 46. Oil pressure sensor
- 47. Bulb for oil pressure warning light
- 48. Immobilizer LED warning light


Devices and accessories

**Key:**

- 3. Battery 12V-10 Ah
- 7. Fuse No.1 - 20A
- 8. Fuse No.2 - 7.5A
- 9. Stop light bulb
- 10. ignition key contacts
- 15. Fuse No.6 - 15A
- 16. Fuse No.4 - 7.5A
- 19. Pre-installation for anti-theft device
- 20. Turn indicator bulbs
- 21. Turn indicator switch
- 22. Turn indicator control device
- 26. Fuse No.3 - 7.5A
- 27. Immobilizer aerial
- 28. Injection electronic control unit
- 29. Fuel system pump
- 36. Horn button
- 37. Horn

- 38. Injection load solenoid
- 40. Turn indicator warning light bulb
- 44. Bulb for engine control telltale light
- 45. Immobilizer
- 51. Condenser
- 52. Resistance
- 53. Immobilizer LED warning light
- 54. Resistance

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.




Key:

- 1. Left turn indicator bulbs
- 2. Right turn indicator bulbs
- 6. Pre-installation for anti-theft device
- 14. Fuses No. 3- 7.5A; No. 4- 7.5A
- 19. Ignition switch contacts
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 31. Horn button

32. Horn


Lights and turn indicators

**Key:**

- 3. Battery 12V-10 Ah
- 7. Fuse No.1 - 20A
- 8. Fuse No.2 - 7.5A
- 9. Stop light bulb
- 10. ignition key contacts
- 11. Low beam light solenoid
- 12. Stop buttons
- 13. Light switch
- 14. Fuse No.5 - 7.5A
- 15. Fuse No.6 - 15A
- 16. Fuse No.4 - 7.5A
- 17. Front and rear daylight running light bulbs and license plate light
- 18. Headlight with twin-filament bulb
- 20. Turn indicator bulbs
- 21. Turn indicator switch
- 22. Turn indicator control device

- 23. Instrument panel bulb
- 26. Fuse No.3 - 7.5A
- 28. Injection electronic control unit
- 39. High-beam light solenoid
- 40. Turn indicator warning light bulb
- 46. Bulb for high beam headlight warning light
- 47. Engine stop switch

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.




Key:

- 1. Left turn indicator bulbs
- 2. Right turn indicator bulbs
- 3. Turn indicator warning light bulb
- 4. Turn indicator switch
- 5. Turn indicator control device
- 7. Headlight with twin-filament bulb
- 8. Bulb for high beam headlight warning light
- 9. Front daylight running light bulb
- 10. Rear tail light bulb
- 11. License plate bulb

- 12. Instrument panel lighting bulbs
- 14. Fuses No. 3- 7.5A; No. 4- 7.5A; No. 5- 7.5A
- 15. High-beam light solenoid
- 16. Low beam light solenoid
- 17. Light switch
- 19. Ignition switch contacts
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 40. Injection electronic control unit

INJECTION



Key:

- 13. engine stop switch
- 14. Fuses No. 3- 7.5A; No. 6- 15A
- 15. High-beam light solenoid
- 16. Low beam light solenoid
- 19. Ignition switch contacts
- 20. Fuse No.2 - 7.5A
- 23. Starter remote control switch
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery

- 30. Injection load relay
- 33. Lambda probe
- 34. Engine speed sensor
- 35. HV coil
- 36. Fuel injector
- 37. Engine temperature sensor
- 38. Fuel system pump
- 39. Diagnostics socket
- 40. Injection electronic control unit
- 41. Immobilizer antenna
- 42. Bulb for engine control telltale light
- 48. Immobilizer LED warning light

Checks and inspections

Immobiliser

The electronic ignition system is managed by the control unit in which the immobiliser system is integrated. The immobiliser is an antitheft system which allows the vehicle to function only if it is activated by means of the coded keys that the control unit recognises. The code is integrated in a transponder in the key block. This allows the driver clear operation without having to do anything other than just turning the key. The Immobilizer system consists of the following components:

- Control unit
- Immobilizer aerial
- master and service keys with built-in transponder
- HV coil
- diagnosis LED

The diagnosis led also works as a blinking light to deter theft. This function is activated every time the ignition key is turned to "OFF" and it remains active 48 hours so as not to damage the battery charging process.



When the ignition key is turned to "ON", it interrupts the function of the immobiliser lamp and a start enable lamp comes "ON".

The duration of the flash depends on the programming of the electronic control unit


If the LED is off regardless of the position of the ignition key and/or the instrument panel is not initiated, check if:

- there is battery voltage
- that fuse 1 and fuse 6 are in good conditions.
- there is power to the control unit as specified below:

Remove the connector mounting bracket shown in the photograph and disconnect the connector from the control unit. Check the following conditions:


With the key switch set to OFF:

- there is battery voltage between terminals 6-26 and terminal 6-chassis ground (fixed power supply). If there is no voltage check that fuse 3 and its cable are in working order.




With the key switch set to ON:

- there is battery voltage between terminals 5-26 and terminal 5-chassis ground (fixed power supply). If there is no voltage, check the ignition key contacts, that fuse 2 and its cable are in working order.




After removing the leg shield back plate, remove the electrical connection from the aerial as shown in the picture.



Remove the protective base from the connector.



With the ignition switch at ON check there is battery voltage between the Red-White and Black cables




With MIU connector disconnected, check the continuity between the Orange-White cable and pin 7 of the interface wiring.

Specific tooling

020481Y Control unit interface wiring

020331Y Digital multimeter





THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

The electronic ignition system is controlled by the control unit with the integrated Immobilizer system. The immobiliser is an antitheft system which allows the vehicle to function only if it is activated by means of the coded keys that the control unit recognises. The code is integrated in a transponder in the key block. This allows the driver clear operation without having to do anything other than just turning the key. The Immobilizer system consists of the following components:

- Control unit
- Immobilizer aerial
- master and service keys with built-in transponder
- H.V. coil
- diagnosis LED

The diagnosis led also works as a blinking light to deter theft. This function is activated every time the ignition switch is turned to "OFF" and it remains active 48 hours so as not to damage the battery charging process.

When the ignition switch is turned to "ON", it interrupts the function of the immobiliser lamp and a start enable lamp comes "ON".

The duration of the flash depends on the programming of the electronic control unit.




If the LED is off regardless of the position of the ignition switch and/or the instrument panel is not initiated, check if:

- there is battery voltage
- fuse No. 1, fuse No. 2 and fuse No. 6 efficiency.
- there is power to the control unit as specified below:

Remove the connector mounting bracket shown in the photograph and disconnect the connector from the control unit. Check the following conditions:


With the key switch set to OFF:

- there is battery voltage between terminals 7-9 and terminal 9-chassis ground (fixed power supply). If there is no voltage, check that fuse 6 and its cable harness are in working order.




With the key switch in the ON position:

- there is battery voltage between terminals 6-7 and terminal 6-chassis ground (fixed power supply). If there is no voltage, check the ignition switch contacts, that fuse 2 and its cable are in working order.




After removing the leg shield back plate, remove the electrical connection from the aerial as shown in the picture.



Remove the protective base from the connector.



With the ignition switch at ON check there is battery voltage between the Red-White and Black cables





With MIU connector disconnected, check the continuity between the Orange-White cable and pin 14 of the control unit.

Specific tooling

020481Y Control unit interface wiring

020331Y Digital multimeter



Virgin circuit

When the ignition system is not encrypted, any key will start the engine but limited to 2000 rpm. The keys can only be recognised if the control unit has been programmed properly.

The data storage procedure for a previously un-programmed control unit provides for the recognition of the red key (master key) as the first key to be stored to memory: this becomes particularly important because it is the only key that enables the control unit to be wiped clean and reprogrammed for the memorisation of the service keys.

The master and service keys must be used to code the system as follows:

- Insert the Master key, turn it to «ON» and keep this position for two seconds (lower and upper limits 1 to 3 seconds).
- Insert the blue key and set to «ON» for 2 seconds.
- If you have copies of the key, repeat the operation with each key.
- Insert the MASTER key again and turn it to «ON» for 2 seconds.


The maximum time to change keys is 10 seconds. A maximum of 7 service keys (blue) can be programmed at one time.

It is essential to adhere to the times and the procedure. If you do not, start again from the beginning.

Once the system has been programmed, master key transponder, decoder and control unit are strictly matched.

With this link established, it is now possible to encode new service keys, in the event of losses, replacements, etc.

Each new programming deletes the previous one so, in order to add or eliminate keys, you must re-



peat the procedure using all the keys you intend to keep using.

If a service key becomes uncoded, the efficiency of the high voltage circuit shielding must be thoroughly inspected. In any case it is advisable to use resistive spark plugs.

Characteristic

Shielded cap resistance


~ 5000 Ω .

Diagnostic codes

The Immobilizer system is tested each time the ignition key is turned from «OFF» to «ON». During this diagnosis phase a number of control unit statuses can be identified and various light codes displayed. Regardless of the code transmitted, if at the end of the diagnosis the LED remains off permanently, the ignition is enabled. If, however, the LED remains on permanently, it means the ignition is inhibited:


1. Previously unused control unit - key inserted: a single 2 second flash is displayed, after which the LED remains off permanently. The keys can be stored to memory, the vehicle can be started but with a limitation imposed on the number of revs.

2. Previously unused control unit - transponder absent or cannot be used: the LED is on permanently. In this condition no operations are possible including the start up of the vehicle.




3. Programmed control unit - the service key in (normal condition of use): a single 0.7-second flash is displayed, after which the LED remains off steadily. The engine can be started.

3)



4. Programmed control unit - Master key in: a 0.7-sec flash is displayed followed by the LED remaining off for 2 sec and then by short 0.46-sec flashes, the same number of times as there are keys stored in the memory including the Master key. When the diagnosis has been completed, the LED remains permanently OFF. The engine can be started.

4)




5. Programmed control unit - fault detected: a light code is displayed according to the fault detected, after which the LED remains on steadily. The engine cannot be started. The codes that can be transmitted are:

- 1-flash code
- 2-flash code
- 3-flash code

Diagnostic code - 1 flash


A one-flash code indicates a system where the serial line is not present or is not detected. Check the Immobilizer antenna wiring and change it if necessary.



Diagnostic code - 2 flashes


A two-flash code shows a system where the control unit does not show the transponder signal. This might depend on the inefficiency of the immobilizer antenna or the transponder.

Turn the switch to ON using several keys: if the code is repeated even with the Master key, check the aerial wiring and change it if necessary. If this is not the case, replace the defective key and/or reprogram the control unit. Replace the control unit if the problem continues.



Diagnostic code - 3 flashes

A three-flash code indicates a system where the control unit does not recognise the key. Turn the switch to ON using several keys: if the error code is repeated even with the Master key, replace the control unit. If this is not the case, reprogram the decoder.



Battery recharge circuit

The charging circuit consists of three-phase alternator and a permanent magneto flywheel.

The alternator is directly connected to the voltage regulator.

This, in its turn, is connected directly to the ground and the battery's positive terminal passing through the 20A protective fuse.

The three-phase alternator provides good recharge power and at low revs a good compromise is achieved between generated power and idle stability.

Stator check

Checking the stator windings

WARNING

THIS CHECK-UP CAN BE MADE WITH THE STATOR PROPERLY INSTALLED.

- 1) Lift the saddle and remove the helmet compartment.
- 2) Disconnect the connector between stator and regulator with the three yellow cables as shown in the picture.

- 3) Measure the resistance between each of the yellow terminals and the other two.

Electric characteristic**Resistance:**

0.2 - 1 Ω

- 4) Check that there is insulation between the each yellow cable and the ground.
5) If values are incorrect, replace the stator.



Recharge system voltage check**Look for any leakage**

- 1) Access the battery by removing the specific cover.
- 2) Check that the battery does not show signs of losing fluid before checking the output voltage.
- 3) Turn the ignition key to position OFF, connect the terminals of the tester between the negative pole (-) of the battery and the black cable and only then disconnect the black cable from the negative pole (-) of the battery.
- 4) With the ignition key always at OFF, the reading indicated by the ammeter must be ≤ 0.5 mA.

Charging current check**WARNING**

BEFORE CARRYING OUT THE CHECK, MAKE SURE THAT THE BATTERY IS IN GOOD WORKING ORDER.

- 1) Place the vehicle on its centre stand
- 2) With the battery correctly connected to the circuit, place the multimeter leads between the battery terminals..
- 3) Start the engine, ensure that the lights are all out, increase the engine speed and at the same time measure the voltage.

Electric characteristic


Voltage ranging between 14.0 and 15.0V at 5000 rpm.

Maximum current output check.

- With engine off and panel set to "ON" turn on the lights and let the battery voltage set to 12V.
 - Connect ammeter pliers to the 2 recharge positive poles in output from the regulator.
 - Keep the lights on and start the engine, bring it to normal speed and read the values on the ammeter.
- With an efficient battery a value must be detected: > 20A

VOLTAGE REGULATOR/RECTIFIER

Specification	Desc./Quantity
Type	Non-adjustable three-phase transistor
Voltage	14 to 15V at 5000 rpm with lights off

Starter motor**KEY**

1. Battery
2. Starter remote control
3. Fuse No. 1
4. Fuse No. 6
5. Ignition key contacts
6. Fuse No. 2
7. Electronic control unit
8. Starter motor
9. Stop buttons
10. Fuse No. 3
11. Starter button


WARNING

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

- 1) Check fuses No. 1, 2, 3 and 6.
- 2) Check ignition key contacts.
- 3) Check the contacts of the stop buttons and the starter button.

- 4) With the ignition key set to «ON», the brake pulled and the starter button pressed, check if there is voltage between the Orange-White cable of the start-up remote control switch and the ground connection. If there is not, check the cable harnesses.
- 5) Check the start-up remote control switch.
- 6) Check that the Red cable between the battery and the start-up remote control switch is not interrupted. Also check continuity between the latter and the starter motor.
- 7) Check the starter motor ground connection.
- 8) Check that the Orange-Blue cable between the start-up remote control switch and the control unit (pin 24) is not interrupted.

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.




KEY

1. Battery
2. Starter relay
3. Fuse No. 1
4. Fuse No. 6
5. Ignition switch contacts
6. Fuse No. 2
7. Electronic control unit
8. Starter motor
9. Stop buttons

10. Fuse No. 3**11. Starter button****WARNING**

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

- 1) Check fuses No. 1, 2, 3 and 6.
- 2) Check ignition switch contacts.
- 3) Check the contacts of the stop buttons and the starter button.
- 4) With the ignition switch set to «ON», the brake pulled and the starter button pressed, check if there is voltage between the Orange-White cable of the start-up relay and the ground connection. If there is not, check the cable harnesses.
- 5) Check the starter relay.
- 6) Check that the Red cable between the battery and the starter relay is not interrupted. Also check continuity between the latter and the starter motor.
- 7) Check the starter motor ground connection.
- 8) Check that the Orange-Blue cable between the starter relay and the control unit (pin 10) is not interrupted.

Horn control**KEY**

1. Battery
2. Fuse No. 1


3. Ignition switch contacts
4. Fuse No. 3
5. Horn button
6. Horn

WARNING

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

- 1) Check fuses No. 1 and 3.
- 2) Check the ignition switch and horn button contacts.
- 3) With the ignition switch set to «ON» and the horn button pressed, check if there is voltage between the Grey-Black cable of the horn device and the ground connection. If there is not, check the cable harnesses.
- 4) Check the horn device ground connection.

Turn signals system check

**KEY**

1. Battery
2. Fuse No. 1
3. Ignition key contacts
4. Fuse No. 3
5. Turn indicator control device
6. Turn indicator switch
7. Turn indicator bulbs (12V - 10W)

8. Turn indicator warning light bulb**WARNING**

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.


- 1) Check that bulbs operate properly.
- 2) Check fuses No. 1 and 3.
- 3) Check ignition switch contacts.
- 4) With the ignition key set to «ON», check if there is voltage between the Blue-Black cable of the turn indicators switch and the ground connection. If there is not, check the cable harnesses and the connections of the turn indicator control device.
- 5) Check the turn indicator switch contacts.
- 6) With the turn indicator switch pressed to the right, check if there is voltage between the White-Blue cable of the switch and the ground connection. If there is not, check the cable harnesses.
- 7) With the turn indicator switch pressed to the left, check if there is voltage between the Pink cable of the switch and the ground connection. If there is not, check the cable harnesses.
- 8) Check that the cable harnesses of the bulbs and their ground connection are not interrupted.

level indicators**WARNING**

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

If faults are detected:

- 1) With a multimeter, check resistance values between the White-Green cable and the Black cable of the fuel level transmitter under different conditions.
- 2) If the transmitter operates correctly but the indication on the instrument panel is not exact, check that the cable harnesses between them are not interrupted.


**Electric characteristic****Resistance value when the tank is full**

$\leq 7 \Omega$

Resistance value when the tank is empty

$90 \pm 13/3 \Omega$

Lights list



KEY

1. Battery
2. Fuse No. 1
3. Fuse No. 4
4. ignition key contacts
5. Low beam light solenoid
6. Fuse No. 5
7. Electronic control unit
8. Daylight running lights, license plate lamp (12V - 5W) and dashboard lighting bulb (12V - 1.2W)
9. Low/high beam twin-filament bulb (12V - 55/60W)
10. Light switch
11. High-beam light solenoid
12. High beam warning light
13. Fuse No. 3

WARNING

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

LINE FOR DAYLIGHT RUNNING LIGHTS, LICENSE PLATE LIGHT AND DASHBOARD LIGHTING BULB

- 1) Check that bulbs operate properly.
- 2) Check fuses No. 1 and 5.
- 3) Check ignition key contacts.

4) Check if there is voltage between the Yellow-Black cable of fuse No. 5 and the ground. If not, check cable harnesses.

5) Check that the cable harnesses of the bulbs and their ground connection are not interrupted.

HIGH BEAM/LOW BEAM LIGHTS LINE

1) Check that bulbs operate properly.

2) Check fuses No. 1, 3 and 4.

3) Check ignition key contacts.

4) Check the voltage between the Grey cables (30) of the low and high beam light solenoids and the ground, if not check the cable harnesses.

5) With the ignition key set to «ON» and the engine running, check if there is voltage between the Violet cable (87) of the headlight solenoid and the ground connection. If there is not, check cable harnesses.

6) With the ignition key set to «ON» and the engine running, check if there is voltage between the Brown cable (87) of the high-beam light solenoid and the ground connection. If there is not, check cable harnesses.


7) Check the continuity of the White-Black cables that connect the low and high beam light solenoids to the control unit (pin 19).

8) Check low and high beam light solenoids.

9) Check the light switch contacts.

10) Check that the cable harnesses of the bulbs and their ground connection are not interrupted.

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



KEY

1. Battery
2. Fuse No. 1
3. Key switch contacts
4. Light switch
5. Low/high beam twin-filament bulb (12V - 55/60W)
6. High beam warning light
7. High-beam light solenoid
8. Low beam light solenoid
9. Fuse No. 4
10. Fuse No. 3
11. Fuse No. 5
12. Daylight running lights, license plate lamp (12V - 5W) and dashboard lighting bulb (12V - 1.2W)
13. Electronic control unit

WARNING

ALL CONTINUITY TESTS MUST BE CARRIED OUT WITH THE CORRESPONDING CONNECTORS DISCONNECTED.

LINE FOR DAYLIGHT RUNNING LIGHTS, LICENSE PLATE LIGHT AND DASHBOARD LIGHTING BULB

- 1) Check that bulbs operate properly.
- 2) Check fuses No. 1 and 5.
- 3) Check ignition switch contacts.
- 4) With the ignition switch set to «**ON**», check the presence of the voltage between the yellow/black cable of the fuse No. 5 and the ground. If there is not, check the cable harnesses.
- 5) Check that the cable harnesses of the bulbs and their ground connection are not interrupted.

HIGH BEAM/LOW BEAM LIGHTS LINE

- 1) Check that bulbs operate properly.
- 2) Check fuses No. 1, 3 and 4.
- 3) Check ignition switch contacts.
- 4) Check the presence of voltage between the grey (30) cables of the low and high beam light solenoids and the ground. If there is not, check the cable harnesses.
- 5) With the ignition switch set to «**ON**», with the engine on and light switch set to high beam, check the presence of voltage between the purple (87) cable of the high-beam light solenoid and the ground. If there is not, check the cable harnesses.
- 6) With the ignition switch set to «**ON**», with the engine on and light switch set to low beam, check the presence of voltage between the brown (87) cable of the low-beam light solenoid and the ground. If there is not, check the cable harnesses.
- 7) Check the continuity of the White-Black cables that connect the low and high beam light solenoids to the control unit (pin 33).

- 8) Check low and high beam light solenoids.
- 9) Check the light switch contacts.
- 10) Check that the cable harnesses of the bulbs and their ground connection are not interrupted.

Fuses

The electrical system is equipped with:

- 1. four protection fuses «A» that can be reached by removing the shield front cover.
- 2. two fuses «B», located in the battery compartment.

The chart shows the position and specifications of the fuses in the vehicle.

CAUTION




BEFORE REPLACING A BLOWN FUSE, FIND AND SOLVE THE FAILURE THAT CAUSED IT TO BLOW. NEVER TRY TO REPLACE THE FUSE WITH ANY OTHER MATERIAL (E.G., A PIECE OF ELECTRIC WIRE).

CAUTION



MODIFICATIONS OR REPAIRS TO THE ELECTRICAL SYSTEM, PERFORMED INCORRECTLY OR WITHOUT STRICT ATTENTION TO THE TECHNICAL SPECIFICATIONS OF THE SYSTEM CAN CAUSE MALFUNCTIONING AND RISK OF FIRE.




FUSES

	Specification	Desc./Quantity
1	Fuses No. 4 - Current rating: 7.5 A	Protected circuits: Battery-powered, lights remote control and antitheft-device pre-installation.
2	Fuses No. 3 - Current rating: 7.5 A	Protected circuits: Live accessories, instrument panel, horn, stop buttons and start-up remote control.
3	Fuses No. 5 - Current rating: 7.5A	Protected circuits: Live, daylight running lights and dashboard lighting.
4	Fuses No. 2 - Current rating: 7.5A	Protected circuits: Live, coil, injection load remote control, immobilizer aerial and MIU.
5	Fuses No. 1 - Current rating: 20A	Protected circuits: Vehicle main fuse.
6	Fuses No. 6 - Current rating: 15A	Protected circuits: Battery-powered injection loads, injection ECU and immobilizer LED.

Dashboard

- A = Fuel gauge
- B = High-beam warning light
- C = Turn indicator warning light
- D = Odometer
- E = Speedometer
- F = Low fuel warning light
- G = Low engine oil pressure warning light
- H = Engine control telltale light
- I = Immobilizer LED



Sealed battery

If the vehicle is provided with a sealed battery, the only maintenance required is the check of its charge and recharging, if necessary.

These operations should be carried out before delivering the vehicle, and on a six-month basis while the vehicle is stored in open circuit.

Besides upon pre-delivery it is therefore necessary to check the battery charge and recharge it, if required, before storing the vehicle and afterwards every six months.

INSTRUCTIONS FOR THE BATTERY REFRESH AFTER OPEN-CIRCUIT STORAGE

1) Voltage check

Before installing the battery on the vehicle, check the open circuit voltage with a standard tester.

- If voltage exceeds 12.60 V, the battery can be installed without any renewal recharge.
- If voltage is below 12.60 V, a renewal recharge is required as explained in 2).

2) Constant voltage battery charge mode

- Constant voltage charge equal to 14.40 to 14.70V
- Initial charge voltage equal to 0.3 to 0.5 for Nominal capacity
- Charge time:

10 to 12 h recommended

Minimum 6 h

Maximum 24 h

3) Constant current battery charge mode

- Charge current equal to 1/10 of the battery rated capacity
- Charge time: Maximum 5 h

Battery installation

VRLA battery (valve-regulated lead-acid battery) Maintenance Free (MF)

WARNING

BATTERY ELECTROLYTE IS TOXIC AND IT MAY CAUSE SERIOUS BURNS. IT CONTAINS SULPHURIC ACID. AVOID CONTACT WITH YOUR EYES, SKIN AND CLOTHING. IN CASE OF CONTACT WITH YOUR EYES OR SKIN, RINSE WITH ABUNDANT WATER FOR ABOUT 15 MINUTES AND SEEK IMMEDIATE MEDICAL ATTENTION.

IN THE EVENT OF ACCIDENTAL INGESTION OF THE LIQUID, IMMEDIATELY DRINK LARGE QUANTITIES OF WATER OR MILK. MAGNESIUM MILK, BATTERED EGG OR VEGETABLE OIL. SEEK IMMEDIATE MEDICAL ATTENTION.

BATTERIES PRODUCE EXPLOSIVE GASES; KEEP CLEAR OF NAKED FLAMES, SPARKS OR CIGARETTES; VENTILATE THE AREA WHEN RECHARGING INDOORS.

ALWAYS PROTECT YOUR EYES WHEN WORKING CLOSE TO BATTERIES.

KEEP OUT OF THE REACH OF CHILDREN

1) Battery preparation


Position the battery on a flat surface. Remove the adhesive sheet closing cells and proceed as quickly as possible to run the subsequent activation phases.



2) Electrolyte preparation.

Remove the container of the electrolyte from the pack. Remove and preserve cover strips from the container, in fact, the strip will later be used as a closing cover.

Note: Do not pierce the sealing of the container or the container itself because inside there is sulphuric acid.



3) Procedure for filling the battery with acid.

Position the electrolyte container upside down with the six areas sealed in line with the six battery filler holes. Push the container down with enough force to break the seals. The electrolyte should start to flow inside the battery.

Note: Do not tilt the container to prevent the flow of electrolyte from pausing or stopping.



4) Control the flow of electrolyte

Make sure air bubbles are rising from all six filling holes. Leave the container in this position for 20 minutes or more.

Note: If there are no air bubbles coming out of the filling holes, lightly tap the bottom of the container two or three times. Do not remove the container from the battery.

5) Take out the container.

Make sure all the electrolyte in the battery is drained. Gently tap the bottom of the container if electrolyte remains in the container. Now, gently pull the container out from the battery, only do this when the container is completely empty, and proceed immediately to the next point.

6) Battery closing.

Insert the airtight cover strips into the filling holes. Press horizontally with both hands and make sure that the strip is levelled with the top part of the battery.

Note: To do this, do not use sharp objects that could damage the closing strip, use gloves to protect your hands and do not bring your face close to the battery.

The filling process is now complete.

Do not remove the strip of caps under any circumstances, do not add water or electrolyte.

Place the battery down for 1 to 2 hours prior to the charging from the battery.

7) Recharging the new battery

With the above-mentioned procedure, the battery will have gained around 70% - 75% of its total electrical capacity. Before installing the battery on the vehicle, it must be fully charged and then must be recharged.

If the battery is to be installed on the vehicle prior to this pre-charged one, the battery will not be able to exceed 75% charge without jeopardising its useful life on vehicle.

The dry charge battery MF like the completely loaded YTX, must have a no-load voltage between 12.8 - 13.15 V. Bring the battery to full charge, using the 020648Y battery charger:

- a - select the type of battery with the red switch on the left of the panel battery charger panel
- b - select NEW on the yellow timer
- c - connect the clamps of the battery charger to the battery poles (black clamp to negative pole (-) and red clamp to positive pole (+)).



d - Press the red button, as shown in figure.



e - Press the "MF" black button to activate the battery recharge **Maintenance Free** as shown in figure.



f - Check the ignition of the green LED indicated with a red arrow in figure.



g - The activation cycle of the new battery lasts for 30 minutes after the ignition of the recharge LED has taken place




h - Disconnect the clamps from the battery and check the voltage, if voltages are detected of less than 12.8 V, proceed with a new recharge of the battery starting from point c of the recharge procedure of **the new battery**, otherwise go to point i



i - The battery is now completely activated, disconnect the battery charger from the fuel supply grid, disconnect the clamps from the battery and proceed to fitting the battery on the vehicle.

Sensore di temperatura



Key:



1. Engine temperature sensor

With the connector control unit side disconnected and the coolant temperature sensor connector connected, check the resistance between pins 9 and 26 in relation to the engine temperature.


20°C = 3502 ± 237 ohm

80°C = 357 ± 19 ohm

With the connector control unit side disconnected and the engine temperature sensor connector disconnected, check the insulation between the two Light Blue-Green and Grey-Green cables.



THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

**Key:**



1. Engine temperature sensor

With the connector on the control unit side disconnected and the engine temperature sensor connector connected, check that the resistance values between pin 13 and 7 and the ground lead correspond with the engine temperature.

20°C = 3502 ± 237 ohm

80°C = 357 ± 19 ohm

With the connector on the control unit side disconnected and the engine temperature connector disconnected, check the insulation between the light-blue/green and grey/green cables.






Connectors


DIAGNOSTICS CONNECTOR

1. Not connected
2. Ground lead (Black)
3. Electronic control unit (Violet - White)




PICKUP CONNECTOR

1. Control unit positive (Red)
2. Negative from control unit (Brown)
3. Not connected




FUEL PUMP CONNECTOR

1. Not connected
2. Ground lead (Black)
3. Not connected
4. Not connected
5. Power from relay (Black - Green)




ELECTRONIC CONTROL UNIT CONNECTOR

1. Injection telltale light (Brown-Black)
2. Not connected
3. Not connected
4. Lambda probe negative (White-Green)
5. Live supply (Red-White)
6. Battery-powered (Grey-Black)
7. Immobilizer aerial (Orange-White)
8. Not connected
9. Engine temperature sensor (Sky blue-Green)
10. Not connected
11. Lambda probe positive (Sky blue-Black)
12. Engine stop switch (Green-Black)
13. Engine speed sensor positive (Red)
14. Injector (Red-Yellow)
15. Engine speed sensor negative (Brown)
16. Diagnosis (Purple-White)
17. Immobilizer warning light (Red-Green)
18. To ground (Grey-Green)
19. Low beam lights automatic ignition (White-Black)
20. Injection load remote control (Black-Purple)
21. Lambda probe (Green - Yellow)
22. HV coil (Pink-Black)
23. Not connected
24. Starter enabling (Orange-Blue)
25. Not connected
26. Ground lead (Black)


**ENGINE TEMPERATURE SENSOR CONNECTOR**

1. Electronic control unit (Sky blue - Green)
2. Ground lead (Grey-Green)




INJECTOR CONNECTOR


1. Power from relay (Black - Green)
2. Electronic control unit (Red - Yellow)

**LAMBDA PROBE CONNECTOR**


1. Positive from control unit (Sky blue - Black)
2. Control unit negative (White - Green)
3. Electronic control unit (Green - Yellow)
4. Power from solenoid (Black - Green)

**VOLTAGE REGULATOR CONNECTOR**

1. Battery positive (Red-Black)
2. Ground lead (Black)

**INSTRUMENT PANEL CONNECTOR**


1. Indicator warning light (Pink)
2. Indicator warning light (White - Blue)
3. Live supply (White)
4. Low fuel warning light (Yellow-Green)
5. Oil pressure sensor (Pink-White)
6. High-beam warning light (Violet)
7. Ground lead (Black)
8. Lighting (Yellow - Black)
9. Immobilizer warning light (Red-Green)
10. Battery-powered (Grey-Black)
11. Fuel level indicator (White-Green)



12. Engine management warning light (Brown - Black)


H.V. COIL CONNECTOR

1. Power from relay (Black - Green)
2. Electronic control unit (Pink - Black)




ANTITHEFT DEVICE PRE-INSTALLATION CONNECTOR

1. Ground lead (Black)
2. Left indicator (White - Blue)
3. Right indicator (Pink)
4. Battery-powered (Grey)
5. Key powered (White)
6. Not connected
7. Not connected
8. Not connected




IMMOBILIZER ANTENNA CONNECTOR

1. Key powered (Red-White)
2. Ground lead (Black)
3. Electronic control unit (Orange-White)



FUEL LEVEL TRANSMITTER CONNECTOR


1. Fuel level indicator (White - Green)
2. Ground lead (Black)
3. Low fuel warning light (Yellow-Green)




THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

DIAGNOSTICS CONNECTOR


1. Not connected
2. Ground lead (Black)
3. Electronic control unit (Violet - White)

**PICK-UP CONNECTOR**


1. Control unit positive (Red)
2. Negative from control unit (Brown)
3. Oil pressure sensor (Pink-White)

**FUEL PUMP CONNECTOR**

1. Not connected
2. Ground lead (Black)
3. Not connected
4. Not connected
5. Power from relay (Black - Green)

**ELECTRONIC CONTROL UNIT CONNECTOR**


1. H.V. COIL (Pink-Black)
2. Not connected
3. Not connected
4. Ground (Green-Black)
5. Not connected
6. Key powered (Red-White)
7. Ground No. 1 (Black)
8. Not connected
9. Battery-powered (Grey-Black)
10. Start-up enabling switch (Orange-Blue)
11. Lambda probe positive (Sky blue-Black)
12. Lambda probe negative (White-Green)



- 13.** Water temperature sensor (Sky blue-Green)
- 14.** Immobilizer aerial (Orange-White)
- 15.** Not connected
- 16.** K serial line (Purple-White)
- 17.** Immobilizer (Red-Green)
- 18.** Not connected
- 19.** Side stand (Grey-Green)
- 20.** Engine speed sensor negative (Brown)
- 21.** Not connected
- 22.** Injection load relay (Black-Purple)
- 23.** Not connected
- 24.** Not connected
- 25.** Injection warning light (Brown-Black)
- 26.** Not connected
- 27.** Not connected
- 28.** Not connected
- 29.** Engine speed sensor positive (Red)
- 30.** Not connected
- 31.** Lambda probe heater (Green-Yellow)
- 32.** Not connected
- 33.** Low beam lights automatic ignition enabling (White-Black)
- 34.** Fuel injector (Red-Yellow)


ENGINE TEMPERATURE SENSOR CONNECTION

- 1.** Electronic control unit (Sky blue - Green)
- 2.** Ground lead (Grey-Green)




INJECTOR CONNECTOR


1. Power from relay (Black - Green)
2. Electronic control unit (Red - Yellow)

**LAMBDA PROBE CONNECTOR**


1. Positive from control unit (Sky blue - Black)
2. Control unit negative (White - Green)
3. Electronic control unit (Green - Yellow)
4. Power from solenoid (Black - Green)

**VOLTAGE REGULATOR CONNECTOR**

1. Battery positive (Red-Black)
2. Ground lead (Black)

**INSTRUMENT PANEL CONNECTOR**


1. Indicator warning light (Pink)
2. Indicator warning light (White - Blue)
3. Live supply (White)
4. Low fuel warning light (Yellow-Green)
5. Oil pressure sensor (Pink-White)
6. High-beam warning light (Violet)
7. Ground lead (Black)
8. Lighting (Yellow - Black)
9. Immobilizer warning light (Red-Green)
10. Battery-powered (Grey-Black)
11. Fuel level indicator (White-Green)



12. Engine management warning light (Brown - Black)


H.V. COIL CONNECTOR

1. Power from relay (Black - Green)
2. Electronic control unit (Pink - Black)




ANTITHEFT DEVICE PRE-INSTALLATION CONNECTOR

1. Ground lead (Black)
2. Left indicator (White - Blue)
3. Right indicator (Pink)
4. Battery-powered (Grey)
5. Key powered (White)
6. Not connected
7. Not connected
8. Not connected




IMMOBILIZER ANTENNA CONNECTOR

1. Key powered (Red-White)
2. Ground lead (Black)
3. Electronic control unit (Orange-White)



FUEL LEVEL TRANSMITTER CONNECTOR

1. Fuel level indicator (White - Green)
2. Ground lead (Black)
3. Low fuel warning light (Yellow-Green)



Diagnostic instrument

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

STARTER COMMAND

Function

Commands engine starting through the injection control unit.

Operation / Operating principle

The starter button, the brake switches, the starter command relay and the injection control unit are involved with Pin 10.

ELECTRICAL ERRORS

Starter command P0170 - shorted to positive.

Error cause

Short circuit to positive: excessive voltage at PIN 10 of the control unit connector.

Troubleshooting

Short circuit to positive:

- This malfunction is detected with a brake activated and the starter button pressed.
- If the battery voltage does not drop (thanks to the absorption of the starter command relay excitation coil) the control unit understands that PIN 10 is shorted to battery.
- Restore the cabling (if the short is in the cabling) or the relay (if the short is in the relay).

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

ENGINE TEMPERATURE SENSOR

Function


Serves the purpose of communicating the engine temperature to the control unit in order to optimise performance.

Operation / Operating principle

NTC type sensor (resistance sensor, inversely variable with temperature).

Pinout:

1. Injection ECU
2. Ground from control unit



Engine temperature sensor P0115 - open circuit or shorted to positive / shorted to negative.

Error cause

Open circuit or short circuit to positive: interruption of the circuit or excessive voltage at PIN 13 of the control unit connector. Short circuit to negative: null voltage between PIN 13 and 7 of the control unit connector.

Troubleshooting

Open circuit:

- Disconnect the connector of the control unit.
- Measure the resistance value of the sensor at different temperatures between PIN 13 and 7.
- Disconnect the sensor connector.
- Check the continuity of the cable harness between the sensor connector and control unit connector: Control unit PIN 13 - sensor PIN 1 and control unit PIN 7 - sensor PIN 2. If necessary, restore the cable harness.
- If the cabling is intact but the sensor resistance value is incorrect, this means that the sensor is faulty and must be replaced, otherwise proceed with the checks.

Short circuit to positive:

- With the sensor connector and the control unit disconnected, verify that the fault is shorted with the battery positive of sensor connector PIN 1 (or control unit PIN 13) and restore the cabling.

Short circuit to negative:

- Disconnect the sensor connector.
- Check the sensor connector PIN 1 ground insulation.
- If there is no ground insulation restore the cabling.
- If PIN 1 is insulated from the ground and the error persists, this means that there is a probable fault in the control unit.

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.


LAMBDA PROBE

Function

In charge of telling the control unit whether the mixture is lean or rich.

Operation / Operating principle

Based on the difference of oxygen in the exhaust fumes and the environment, this generates voltage which is read and interpreted by the injection control unit. It does not require an external supply source but, in order to work properly, it should reach a high operating temperature: that is why there is a heating circuit inside.



Pin-out:

1. Positive from control unit
2. Negative from control unit
3. Negative heater from control unit
4. Heater supply from relay

ELECTRICAL ERRORS

Check the air-fuel ratio / Lambda probe P0130 - Shorted to positive / open circuit, shorted to negative or carburetion excessively lean / signal not plausible for abnormal title correction or probe signal fault.

Error cause

Short circuit to positive: excessive voltage at PIN 11 or PIN 12 of the control unit connector.

Circuit open or short circuit to negative: interruption of the circuit or null voltage between control unit connector PIN 11 and 12.

Troubleshooting

Short circuit to positive:

- Disconnect the control unit connector and the sensor connector.
- Verify that there is no short circuit with the battery positive on the PIN 1 of the sensor connector (corresponding to the PIN 11 of the control unit connector); in the presence of short circuit, restore the cable harness.
- Verify that there is no short circuit with the battery positive on the PIN 2 of the sensor connector (corresponding to the PIN 12 of the control unit connector); in the presence of short circuit, restore the cable harness.

Open circuit:

- Disconnect the control unit connector and the sensor connector.
- Check the continuity of the cable harness between the sensor connector and control unit connector: PIN 11 of the control unit - PIN 1 of the sensor and PIN 12 of the control unit - PIN 2 of the sensor. If necessary, restore the cable harness.
- If the cable harness is intact and the error persists, proceed with the following checks.

Short circuit to negative:

- Disconnect the sensor connector and the control unit connector.
- Check the sensor connector PIN 1 ground insulation. If there is no insulation, restore the cable harness.
- Check the insulation from the ground of PIN 2 of the sensor connector. If there is no insulation, restore the cable harness.
- If PIN 1 and 2 are insulated from ground and the error persists, it means that there is a probable defect in the control unit.

P0135 Lambda probe heating - shorted to positive / shorted to negative / open circuit.

Error cause

Short circuit to positive: excessive voltage at PIN 31 of the control unit connector.

Short circuit to negative: lack of insulation from ground on the sensor connector PIN 4.

Open circuit: circuit interruption.

Troubleshooting

Short circuit to positive:

- Disconnect the control unit connector and the sensor connector.
- Verify that there is no short to battery positive on sensor connector PIN 3 (corresponding to control unit connector PIN 31); in the presence of short circuit, restore the cable harness.

Open circuit:

- Disconnect the control unit connector and the sensor connector.
- Check the continuity of the cable harness between the sensor connector and control unit connector: control unit PIN 31 - sensor PIN 3. If necessary, restore the cable harness.
- Verify continuity of the cabling between the sensor connector and the injection relay: sensor PIN 4 - injection relay PIN 87. If necessary, restore the cable harness.
- If the cable harness is intact and the error persists, proceed with the following checks.

Short circuit to negative:

- Disconnect the sensor connector.
- Check the sensor connector PIN 4 from ground insulation. If there is no insulation, restore the cable harness.
- If PIN 4 is insulated from ground and in the absence of other errors (fuel pump, injector, coil), this means that the control unit is most likely faulty.

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

INJECTOR

Function


Provide the correct amount of fuel at the correct time.

Operation / Operating principle

Injector coil is excited for the petrol passage to open.

Pinout:

1. Power from relay
2. Ground from control unit



ELECTRICAL ERRORS

Injector P0201 - short circuit to positive / short circuit to negative / open circuit.

Error cause

Short circuit to positive: excessive voltage to PIN 34 of the control unit connector.

Short circuit to negative: zero voltage to the PIN 1 of the injector connector.

Open circuit: circuit interruption.

Troubleshooting

Short circuit to positive:

- Disconnect the injector connector, turn ignition switch to ON and activate the component using the diagnostic tool.
- Verify the absence of voltage at the injector connector PIN 2; if present restore the cable harness, otherwise proceed with the following checks.

Short circuit to negative:

- Disconnect the injector connector, turn ignition switch to ON and activate the component using the diagnostic tool.
- Verify the presence of voltage at the ends of the injector connector; if there is no voltage, restore the cable harness, otherwise proceed with the following checks.

Open circuit:

- Perform the check of the injector and control unit connectors.
- Verify continuity of the cable harness between the control unit connector and the injector connector (control unit PIN 34 - injector PIN 2). If there is no continuity, restore the cable harness.

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

FUEL PUMP

ELECTRICAL ERRORS

Fuel pump relay P0230 - shorted to positive / shorted to negative / open circuit.

Error cause

Short circuit to positive: excessive voltage at PIN 22 of the control unit connector.

Short circuit to negative: null voltage at PIN 86 of the injection relay.

Open circuit: circuit interruption.

Troubleshooting

Short circuit to positive:

- Disconnect the injection relay, turn the key to ON and activate the relay through the diagnostics instrument.
- Verify the presence of voltage between relay connector PIN 86 and 85 toward the cabling.
- If no voltage is read, disconnect the control unit and verify insulation from battery positive of the relay PIN 85 (or control unit PIN 22). If necessary, restore the cable harness.

Short circuit to negative:

- Disconnect the injection relay and the control unit.
- Verify ground insulation of the relay connector PIN 86 and 85 toward the cabling: if there is no insulation, restore the cabling.

Open circuit:

- Disconnect the injection relay and the control unit.
- Verify continuity of the cabling between the relay and control unit: Relay PIN 85 - control unit PIN 22. If necessary, restore the cable harness.


THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.

COIL**Function**

Allows generation of the electrical discharge on the spark plug, with an increase of voltage.

Pin-out:

1. Power from relay
2. Activation by control unit (control unit side PIN 1)

**ELECTRICAL ERRORS**

H.V. Coil P0351 - shorted to positive / open circuit or shorted to negative.

Error cause

Short circuit to positive: excessive voltage at PIN 1 of the control unit connector.

Circuit open or short circuit to negative: interruption of the circuit or null voltage at PIN 1 of the control unit connector.

Troubleshooting

Short circuit to positive:

- Disconnect the coil connector, turn the key to ON and activate the component through the diagnostics instrument.
- Verify the presence of voltage on the coil connector PIN 2: if present, restore the cabling, otherwise replace the coil.

Open circuit:

- Carry out the check procedure of the coil and control unit connectors.
- Verify continuity of the cabling between the coil and control unit: Coil PIN 2 - control unit PIN 1. If there is no continuity, restore the cable harness.
- Verify, with the key turned ON, the presence of voltage on the coil connector PIN 1. If no voltage is detected, check that the cable harness between the coil and injection relay is not interrupted: Coil PIN 1 - relay PIN 87.
- If the above tests provided a positive result, the coil should be replaced.

Short circuit to negative:

- Disconnect the control unit connector and the coil connector.
 - Verify the coil connector PIN 2 ground insulation (or control unit connector PIN 1). If necessary, restore the cable harness.
-

INDEX OF TOPICS

ENGINE FROM VEHICLE

ENG VE

Exhaust assy. Removal


- Remove the 2 fixing nuts from the manifold to the head



- Remove the Lambda probe from its support and disconnect it.
- Release the lambda probe cable from the brackets on the fan cover.



- Loosen the 2 exhaust fixing screws to the crank-case, then remove the whole exhaust.



- Remove the lambda probe from the manifold.



CAUTION: SHOULD IT BE NECESSARY TO REMOVE ONLY THE SILENCER TIP, ALWAYS REPLACE THE GRAPHITE GASKET BETWEEN STUB AND TIP.

Removal of the engine from the vehicle

CAUTION




SUPPORT THE VEHICLE ADEQUATELY.

- Disconnect the battery.
 - Remove the side fairings and footrest left and right terminals.
 - Remove the helmet compartment.
 - Remove the full silencer unit.
 - Remove the 3 screws of the rear brake transmission retainer brackets indicated in the picture.
 - Disconnect the rear brake transmission by unscrewing the adjuster screw.
-
- Disconnect the belt cooling pipe and the swinging arm retaining spring shown in the picture.
 - Disconnect the ground lead (1) from the engine.
 - Disconnect the spark plug tube.




-
- Loosen the clamp indicated in the picture and disconnect the sleeve connecting the air filter to the throttle body.




- Disconnect the two connectors of the magneto flywheel cable harness and slide them from the bottom.



- Remove the ground lead and the positive cable from the starter motor shown in the figure.
- Open the clamp indicated and remove the throttle body cables.




- Undo the three screws, with anti-tampering device, that fasten the intake manifold on the head.
- Detach from the head the manifold with throttle body and commands and collect the gasket.



- Unscrew the engine pin-swinging arm nut on the right-hand side of the vehicle and slide off the pin on the left hand side
- Support the vehicle adequately (with a jack) and remove the shock absorber lower clamping. The engine is now free.





INDEX OF TOPICS

ENGINE

ENG

This section describes the operations to be carried out on the engine and the tools to be used.

Automatic transmission

Transmission cover

- To remove the transmission cover it is necessary to remove the rear plastic cover first by inserting a screwdriver in the corresponding slotted holes. Using the clutch bell lock wrench, remove the driven pulley axle locking nut and recover the washer.
- Remove the cap/dipstick from the engine oil filling hole.
- Remove the ten screws.
- Remove the transmission cover. If this operation is performed directly on the vehicle, it is necessary to remove the cooling air sleeve and the three air filter housing retainers.





Specific tooling

020423Y Driven pulley lock wrench

Air duct

- Unscrew the Torx screws fixing the air duct bulkhead and remove the bulkhead.
- Remove the 3 screws, then take out the duct as well as the filter.





Removing the driven pulley shaft bearing

- Remove the clip from the inside of the cover.
- Use the specific tools to remove the bearing from the crankcase.


CAUTION

USE AN APPROPRIATE REST SURFACE TO AVOID DAMAGING THE COVER PAINT.

Specific tooling

020376Y Adaptor handle

020375Y 28 x 30 mm adaptor



Refitting the driven pulley shaft bearing

- Heat up the crankcase inside with the hot air gun.
- Insert the bearing in its housing, refit the Seeger ring.


N.B.

ALWAYS REPLACE THE BEARING WITH A NEW ONE UPON REFITTING.

Specific tooling

020151Y Air heater

020376Y Adaptor handle



020357Y 32 x 35-mm Adaptor


020412Y 15-mm guide

Removing the driven pulley

- Remove the spacer, the clutch housing and the whole driven pulley unit.

N.B.

THE UNIT CAN ALSO BE REMOVED WITH THE DRIVING PULLEY MOUNTED.



Inspecting the clutch drum

- Check that the clutch bell is not worn or damaged.
- Measure the clutch bell inside diameter.


Characteristic

Max. value clutch housing

Max. value: Ø 134.5 mm

clutch housing standard value

Standard value: Ø 134 - 134.2 mm



Checking the bell working surface eccentricity

- Install the bell on a driven pulley shaft using 2 bearings (inside diameter: 15 and 17 mm).
- Lock with the original spacer and nut.
- Place the bell/shaft unit on the support to check the crankshaft alignment.



- Using a feeler dial gauge and the magnetic base, measure the bell eccentricity.
- Repeat the measurement in 3 positions (Central, internal, external).
- If faults are found, replace the bell.

Specific tooling

020074Y Support base for checking crankshaft alignment

020335Y Magnetic mounting for dial gauge

Characteristic

clutch housing inspection: Limit eccentricity.

Admissible limit eccentricity: 0.15 mm




Removing the clutch

- Prepare the locking tool for the driven pulley with the pins half-screwed in the tool set to «C».
- Introduce the adapter ring 11 with the chamfering facing the inside of the tool.



- Fit the driven pulley unit in the tool so as the bolt get into the masses clutch support holes. Afterwards make the support screw make contact with a minimum force.
- Using the specific wrench, inserted 46 mm from the side, remove the clutch central locking nut.



- Separate the driven pulley into its components (clutch with fan and contrast spring with plastic fittings).

CAUTION

THE TOOL MUST BE FIRMLY FIXED IN THE VICE AND THE CENTRAL SCREW MUST NOT BE TIGHTENED WITH EXCESSIVE TORQUE AS THIS MAY DAMAGE THE PULLEY OR DEFORM THE SPECIFIC TOOL.

Specific tooling

020444Y Tool for fitting/ removing the driven pulley clutch

020444Y011 adapter ring

020444Y009 wrench 46 x 55

Inspecting the clutch

- Check the thickness of the clutch mass friction material.
- The masses must not show traces of lubricants; otherwise, check the driven pulley unit seals.

N.B.

UPON RUNNING-IN, THE MASSES MUST EXHIBIT A CENTRAL FAYING SURFACE AND MUST NOT BE DIFFERENT FROM ONE ANOTHER.
VARIOUS CONDITIONS CAN CAUSE THE CLUTCH TO TEAR.

CAUTION

DO NOT OPEN THE MASSES USING TOOLS TO PREVENT A VARIATION IN THE RETURN SPRING LOAD.

Characteristic

Check minimum thickness

1 mm



Pin retaining collar

- Simultaneously turn and pull the collar manually to remove it.

N.B.

USE TWO SCREWDRIVERS IF YOU HAVE ANY DIFFICULTY.

N.B.

BE CAREFUL NOT TO PUSH THE SCREWDRIVERS IN TOO FAR TO AVOID DAMAGE THAT COULD COMPROMISE THE O-RING SEAL.



Removing the driven half-pulley bearing

- Remove the retainer ring using two flat blade screwdrivers.
- Using a hammer and pin, knock the ball bearing out as shown in the figure.
- Remove the roller bearing using the specific extractor.

N.B.



REST THE HALF-PULLEY ON A WOOD SURFACE TO AVOID DAMAGING THE THREADED RINGLET OF THE DRIVEN PULLEY UPON REMOVING IT.

Specific tooling

020375Y 28 x 30 mm adaptor

020376Y Adaptor handle

020439Y 17-mm guide



Inspecting the driven fixed half-pulley

- Measure the outside diameter of the pulley bushing.

Characteristic

Minimum diameter permitted

Ø 40.96 mm

Standard diameter

Ø 40.965 mm



Inspecting the driven sliding half-pulley

- Remove the 2 inner sealing rings and the two O-rings.
- Measure the inside diameter of the mobile half-pulley bushing.

Characteristic

Minimum admissible diameter:

Ø 41.08 mm

Standard diameter

Ø 41.035 mm



Refitting the driven half-pulley bearing

- Assemble a new roller bearing using the specific punch, fit the bearing with the label facing outward and insert it completely up to the punch on the half-pulley.

N.B.

REST THE HALF-PULLEY ON A WOOD SURFACE TO AVOID DAMAGING THE THREADED RINGLET OF THE DRIVEN PULLEY UPON REMOVING IT.

Specific tooling

020424Y Driven pulley roller casing fitting punch



- To assemble the new ball bearing insert it completely down in its housing with the specific punch and finally assemble the Seeger ring.

Specific tooling

020375Y 28 x 30 mm adaptor


020376Y Adaptor handle

020439Y 17-mm guide



Refitting the driven pulley

- Check that the faying surfaces between the 2 half-pulleys and the belt do not show any signs of wear, scoring and grease.
- Insert the new oil seals and O-rings on the movable half-pulley.
- Assemble the half-pulley on the ringlet with the appropriate protection sheath.
- Make sure the pins and collar are not worn, re-assemble the pins and collar.
- Use a greaser with a curved spout to lubricate the driven pulley unit with around 6 g of grease. This operation must be done through one of the holes inside the bushing until grease comes out of the opposite hole. This operation is necessary to avoid the presence of grease beyond the O-rings.



Specific tooling

020263Y Driven pulley assembly sheath**Recommended products**

AGIP GREASE SM 2 Gray black smooth-textured lithium grease, containing molybdenum disulphide.

-

Inspecting the clutch spring


- Measure the length of the spring when it is relaxed.

Characteristic**Standard length:**

106 mm

Acceptable limit after use

102.5 mm (4.035 in)



Refitting the clutch

- Check the thickness of the clutch mass friction material.
- The masses must not show traces of lubricants; otherwise, check the driven pulley unit.

N.B.


UPON RUNNING-IN, THE MASSES MUST EXHIBIT A CENTRAL CONTACT SURFACE AND MUST NOT BE DIFFERENT FROM ONE ANOTHER. VARIOUS CONDITIONS CAN CAUSE THE CLUTCH TO TEAR.

CAUTION

DO NOT OPEN THE MASSES USING TOOLS SO AS TO PREVENT A VARIATION IN THE RETURN SPRING LOAD.

Characteristic**Minimum thickness permitted:**

1 mm




- Support the driven pulley spring compressor specific tool with the control screw in vertical axis.
- Arrange the tool with the medium length pins screwed in position "C" on the inside.
- Introduce the adapter ring No. 11 with the chamfering facing upwards.
- Insert the clutch on the adapter ring.
- Lubricate the end of the spring that abuts against the torque server closing collar.
- Insert the spring with its plastic holder in contact with the clutch.
- Insert the drive belt into the pulley unit according to their direction of rotation.
- Insert the pulley unit with the belt into the tool.
- Slightly preload the spring.
- Make sure that the clutch is perfectly inserted into the adapter ring before proceeding to tighten the clutch nut.
- Place the tool in the clamp with the control screw on the horizontal axis.
- Fully preload the spring.
- Apply the clutch fixing nut and tighten it to the prescribed torque using the special 46x55 wrench.
- Loosen the tool clamp and insert the belt according to its direction of rotation.
- Lock the driven pulley again using the specific tool.
- Preload the clutch return spring with a traction/rotation combined action and place the belt in the smaller diameter rolling position.
- Remove the driven pulley /belt unit from the tool.

N.B.

DURING THE SPRING PRELOADING PHASE, BE CAREFUL NOT TO DAMAGE THE PLASTIC SPRING STOP AND THE BUSHING THREADING.

N.B.

FOR DESIGN REASONS, THE NUT IS SLIGHTLY ASYMMETRIC; THE FLATTEST SURFACE SHOULD BE MOUNTED IN CONTACT WITH THE CLUTCH.

Specific tooling

020444Y Tool for fitting/ removing the driven pulley clutch

020444Y011 adapter ring


020444Y009 wrench 46 x 55

Locking torques (N*m)

Nut locking clutch unit on pulley 55 - 60 Nm

Refitting the driven pulley

- Reassemble the clutch housing and spacer.



Drive-belt


- Make sure the drive belt is not damaged and does not show abnormal wear.
- Replace as indicated in the scheduled maintenance table.

Removing the driving pulley


- Lock the driving pulley with the specific tool as shown in the figure.
- Disassemble the central nut and the cup washer, remove the drive and the 2 washers.
- Remove the stationary half pulley and the steel washer.

Specific tooling

020368Y driving pulley lock wrench



- Remove the belt and slide the movable half-pulley with the relevant bush, taking care of the falling free assembled rollers.
- Remove the return rollers plate with the relative guide sliders.



Inspecting the rollers case

- Check that the internal bushing is not abnormally worn and measure inner diameter.

N.B.

DO NOT LUBRICATE OR CLEAN THE BUSHING.

BUSHING ROLLER HOUSING


Specification	Desc./Quantity
Maximum allowable diameter	Ø 26.121 mm
Standard diameter	Ø 26+0 +0.021 mm

BUSH SLIDE PULLEY

Specification	Desc./Quantity
Minimum diameter permitted	Ø 25.950 mm
Standard diameter	Ø 26-0.020 -0.041 mm

CVT ROLLERS

Specification	Desc./Quantity
Minimum diameter permitted	Ø 18.5 mm
Standard diameter	Ø 26±0.1 mm




- Check the guide shoes for the variator back-plate are not worn.
- Check there is no wear in the roller housing, and the surfaces in contact with the belt on either of the pulley halves.



Refitting the driving pulley

- Reassemble the parts of the unit (internal lining, fixed half-pulley, external lining, drive, belleville washer and nut), spread recommended product on the thread and tighten the nut to the prescribed torque.
- Avoid half-pulley rotation using a calliper spanner.



N.B.

REPLACE THE NUT WITH A NEW ONE AT EVERY REFIT

Specific tooling

020368Y driving pulley lock wrench

Recommended products

Loctite 243 Medium-strength threadlock

Medium Loctite 243 threadlock

Locking torques (N*m)

Locking torque 75 to 83

Refitting the transmission cover

- Check that there are 2 alignment dowels and that the sealing gasket for the oil sump on the transmission cover is adequately fitted.
- Replace the cover and tighten the 10 screws to the specified torque.
- Refit the oil loading cap/bar.
- Refit the steel washer and the driven pulley nut.
- Tighten the nut to the prescribed torque using the lock wrench and the torque wrench tools.



- Refit the plastic cover.

Specific tooling

020423Y Driven pulley lock wrench


Locking torques (N*m)

Transmission cover screws 11 - 13 Driven pulley
shaft nut 54 - 60

End gear


Removing the hub cover

- Empty the rear hub through the oil drainage tap located inside the hub cover
- Remove the brake shoe and relevant spring
- Remove the 7 flanged screws as shown in the figure.
- Remove the rubber cover and the brake shoes lever sliding unscrewing the relevant retaining screw to reach the rear of the cover
- Take off the hub cover and relevant gaskets




Removing the wheel axle

Remove the intermediate gear and the complete hub cover.



Removing the hub bearings

- Check the state of the bearings being examined (wear, clearance and noisiness). If faults are detected, do the following.
- Use the specific bearing extractor to remove the three 15 mm bearings (2 in the crankcase and 1 in the hub cover).




Specific tooling

001467Y009 Bell for OD 42-mm bearings

001467Y013 Calliper to extract $\varnothing$ 15-mm bearings

Removing the wheel axle bearings

- Take out the clip on the outside of the hub cover.
- Remove the bearing with the adequate tools adequately supporting the hub cover, as shown in the figure.




Specific tooling

020376Y Adaptor handle

020364Y 25-mm guide

With the appropriate tools, remove the oil seal as shown in the figure.



Specific tooling

020376Y Adaptor handle

020359Y 42 x 47-mm Adaptor

Removing the driven pulley shaft bearing

If it is necessary to remove the driven pulley shaft, from the relevant bearing and oil seal, remove driven pulley.

- Extract the driven pulley shaft from its bearing.
- Remove the oil seal using a screwdriver, working from inside the bearing and being careful not to damage the housing, make it come out of the belt transmission side.
- Remove the Seeger ring shown in the figure


With the sectional punch, remove the driven pulley shaft bearing.

Specific tooling

020376Y Adaptor handle

020375Y 28 x 30 mm adaptor

020363Y 20-mm guide

**See also**

[Removing the driven pulley](#)

Inspecting the hub shaft

- Check the three shafts for wear or distortion of the toothed surfaces, the bearing housings, and the oil seal housings.
- If faults are found, replace the damaged components.



Inspecting the hub cover

- Check that the fitting surface is not dented or distorted.
- Check the load capacity of the bearings and the brake camshaft.
- If faults are found, replace the hub cover.

Refitting the driven pulley shaft bearing

- Heat up the parts using the specific heat gun.

Specific tooling

020150Y Air heater mounting


020151Y Air heater

- Reassemble the driven pulley axle bearing positioning it with ball bearing in view from the inside of the hub cover using the adequate tools

Specific tooling

020376Y Adaptor handle

- Refit the Seeger ring with the opening facing the bearing as shown in the figure and fit a new oil seal flush with the crankcase.



Refitting the wheel axle bearing

- Heat up the parts using the specific heat gun

Specific tooling

020151Y Air heater

020150Y Air heater mounting

- The wheel axle bearing on the cover, should be assembled with the specific tools


Specific tooling

020364Y 25-mm guide

020360Y 52 x 55-mm Adaptor

020376Y Adaptor handle

- Assemble the Seeger ring.
- Assemble the oil seal flush with the internal surface as shown in the figure to the hub using the adequate tools and with the seal lip towards the inside of the hub.



Specific tooling

020376Y Adaptor handle

020360Y 52 x 55-mm Adaptor

Refitting the hub cover bearings


- For the fitting of the hub box bearings the engine crankcase and the cover must be heated with the specific heat gun.

Specific tooling

020150Y Air heater mounting


020151Y Air heater

- The three 15 mm bearings must be fitted using the appropriate tools.



Refitting the hub bearings

- Insert the cover prepared in the crankcase taking care of inserting the gear of the pulley shaft on the intermediary gear.




Refitting the ub cover

- Fit a new gasket together with the alignment dowels.
- Fit the gearbox cover, making sure the breather pipe is in the correct position.
- Tighten the 7 screws to the prescribed torque.

Locking torques (N*m)

Locking torque 24 to 27



Flywheel cover


Cooling hood

- Remove the fan cover cap acting on the 4 fixing screws.



CAUTION

DURING REMOVAL SLIDE THE CABLE GROMMET FROM THE HOUSING ON THE CAP.

- Slide the access flap to the spark plug.




- Remove the two self threading screws, left and right and the lateral left fixing screw on the crank-case base.
- Take off the two caps from the thermal group.
- Remove the gasket seal of the housing on the head.




Cooling fan

- Remove the fan cover cap.
- Remove the cooling fan by acting on the three fixings indicated in the figure.



Removing the stator

- Remove the magneto flywheel.
- Remove the electric terminal of the minimum oil pressure switch.
- Remove the two Pick-Up screws and the one for the wiring harness bracket as well as the two stator fixing screws shown in the figure.
- Remove the stator and its wiring.



Refitting the stator



- Refit the stator and flywheel carrying out the removal procedure in reverse, tightening the retainers to the specified torque.
- Place the cable harness as shown in the figure.

N.B.

THE PICK-UP WIRE SHOULD BE POSITIONED BETWEEN THE UPPER SCREW AND THE REFERENCE DOWEL AS SHOWN IN THE DETAIL DRAWING.

Locking torques (N*m)


Stator screw 3 - 4



Flywheel and starting

Removing the starter motor

- Remove the two screws indicated in the figure.
- Take the starter motor out of its seat.



Removing the flywheel magneto


- Lock the rotation of the flywheel using the calliper spanner.
- Remove the nut.

CAUTION

THE USE OF A CALLIPER SPANNER OTHER THAN THE ONE SUPPLIED COULD DAMAGE THE STATOR COILS

Specific tooling


020565Y Flywheel lock calliper spanner



- Extract the flywheel with the extractor.

Specific tooling

008564Y Flywheel extractor



Inspecting the flywheel components

- Check the integrity of the internal plastic parts of the flywheel and the Pickup control plate.
-

Refitting the flywheel magneto

- Fit the flywheel being careful to insert the key properly.
- Lock the flywheel nut to the prescribed torque
- Check that the Pick-Up air gap is between 0.34 to 0.76 mm.

The air gap cannot be modified when assembling the Pick-Up.


Different values result from deformations visible on the Pick-Up mounting.

N.B.

A VARIATION IN THE AIR GAP DISTANCE MODIFIES THE IGNITION SYSTEM IDLE SPEED

Locking torques (N*m)

Flywheel nut 52 - 58



Refitting the starter motor


- Fit a new O-ring on the starter and lubricate it.
- Fit the starter motor on the crankcase and lock the 2 screws to the prescribed torque.

N.B.

REFIT THE REMAINING PARTS AS DESCRIBED IN THE CYLINDER HEAD, TIMING, LUBRICATION, FLYWHEEL AND TRANSMISSION CHAPTERS.

Locking torques (N*m)

Starter motor screws 11 - 13



Cylinder assy. and timing system

Removing the timing system drive

- Remove the parts listed below first: transmission cover, belt driving pulley, oil pump pulley cover and pinion separator washer.
- Remove the tappet cover.
- Remove the central screw fastener and the automatic valve lifter retaining cover, as shown in the figure.
- Remove the return spring of the automatic valve lifter unit and the automatic valve lifter unit and its end of stroke washer.
- Loosen the central screw on the tensioner first.
- Remove the two fixings shown in the figure.
- Remove the tensioner with its gasket.
- Remove the internal hex screw and the counterweight shown in the figure.
- Remove the camshaft control pulley with its washer.
- Remove the control sprocket wheel and the timing chain.
- Remove the screws indicated in the figure, the spacer bar and the tensioner slider.

The tensioner pad must be removed from the transmission side. As regards the lower chain guide slider, it may only be removed after the head has been removed.


N.B.

IT IS ADVISABLE TO MARK THE CHAIN IN ORDER TO ENSURE THAT THE INITIAL DIRECTION OF ROTATION IS MAINTAINED.

See also


[Removing the driving pulley](#)

Transmission cover
[Removal](#)




Removing the cam shaft

- Remove the 2 screws and the camshaft retainer shown in the diagram.




- Remove the cam shaft.



- Remove the pin of the rocking levers from the flywheel side holes.
- Remove the rocking levers and the elastic washer.

N.B.

MARK THE ROCKERS ASSEMBLE POSITION, SO AS TO AVOID THE INVERSION OF INTAKE WITH THE EXHAUST.




Removing the cylinder head

- Remove the spark plug.
- Remove the 2 side fixings shown in the figure.
- Loosen the 4 head-cylinder fastening nuts in two or three stages and in criss-cross fashion.
- Remove the head, the two alignment dowels and the gasket.

N.B.

IF NEEDED, THE HEAD MAY BE REMOVED WITH THE CAMSHAFT, ROCKER PINS AND FIXING BRACKET. THE HEAD CAN ALSO BE REMOVED WITHOUT REMOVING THE CHAIN AND THE CRANKSHAFT CHAIN TENSIONER.




Removing the valves

- Using the specific tool fitted with the element shown in the figure, remove the cotters, the caps and the spring between the valves.

Specific tooling

020382Y Valve cotters equipped with part 012 removal tool


020382Y011 adapter for valve removal tool



- Remove the oil seals with the appropriate tool.
- Remove the lower spring supports.

Specific tooling

020431Y Valve oil seal extractor




Removing the cylinder - piston assy.

- Remove the chain guide slider.
- Remove the cylinder base gasket.

CAUTION


TO AVOID DAMAGING THE PISTON, SUPPORT IT WHILE REMOVING THE CYLINDER.



- Remove the two retainer rings, the wrist pin and the piston.
- Remove the 3 piston rings from the piston.

N.B.

BE CAREFUL NOT TO DAMAGE THE PISTON RINGS DURING REMOVAL.



Inspecting the small end

- Measure the internal diameter of the connecting rod small end using an internal micrometer.

N.B.

IF THE DIAMETER OF THE CONNECTING ROD SMALL END EXCEEDS THE MAXIMUM DIAMETER ADMISSIBLE, SHOWS SIGNS OF WEAR OR OVERHEATING REPLACE THE CRANKSHAFT AS DESCRIBED IN THE "CRANKCASE AND CRANKSHAFT" CHAPTER".


Characteristic

Connecting rod small end check-up: Maximum diameter

15.030 mm

Connecting rod small end check-up: Standard diameter

15+0.015+0.025 mm



Inspecting the wrist pin

- Check the outer diameter of the gudgeon pin.


Characteristic

Standard pin diameter

14.996 - 15 mm

Minimum diameter permitted

Ø 14.994 mm



- Calculate the piston pin coupling clearance.

N.B.

THE PIN HOUSINGS HAVE 2 LUBRICATION CHANNELS. FOR THIS REASON MEASUREMENT OF THE DIAMETER MUST BE CARRIED OUT ACCORDING TO THE AXIS OF THE PISTON.

Characteristic

Piston pin bore - standard diameter


Ø 15+0.001 +0.006




- Measure the outside diameter of the piston, perpendicular to the gudgeon pin axis.
- Measure 36.5 mm from the piston crown's shown in the figure.

N.B.

THE PIN HOUSINGS HAVE 2 LUBRICATION CHANNELS. FOR THIS REASON MEASUREMENT OF THE DIAMETER MUST BE CARRIED OUT ACCORDING TO THE AXIS OF THE PISTON.




- Using a bore meter, measure the inner cylinder diameter at three different points according to the directions shown in the figure.
- Check that the coupling surface with the head is not worn or misshapen.
- Pistons and cylinders are classified into categories based on their diameter. The coupling is carried out in pairs (A-A, B-B, C-C, D-D).

**Characteristic****Maximum allowable run-out:**

0.001 over 0.05 mm

- The cylinder rectifying operation should be carried out with a surfacing that respects the original angle.
- The cylinder surface roughness should be 0.9 micron.
- This is indispensable for a good seating of the sealing rings, which in turn minimises oil consumption and guarantees optimum performance.
- The pistons are oversized due to cylinder rectification and are subdivided into three categories 1st, 2nd, 3rd with 0.2-0.4-0.6 mm oversize. They are also classified into 4 categories A-A, B-B, C-C, D-D.

**Inspecting the piston**


- Carefully clean the seal housings.
- Measure the coupling clearance between the sealing rings and the piston grooves using suitable sensors, as shown in the diagram.
- If the clearance is greater than that indicated in the table, replace the piston.

STANDARD COUPLING CLEARANCE


Name	Description	Dimensions	Initials	Quantity
Top piston ring		0.025 - 0.070		
Middle piston ring		0.015 - 0.060		
oil scraper		0.015 - 0.060		

MAXIMUM ADMITTED CLEARANCE AFTER USE

Name	Description	Dimensions	Initials	Quantity
Top piston ring		0.080 mm		
Middle piston ring		0.070 mm		
oil scraper		0.070 mm		

**Removing the piston**

- Install piston and wrist pin onto the connecting rod, aligning the piston arrow the arrow facing towards the exhaust.
- Fit the pin retainer ring onto the appropriate tool.

Specific tooling**020430Y Pin lock fitting tool**


- With the opening in position indicated on the tool, take retainer ring in the closed position using the punch.
- Fit the pin retainer ring using the plug as shown in the figure

N.B.

THE TOOL FOR INSTALLING THE RETAINER RINGS MUST BE USED MANUALLY.

CAUTION

USING A HAMMER TO POSITION THE RINGS CAN DAMAGE THE LOCKING HOUSING.




Refitting the piston rings

- Place the oil scraper spring on the piston.
- Refit the oil scraper ring with the join of spring ends on the opposite side from the ring gap and the word 'TOP' towards the piston crown. The tapered side of the middle piston ring should always be facing away from the piston crown.
- Fit the middle piston ring with the identification letter facing the piston crown. In any case, the step must be facing opposite the piston crown.
- Fit the top piston ring with the word 'top' or the reference mark facing the crown of the piston.
- Offset the piston ring gaps on the three rings by 120° to each other as shown in the figure.
- Lubricate the components with engine oil.

N.B.

SO AS TO OBTAIN THE BEST CONFIGURATION THE 2 SEALING RINGS ARE MADE WITH A CONTACT CONICAL CYLINDER SECTION.



Refitting the cylinder


- Insert the cylinder base gasket with the thickness determined above.
- Using the fork support and the piston ring retaining band, refit the cylinder as shown in the figure.

N.B.

BEFORE FITTING THE CYLINDER, CAREFULLY BLOW OUT THE LUBRICATION DUCT AND OIL THE CYLINDER LINER.


Specific tooling

020426Y Piston fitting fork



020427Y Piston assembly band**Inspecting the cylinder head**


- Using a trued bar check that the cylinder head surface is not worn or distorted.
- Check that the camshaft and rocking lever pin bearings show no signs of wear.
- Check that the cylinder head cover surface, the intake manifold and the exhaust manifold are not worn.

**Characteristic****Maximum admitted unevenness: Cylinder head check**


0.05 mm

STANDARD DIAMETER


Specification	Desc./Quantity
Standard diameter	A Ø 32.5 - 32.525
Standard diameter	B Ø 20 - 20.021
Standard diameter	C Ø 12 - 12.018

**Inspecting the timing system components**

- Check that the guide slider and the tensioner slider are not worn out.
- Ensure that the camshaft drive pulley, the chain assembly and the sprocket wheel are not worn.
- If signs of wear are found, replace the parts. If the chain, pinion or pulley are worn, replace the whole assembly.



- Remove the central screw and the tensioner spring. Check that the one-way mechanism is not worn.
- Check the condition of the tensioner spring.
- If examples of wear are found, replace the whole unit.




Inspecting the valve sealings

- Measure the width of the sealing surface on the valve seats.

VALVE SEAL SURFACE

Specification	Desc./Quantity
Intake valve - seal surface	2.4 - 2.8 mm
Exhaust valve - seal surface	2.2 - 2.6 mm



Inspecting the valve housings

- Remove any carbon formation from the valve guides.
- Measure the inside diameter of each valve guide.
- Take the measurement at three different heights in the rocker arm push direction.

Characteristic


Standard drainage guide diameter

5.012 mm

Standard intake guide diameter

5.012 mm

- If the width of the impression on the valve seat or the diameter of the valve guide exceed the specified limits, replace the cylinder head.
- Check width of the impression on the valve seat «V»




Characteristic

Wear limits:

Max. 1.6 mm.

Inspecting the valves

- Measure the diameter of the valve stems in the three positions indicated in the diagram.
- Calculate the clearance between valve and valve guide.



Characteristic

Minimum diameter admitted - Intake:

4.96 mm

Minimum diameter admitted - Exhaust:

4.95 mm

Standard clearance - Intake:

0.013 - 0.040 mm

Standard clearance - Exhaust:

0.025 - 0.052 mm


Maximum clearance admitted- Intake:

0.062 mm

Maximum clearance admitted - Exhaust:

0.072 mm

- Check that there are no signs of wear on the contact surface with the articulated register terminal.
- If the sealing surface on the valves is wider than the specified limit, damaged in one or more points or curved, replace the valve with a new one.



Characteristic


Standard valve length - Intake:

80.6 mm

Valve standard length: Exhaust

79.6 mm


- If no faults are found during the above checks, you can use the same valves. For best sealing results, it is advisable to grind the valves. Grind the valves gently with a fine-grained lapping compound. During grinding, keep the cylinder head in a horizontal position. This will prevent the lapping compound residues from penetrating between the valve stem/guide coupling.



CAUTION

TO AVOID SCORING THE FAYING SURFACE, DO NOT KEEP ROTATING THE VALVE WHEN NO LAPPING COMPOUND IS LEFT. CAREFULLY WASH THE CYLINDER HEAD AND THE VALVES WITH A SUITABLE PRODUCT FOR THE TYPE OF LAPPING COMPOUND BEING USED.

- Insert the valves into the cylinder head.
- Test the 2 valves alternatively.
- The test is carried out by filling the manifold with petrol and checking that the head does not ooze through the valves when these are just pressed with the fingers.




Inspecting the springs and half-cones

- Check that the upper spring caps and the cotter halves show no signs of abnormal wear.
- Check the unloaded springs length.

Characteristic

Valve spring length

33.9 - 34.4 mm




Refitting the valves

- Lubricate the valve guides with engine oil.
- Place the lower caps of the valve spring on the head.
- Use the punch to fit the 2 sealing rings one at a time.

Specific tooling

020306Y Punch for assembling valve seal rings




- Fit the valves, the springs and the spring retaining caps. Using the appropriate tool with adapter 11, compress the springs and insert the cotters in their seats.

Specific tooling

020382Y Valve cotters equipped with part 012 removal tool

020382Y011 adapter for valve removal tool



Inspecting the cam shaft

- Inspect the cam shaft for signs of abnormal wear on the cams.

Characteristic

Standard diameter Bearing A

Ø: 32.5 mm -0.025 -0.050 mm

Standard diameter Bearing B

20 -0.020 -0.041 mm

Minimum admitted diameter bearing A

Ø: 32.440 mm

Minimum admitted diameter bearing B



Ø: 19.950 mm

Intake cam height


27.512 mm

Exhaust cam height

27.212 mm



- Check there is no wear on the cam shaft retaining plate and its associated groove on the cam shaft.
- If any of the above dimensions are outside the specified limits, or there are signs of excessive wear, replace the defective components with new ones.




Characteristic


Maximum axial clearance admitted

0.42 mm

- Check there are no signs of wear on the automatic valve lifter cam, or the end-of stroke roller, or the rubber buffer on the automatic valve-lifter retaining cover.
- Check that the valve lifter spring has not yielded.
- Replace any defective or worn components.



- Check there are no signs of scoring or wear on the rocking lever bolt.
- Check there are no signs of wear on the pad from contact with the cam and on the jointed adjustment plate.
- Measure the internal diameter of each rocking lever.
 - Check that the elastic washer dedicated to the axle clearance of the rocking levers is not worn.
 - In case of failure, replace the damaged components.



Characteristic

Minimum diameter permitted

Ø 11.970 mm

Maximum diameter allowed

Ø 12.030 mm

Refitting the head and timing system components

- Fit the timing chain guide slider.
- Insert the head and cylinder alignment dowels, fit the head gasket and the head on the cylinder.

-Screw the nuts and lock them in a crossed sequence and in 2 or 3 stages to the specific torque.

Locking torques (N*m)

Locking torque 28 to 30


- Fit the two screws on the outside of the timing chain side and tighten them to the specified torque.

N.B.


BEFORE INSTALLING THE HEAD, MAKE SURE THAT THE LUBRICATION CHANNEL IS CLEAN USING A COMPRESSED AIR JET.

Locking torques (N*m)

Locking torque 11 to 13




- Fit the timing chain sprocket wheel on the crankshaft, with the chamfer facing the insertion side.
- Loop the timing chain around the sprocket on the crankshaft.
- Fit the tensioner pad by the cylinder head.
- Fit the spacer and the screw fastener.
- Fit the pin, the exhaust rocking lever, the spring washer and the intake rocking lever.
- Lubricate the 2 rocking levers through the holes at the top.
- Lubricate the 2 bearings and insert the camshaft in the cylinder head with the cams opposing the rocking levers.



- Insert the retention plate and tighten the two screws shown in the figure to the prescribed torque.

Locking torques (N*m)


Locking torque 4 to 6



- Refit the spacer on the cam shaft.
- Rotate the engine so that the piston is at top dead centre, using the reference marks on the flywheel and the crankcase.
- While doing so, fit the chain onto the control camshaft pulley and keep the reference 2V in correspondence with the reference mark on the head.
- Fit the pulley onto the camshaft.
- Assemble the counterweight with the corresponding fixing screw and tighten to the specified torque.

Locking torques (N*m)


Locking torque 7 to 8.5



- Fit the end-stop ring on the automatic valve lifter cam and fit the automatic valve lifter cam to the cam shaft.
- Fit the automatic valve lifter return spring.
- During this operation the spring must be loaded approximately 180°.

N.B.


GREASE THE END STOP RING TO PREVENT IT COMING OUT AND FALLING INTO THE ENGINE.



- Fit the automatic valve-lifter retaining dish, using the counterweight screw fastener as a reference.
- Tighten the clamping screw to the prescribed torque.

Locking torques (N*m)

Locking torque 12 to 14



- Set the tensioner cursor in the rest position.
- Fit the chain tensioner on the cylinder, using a new gasket, and tight the two screws to the prescribed torque.

Locking torques (N*m)**Locking torque 11 to 13**

- Insert the chain tensioning screw, together with the spring and washer, tightening it to the prescribed torque.

Locking torques (N*m)**Locking torque 5 to 6**

- Adjust the valve clearance.
- Fit the spark plug

Characteristic**Spark plug (125 cm³)**


NGK CR8EB

Spark plug (150cm³)


NGK CR7EB

Electric characteristic**Electrode gap**


0.7 - 0.8 mm

**Locking torques (N*m)****Locking torque 12 to 14**

- Assemble the casing sealing gasket on the head. On the fitting direction, use the supplements on the timing side as reference.
- Assemble the screw fixing the housing to the crankcase to the specified torque and the 2 self-tapping screws joining the half-shells.
- Take care that the gasket is well inserted in its housing during the assembly stage.
- Place the spark plug access cap.

**Locking torques (N*m)****Locking torque 3 to 4**

- Refit the cylinder head cover, tightening the 4 clamping screws to the prescribed torque.
- Refit the fan and the housing.
- Reassemble the oil pump control, the chain compartment cover, the by-pass and the oil sump as described in the lubrication chapter.




- Reassemble the driving pulley, the belt and the transmission cover as described in the transmission chapter.

Locking torques (N*m)


Locking torque 11 to 13

Crankcase - crankshaft

- Precautionary remove the following units: transmission cover, driving pulley, driven pulley and belt, rear hub cover, gears, bearings and oil seals as described in the transmission chapter.
- Remove the oil sump, the by-pass, the chain compartment cover and the oil pump as in the lubrication chapter.
- Remove the flywheel cover, the fan, the flywheel and the stator as described in the magneto flywheel chapter.
- Remove the oil filter and the oil pressure bulb.
- Remove the cylinder-piston-head unit as described in the cylinder head timing system chapter.
- Remove the 2 retainers indicated in the figure and the starter motor.



- Before opening the crankcase, it is advisable to check the axial clearance of the crankshaft. To do this, use a plate and a support with specific tool dial gauge.

**Specific tooling**

020262Y Crankcase splitting plate

020335Y Magnetic mounting for dial gauge

Characteristic**Standard clearance**

0.15 - 0.40 mm

Splitting the crankcase halves


Remove the 11 coupling screws to the crankcase.

- Separate the crankcase while keeping the crankshaft in one of the two halves of the crankcase.

Remove the crankshaft.

CAUTION

IF YOU FAIL TO DO THIS, THE CRANKSHAFT MIGHT ACCIDENTALLY FALL.




- Remove the coupling gasket of the crankcase halves.


- Remove the two screws and the internal shield shown in the diagram.

CAUTION

WHILE OPENING THE CRANKCASES AND REMOVING THE CRANKSHAFT, CHECK THAT THE THREADED SHAFT ENDS DO NOT INTERFERE WITH THE MAIN BUSHINGS. FAILURE TO OBSERVE THIS PRECAUTION CAN DAMAGE THE MAIN BUSHINGS.



- Remove the oil seal on the flywheel side.
- Remove the oil filter fitting shown in the diagram



- Check the axial clearance on the connecting rod.

Characteristic

Standard clearance

0.20 - 0.50 mm




- Check the radial clearance on the connecting rod.
- Check the surfaces that limit the axial clearance are not scored and measure the width of the crankshaft between these surfaces, as shown in the diagram.

CAUTION
BE CAREFUL NOT TO LET THE MEASUREMENT BE AFFECTED BY THE UNIONS WITH THE CRANKSHAFT ENDS.

Characteristic


Standard clearance

0.036 - 0.054 mm



- If the axial clearance between crankshaft and crankcase is exceeding and the crankshaft does not have any defect, the problem must be due to either excessive wear or wrong machining on the crankcase.

CAUTION
THE CRANKSHAFT CAN BE REUSED WHEN THE WIDTH IS WITHIN THE STANDARD VALUES AND THE SURFACES SHOW NO SIGNS OF SCORING.



Characteristic


Distance between the shoulders

55.67 - 55.85 mm

- Check the diameters of both the bearings of the crankshaft in accordance with the axes and surfaces shown in the figure. The half-shafts are classified in two categories Cat. 1 and Cat. 2 as shown the chart below.

STANDARD DIAMETER

Specification	Desc./Quantity
Category 1	28.998 - 29.004
Category 2	28.004 to 29.010



Inspecting the crankshaft alignment

To install the crankshaft on the support and to measure the misalignment in the 4 points indicated in figure.

- Check that the crankshaft cone, the tab seat, the oil seal capacity, the toothed gear and the threaded tangs are in good working order.
- In case of failures, replace the crankshaft.

The big end bushings cannot be replaced. For the same reason, the connecting rod may not be replaced and, when cleaning the crankshaft, be very careful that no impurities get in through the shaft's lubrication holes.

In order to prevent damaging the connecting rod bushings, do not attempt cleaning the lubrication duct with compressed air.

- Make sure that the 2 caps on the crankpin are properly fitted.
- A wrong installation of a cap can seriously affect the bushing lubrication pressure.

N.B.

THE MAIN BEARINGS ARE NOT GRINDABLE

Specific tooling

020074Y Support base for checking crankshaft alignment

Characteristic


Off-line maximum admitted

A = 0.15 mm

B = 0.01 mm


C = 0.01 mm

D = 0.10 mm



Inspecting the crankcase halves


- Before proceeding to check the crankcase halves, thoroughly clean all surfaces and oil ducts.
- On the transmission side crankcase half, take particular care cleaning the housing and oil ducts for the following components: the oil pump, the oil by-pass valve, the main bushings and the cooling jet on the transmission side (see diagram).
- Take particular care, also, that there are no signs wear in the oil by-pass valve housing (see Chapter Lubrication), as this could prevent a good seal in the piston, which regulates the oil pressure.



N.B.

THE JET IS FED THROUGH THE MAIN BUSHINGS. PROPER OPERATION OF THIS COMPONENT IMPROVES PISTON CROWN COOLING. CLOGGING HAS EFFECTS THAT ARE DIFFICULT TO DETECT (PISTON TEMPERATURE INCREASE). FAILURE OR LEAKS CAN CAUSE A CONSIDERABLE DROP IN THE LUBRICATION PRESSURE FOR MAIN BUSHINGS AND CONNECTING ROD.

- On the flywheel side crankcase half, take particular care cleaning the oil ducts for the main bushings, the oil duct for the jet that lubricates the cylinder head and the oil drainage duct at the fly-wheel side oil seal.




N.B.

THE HEAD LUBRICATION CHANNEL IS PROVIDED WITH A SHUTTER JET; THIS GIVES A "LOW PRESSURE" HEAD LUBRICATION; THIS CHOICE WAS MADE TO REDUCE THE OIL TEMPERATURE IN THE SUMP. THE JET CLOGGING IMPAIRS THE HEAD LUBRICATION AND THE TIMING MECHANISMS. A JET FAILURE CAUSES A DECREASE OF THE MAIN BUSHING AND CONNECTING ROD LUBRICATION PRESSURE.

- Inspect the mating surfaces on the crankcase halves for scratches or deformation, taking particular with the surfaces that mate with the cylinder and the mating surfaces between the crankcase halves.
- Defects in the crankcase coupling gasket or the surfaces indicated in the figure can cause a drop in the oil pressure and affect the lubricating pressure for the main bushings and the connecting rod.




- Check the main bearing seats that limit axial clearance in the crankshaft show no signs of wear. The dimension between these seats is measured by way of the procedure described previously for measuring the crankshaft axial clearance and dimensions.



Inspecting the crankshaft plain bearings

- To obtain a good bushing lubrication it is necessary to have both an optimal lubricating pressure (4 bar) and a good oil flow rate; the bushings must be correctly positioned so as not to obstruct the oil supply channels.
- The main bushings are comprised of two half-bearings, one with holes and channels for lubrication whereas the other is solid.
- The solid half-bearing is intended to stand the thrusts caused by combustion, and for this reason it is arranged opposite the cylinder.
- To prevent shutters in the oil feeding channels, the matching surface of the two half-bearings must be perfectly orthogonal to the cylinder axis, as shown in the figure.
- The oil feeding channel section is also affected by the bushings driving depth compared with the crankshaft axial clearance of the limiting surface.



N.B.

TO KEEP THIS POSITION OF THE BUSHINGS ON THE CRANKCASE, FITTING IS FORCED ON STEEL RINGS INSERTED IN THE CASTING OF BOTH CRANKCASE HALVES.

Characteristic

Standard driving depth

1.35 - 1.6

- Check the inside diameter of the main bushings in the three directions indicated in the diagram.
- Repeat the measurements for the other bushing half. see diagram.
- The standard bushing diameter after driving is variable on the basis of a coupling selection.


- The bushing housings in the crankcase are classified into 2 categories - Cat. 1 and Cat. 2 - just like those for the crankshaft.
- The main bushings are subdivided into 3 thickness categories; see the table below:

N.B.

DO NOT TAKE THE MEASUREMENT ON THE TWO HALF-SHELL COUPLING SURFACE SINCE THE ENDS ARE RELIEVED TO ALLOW BENDING DURING THE DRIVING OPERATION.

MAIN BEARINGS

Specification	Desc./Quantity
B	Blue
C	Yellow
E	Green




Refitting the crankcase halves

- Fit the internal bulkhead by locking the two screws to the prescribed torque.

Locking torques (N*m)

Locking torque 4 to 6




- Fit the oil filter joint and tighten it to the prescribed torque.

- Place a new gasket on one of the crankcase halves, preferably on the transmission side, together with the alignment dowels.

Locking torques (N*m)

Locking torque 27 to 33



- Lubricate the main bushings and insert the crankshaft in the transmission side crankcase half.
- Reassemble both crankcase halves.
- Fit the 11 screws and tighten them to the prescribed torque.

N.B.

WHEN FITTING THE HALF CASING AND THE CRANK-SHAFT, TAKE CARE NOT TO DAMAGE THE SHAFT THREADED TANGS.

Locking torques (N*m)**Locking torque 11 to 13**

- Lubricate the flywheel oil seal.
- Use the appropriate tool to assemble the oil seal.
- Fit a new O-ring on the pre-filter and lubricate it.
- Insert the pre-filter on the engine with its corresponding cover to the specific torque.

N.B.

REMOVE ANY EXCESS FROM THE CRANKCASE COUPLING GASKET ON THE CYLINDER PLANE, TO ENSURE BETTER SEALING PERFORMANCE.

N.B.



FAILURE TO USE THE SPECIFIC TOOL CAN RESULT IN AN INCORRECT DEPTH POSITION AND AS A CONSEQUENCE IN INADEQUATE OIL SEAL.

Specific tooling

020425Y Punch for flywheel-side oil seal


Locking torques (N*m)

Locking torque 24 to 30



Lubrication

Conceptual diagrams



Oil pressure check

- After removing the cover protections as described in the "Flywheel" chapter, disconnect the electrical connexion of the minimum oil pressure switch and then remove the switch.
- With the engine idling at 1650 rpm and the oil temperature at $\sim 90^{\circ}\text{C}$, check that the oil pressure is between 0.5 to 1.2 atm.
- With the engine idling at 6000 rpm and the oil temperature at $\sim 90^{\circ}\text{C}$, check that the oil pressure is between 3.2 to 4.2 atm.
- Remove the appropriate tools once the measurement is complete, refit the oil pressure switch and washer, tightening it to the prescribed torque and fit the flywheel cover.
- If the oil pressure is not within the specified limits, in the following order, check: the oil filter, the oil by-pass valve, the oil pump and the crankshaft seals.

N.B.

THE CHECK MUST BE CARRIED OUT WITH OIL AT THE CORRECT LEVEL AND WITH AN OIL FILTER IN PROPER CONDITION.

Specific tooling

020193Y Oil pressure check gauge


Characteristic

Minimum pressure admitted

3.2 atm.

Locking torques (N*m)


Locking torque 12 to 14 (also valid for the control connector).




Crankshaft oil seals

Removal


- Remove the transmission cover and the complete drive pulley beforehand



- Install the base of the appropriate tool on the oil seal using the screws provided.



- Screw the threaded bar onto the base of the tool and extract the oil seal.



Specific tooling

020622Y Transmission-side oil seal punch

Refitting

- Prepare the new oil seal, lubricating the sealing lip. Warning: do not lubricate the surface for keying onto the engine crankcase.

CAUTION

DO NOT LUBRICATE THE KEYING SURFACE ONTO THE ENGINE CRANKCASE.



- Preassemble the oil seal with the appropriate tool, positioning the screws
- Place the sheath over the crankshaft



- Insert the tool with the oil seal on the crankshaft until it comes into contact with the crankcase

CAUTION

ORIENT THE OIL SEAL BY POSITIONING THE CHAIN HOUSING CHANNEL FACING DOWNWARDS. WHEN THE POSITION IS REACHED, DO NOT RETRACT THE OIL SEAL. FAILURE TO COMPLY WITH THIS RULE CAN CAUSE A WRONG POSITIONING OF THE OIL SEAL SHEATH.



- Orientate the oil seal by inserting the bracket which is part of the specific tool.



- Tighten the threaded bar onto the crankshaft as far as it will go.



- Use the nut to move the base of the tool until you can see end of the oil seal driving stroke



- Remove all of the tool components following the procedure in reverse order

CAUTION

FAILURE TO COMPLY WITH THIS ASSEMBLY PROCEDURE CAN SERIOUSLY DAMAGE THE ENGINE DUE TO THE WRONG TENSIONING OF THE OIL PUMP CONTROL CHAIN.


Assemble a new oil seal on the flywheel side using the specific tool as shown in the photograph

N.B.

FAILURE TO USE THE SPECIFIC TOOL CAN RESULT IN AN INCORRECT DEPTH POSITION AND AS A CONSEQUENCE IN INADEQUATE OIL SEAL.

Specific tooling


020425Y Punch for flywheel-side oil seal




Oil pump

Removal

- Remove the cover of the pump control pulley using the two retainers, as shown in the figure.
- Block the rotation of the oil pump control pulley using a screwdriver inserted through one of its two holes.




- Remove the central screw with cup washer, as shown in the diagram.
- Remove the chain with the pulley.
- Remove the crankshaft control pinion.




- Remove the oil pump acting on the 2 retainers as shown in the figure.
- Remove the oil pump seal.

IT IS ADVISABLE TO MARK THE CHAIN IN ORDER TO ENSURE THAT THE INITIAL DIRECTION OF ROTATION IS MAINTAINED.



Inspection

- Remove the two screws and the oil pump cover.
- Remove the circlip retaining the innermost rotor.
- Remove and wash the rotors thoroughly with petrol and compressed air.
- Reassemble the rotors in the pump body, keeping the two reference marks visible. Replace the retainer ring.




- Using a feeler gauge, check the distance between the rotors in the position shown in the figure.

Characteristic

Maximum clearance admitted

0.12 mm



Measure the distance between the outer rotor and the pump body; see figure.

Characteristic**Admissible limit clearance:**


0.20 mm



Check the axial clearance of the rotors with a trued bar as reference, as shown in the figure.

Characteristic**Limit values admitted:**

0.09 mm



Refitting


- Check there are no signs of wear on the oil pump shaft or body.
- Check there are no signs of scoring or wear on the oil pump cover.
- If you detect non-conforming measurements or scoring, replace the faulty parts or the assembly.
- Fit the pulley to the pump, the central screw to the specified torque and the cup washer.
- Fit the oil pump cover, by tightening the two screws to the prescribed torque.

N.B.

FIT THE CUP WASHER SO THAT ITS OUTER (CURVED) RIM TOUCHES THE PULLEY.



Locking torques (N*m)

Central screw 12 to 14 Nm Cover screws 0.7 to 0.9 Nm




Removing the oil sump

- Remove the oil filler plug, the transmission cover, the complete drive pulley assembly with belt and the sprocket wheel, as described in the Transmission chapter.
- Drain the oil from the sump as described above.
- Remove the 7 screws indicated in the figure and the 2 rear brake transmission fixing brackets.
- Remove the spring, the by-pass piston and the gasket shown in the second image.



Inspecting the by-pass valve

- Check the unloaded spring length.
- Check that the small piston is not scored.
- Ensure that it slides freely on the crankcase and that it guarantees a good seal.
- If not, eliminate any impurities or replace defective parts.




Characteristic

By-pass check up: Standard length

54.2 mm

Refitting the oil sump

- Refit the by-pass piston in its housing.
- Insert the pressure-regulating spring.
- Fit a new sump seal.
- Refit the sump, taking care to locate the spring in the appropriate recess machined into the inside of the sump.
- Refit the rear brake transmission mounting brackets and the screws in the reverse order from which they were removed.
- Tighten the screws to the prescribed torque.
- Refit the driving pulley assembly, the drive belt, the sprocket wheel and the transmission cover, as described in the "Transmission" chapter.
- **When testing the lubrication system, refer to the "Crankcase and Crankshaft" chapter, regarding lubrication of the connecting rod assembly**



Locking torques (N*m)

Locking torque 11 to 13

INDEX OF TOPICS

INJECTION	INJEC
-----------	-------



COMPONENT TRANSPOSITION

	Specification	Desc./Quantity
1	Instrument panel	
2	Throttle body and electronic injection control unit (MIU)	
3	Diagnostics socket connector	
4	Fuel pump	
5	Engine temperature sensor	
6	Fuel injector	
7	HV coil	
8	Engine speed sensor	
9	Lambda probe	
10	Injection load relay	
11	Battery	12V - 10Ah

MIU injection system

This vehicle is fitted with an integrated injection and ignition system.

Injection is indirect in the manifold through an electro-injector.

The injection and ignition are timed on the four-stroke cycle by means of a tone wheel keyed on to the crankshaft (24-2 teeth) and pick-up sensor.

Combustion and ignition are managed on the basis of engine revs and throttle valve opening. Further corrections are made according to the following parameters:

- Engine temperature
- Intake air temperature
- Lambda probe

The system implements cold engine idle fuel/air mixture correction with a stepper motor on a by-pass circuit of the throttle valve. The control unit manages the Stepper motor and the injector opening time, thereby ensuring the idle steadiness and the proper combustion.

In all conditions of use, mixture preparation is managed by modifying the injector opening time.

The fuel system pressure is kept constant in relation to ambient pressure.

The **fuel system circuit** consists of:

- Fuel pump
- Fuel filter
- Injector
- Pressure regulator

The pump, the filter and the regulator are placed inside the fuel tank on a single support.

The injector is connected by a pipe with fast-release fittings. The pressure regulator is located at the beginning of the circuit.

The fuel pump is controlled by the MIU; this ensures safety of the vehicle.

The **ignition circuit** consists of:

- HV coil
- HV cable.
- Shielded cap
- MIU control unit
- Spark plug

The MIU control unit manages ignition with the best advance ensuring four-stroke timing (ignition only in the compression phase) at the same time.


The MIU injection-ignition system controls engine functions by means of a pre-set program.

Should any input signals fail, an acceptable working order of the engine is ensured to allow the user to reach a service station.

Of course, this cannot happen when the rpm-timing signal is missing, or when the failure involves the control circuits:

- Fuel pump
- HV coil
- Injector

The control unit is provided with a self-diagnosis system connected to an indicator light in the instrument panel.



Failures are detected and restored by the diagnostic tester.

In any case, when the fault is no longer present, the data storage is automatically cleared after 16 cycles of use (cold start, running at regular engine temperature, stop).

The diagnostic tester is also required to adjust the idle mixture.




Specific tooling

020922Y Diagnosis Tool

The MIU control unit has a decoder for the anti-theft immobilizer system.

The MIU control unit is connected to a diagnostic LED on the instrument panel, that also carries out the deterrent flashing functions.



Precautions

Troubleshooting tips

1 A MIU failure is more likely to be due to the connections than to the components.

Before troubleshooting the MIU system, carry out the following checks:

A: Electrical power supply

- a. Battery voltage
- b. Burnt fuse
- c. Remote control switches
- d. Connectors

B: Chassis ground

C: Fuel system

- a. Faulty fuel pump
- b. Dirty fuel filter

D: Ignition system

- a. Faulty spark plug
- b. Faulty coil
- c. Faulty screened cap

E: Intake circuit

- a. Air filter dirty
- b. Dirty by-pass circuit
- c. Faulty stepper motor

F: Other

- a. Wrong distribution timing
- b. Incorrect idle speed carburetion
- c. Incorrect reset of the throttle valve position sensor

2 MIU system faults may be caused by loose connectors. Make sure that all connections have been correctly made.

Check the connectors taking into consideration the following point:

A check that the terminals are not bent.

B check that the connectors have been properly connected.

C - Check whether the malfunction can be fixed by shaking the connector slightly.

3 Check the entire system before replacing the MIU. If the fault is fixed by replacing the MIU, install the original control unit again and check if the fault occurs again.

4 Use a multimeter with an internal resistance of more than 10K Ohm /V when troubleshooting. Instruments that are not suitable might damage the MIU central control unit. Use instruments with definitions over 0.1V and 0.5 W, the precision must be greater than 2%.

1. Before fixing any part of the injection system, check to see if there are any registered faults. Do not disconnect the battery before checking for faults.

2. The fuel system is pressurised at 250 kPa (2.5 BAR). Before disconnecting the fast-release fitting of the fuel supply pipe, check that there are no naked flames. Do not smoke. Act with caution to avoid spraying fuel to your eyes.

3. When fixing electric components, operate with the battery connected only when actually required.


4. When functional checks are performed, check that the battery voltage is over 12V.

5. Before any attempt to start the vehicle, check to make sure there is at least two litres of fuel in the tank. Failure to respect this norm will damage the fuel pump.

6. If the vehicle is expected to remain unused for a long time, refill the tank up to a little over half the level. This will ensure the pump will be covered by fuel.

7. When washing the vehicle, be careful with the electric components and cable harnesses.
8. When an ignition problem is detected, start the checks from the battery and the injection system connections.
9. Before disconnecting the MIU ECU connector, perform the following steps in the order shown:
 - Set the switch to «OFF»
 - Disconnect the batteryFailure to respect this norm may damage the control unit.
10. Do not invert the poles when fitting the battery.
11. To avoid causing any damage, disconnect and reconnect the MIU system connectors only if required. Before reconnecting, check that the connectors are dry.
12. When carrying out electric inspections, do not force the tester probes into the connectors. Do not take measurements not specifically foreseen by the manual.
13. At the end of every check performed with the diagnostic tester, remember to protect the system connector with its cap. Failure to observe this precaution may damage the MIU control unit.
14. Before reconnecting the quick couplers of the power supply system, check that the terminals are perfectly clean.


Terminals setup



1. Injection warning light
2. incomplete
3. incomplete
4. (-) lambda probe
5. (+) live battery
6. (+) battery
7. Immobilizer aerial
8. incomplete

9. Engine temperature sensor
- 10.incomplete
- 11.(+) lambda probe
- 12.Engine stop switch
- 13.(+) engine speed sensor
- 14.(-) fuel injector
- 15.(-) engine speed sensor
- 16.Diagnostics output
- 17.Immobilizer LED
- 18.Pin short-circuited with pin 26
- 19.(-) low beam automatic ignition
- 20.(-) injection load remote control
- 21.Lambda probe
- 22.(-) HV coil
- 23.incomplete
- 24.Start up enabling
- 25.incomplete
- 26.Ground lead

**THE FOLLOWING INFORMATION REFER TO
THE VERSION EQUIPPED WITH MIU G3 ECU.**




ELECTRONIC CONTROL UNIT CONNECTOR

1. H.V. COIL (Pink-Black)
2. Not connected
3. Not connected
4. Ground (Green-Black)
5. Not connected
6. Key powered(Red-White)
7. Ground No. 1 (Black)
8. Not connected
9. Battery-powered (Grey-Black)
10. Start-up enabling switch (Orange-Blue)

- 11.** Lambda probe positive (Sky blue-Black)
 - 12.** Lambda probe negative (White-Green)
 - 13.** Water temperature sensor (Sky blue-Green)
 - 14.** Immobilizer aerial (Orange-White)
 - 15.** Not connected
 - 16.** K serial line (Purple-White)
 - 17.** Immobilizer (Red-Green)
 - 18.** Not connected
 - 19.** Side stand (Grey-Green)
 - 20.** Engine speed sensor negative (Brown)
 - 21.** Not connected
 - 22.** Injection load relay (Black-Purple)
 - 23.** Not connected
 - 24.** Not connected
 - 25.** Injection warning light (Brown-Black)
 - 26.** Not connected
 - 27.** Not connected
 - 28.** Not connected
 - 29.** Engine speed sensor positive (Red)
 - 30.** Not connected
 - 31.** Lambda probe heater (Green-Yellow)
 - 32.** Not connected
 - 33.** Low beam lights automatic ignition enabling (White-Black)
 - 34.** Fuel injector (Red-Yellow)
-


EMS circuit diagram



1. Battery 12V - 10 Ah
2. Engine speed sensor
3. Engine temperature sensor
4. Immobilizer aerial
5. Stop buttons
6. Fuse No. 1 of 20A
7. Key switch contacts
8. Fuse No. 3 of 7.5A
9. Fuse No. 6; 15A
10. Engine control telltale light
11. Fuse No. 2; 7.5A
12. Injection load remote controls
13. Fuse No. 4; 7.5A
14. Starter button
15. Starter relay
16. Diagnostics socket output
17. Starter motor
18. "IMMOBILIZER" led
19. Fuel pump
20. HV coil

- 21.Injector
- 22.Lambda probe
- 23.Low beam light solenoid
- 24.High-beam light solenoid
- 25.Light switch
- 26.Electronic control unit

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Key:

- 13. engine stop switch
- 14. Fuses No. 3- 7.5A; No. 6- 15A
- 15. High-beam light solenoid
- 16. Low beam light solenoid
- 19. Ignition switch contacts
- 20. Fuse No.2 - 7.5A
- 23. Starter remote control switch
- 25. Fuse No.1 - 20A
- 26. 12v-10Ah battery
- 30. Injection load relay
- 33. Lambda probe

- 34. Engine speed sensor
- 35. HV coil
- 36. Fuel injector
- 37. Engine temperature sensor
- 38. Fuel system pump
- 39. Diagnostics socket
- 40. Injection electronic control unit
- 41. Immobilizer antenna
- 42. Bulb for engine control telltale light
- 48. Immobilizer LED warning light

Troubleshooting procedure

Engine does not start

ENGINE DOES NOT START IF ONLY PULLED

Possible Cause	Operation
Immobiliser enabling signal	System not encoded System not efficient, repair according to the indications of the self-diagnosis
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor
Fuel system	Fuel in the tank Fuel pump activation Fuel pressure (low) Injector capacity (low)
Power to the spark plug	Shielded spark plug cap HV coil (secondary insulation)
Parameter reliability	Engine temperature Distribution timing - injection ignition Intake air temperature
End of compression pressure	End of compression pressure

Starting difficulties

ENGINE STARTER PROBLEMS

Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature
Start-up speed	Starter motor and solenoid Battery Ground connections
End of compression pressure	End of compression pressure
Power to the spark plug	Spark plug Shielded cap HV coil Speed-timing sensor Ignition advance

Possible Cause	Operation
Fuel system	Fuel pressure (low) Injector capacity (low) Injector sealing (poor)
Correctness of the parameters	Engine temperature Stepper throttle valve position intake air temperature (steps and actual opening) Cleaning the throttle valve, air filter efficiency

Engine stops at idle

ENGINE DOES NOT IDLE/ IDLING IS UNSTABLE/ IDLING TOO LOW

Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature
Ignition efficiency	Spark plug Ignition timing
Correctness of the parameters	Throttle valve position sensor Stepper Engine temperature sensor Intake air temperature sensor
Intake system cleaning	Air filter Diffuser and throttle valve Stepper
Intake system sealing (infiltrations)	Intake manifold - head Throttle body - manifold Air cleaner joint Filter box
Fuel system (low pressure)	Fuel pump Pressure regulator Fuel filter Injector capacity

Engine does not rev down

ENGINE DOES NOT RETURN TO IDLING SPEED/IDLING SPEED TOO HIGH

Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature
Ignition efficiency	Ignition timing
Correctness of the parameters	Throttle valve position sensor Stepper Engine temperature sensor Intake air temperature sensor
Intake system sealing (infiltrations)	Intake manifold - head Throttle body - manifold Air cleaner joint Filter box
Fuel system (low pressure)	Fuel pump Pressure regulator Fuel filter Injector capacity

Exhaust backfires in deceleration

EXHAUST BACKFIRES WHEN DECELERATING

Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature Lambda sensor
Correctness of the parameters	Throttle valve position sensor Stepper Engine temperature sensor Intake air temperature sensor
Intake system sealing (infiltrations)	Intake manifold - head Throttle body - manifold Air cleaner joint Filter box
Fuel system (low pressure)	Fuel pump Pressure regulator Fuel filter Injector capacity
Exhaust system sealing (infiltrations)	Manifold - head Manifold - silencer silencer welding

Engine revs irregularly

ENGINE IRREGULAR PERFORMANCE WITH VALVE SLIGHTLY OPEN

Possible Cause	Operation
Intake system cleaning	Air filter Diffuser and throttle valve Stepper
Intake system sealing	Air cleaner joint Filter box
Ignition system	Spark plug wear check
Parameter reliability	Throttle valve position signal Engine temperature signal Intake air temperature indicator Ignition advance
TPS reset successful	TPS reset successful
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature Lambda sensor

Poor performance at full throttle

POOR ENGINE PERFORMANCE AT FULL POWER/ ENGINE IRREGULAR PERFORMANCE ON PICKUP

Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay HV coil Injector Revolution timing sensor Air temperature Engine temperature

Possible Cause	Operation
Spark plug power supply	Lambda sensor
	Spark plug
	Shielded cap
	HV cable
	HV coil
Intake system	Air filter
	Filter box (sealing)
	Air cleaner joint (sealing)
Parameter reliability	Throttle valve position signal
	Engine temperature signal
	Intake air temperature indicator
	Ignition advance
Fuel system	Fuel level in the tank
	Fuel pressure
	Fuel filter
	Injector capacity

Engine knocking

PRESENCE OF KNOCKING (COMBUSTION SHOCKS)


Possible Cause	Operation
Presence of faults detected by the self diagnosis	Pump relay
	HV coil
	Injector
	Revolution timing sensor
	Air temperature
	Engine temperature
	Lambda sensor
Ignition efficiency	Spark plug
Parameter reliability	Throttle valve position signal
	Engine temperature signal
	Intake air temperature indicator
	Ignition advance
Intake system sealing	Air cleaner joint
	Filter box
TPS reset successful	TPS reset successful
Fuel system	Fuel pressure
	Fuel filter
	Injector capacity
	Fuel quality
Selection of the cylinder base gasket thickness	Selection of the cylinder base gasket thickness

Fuel supply system

The fuel system circuit includes the electric pump, the filter, the pressure regulator, the electro-injector and the fuel delivery pipes.

The electrical pump is located in the tank from which the fuel is pumped and sent to the injector through the filter.

The pressure is controlled by the pressure regulator situated in the pump assembly in the tank.



Removing the injector


- Remove the helmet compartment.
- Remove the connector from the injector.
- Remove the quick release of the petrol delivery pipes.



- Undo the fixing screws and slide the injector from the manifold being careful not to damage the sealing OR gasket.


CAUTION

DO NOT DISASSEMBLE THE INJECTOR COMPONENTS.




Refitting the injector

For refitting, perform the removal operations in reverse order and lubricate the sealing OR gasket with grease for internal application before fitting the injector on the manifold.




Removing the butterfly valve


- Remove the helmet compartment.
- Remove the fuel piping clamping screw indicated in the figure.




- Remove the fast-release fitting from the injector.
- Remove the injector connector.
- Remove the three screws with anti-tampering device fixing the manifold to the head and the clip fixing the throttle body to the manifold.




Remove the MIU ECU connector.



- Remove the fastening clamp of the air cleaner joint to the air filter body.




- Remove the mounting bracket of the throttle control cables undoing the two fixing screws.
- Release the cable ends of the throttle body pulley.
- Remove the throttle body with air cleaner joint, manifold and injector.




Refitting the butterfly valve

- For refitting, perform the steps in the reverse direction to disassembly taking care to orientate the air cleaner joint by inserting it in the reference tooth on the throttle body as shown in the picture.
- To adjust the throttle control cables, act on the specific adjuster screws.



Pump supply circuit



1. 12V - 10Ah Battery
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Key switch contacts
5. 7.5A fuse No. 2


6. Injection load remote control
7. Fuel pump
8. HV coil
9. Fuel injector
10. Lambda probe

When switched to "ON", the fuel pump starts to rotate for two seconds and then stops. When the engine starts, in the presence of rpm timing signal the pump is continuously supplied.

ELECTRICAL DATA


- Pump winding resistance ~ 1.5 Ohm
- Input current during normal functioning 1.4 to 1.8 A
- input current to the closed hydraulic circuit ~ 2 A (to be checked with specific tool for fuel pressure)

Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.



Check efficiency of fuse No. 2 of 7.5A, a 7,5A live control unit power supply, after removing the central cover of the shield.






Check efficiency of the injection load relay, that can be reached by removing the central cover of the shield: check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.






Check the power supply line of the injection load solenoid energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the solenoid base. If there is not, check the continuity of the Red-White cable between the fuse box and the solenoid base and of the Black-Purple cable between the pin 20 of the control unit and the solenoid base.



N.B.



CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).



Check the presence of fixed voltage between the grey/black cable of the remote control base and ground. If there is not, check the continuity of the Grey/Black cable between the fuse box (No. 6, 15 A) and the remote control base.

N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).

**pump circuit6**

Check, on switching to "ON", that there is battery voltage, for about two seconds, to the Black-Green cable of the pump connector and ground with pump connector disconnected. Otherwise, check the continuity of the Black-Green cable between the pump connector and the remote control base. Check the efficiency of the ground line of the fuel pump by measuring the continuity between the pump connector black cable, system side, and the ground.


If, when switching to "ON", the pump continues to turn after two seconds of activation, check, with the control unit disconnected and the injection load re-




mote control disconnected, that the Black-Purple cable (pin 20 on the interface wiring) is insulated from the ground.

Specific tooling

020331Y Digital multimeter



THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



1. Battery 12V- 6 Ah
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Ignition switch contacts
5. 7.5A fuse No. 2
6. Injection load relay
7. Fuel pump


8. HV coil
9. Fuel injector
10. Lambda probe

When switched to "ON", the fuel pump starts to rotate for two seconds and then stops. When the engine starts, in the presence of rpm timing signal the pump is continuously supplied.


ELECTRICAL DATA

- Pump winding resistance ~ 1.5 Ohm
- Input current during normal functioning 1.4 to 1.8 A
- input current to the closed hydraulic circuit ~ 2 A (to be checked with specific tool for fuel pressure)

Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.




Check efficiency of fuse No. 2 of 7.5A, live control unit power supply, after removing the central cover of the shield.



Check efficiency of the injection load relay, that can be reached by removing the central cover of the shield: check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.








Check the power supply line of the injection load relay energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the relay base. If there is not, check the continuity of the Red-White cable between the fuse box and the relay base and of the Black-Purple cable between the pin 22 of the control unit and the relay base.

N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).








Check the presence of fixed voltage between the grey/black cable of the relay base and ground. Otherwise, check the continuity of the grey-black cable between the fuse-box (No. 6, 15 A) and the relay base.

N.B.


CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).



Check, on switching to "ON", that there is battery voltage, for about two seconds, to the Black-Green cable of the pump connector and ground with pump connector disconnected. Otherwise, check the continuity of the Black-Green cable between the pump connector and the relay base.

Check the efficiency of the ground line of the fuel pump by measuring the continuity between the pump connector black cable, system side, and the ground.

If, when switching to "ON", the pump continues to turn after two seconds of activation, check, with the control unit disconnected and the injection load remote control disconnected, that the Black-Purple cable (pin 22 on the control unit) is insulated from the ground.



Specific tooling

020331Y Digital multimeter

Circuit leak test

Install the specific tool for checking the fuel pressure, with the pipe fitted with the gauge.

Check during regular operation by placing the appropriate tool between the pump and the injector. With the battery voltage > 12 V check that the fuel pressure is 2.5 BAR and that the input current is 1.4 to 1.8 A.




With the battery voltage > 12 V, check the pump flow rate by disconnecting from the injector the pipe equipped with the pressure gauge of the appropriate tool. Make a graded burette available with a flow rate of approximately 1 L. Rotate the pump using the active diagnosis of the palm top computer. Using a pair of long flat needle-nose pliers, choke the fuel pipe making the pressure stabilise at approx. 2.5 bar. Check that within 15 seconds the pump has a flow rate of approx. 110 cm³.

Specific tooling


020480Y Petrol pressure check kit

Fuel filter check

After removing from the tank, disconnect the electric pump terminals.




Remove the screw shown in the picture



Remove the clip fixing the piping to the filter shown in the picture




Separate the lower part of the pump mounting as shown in the picture.



Remove the filter from the pump mounting



Inspecting the injector circuit





1. 12V - 10Ah Battery
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Key switch contacts
5. 7.5A fuse No. 2

6. Injection load remote control
7. Fuel pump
8. HV coil
9. Fuel injector
10. Lambda probe


Check the resistance at the injector ends: $14.5 \pm 5\%$ Ohm

Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.



Check efficiency of fuse No. 2 of 7.5A, a 7,5A live control unit power supply, after removing the central cover of the shield.





Check efficiency of the injection load relay, that can be reached by removing the central cover of the shield: check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.






Check the power supply line of the injection load solenoid energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the solenoid base. If there is not, check the continuity of the Red-White cable between the fuse box and the solenoid base and of the Black-Purple cable between the pin 20 of the control unit and the solenoid base.



N.B.



CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).




Check the presence of fixed voltage between the grey/black cable of the remote control base and ground. If there is not, check the continuity of the Grey/Black cable between the fuse box (No. 6, 15 A) and the remote control base.

N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).



With the control unit and the injector disconnected, check the continuity of the Red-Yellow cable between pin 14 of the interface wiring and the injector connector




Switch to «ON» and check if there is voltage, with injector disconnected and control unit connected, between the Black-Green cable of the injector connector and the ground lead



With injector disconnected and the injector load relay disconnected, check the continuity of the Black-Green cable between the injector connector and relay base.



THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.




1. Battery 12V- 6 Ah
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Ignition switch contacts
5. 7.5A fuse No. 2
6. Injection load relay
7. Fuel pump


8. HV coil
9. Fuel injector
10. Lambda probe

Check the resistance at the injector ends: $14.5 \pm 5\%$ Ohm

Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.



Check efficiency of fuse No. 2 of 7.5A, live control unit power supply, after removing the central cover of the shield.






Check efficiency of the injection load relay, that can be reached by removing the central cover of the shield: check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.



Check the power supply line of the injection load relay energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the relay base. If there is not, check the continuity of the Red-White cable between the fuse box and the relay base and of the Black-Purple cable between the pin 22 of the control unit and the relay base.

N.B.



CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).




Check the presence of fixed voltage between the grey/black cable of the relay base and ground. Otherwise, check the continuity of the grey-black cable between the fuse-box (No. 6, 15 A) and the relay base.

N.B.


CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).



With the control unit and the injector disconnected, check if there is continuity in the Red-Yellow cable between pin 34 of the control unit connector and the injector connector.



Switch to «ON» and check if there is voltage, with injector disconnected and control unit connected, between the Black-Green cable of the injector connector and the ground lead




With injector disconnected and the injector load relay disconnected, check the continuity of the Black-Green cable between the injector connector and relay base.



Inspecting the injector hydraulics

To carry out the injector check, remove the intake manifold by removing the three screws, with anti-tampering device, fixing the head and loosening the clamp connecting the throttle body to the manifold.

Release the injector fuel delivery pipe from the bracket on the throttle body.



Install the appropriate tool for checking fuel pressure and position the manifold over a container graduated by at least 100 cm³. Connect the injector with the cable making up part of the supply for the injection tester. Connect the clamps of the cable to an auxiliary battery. Activate the fuel pump with the active diagnosis. Check that, within fifteen seconds, approximately 40 cm³ of fuel is dispensed with an adjustment pressure of approximately 2.5 BAR.




Specific tooling**020480Y Petrol pressure check kit**


Proceed with the injector seal test.

Dry the injector outlet with a blast of compressed air. Activate the fuel pump. Wait for one minute, making sure there are no leaks coming from the injector. Slight oozing is normal.

Value limit = 1 drop per minute

**Tachometer**


With wiring disconnected from the control unit and connected to the system, check that the sensor resistance between pins 13 - 15 is between 100 and 150 Ohm at an engine temperature of approximately 20°




Disconnect the fuel pipe connector. Start up the engine and wait for it to stop. With the wiring connected to the control unit and system try to start up the engine and check that the voltage between pins 13 and 15 is around 2.8 V



With the interface cable harness disconnected from the control unit, check continuity between pin 13 and the red cable of the engine speed sensor connector and between pin 15 and the brown cable of the engine speed sensor connector



With the interface wiring and rpm sensor connector disconnected from the control unit, check that the Red and Brown cables (pin 13 - 15) are isolated from each other and insulated from the ground.




Specific tooling

020481Y Control unit interface wiring

020331Y Digital multimeter

THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



Con cablaggio scollegato dalla centralina e collegato all'impianto verificare che la resistenza del sensore tra i pin 20 - 29 sia compresa tra 100 e 150 ohm ad una temperatura motore di circa 20°.


Disconnect the fuel pipe connector. Start up the engine and wait for it to stop. With the wiring connected to the control unit and system try to start up the engine and check that the voltage between pins 29 and 20 is around 2.8 V

- Check the continuity between pin 29 of the injection control unit and the red cable of the engine speed sensor.
- Check the continuity between pin 20 of the injection control unit and the brown cable of the engine speed sensor.
- Check that the pins 20 and 29 of the control unit are insulated from each other and insulated from the ground.

Specific tooling

020331Y Digital multimeter

HT coil



1. 12V - 10Ah Battery
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Key switch contacts
5. 7.5A fuse No. 2

6. Injection load remote control
7. Fuel pump
8. HV coil
9. Fuel injector
10. Lambda probe

The ignition system is integrated with the injection and it is a high-efficiency inductive type ignition.

The control unit manages two significant parameters:

- Ignition advance

This is optimised at the moment in accordance with the engine revs, engine load, temperature and environmental pressure.

With the engine at idle, the ignition advance is optimised to stabilise the speed at 1450 ± 50 rpm.

- Magnetisation time


The coil magnetisation time is controlled by the control unit. The ignition power is increased during the engine start-up phase.

The injection system recognises the 4-stroke cycle so ignition is only commanded in the compression phase.



Specific tooling

020331Y Digital multimeter


Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.



Check efficiency of fuse No. 2 of 7.5A, a 7,5A live control unit power supply, after removing the central cover of the shield.





Check there is voltage between pins 22 and 26 of the interface wiring for around two seconds when switching to «ON».



Check the resistance of primary coil between pin 22 of the interface wiring and the Black-Green cable of the injection load remote control base, that can be reached by removing the shield central cover, with the control unit disconnected and the remote control disconnected.

Resistance of the primary = $0.5 \pm 8\%$ Ohm





Check the efficiency of the injection load relay.
Check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.






Check the power supply line of the injection load solenoid energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the solenoid base. If there is not, check the continuity of the Red-White cable between the fuse box and the solenoid base and of the Black-Purple cable between the pin 20 of the control unit and the solenoid base.

**N.B.**

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).







Check the presence of fixed voltage between the grey/black cable of the remote control base and ground. If there is not, check the continuity of the Grey/Black cable between the fuse box (No. 6, 15 A) and the remote control base.


N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).





THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



1. Battery 12V- 6 Ah
2. Fuse No. 6; 15A
3. Fuse No. 1; 20A
4. Ignition switch contacts
5. 7.5A fuse No. 2
6. Injection load relay
7. Fuel pump

- 8. HV coil
- 9. Fuel injector
- 10. Lambda probe

The ignition system is integrated with the injection and it is a high-efficiency inductive type ignition.

The control unit manages two significant parameters:

- Ignition advance

This is optimised at the moment in accordance with the engine revs, engine load, temperature and environmental pressure.

With the engine at idle, the ignition advance is optimised to stabilise the speed at 1450 ± 50 rpm.

- Magnetisation time


The coil magnetisation time is controlled by the control unit. The ignition power is increased during the engine start-up phase.

The injection system recognises the 4-stroke cycle so ignition is only commanded in the compression phase.


Specific tooling

020331Y Digital multimeter

Check efficiency of the fuse No. 6 of 15A injection loads, next to the battery.




Check efficiency of fuse No. 2 of 7.5A, live control unit power supply, after removing the central cover of the shield.




Check that there is voltage, for about two seconds, between red/black cable of the coil connector and ground switching in «ON».

Check the resistance of the coil primary between the pin 1 of the control unit and the black/green cable of the injection load relay, that can be reached by removing the central cover of the shield, with the control unit and relay disconnected.

Resistance of the primary = $0.5 \pm 8\%$ Ohm



Check efficiency of the injection load relay, that can be reached by removing the central cover of the shield: check the resistance of the energising coil between pins 86 and 85: 40 to 80 Ohm
Apply a voltage of 12V to pins 86 and 85; make sure that there is continuity between pins 30 and 87 of the relay.





Check the power supply line of the injection load relay energising coil: after switching to "ON", make sure there is battery voltage, for 2 seconds, between the Red-White cable and Black-Purple cable of the relay base. If there is not, check the continuity of the Red-White cable between the fuse box and the relay base and of the Black-Purple cable between the pin 22 of the control unit and the relay base.

N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).








Check the presence of fixed voltage between the grey/black cable of the relay base and ground. Otherwise, check the continuity of the grey-black cable between the fuse-box (No. 6, 15 A) and the relay base.

N.B.

CONTINUITY TESTS MUST BE CARRIED OUT WITH THE COMPONENTS DISCONNECTED. (RELAYS, CONTROL UNIT, FUSES ETC.).





Zeroing the throttle

Resetting the throttle valve position signal (TPS reset)

The MIU control unit is supplied with a throttle valve position sensor that is pre-calibrated.

Pre-calibration entails regulating the minimum opening of the throttle valve to obtain a certain flow of air under pre-set reference conditions.

Pre-calibration ensures optimal air flow to control idling.

This regulation must not be tampered with in any way whatsoever.

The injection system will complete the management of the idling through the Stepper motor and the variation of the ignition advance.

The throttle body after the pre-calibration has an opened valve with an angle that can vary depending on the tolerances of the machining of the pipe and the valve itself.

The valve position sensor can also assume various fitting positions. For these reasons the mV of the sensor with the valve at idle can vary from one throttle body to another.

To obtain the optimum fuel mixture, especially at small openings of the throttle valve, it is essential to match the throttle body with the control unit following the procedure known as TPS resetting.

With this operation we inform the control unit, as the starting point, of the mV value corresponding to the pre-calibrated position.

To reset, proceed as follows.

Connect the diagnostic tester.

Switch to «ON».

Select the functions of the diagnostic tester on


«TPS RESET».

Specific tooling

020922Y Diagnosis Tool



Make sure that the throttle valve with the control is supporting the stop screw.



Guaranteeing that this position will be kept, send a confirmation for the TPS reset procedure.





Reset should be performed in the following cases:


- on first fitting.
- if the injection control unit is replaced.

N.B.

THE TPS RESET PROCEDURE MUST NOT BE CARRIED OUT WITH A USED THROTTLE BODY BECAUSE POSSIBLE VALVE WEAR AND STOP WEAR FOR THE MINIMUM OPENING MAKE THE AIR FLOW DIFFERENTLY FROM THAT OF PRE-CALIBRATION.


Lambda probe

SIGNAL CONTROL




1. Lambda probe


Install the electronic control unit interface wiring.
Start the engine and let it warm up.
Use an analogue multimeter with a direct voltage scale measuring down to 2 V.
Place the tips of the multimeter between pins 4 (-) and 11 (+)



With the engine running at idle speed, check that the voltage oscillates between 0V and 1V
With the throttle valve completely open, the voltage is approx. 1V.
During the closing phase, the voltage is approx. 0V.
If the voltage remains constant, the sensor may be damaged. Remove the sensor and check that there are no oil or carbon deposits inside it..



THE FOLLOWING INFORMATION REFER TO THE VERSION EQUIPPED WITH MIU G3 ECU.



LAMBDA PROBE

	Specification	Desc./Quantity
1	Lambda probe	

	Specification	Desc./Quantity
2	Injection ECU	

PIN RELATIONSHIP


PIN	PIN	Component	Reference value
12	11	Lambda probe	~ 0V with throttle valve closed; ~ 1V with throttle valve fully opened

With the engine running at idle speed, check that the voltage oscillates between 0V and 1V

With the throttle valve completely open, the voltage is approx. 1V.

During the closing phase, the voltage is approx. 0V.

If the voltage remains constant, the sensor may be damaged. Remove the sensor and check that there are no oil or carbon deposits inside it..



INDEX OF TOPICS

SUSPENSIONS	SUSP
-------------	------


Front suspension

This section is dedicated to operations that can be carried out on the suspensions.

Front


Removing the front wheel

- Support the vehicle adequately.
- Loosen the five screws fixing the wheel to the hub.



Front wheel hub overhaul


- Support the vehicle adequately.
- Remove the front wheel.
- Remove the front brake calliper.
- Remove the cotter pin and remove the cap.



- Unscrew the nut fixing the front wheel hub.



-
- Remove the wheel hub.



-
- Remove the ball bearing check Seeger ring indicated in the picture



Extract the ball bearing using the specific tool


Specific tooling

001467Y014 Calliper to extract $\varnothing$ 15-mm bearings

001467Y017 Bell for bearings, OD 39 mm



-
- Remove the oil seal on the roller bearing side using a screwdriver.



- Remove the roller bearing using the specific tool

Specific tooling

020376Y Adaptor handle

020456Y Ø 24 mm adaptor

020363Y 20-mm guide



- Heat the roller bearing seat with a heat gun
- Use the specific tool to introduce and push the bearing until it stops, with the shielded side facing out
- Refit the ball bearing check Seeger ring


Specific tooling

020151Y Air heater

020376Y Adaptor handle

020357Y 32 x 35-mm Adaptor

020412Y 15-mm guide



- Use the specific tool to fit and push the roller casing until it stops
- Refit the oil seal on the roller bearing side
- Lubricate the area between the roller bearing and the ball bearing

Specific tooling

020038Y Punch

Recommended products

AGIP GREASE MU3 Yellow-brown, lithium-base, medium-fibre multipurpose grease.

ISO L-X-BCHA 3 - DIN 51 825 K3K -20

- To refit, follow the removal steps but in reverse order; be careful to tighten to the prescribed torque.

Locking torques (N*m)

Front wheel axle nut 75 to 90




Refitting the front wheel

- Upon refitting, tighten the five screws to the prescribed torque.

Locking torques (N*m)

Wheel rim screws 20 to 25



Handlebar

Removal

Before carrying out these operations, remove the instrument panel.

- After removing the transmissions and disconnecting the electrical terminals, remove the terminal fixing the handlebar to the steering.
- Check all components and replace faulty parts.

N.B.

IF THE HANDLEBAR IS BEING REMOVED TO REMOVE THE STEERING, TILT THE HANDLEBAR FORWARD TO AVOIDING DAMAGING THE TRANSMISSIONS.




Refitting

Carry out the removal operations but in the reverse order, observing the prescribed tightening torque.

Locking torques (N*m)

Handlebar lock nut 45 to 50



Steering column

Removal

After removing the upper seat, lean the vehicle on one side and extract the steering tube completely from the fork.

Specific tooling

020055Y Wrench for steering tube ring nut



Overhaul


Servicing the front suspension-steering assembly, described below, deals mainly with replacing parts (pin- NADELLA roller bushings - sealing rings unit and dust gaiter) which connect the steering tube to the front wheel holder swinging hub.

N.B.

BEFORE PROCEEDING WITH THE DESCRIBED SERVICE, CHECK THAT THE STEERING TUBE AND THE WHEEL HOLDER HUB ARE IN EXCELLENT CONDITIONS: ONLY THEN IS THE SERVICE JUSTIFIABLE. MOREOVER, REMEMBER THE STEERING TUBE SHOULD BE REPLACED WITH A NEW ONE WHEN DEFORMED.

a = Ø 12 Punch

b = Sharp-edged end




Use a suitable punch with the dimensions indicated on the figure; hit with a mallet until the wedging washer is crushed and then extract it with the help of a pointed end.

Repeat the operation for the second washer using the punch on the side opposite to the one shown in the figure.

Use the tool fitted with part 1 as shown in the figure and move the tool handgrip until the pin and the NADELLA are simultaneously ejected in the direction opposite the tool thrusting force.

After removing the pin and the first NADELLA, the swinging hub gets detached from the steering tube.



To remove the second NADELLA, use the tool fitted with part 2 instead of part 1, on the side opposite the one shown in the figure.

N.B.

DURING THE REMOVAL OPERATIONS DESCRIBED ABOVE, THE ROLLER BUSHINGS ARE DESTROYED WHEN THE EXTRACTOR IS USED. UPON REFITTING, IT IS THEREFORE NECESSARY TO USE NEW BUSHINGS AS WELL AS A NEW PIN, NEW SEALING RINGS AND DUST GAITER.

Specific tooling

020021Y Front suspension service tool

Connect the swinging hub to the steering tube with the guiding pin.

- Use the tool fitted with part 3 on the stem and part 4.

Lubricate the pin with recommended grease and insert it temporarily on the swinging hub, move the tool handgrip until part 3 is fully inserted on the steering tube.

After fitting the pin, insert the two spacers, slightly hitting them with the mallet.

N.B.

BEFORE PROCEEDING WITH THE DESCRIBED FITTING, PLACE THE TWO DUST GAITER RINGS ON THE SWINGING HUB AS SHOWN IN THE FIGURE.

Specific tooling

020021Y Front suspension service tool



Recommended products

AGIP GREASE SM 2 Gray black smooth-textured lithium grease, containing molybdenum disulphide.

-

Insert the sealing ring on the pin and the roller bushing with its wedging washer at the same time.

- Remove the tool and the part 5 (guide), which has been partially ejected during the previous pin fitting phase, and leave part 4 always fitted.
- Replace part 3 with part 16 (on the stem).
- By moving the tool handgrip, push the wedging washer - roller bushing - seal ring unit, placing part 16 until it stops on the swinging hub.



- Repeat the above operation using the tool with part 16 and part 22, instead of part 4, always fitted to the stem, on the side opposite that indicated in the figure to fit the second wedging washer - roller bushing - sealing ring unit.

WARNING

BEFORE PROCEEDING WITH THE DESCRIBED PRE-FITTING, DIP THE SEALING RINGS IN MINERAL OIL AND THE "NADELLA" ROLLER BUSHINGS (PREVIOUSLY WASHED IN PURE PETROL OR NEUTRAL PETROLEUM TO ELIMINATE THE ANTIRUST PROTECTION), HALF-FILLED WITH GREASE.

Specific tooling


020021Y Front suspension service tool

Recommended products

AGIP GREASE MU3 Yellow-brown, lithium-base, medium-fibre multipurpose grease.

ISO L-X-BCHA 3 - DIN 51 825 K3K -20

- Use the tool fitted with part 20 on its stem and part 21 on the tool base as shown in the figure.
- By moving the tool handgrip, push the two NADELLA bushings until their internal bottoms make contact with the pin end.
- Use the tool fitted with parts 3 and 4 to fit the pin, and press moving the tool handgrip, until wedging the washers on the swinging hub.
- Now, remove the two spacers (parts 17 and 16) and, once the space between the NADELLAs - steering tube and swinging hub - has been fully filled with grease, move the dust gaiter rings until they are placed in that space.
- By wedging the washers as described above, the front suspension unit refitting stage is finished.

**Recommended products**

AGIP GREASE MU3 Yellow-brown, lithium-base, medium-fibre multipurpose grease.

ISO L-X-BCHA 3 - DIN 51 825 K3K -20

Refitting**CAUTION**

USE NEW ROLLER CASINGS, PIN, SEALING RINGS AND DUST GUARDS FOR REFITTING.

When fitting the fork, lubricate with the steering bearing tracks with the recommended grease. Tighten the lower ring nut "A" and the upper ring nut "B" to the specified torque


Recommended products

AGIP GREASE PV2 Ivory smooth-textured, slightly-stringy anhydrous calcium-base grease.

TL 9150 066, symbol NATO G 460


Locking torques (N*m)

Steering lower ring nut 8 ÷ 10 **Steering upper ring nut** 35 to 40


**Front shock absorber**

Removal


- Support the vehicle adequately.
- Remove the wheel hub.
- Loosen the shock absorber lower clamps and remove the brake calliper shock absorber mounting.



- Loosen the screws fixing the front brake pipe retainer clamp and the odometer cable in order to reach the upper clamps.



- Unscrew the upper fixing nuts.



- Remove the front shock absorber.



Refitting

To refit, carry out the removal operations in reverse order, observing the prescribed tightening torques.

Locking torques (N*m)

shock absorber lower clamping 20 - 27 shock absorber upper clamp 20 to 30

Shock-absorber - calliper bracket

Removal

- Remove the front wheel hub with the brake disc
- Remove the front shock absorber lower clamps



- Remove the bracket locking Seeger ring
- Unscrew the bracket



- Before refitting the bracket in the wheel axle, place the O-ring as shown in the photograph so that it is correctly placed after fitting the bracket.
- Refit the washer and the Seeger ring.
- Refit the lower screws fixing the shock absorber to the bracket and tighten at the prescribed torque



Locking torques (N*m)

Shock absorber lower clamping 20 to 27

Overhaul

- The bracket for the shock absorber -calliper attachment has two roller bearings separated one from the other as shown in the photograph



- Remove the two roller bearings from the bracket with the specific tool operating on the shock absorber attachment side as shown in the photograph

Specific tooling

020376Y Adaptor handle

020441Y 26 x 28 mm adaptor

020365Y 22 mm guide



- Remove the oil seal on the wheel hub side with the screwdriver as shown in the photograph



- Suitably hold the brake calliper - shock absorber attachment bracket
- Fit a new oil seal and move it until it stops using the specific tool

Specific tooling

020376Y Adaptor handle

020360Y 52 x 55-mm Adaptor



-
- Assemble a new roller bearing on the shock absorber side and move it until it stops using the specific tool

Specific tooling**020036Y Punch**

-
- Suitably hold the brake calliper - shock absorber attachment bracket
 - Assemble a new roller bearing on the wheel hub side and move it until it stops using the specific tool

Specific tooling**020037Y Punch**

Refitting

-
- Refit the parts in reverse order of the removal operation.


CAUTION

BEFORE CARRYING OUT REFITTING OPERATIONS IN THE AREAS MARKED WITH AN ASTERISK, LUBRICATE THEM WITH THE RECOMMENDED PRODUCT

Specific tooling**020036Y Punch****020037Y Punch****Recommended products**

AGIP GREASE PV2 Ivory smooth-textured, slightly-stringy anhydrous calcium-base grease.

TL 9150 066, NATO G 460 symbol



Steering bearing

Removal

-
- Use the specific tool both to remove the lower seat of the upper bearing and to remove the upper seat of the lower bearing fitted on the chassis.

N.B.

TO REMOVE THE LOWER SEAT OF THE LOWER STEERING BEARING JUST USE A SCREW-DRIVER AS A LEVER BETWEEN THE SEATING AND THE SLEEVE.

Specific tooling

020004Y Punch for removing steering bearings from headstock

- Remove the fifth wheel fitting and the dust gaiter on the steering bearing as shown in figure, using the specific tool. Proceed giving a few taps with the mallet.



Specific tooling

020004Y Punch for removing steering bearings from headstock

- Refit the fifth wheel fitting and the dust gaiter on the steering bearing until they stop, using the specific tool.

Specific tooling

006029Y Punch for fitting steering bearing seat on steering tube



Rear

Removing the rear wheel

- Remove the silencer.
- Remove the cotter pin and remove the cap.



- Unscrew the nut fixing the wheel axle and collect the washer.




Refitting the rear wheel

- To refit, follow the removal steps but in reverse order; be careful to tighten to the prescribed torque.

Locking torques (N*m)

Locking torque 137 to 152 Nm




Swing-arm




Removal


- Support the vehicle adequately.
- Remove the central tunnel inspection door.
- To remove the upper clamp from the chassis, proceed as follows:
- Unscrew the pin and collect the washer.




- Remove the cap from the lower part.




- Collect the lower fixing nut and collect the washer.



- Working on both sides, remove the cover caps.




- Working on the right side, unscrew the side fixing nut to the chassis and collect the washer.



- Working on the left side, remove the pin.



- Remove the spoiler terminal from both sides.
- Working on the right side, unscrew the fixing nut.



- Working on the left side, release the pin from the spring shown.



- Remove the fixing pin to the engine and collect the spacer.
- Now the swinging arm is free.




- Remove the swinging arm from the vehicle; first release it from the engine side and then from the chassis side.



Overhaul

- Check that the silent-blocks are in good conditions.
- Otherwise, replace the swinging arm.




Refitting

- To fit, follow the removal steps but in reverse order; be careful to tighten to the prescribed torques.

Locking torques (N*m)

Part A 33 to 41 **Part B** 44 to 52 **Part C** 33 to 41




Shock absorbers

Removal

- Adequately support the rear part of the vehicle.
- Remove the battery.
- Undo the indicated upper fixing screw to the chassis.



- Unscrew the lower fixing pin to the transmission crankcase.



Refitting

- To fit, follow the removal steps but in reverse order; be careful to tighten to the prescribed torques.

Locking torques (N*m)

Shock absorber/engine pin torque 33 to 41 N·m Shock absorber/chassis nut torque 20 - 25 Nm

Centre-stand

REMOVAL

- Use a jack to support the vehicle properly.
- Remove the two return springs from the centre stand.
- Undo the nut shown in the figure.
- Remove the pin from the right side.
- Remove the centre stand.



FITTING

- On refitting tighten the nut to the specified torque.

Locking torques (N*m)

Centre stand screw 32 to 40

INDEX OF TOPICS

BRAKING SYSTEM

BRAK SYS


Front brake calliper

Removal

- Remove the front wheel.
- Remove the two screws fixing the brake calliper to the mounting bracket, then remove the brake calliper with the pipe from the disc.
- Remove the brake pad retention pin snap ring.
- Remove the brake pad retention pin using a plug.
- Complete the extraction of the protection cover, the springs and the pads.

N.B.

IF BRAKE CALLIPER REPLACEMENT IS NEEDED, BEFORE REMOVING THE CALLIPER CLAMPS TO THE MOUNTING BRACKET, LOOSEN THE OIL JOINT FITTING.



Refitting

- Insert the brake pads in the calliper.
- Insert the pad fixing pin and the retention screw being careful to position the terminals of it pointing towards the bleed screw as shown in the photo.
- Insert the clip on the pad fixing pin

N.B.

FAILURE TO RESPECT THE PAD POSITIONING REQUIREMENTS WITH RESPECT TO THE DIRECTION OF ROTATION COULD COMPROMISE PROPER BRAKE FUNCTIONING AND NOISELESSNESS.





- Keep the brake pads in contact with the pistons and insert the calliper in the brake disc.
- Fix the calliper to the mounting bracket with the two screws with spring washer to the prescribed torque



- If it is disconnected, fasten the brake pipe joint to the calliper and tighten to the prescribed torque
- Purge the circuit and refit the front wheel


Locking torques (N*m)

Brake calliper mounting clamping 20 to 25 Nm Brake pipe connection 20 to 25 N•m

Front brake disc

Removal

- Remove the front wheel
- Remove the front brake calliper
- Remove the hub and the disc operating on the wheel axle nut
- Adequately support the hub with the disc and operating on the five screws shown in the photograph, remove the brake disc




Refitting

- Carry out the operations in the reverse order from the removal being careful to respect the direction of disc rotation shown by the arrow printed on it
- Tighten the 5 screws to the specified torque

Locking torques (N*m)

Brake disc screws: 6 +0.5 -1 Nm



Disc Inspection

- Remove the front wheel
- Use a micrometer to check the disc thickness as shown in the photograph
- Repeat the measurement in at least 6 points on the disk
- Remove the front brake calliper
- In order to secure the appropriate tool adequately use a metal plate with M8 threaded hole and fix it to one of the two front brake calliper attachment points
- Place the dial gauge on the disk outer edge
- Make the wheel hub turn and check the disk deviation



Specific tooling

020335Y Magnetic mounting for dial gauge

Characteristic

Standard thickness:

4 +0.2-0.2 mm


Max. deviation allowed:

0.1 mm


Front brake pads

Removal

- Remove the front wheel
- Remove the brake calliper
- Remove protection cover, the pin and the spring
- Remove the brake pads
- Check that there are no faults or warping. If there are, replace them.
- Check that the thickness of the friction material is more than 1.5 mm. Otherwise, replace it.
- The replacement must be made with greater residual thickness if the brake pad has not worn



evenly. A 0.5 mm thickness difference in the residual friction material is permitted



Refitting


- Insert the brake pads
- Insert the fixing pin being careful to position the clip with the ends towards the bleed screw as in the photo.
- Insert the lock on the bolt and then the protection cover
- Fix the brake calliper to the bracket and tighten the two screws to the specified torque.

CAUTION

BEFORE USING THE BRAKE, OPERATE THE LEVER A FEW TIMES.

Locking torques (N*m)

Rear brake calliper tightening screw 20 to 25 Nm



Fill

Front

- Remove the rubber cap from the bleed screw.
- Insert a rubber pipe in the bleed screw to permit the brake fluid to be recovered.
- With the right-hand brake lever, load the system and bring it up to the required pressure.
- Keeping the right-hand brake lever pulled, loosen the bleed screw to purge the air. Then tighten the bleed screw
- Release the brake lever
- Repeat the operation until only brake fluid comes out of the rubber pipe.
- Remove the fluid recovery pipe and refit the rubber cap over the bleed screw.
- Top up the brake fluid to the right level in the reservoir.



If necessary, bleeding can be done using a special vacuum pump

N.B.

DURING PURGING FREQUENTLY CHECK THE LEVEL TO PREVENT AIR GETTING INTO THE SYSTEM THROUGH THE PUMP.

N.B.

DURING THE BLEEDING OPERATIONS, MAKE SURE THE BRAKE FLUID DOES NOT COME INTO CONTACT WITH THE BODYWORK SO AS NOT TO DAMAGE IT. FURTHERMORE, DURING THE BLEEDING OPERATIONS REGARDING THE BRAKE CALLIPERS, MAKE SURE THE BRAKE FLUID DOES NOT COME INTO CONTACT WITH THE DISC BRAKES AND WITH THE BRAKE PADS. FAILURE TO OBSERVE THIS PRECAUTION WILL ENDANGER THE PROPER WORKING AND EFFICIENCY OF THE BRAKING SYSTEM

Specific tooling

020329Y Mity-Vac vacuum-operated pump

Locking torques (N*m)

System bleed calliper fitting: 20 to 25 Nm

Brake fluid level check

- Rest the vehicle on its centre stand on flat ground.
- The brake fluid reservoir has a sight glass «A» made of transparent material; the quantity of liquid contained in the sight glass indicates the level of fluid in the reservoir.
- When the sight glass «A» is full, the level inside the reservoir is above the MIN level; when it is partially full, the level has dropped to the MIN level;



when it is fully empty, the level of fluid in the reservoir is below the MIN level.

N.B.



THE LEVEL TENDS TO DROP AS THE BRAKE PADS GET WORN, A MINIMUM LEVEL SHOULD NOT BE REACHED. IF THE LEVEL IS TOO LOW, CHECK AND FIX THE SYSTEM SEALS, IF REQUIRED. TOP UP THE PUMP RESERVOIR, IF REQUIRED, CONSIDERING THAT THE "MAX." LEVEL MUST ONLY BE OBTAINED WITH NEW PADS.

- Under standard climatic conditions, replace fluid as indicated in the scheduled maintenance table.
-

Front brake pump

Removal

- Remove the two screws fixing the brake pump to the handlebar indicated in the photograph
- Remove the oil pipe joint from the pump
- Remove the connector from the stop lights switch



Refitting

For the refit, carry out the operations in the reverse order from which they were removed, observing the tightening torques and installing the collar with the word "UP" upwards.


Locking torques (N*m)

Oil pipe joint to the pump: 20 - 25 Brake pump fixing screws to the handlebar: 7 to 10 Nm

Rear drum brake

Once the silencer and the wheel have been removed, follow these steps:

1. Remove the shoe springs using the specific spanner.
2. Remove the shoe with the aid of a lever.
3. Refit the new shoes giving a few taps with the mallet.
4. Attach the springs using the specific pliers.



Specific tooling

020325Y Pliers for brake-shoe springs

INDEX OF TOPICS


CHASSIS

CHAS


Seat

Remove the saddle opening cable

Remove the four screws shown in the figure and the rear seat from the chassis saddle.




Unscrew the two screws of saddle fixing hook cover.




To remove the cable and the sheath:

- Remove the elastic ring and unscrew the cable end from the seat on the saddle fixing hook.
- Remove the other end of the cable from the fixing seat on the locking block.




Instrument panel

- Remove the front central cover
- Remove the shield back plate
- Remove the two fixing screws of the instrument panel.




- Remove the odometer cable.
- Remove the connector of the electric connections from the instrument panel




Instrument panel lower shell

- Remove the instrument panel
- Remove the handlebar
- Remove the two screws indicated in the figure.




- Remove the screw indicated in the figure, placed under the handlebar light fitting



Headlight assy.


- Remove the four fixing screws from the light support.



- Collect the nut in correspondence with the rear screws.



- Undo the two screws fixing of the front frame.




- Disconnect the frame with headlight and the connections of the bulbs.
- Remove the chassis from the headlight body.




Knee-guard

- Unscrew the two screws shown in the figure placed under the front central cover.



- Remove the 3 screws shown in the figure, placed inside the glove-box; they can be reached opening the glove-box door.
- Remove the shield back plate by pulling it upwards.




Taillight assy.

- Undo the two fixing screws and remove the rear light unit.



- Undo the screw indicated and disconnect the connector.




Footrest


- Remove the leg shield back plate.
- Remove the side fairings.
- Remove the central tunnel inspection door.

From both sides, unscrew:


- The fixing screw at the back.




- The fixing screw on the central part.



- The fixing screw at the front.



- Remove the footrest.




Side fairings

- Undo the upper screw and the smallest lower screw.




- Detach the seats on the fairing.




License plate holder

- Remove the side fairings.
- Working on both sides, undo the two screws indicated.




- Remove the license plate light.




Air filter

- Remove the helmet compartment.
- Remove the side fairings.
- Undo the two indicated clamps to the crankcase.




- Undo the two clamps indicated.



Front mudguard

- First remove the steering tube and uncouple the front brake pipes from the calliper in order to remove the front mudguard
- Remove the three mudguard-steering tube clamps indicated in the figure



Front central cover

- Remove the "PIAGGIO" clip-on badge
- Unscrew the screw indicated in the figure
- Remove the grille



INDEX OF TOPICS

PRE-DELIVERY

PRE DE

Aesthetic inspection

Appearance check:

- Paintwork
- Fitting of plastics
- Scratches
- Dirt

Tightening torques inspection

Lock check

- Safety fasteners
- Fixing screws

Safety fasteners:

- Rear shock absorber upper retainer
- Rear shock absorber lower clamping
- Front wheel axle nut
- Front wheel screws
- Wheel hub nut
- Front brake calliper fixing screws
- Swinging arm - chassis pin
- Engine-swinging arm pin
- Engine arm pin - Chassis arm
- Handlebar lock nut
- Lower steering ring nut
- Upper steering ring nut

Electrical system

Electrical system:

- Main switch
- Headlamps: high beam lights, low beam lights, tail and parking lights and their warning lights
- Adjusting the headlights according to the regulations currently in force
- Rear light, parking light, stop light
- Front and rear stop light switches
- Turn indicators and their warning lights
- Instrument panel lights
- Instrument panel: fuel gauge
- Instrument panel warning lights

- Horn

CAUTION

TO ENSURE MAXIMUM PERFORMANCE, THE BATTERY MUST BE CHARGED BEFORE USE. INADEQUATE CHARGING OF THE BATTERY WITH A LOW LEVEL OF ELECTROLYTE BEFORE IT IS FIRST USED SHORTENS THE LIFE OF THE BATTERY.

WARNING

KEEP SPARKS AND NAKED FLAMES AWAY FROM THE BATTERY WHILE RECHARGING. REMOVE THE BATTERY FROM THE VEHICLE, DISCONNECTING THE NEGATIVE TERMINAL FIRST.

CAUTION

WHEN INSTALLING THE BATTERY, ATTACH THE POSITIVE LEAD FIRST AND THEN THE NEGATIVE ONE.

WARNING

BATTERY ELECTROLYTE IS TOXIC AND IT MAY CAUSE SERIOUS BURNS. IT CONTAINS SULPHURIC ACID. AVOID CONTACT WITH YOUR EYES, SKIN AND CLOTHING.

IN CASE OF CONTACT WITH YOUR EYES OR SKIN, RINSE WITH ABUNDANT WATER FOR ABOUT 15 MINUTES AND SEEK IMMEDIATE MEDICAL ATTENTION.

IF IT ACCIDENTALLY SWALLOWED, IMMEDIATELY DRINK LARGE QUANTITIES OF WATER OR VEGETABLE OIL. SEEK IMMEDIATE MEDICAL ATTENTION.

BATTERIES PRODUCE EXPLOSIVE GASES; KEEP THEM AWAY FROM NAKED FLAMES, SPARKS AND CIGARETTES. IF THE BATTERY IS CHARGED IN A CLOSED PLACE, TAKE CARE TO ENSURE ADEQUATE VENTILATION. ALWAYS PROTECT YOUR EYES WHEN WORKING CLOSE TO BATTERIES.

KEEP OUT OF THE REACH OF CHILDREN

CAUTION

NEVER USE FUSES WITH A CAPACITY HIGHER THAN THE RECOMMENDED CAPACITY. USING A FUSE OF UNSUITABLE RATING MAY SERIOUSLY DAMAGE THE VEHICLE OR EVEN CAUSE A FIRE.

Levels check

Level check:

- Hydraulic braking system fluid level.
- Rear hub oil level
- Engine oil level

Road test

Test ride

- Cold start
 - Instrument operations
 - Response to the throttle control
 - Stability on acceleration and braking
 - Rear and front brake efficiency
 - Rear and front suspension efficiency
 - Abnormal noise
-

Static test

Static control after the test ride:

- Restarting when warmed up
- Minimum hold (turning the handlebar)
- Uniform turning of the steering
- Possible leaks

CAUTION

CHECK AND ADJUST TYRE PRESSURE WITH TYRES AT AMBIENT TEMPERATURE.

CAUTION

NEVER EXCEED THE RECOMMENDED INFLATION PRESSURES OR TYRES MAY BURST.

Functional inspection

Functional Checks:

Braking system (hydraulic)

- Lever travel

Braking system (mechanical)

- Lever travel

Clutch

- Proper functioning check

Engine

- Proper general functioning and no abnormal noise check

Others

- Check documentation
 - Check the chassis and engine numbers
 - Tool kit
 - License plate fitting
 - Check locks
 - Check tyre pressures
 - Installation of mirrors and any accessories
-

A

Air filter: 36, 270

B

Battery: 46, 64, 82, 93

Brake: 255, 256, 258, 260–262

Brake fluid: 260

C

Checks: 73

E

Engine oil: 37

F

Fuel: 187, 203

Fuses: 92

H

Headlight: 42, 266

Horn: 86

Hub oil: 35

I

Identification: 8

Instrument panel: 265

M

Maintenance: 7, 33

O

Oil filter: 39

R

Recommended products:

S

Shock absorbers: 252

Spark plug: 33

Suspension: 46

T

Transmission: 9, 45, 120, 131, 141

Turn indicators: 70

Tyres: 13

V

Vehicle: 8, 115, 116