



YAMAHA

PARTS LIST

www.legends-yamaha-enduros.com

MODEL

RT1

MODEL

RT1-M

ISO

SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.

YAMAHA MOTOR CO., LTD.

YAMAHA RT1/RT1-M



Instructions on Parts List

YAMAHA RT1/ RT1-M

1. **DIMENSIONS:** All dimensions are given in millimeters with the exception of steel balls which are given in inches.
2. **KEY TO SYMBOLS:**
 - R.H. Right hand side (Viewed from the rider's seat facing forward)
 - L.H. Left hand side (Viewed from the rider's seat facing forward)
 - S.R. Suggested retail price
 - UR Use size (thickness) and/or numbers as required
 - ☆ Government inspected parts
 - △ Not supplied as a single part
 - T Number of teeth in a gear
 - V Voltage for light bulbs
 - W Wattage for light bulbs
 - S "S" type oil seal
 - SD "SD" type oil seal
 - SO "SO" type oil seal
 - SW "SW" type oil seal
3. **COMPONENT PARTS:** Component parts of an assembly are preceded by a dot (.) as follows:

CARBURETOR ASS'Y

. JET, pilot	}	Component parts
. NOZZLE, main		
. JET, main		

Component parts which are mounted on either side of the m/c. are listed in the sequence:

- 3a).- Parts to be mounted on "LEFT SIDE" are listed first.-
- 3b).- Parts to be mounted on "RIGHT SIDE" are listed second.-
- 3c).- Parts which can be mounted on "EITHER SIDE" are listed next to the parts.-

You are requested to be very careful, when ordering, not to make a mistake in stating the part numbers, since only a single wrong figure will entirely change the contents and will cause you to receive quite a different part.

We believe that this introduction will prove a great help to you, but if you have any ambiguous point, please do not hesitate to contact us.

CONTENTS

ENGINE

Fig. 1	Crankcase	1
Fig. 2	Crankcase Cover	3
Fig. 3	Crank & Piston	5
Fig. 4	Clutch	7
Fig. 5	Transmission	9
Fig. 6	Shifter A	13
Fig. 7	Shifter B	15
Fig. 8	Kick	17
Fig. 9	Tachometer Gear	19
Fig. 10	Air Cleaner	21
Fig. 11	Carburetor	23
Fig. 12	Muffler	27
Fig. 13	Oil Pump	29
Fig. 14	Flywheel Magneto	31

CHASSIS

Fig. 15	Frame, Rear Cushion & Rear Fender.....	35
Fig. 16	Rear Arm & Chain Case	39
Fig. 17	Stand, Footrest & Rear Brake Pedal	41
Fig. 18	Front Fork & Front Fender	43
Fig. 19	Handle & Wire	49
Fig. 20	Fuel Tank	51
Fig. 21	Oil Tank	53
Fig. 22	Seat	55
Fig. 23	Front Wheel	57
Fig. 24	Rear Wheel	61
Fig. 25	Head Lamp & Speedometer	65
Fig. 26	Tail Lamp	69
Fig. 27	Electrical	71
Fig. 28	Flasher Lamp (Alternate Parts)	73

RT1-M

Fig. 29	Engine (Cylinder & Transmission)	77
Fig. 30	Engine (Carburetor & Exhaust)	79
Fig. 31	Chassis (Front Fork & Front Fender)	81
Fig. 32	Chassis (Front & Rear Wheel)	83


NUMERICAL INDEX

ENGINE

www.legenda-yamaha-enduros.com




Fig. 1 CRANKCASE



CRANKCASE

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
1- 1	275-15111-00	CASE, crank (L.H)		1		
1- 2	275-15121-00	CASE, crank (R.H)	(ISO)	1		
1- 3	91800-05016	PIN, dowel	8.5-12-16	2		
1- 4	92501-06065	SCREW, pan head		6		
1- 5	92501-06045	SCREW, pan head		5		
1- 6	92501-06060	SCREW, pan head		1		
1- 7	92501-06025	SCREW, pan head		1		
1- 8	214-15385-00	PLUG, blind		1		
1- 9	214-15492-00	COVER		1		
1-10	98501-05010	SCREW, pan head	(ISO)	2		
1-11	92901-05100	WASHER, spring		2		
1-12	120-15371-00	BREATHER		1		
1-13	248-15373-00	PIPE, breather	5-7-150	1		
1-14	137-15353-00	GASKET, drain plug	14.5-21-1.5	1		
1-15	214-15351-00	PLUG, drain 9034014034		1		
1-16	214-11361-00	BOLT, cylinder holding (1)	10-112	4		
1-17	275-11351-00	GASKET, cylinder		1		
1-18	275-11311-00	CYLINDER		1		
1-19	275-11181-00	GASKET, cylinder head		1		
1-20	275-11111-00	HEAD, cylinder		1		
1-21	275-11171-00	NUT, holding		4		
1-22	214-11175-00	WASHER, holding	15-26-2	4		
1-23	171-11161-00	ABSORBER		4		
1-24	214-11197-00	PLUG, blind		1		
1-25	214-11198-01	GASKET		1		
1-26	275-11179-00	BOLT, stud		4		
1-27	98801-08200	NUT	(ISO)	4		
1-28	92901-08200	WASHER, plain		4		

Fig. 2 CRANKCASE COVER




CRANKCASE COVER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
2- 1	233-15411-00	COVER, crankcase (1) (L.H)		1		
2- 2	233-15421-00	COVER, crankcase (2) (L.H)	(ISO)	1		
2- 3	233-15417-00	COVER, cap		1		
2- 4	98501-05015	SCREW, pan head	(ISO)	2		
2- 5	92501-06050	SCREW, pan head		3		
2- 6	92501-06050	SCREW, pan head		4		
2- 7	214-15451-01	GASKET, crankcase cover (L.H)		1		
2- 8	214-15461-00	GASKET, crankcase cover (R.H)		1		
2- 9	233-15431-00	COVER, crankcase (R.H)		1		
2-10	233-15416-00	COVER, oil pump		1		
2-11	92501-06030	SCREW, pan head		2		
2-12	214-15363-00	PLUG, oil		1		
2-13	92501-06065	SCREW, pan head		1		
2-14	92501-06030	SCREW, pan head		5		
2-15	92501-06040	SCREW, pan head		2		
2-16	91800-05016	PIN, dowel	8.5-12-16	2		

(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO

YAMAHA MOTOR CO., LTD. CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.

Fig. 3 CRANK & PISTON




CRANK & PISTON

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
3- 0-1	275-11400-00	CRANK ASS'Y		1		
3- 1	275-11412-00	. CRANK (L.H)		1		
3- 2	275-11422-00	. CRANK (R.H)		1		
3- 3	214-11651-00	. ROD, connecting 431-11651-00		1		
3- 4	275-11681-00	. PIN, crank		1		
3- 5	93310-42541	. BEARING, con-rod big end	25-31-20	1		
3- 6	275-11685-00	. WASHER, crank pin 90209	25.2-49-1	2		
3- 7	275-11631-00-96	PISTON (STD)	79.96mm	U.R 1		
	275-11631-00-97	PISTON (STD)	79.97mm			
	275-11631-00-98	PISTON (STD)	79.98mm			
	275-11631-00-99	PISTON (STD)	79.99mm			
	275-11635-00	PISTON (1st O/S)	80.25mm	1		
	275-11636-00	PISTON (2nd O/S)	80.50mm	1		
3- 8	93310-21824	BEARING, con-rod small end	18-22-22	1		
3- 9	275-11633-00	PIN, piston	18ø	1		
3-10	604-11634-00	CLIP, piston pin		2		
3-11	275-11601-00	PISTON RING SET (STD)		1s		
	275-11601-10	PISTON RING SET (1st O/S)		1s		
	275-11601-20	PISTON RING SET (2nd O/S)		1s		
3-12	93306-30602	BEARING	6306	2		
3-13	93420-72023	CIRCLIP	R-72	3		
3-14	93103-30044	OIL SEAL	SW-30-72-10	1		
3-15	214-11557-01	WASHER	12.2-22-2.9	1		
3-16	92901-12100	WASHER, spring		1		
3-17	214-11555-01	NUT, crank shaft	ISO	1		
3-18	93103-42045	OIL SEAL	SW-42-72-10	1		
3-19	214-16111-00	GEAR, primary drive	21T	1		
3-20	93210-25070	O-RING	3.2-24.5	1		
3-21	156-16174-00	NUT, lock		1		
3-22	92901-18100	WASHER, spring		1		
3-23	214-11545-01	KEY, woodruff 15x3x6MM	90280 05013			




Fig. 4 CLUTCH



CLUTCH

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
4- 0-1	275-16301-00	CLUTCH ASS'Y	(ISO)	1		
4- 1	214-16150-00	. PRIMARY DRIVENGEAR	65T	1		
4- 2	93211-20102	. O-RING	5.7-119.6	1		
4- 3	214-16371-01	. BOSS, clutch	(ISO)	1		
4- 4	214-16324-00	. PLATE, clutch (1)		1		
4- 5	168-16367-00	. RING, cushion		7		
4- 6	168-16321-00 360-16321-00	. PLATE, friction		7		
4- 7	168-16325-00	. PLATE, clutch (2)		7		
4- 8	214-16351-00	. PLATE, pressure		1		
4- 9	137-16333-00	. SPRING, clutch	90501-20122	6		
4-10	137-16337-01	. SCREW, spring	(ISO)	6		
4-11	174-16356-00	ROD, push		1		
4-12	93505-16006	BALL	5/16"	1		
4-13	156-16174-00	NUT, lock		1		
4-14	214-16119-00	SPRING, bellevile		1		
4-15	214-16181-00	SPACER		1		
4-16	93341-23305	BEARING		1		
4-17 ✓	170-16164-00	PLATE, thrust (2)	25-50-2	2		
4-18	170-16154-02	PLATE, thrust (1)	25.2-34-2	1		
4-19	214-16357-00	ROD, push	6.8-187	1		
4-20	214-16340-00	PUSH LEVER ASS'Y		1		
4-21	137-16345-00 90506-10020	SPRING, return		1		
4-22	132-16346-00	HOOK, spring		1		
4-23	214-16389-00	JOINT		1		
4-24	214-16379-00	PIN		1		
4-25	91401-10010	PIN, cotter		1		
4-26	214-16343-00 90513/09017	SCREW, adjusting		1		
4-27	214-16344-00 90179/08042 08179	NUT, adjusting		1		

Fig. 5 TRANSMISSION




TRANSMISSION

Ref No.	Parts No.	Parts Name	Description	Q'ty	S · R	Remarks
5- 1	214-17411-10	AXLE, main	15T	1		
5- 2	214-17141-10	GEAR, 4th pinion	26T	1		
5- 3	152-17226-00	WASHER, gear hold	25-32-1	1		
5- 4	93440-25019	CIRCLIP	25φ	2		
5- 5	214-17131-10	GEAR, 3rd pinion	23T	1		
5- 6	214-17216-00	WASHER, gear hold		1		
5- 7	214-17231-10	GEAR, 3rd wheel	30T	1		
5- 8	214-17121-10	GEAR, 2nd pinion	19T	1		
5- 9	132-17216-00	WASHER, gear hold	20-25-1	1		
5-10	93410-19015	CIRCLIP	S-19	1		
5-11	137-17427-00	SHIM	20.2-33-1	1		
5-12	93315-22004	BEARING	20-26-16	1		
5-13	93420-26024	CIRCLIP	R-26	1		
5-14	93109-07009	OIL SEAL	SDO-6.8-26	1		
5-15	156-17417-00-01	SHIM, main axle	25.1-31-0.1	U.R		
	156-17417-00-02	SHIM, main axle	25.1-31-0.2			
	156-17417-00-03	SHIM, main axle	25.1-31-0.3			
5-16	93306-20508	BEARING	6205Z	1		
5-17	93450-52014	CIRCLIP	52φ	1		
5-18	214-15631-00	GEAR, kick pinion	18T	1		
5-19	214-17421-00	AXLE, drive		1		
5-20	214-17481-00	PLUG, blind		1		
5-21	214-17221-10	GEAR, 2nd wheel	34T	1		
5-22	214-17131-10	GEAR, 3rd pinion	23T	1		
5-23	214-17231-10	GEAR, 3rd wheel	30T	1		
5-24	214-17241-10	GEAR, 4th wheel	26T	1		
5-25	214-17211-10	GEAR, 1st wheel	38T	1		
5-26	168-17116-00	WASHER, gear hold	20-30-1.5	1		
5-27	93410-19015	CIRCLIP	S-19	1		
5-28	93440-25019	CIRCLIP	25φ	3		
5-29	214-17216-00	WASHER, gear hold		3		
5-30	156-17429-00	SPACER, drive axle		2		
5-31	168-17428-01-03	SHIM, drive axle	25-34-0.3	U.R		
	168-17428-01-04	SHIM, drive axle	25-34-0.4			
	168-17428-01-05	SHIM, drive axle	25-34-0.5			
5-32	93306-30506	BEARING	6305NR	1		
5-33	93102-35054	OIL SEAL	SD-35-62-6	1		
5-34	214-17462-00	COLLAR, distance	25-35-15.5	1		



Fig. 5 TRANSMISSION




TRANSMISSION

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
5-35	214-17461-30	SPROCKET, drive	13T	1		S. T. D
	214-17461-40	SPROCKET, drive	14T	1		
	214-17461-50	SPROCKET, drive	15T	1		
	214-17461-60	SPROCKET, drive	16T	1		
5-36	156-17464-01	WASHER, lock		1		
5-37	152-17463-00	NUT, lock 90179.18020		1		
5-38	93306-20306	BEARING	6203	1		
5-39	93450-40001	CIRCLIP	40φ	1		
5-40	164-17417-00	SHIM	17.5-26-1	2		
5-41	214-15651-02	GEAR, kick idle 275-15651	23T	1		
5-42	93410-15005	CIRCLIP	S-15	1		

www.legends-yamaha-enduros.com

Fig. 6 SHIFTER A




SHIFTER A

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
6- 1	214-18531-00	BAR, shift fork guide		1		
6- 2	214-18512-00	FORK, shift (2)		1		
6- 3	214-18513-00	FORK, shift (3)		1		
6- 4	136-18551-00	ROLLER, cam follower	5-8-3.7	3		
6- 5	214-18552-00	PIN, cam follower		2		
6- 6	91401-25018	PIN, cotter		3		
6- 7	93430-10016	CIRCLIP	E-10	2		
6- 8	214-18541-01	CAM, shift	(ISO)	1		
6- 9	93604-14012	PIN, dowel	4-13.8	5		
6-10	214-18561-00	PLATE, side		1		
6-11	98701-05015	SCREW, flat head	(ISO)	1		
6-12	214-18511-00	FORK, shift (1)		1		
6-13	168-18552-00	PIN, cam follower		1		
6-14	214-18533-00	PLUG, blind		1		
6-15	137-18577-00	BOLT, stopper		1		
6-16	132-15353-00	GASKET	12.5-19-1.5	1		
6-17	137-18557-00	SPRING, cam stopper		1		
6-18	137-18547-00	STOPPER, cam		1		
6-19	214-18128-00	BRACKET		1		
6-20	214-18188-00	AXLE, bracket		1		
6-21	93430-09019	CIRCLIP	E-9	2		
6-22	214-18123-00	SPRING		1		
6-23	214-18152-00	LEVER, change (4)		1		
6-24	214-18151-00	LEVER, change (3)		1		
6-25	93430-07012	CIRCLIP	E-7	1		
6-26	214-18178-00	ROLLER, change lever (1)		1		
6-27	214-18179-00	GUIDE, change lever		1		
6-28	98501-05010	SCREW, pan head	(ISO)	2		
6-29	92901-05100	WASHER, spring		2		



Fig. 7 SHIFTER B




SHIFTER B

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
7- 1	214-18111-01	PEDAL, change		1		
7- 2	132-18113-01	COVER, change pedal		1		
7- 3	91101-06020	BOLT		1		
7- 4	214-18131-00	BOOT, sealing		1		
7- 5	93101-12004	OIL SEAL	S-12-22-5	2		
7- 6	214-18125-00	SHAFT, change		1		
7- 7	214-18124-00	SPRING, shaft return	90308 32052	1		
7- 8	214-18121-01	LEVER, change (1)		1		
7- 9	214-18186-00	SCREW, adjusting		1		
7-10	92801-06100	NUT		1		
7-11	92901-06100	WASHER, spring		1		
7-12	93430-10016	CIRCLIP	E-10	2		
7-13	150-18138-00	WASHER (2)	12,3-18-0.2	1		
7-14	214-18129-00	COVER, change shaft		1		
7-15	132-18133-00	SCREW, adjusting	90149-08094	1		
7-16	98801-08300	NUT	www.legends-yamaha-enduros.com	1		
7-17	214-18139-01	WASHER, lock	90215-08015	1		



Fig. 8 KICK




KICK

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
8- 0-1	275-15610-00-93	KICK CRANK ASS'Y		1		
8- 1	275-15611-00-93	. CRANK, kick		1		Not for sale
8- 2	214-15612-01	. LEVER, kick		1		
8- 3	214-15625-01	. SPRING, kick crank		1		
8- 4	214-15616-00	. WASHER, kick lever		1		
8- 5	214-15617-00	. CLIP, kick lever		1		
8- 6	214-15618-00	COVER, kick lever		1		
8- 7	97201-08030	BOLT	(ISO)	1		
8- 8	93101-20008	OIL SEAL	S-20-30-7	1		
8- 9	150-17219-00	SHIM (2)	20.2-28- 1	1		
8-10	93410-20009	CIRCLIP	S-20	2		
8-11	214-15676-00	COVER, spring		1		
8-12	214-15665-00	SPRING, kick		1		
8-13	214-15664-00	GUIDE, spring		1		
8-14	214-15661-00	AXLE, kick		1		
8-15	214-15641-01	GEAR, kick	24T	1		
8-16	168-15653-00	WASHER		2		
8-17	132-17414-00	CLIP		1		
8-18	214-15671-01	WHEEL, ratchet		1		
8-19	168-15675-00	SPRING, ratchet wheel		1		
8-20	168-15676-00	COVER, spring	15.2-31-1.6	1		
8-21	93410-15005	CIRCLIP	S-15	1		
8-22	132-15644-00	SHIM (1)	15.7-24-1.2	1		
8-23	214-15668-00	STOPPER		1		
8-24	214-15674-00	GUIDE, ratchet wheel		1		
8-25	214-15686-00	WASHER, lock		1		
8-26	214-15684-00	SCREW, ratchet wheel guide		2		



Fig. 9 TACHOMETER GEAR




TACHOMETER GEAR

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
9- 1	214-17861-00	AXLE, drive gear		1		
9- 2	93430-09019	CIRCLIP	E-9	2		
9- 3	214-17837-00	SHIM	10.2-16-1	2		
9- 4	214-17830-00	DRIVE GEAR ASS'Y		1		
9- 5	214-17811-01	HOUSING		1		
9- 6	214-17841-01	GEAR, driven		1		
9- 7	93210-13016	O-RING	1.8-13	1		
9- 8	93210-07100	O-RING	2.2-7.2	1		
9- 9	214-17847-00	SHIM	2.5-10.8-0.4	1		
9-10	214-17815-00	BUSHING		1		
9-11	214-17812-00	STOPPER		1		
9-12	91201-06010	BOLT		1		
9-13	92901-06100	WASHER, spring		1		
9-14	214-17843-00	BUSHING		1		

www.legends-yamaha-enduro.com



Fig. 10 AIR CLEANER



AIR CLEANER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
10- 1	275-14411-00	CASE, cleaner		1		
10- 2	214-14451-02	ELEMENT		1		
10- 3	214-14458-00	GUIDE		1		
10- 4	275-14412-00	CAP, cleaner case		1		
10- 5	92501-06010	SCREW, pan head		4		
10- 6	92901-06100	WASHER, spring		4		
10- 7	214-21717-00	DAMPER, battery box		1		
10- 8	214-21633-00	COLLAR, fender mount		1		
10- 9	91201-06020	BOLT		1		
10-10	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	1		
10-11	214-14455-01	BAND	(ISO)	1		
10-12	275-14453-00	JOINT		1		
10-13	214-14455-01	BAND	(ISO)	1		
10-14	275-13555-00	JOINT		1		
10-15	275-13556-00	GASKET		2		
10-16	214-13558-00	STUD	8-67	2		
10-17	98801-08100	NUT	(ISO)	2		
10-18	92901-08100	WASHER, spring		2		
10-19	137-21778-00	DAMPER, oil tank		1		




www.legends-quadrifla-enduros.com



CARBURETOR

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
11- 0-1	275-14101-60	CARBURETOR ASS'Y	(ISO)	1		
11- 1	193-14142-30	. JET, pilot	#30 (ISO)	1		
11- 2	239-14190-33	. VALVE SEAT ASS'Y	#3.3	1		
11- 3	136-14195-00	. WASHER, valve seat		1		
11- 4	275-14141-34	. NOZZLE, main	O-4	1		
11- 5	214-14145-00	. SETTER, needle jet		1		
11- 6	137-14153-00	. WASHER, main jet		1		
11- 7	214-14147-00	. O-RING		1		
11- 8	137-14143-44	. JET, main	#220	1		S. T. D
	137-14143-46	. JET, main	#230	1		
	137-14143-48	. JET, main	#240	1		
	137-14143-50	. JET, main	#250	1		
11- 9	214-14166-00	. BOLT, banjo		1		
11-10	214-14198-00	. GASKET		1		
11-11	275-14185-00	. FLOAT		2		
11-12	214-14187-00	. ARM, float		1		
11-13	127-14186-00	. PIN, float		1		
11-14	168-14184-00	. GASKET, float chamber		1		
11-15	275-14181-00	. BODY, float chamber		1		
11-16	275-14112-15	. VALVE, throttle	#1.5	1		
11-17	275-14116-01	. NEEDLE	6DP01	1		
11-18	164-14137-00	. CLIP		1		
11-19	239-14136-00	. SEAT, spring		1		
11-20	275-14131-00	. SPRING, throttle valve		1		
11-21	239-14158-00	. TOP, mixing chamber		1		
11-22	137-14133-00	. SPRING, throttle stop		1		
11-23	204-14122-00	. SCREW, throttle		1		
11-24	802-14161-00	. NUT, wire adjusting		1		
11-25	127-14124-20	. SCREW, wire adjusting		1		
11-26	802-14169-00	. CAP		1		
11-27	127-14134-00	. SPRING, air adjusting		1		
11-28	152-14123-00	. SCREW, air adjusting		1		
11-29	174-14171-00	. PLUNGER, starter		1		
11-30	256-14135-00	. SPRING, plunger		1		
11-31	275-14178-00	. PLATE, starter lever		1		
11-32	275-14175-00	. LEVER, starter	(ISO)	1		
11-33	214-14118-00	. CAP		2		
11-34	802-14174-00	. CAP, plunger		1		

Fig. 11 CARBURETOR




CARBURETOR

Ref No.	Parts No.	Parts Name	Description	Q'ty	S · R	Remarks
11-35	802-14173-00	. COVER, plunger cap		1		
11-36	183-14197-00	. PIPE, overflow	3φ-5φ-100	1		
11-37	214-14197-00	. PIPE, air vent	3φ-5φ-140	1		
11-38	132-14146-00	. PLATE		1		
11-39	98501-04015	. SCREW, pan head	(ISO)	4		
11-40	92901-04100	. WASHER, spring		4		
11-41	93201-37140 10	. O-RING		1		

www.legends-yamaha-enduros.com



Fig. 12 MUFFLER




MUFFLER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
12- 1	275-14610-30	EXHAUST PIPE ASS'Y		1		
12- 2	275-14753-30	. SILENCER 4.50		1		
12- 3	275-14752-30	. PIPE, outlet 3.50		1		
12- 4	92501-06010	. SCREW, pan head		1		
12- 5	92901-06100	. WASHER, spring		1		
12- 6	92901-06200	. WASHER, plain		1		
12- 7	214-14718-00	PROTECTOR		1		
12- 8	91903-06012	SCREW, bind		4		
12- 9	214-14766-00	WASHER, protector	6.2-12-3	4		
12-10	178-14766-00	WASHER, protector	6.2-12-1.5	4		
12-11	214-14613-00	GASKET, exhaust pipe		1		
12-12	214-14612-00	NUT, ring		1		
12-13	91102-06020	BOLT		2		
12-14	92901-06100	WASHER, spring		2		
12-15	214-14683-01	SPRING, hook 90506-12029		2		
12-16	214-14763-02	SPACER		1		
12-17	214-14793-01	PLATE, muffler		1		
12-18	214-14794-00	PLATE, muffler (2)		1		
12-19	91201-06035	BOLT		1		
12-20	92901-06100	WASHER, spring		1		
12-21	214-14771-00	STAY, muffler		1		
12-22	91201-06015	BOLT		1		
12-23	92901-06100	WASHER, spring		1		
12-24	92901-06200	WASHER, plain		1		
12-25	214-21635-00	NUT, crown		1		



Fig. 13 OIL PUMP




OIL PUMP

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
13- 1	126-13116-00	GASKET, pump case		1		
13- 2	275-13175-00	SHAFT, worm		1		
13- 3	93603-22028	PIN, dowel	3-22	1		
13- 4	137-13176-00	METAL, worm shaft outer		1		
13- 5	93101-10002	OIL SEAL	S-10-22-7	1		
13- 6	93430-08006	CIRCLIP	E-8	1		
13- 7	102-18138-00	WASHER	10.2-24-1	1		
13- 8	214-13178-01	GEAR, pump drive	20T	1		
13- 9	92901-08400	WASHER, tooth		1		
13-10	98801-08300	NUT	(ISO)	1		
13-11	98501-05015	SCREW, pan head	(ISO)	2		
13- 0-1	275-13101-00	OIL PUMP ASS'Y	(ISO)	1		
13-12	275-13110-00	. PUMP CASE ASS'Y	(ISO)	1		Not for sale
13-13	137-13137-00	. SHIM, plunger	5.8-10-0.1	1		
13-14	137-13138-01	. PLATE, adjusting		1		
13-15	92901-05100	. WASHER, spring		1		
13-16	98801-05200	. NUT	(ISO)	1		
13-17	93101-10001	. OIL SEAL	S-10-21-5	1		
13-18	137-13128-00	. PLATE, starter		1		
13-19	91401-12018	. PIN, cotter		1		
13-20	98901-04008	. SCREW, bind	(ISO)	1		
13-21	137-13187-00	. GASKET, breather	4.2-8.5-0.5	1		
13-22	93505-32002	. BALL	5/32"	1		
13-23	137-13169-00	. SPRING, check ball		1		
13-24	137-13167-00	. GASKET, banjo bolt	6-13-0.5	2		
13-25	137-13165-00	. BOLT, banjo		1		
13-26	214-13161-01	. PIPE, delivery		1		
13-27	214-13162-00	. BANJO, delivery pipe		2		
13-28	214-13164-00	. CLIP, delivery pipe		2		
13-29	137-13167-00	GASKET, banjo bolt	6-13-0.5	2		
13-30	137-13165-00	BOLT, banjo		1		
13-31	214-13174-01	HOLDER, oil pipe		1		



Fig. 14 FLYWHEEL MAGNETO



FLYWHEEL MAGNETO

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
14- 0-1	275-81300-20	FLYWHEEL MAGNETO ASS'Y	(ISO)	1		
14- 1	275-81350-20	. ROTOR ASS'Y		1		
14- 2	214-81312-21	. COIL, source		1		
14- 3	207-81313-20	. COIL, lighting (1)		1		
14- 4	275-81314-20	. COIL, lighting (2)		1		
14- 5	110-81348-20	. SCREW, pan head	(ISO)	6		
14- 6	92901-04100	. WASHER, spring		10		
14- 7	214-81321-20	. CONTACT BREAKER ASS'Y		1		
14- 8	110-81347-20	. SCREW, cylinder head	(ISO)	1		
14- 9	92901-04200	. WASHER, plain		1		
14-10	214-81326-20	. CONDENSER		1		
14-11	110-81346-20	. SCREW, pan head	(ISO)	2		
14-12	120-81331-20	. LUBRICATOR		1		
14-13	104-81328-20	. CLAMP, lead		1		
14-14	110-81345-20	. SCREW, pan head	(ISO)	1		
14-15	275-81332-20	. PLATE, timing		1		
14-16	92501-06015	SCREW, pan head		3		
14-17	92901-06100	WASHER, spring		3		

(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.




YAMAHA MOTOR CO., LTD.

CHASSIS

www.legends-yamaha-enduros.com




Fig. 15 FRAME, REAR CUSHION & REAR FENDER



FRAME, REAR CUSHION & REAR FENDER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
15- 1	275-21110-00-33	FRAME COMP.	(ISO)	1		
15- 2	214-21471-00	PROTECTOR, engine		1		
15- 3	214-21433-00	BRACKET, protector front		2		
15- 4	91201-06012	BOLT		2		
15- 5	92901-06100	WASHER, spring		2		
15- 6	214-21483-00	BOLT, engine mounting (3)	10 ϕ -109	1		
15- 7	214-21494-00	NUT		2		
15- 8	92901-10100	WASHER, spring		2		
15- 9	214-21481-00	BOLT, engine mounting (1)	8 ϕ -114	1		
15-10	214-21482-00	BOLT, engine mounting (2)	8 ϕ -197	1		
15-11	156-21483-00	BOLT, engine mounting	10 ϕ -165	1		
15-12	183-22143-00	NUT	(ISO)	2		
15-13	92901-08100	WASHER, spring		2		
15-14	275-21610-00-35	REAR FENDER COMP.		1		
15-15	214-21638-00	DAMPER, fender mount (1)		2		
15-16	214-21633-00	COLLAR, fender mount (1)		2		
15-17	91201-06025	BOLT		2		
15-18	92901-06100	WASHER, spring		4		
15-19	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	2		
15-20	275-21635-00	NUT, rear fender		2		
15-21	168-21615-00	WASHER, special	8-16-1	2		
15-22	168-21639-00	DAMPER, rear		2		
15-23	91201-06020	BOLT		2		
15-24	214-21240-10	BATTERY BOX COMP.		1		
15-25	214-21747-00	DAMPER, battery box (2)		1		
15-26	156-83524-00	WASHER, special		1		
15-27	156-83525-00	CLIP		1		
15-28	214-21717-00	DAMPER, battery box (1)		1		
15-29	214-21633-00	COLLAR, fender mount (1)		1		
15-30	92501-06025	SCREW, pan head		1		
15-31	92901-06100	WASHER, spring		1		
15-32	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	1		
15-33	214-21170-00-33	TOOL BOX COMP.		1		
15-34	214-21746-00	DAMPER, tool box		1		
15-35	214-28100-01	TOOL ASS'Y	(ISO)	1		☆
15-36	248-22210-71	REAR CUSHION ASS'Y		2		
15-37	214-22241-00	BOLT, rear cushion		2		
15-38	214-22241-00	BOLT, rear cushion		2		

Fig. 15 FRAME, REAR CUSHION & REAR FENDER




FRAME, REAR CUSHION & REAR FENDER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
15-39	214-21268-00	SEAL, battery box		1		
15-40	92902-06200	WASHER, plain		2		
15-41	214-21779-00	DAMPER, oil tank (2)		1		
						



Fig. 16 REAR ARM & CHAIN CASE





REAR ARM & CHAIN CASE

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
16- 1	275-22110-00-33	REAR ARM COMP.	(ISO)	1		
16- 2	275-22141-00	SHAFT, pivot ✓		1		
16- 3	150-22126-00	COLLAR, distance		1		
16- 4	150-22124-00	BUSHING (2) (95 90387-16226		2		
16- 5	148-22123-00	BUSHING (1) (35 90386-22018		2		
16- 6	156-22127-00	SHIM	19-30-0.3	U.R		
16- 7	150-22128-00	COVER, thrust		2		
16- 8	92901-14100	WASHER, spring		1		
16- 9	98801-14100	NUT	(ISO)	1		
16-10	214-22311-00-35	CHAIN CASE		1		
16-11	141-82596-00	GROMMET		3		
16-12	214-22317-00	SPACER, chain case	5-7-4.5	3		
16-13	98501-05010	SCREW, pan head	(ISO)	3		
16-14	136-22316-00	WASHER, chain case	5.5-14-1.0	3		
16-15	214-22318-01-33	GUARD, chain		1		
16-16	91201-06020	BOLT		1		
16-17	92801-06100	NUT		1		
16-18	92901-06100	WASHER, spring		1		
16-19	92901-06200	WASHER, plain		1		
16-20	97201-08015	BOLT	(ISO)	1		
16-21	92901-08100	WASHER, spring		1		
16-22	97201-08025	BOLT		1		
16-23	98801-08100	NUT	(ISO)	1		
16-24	92901-08100	WASHER, spring	(ISO)	1		
16-25	92901-08200	WASHER, plain		1		

(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.




Fig. 17 STAND, FOOT REST & REAR BRAKE PEDAL



STAND, FOOT REST & REAR BRAKE PEDAL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S · R	Remarks
17- 1	214-27411-00	FOOTREST		1		
17- 2	214-27421-00	FOOTREST		2		
17- 3	214-27413-00	COVER, footrest		2		
17- 4	214-27426-00	SPRING, return		2		
17- 5	214-27418-00	PIN, clevis		2		
17- 6	214-27417-00	WASHER, special	6.5-18-0.6	2		
17- 7	97101-08020	BOLT	(ISO)	2		
17- 8	92901-08100	WASHER, spring		2		
17- 9	214-27311-01	STAND, side		1		
17-10	278-27317-00	BOLT, side stand		1		
17-11	98803-10500	NUT, slotted		1		
17-12	91403-20025	PIN, cotter		1		
17-13	214-27316-00	SPRING		1		
17-14	214-27211-00-33	PEDAL, brake		1		
17-15	91201-06025	BOLT		1		
17-16	214-27212-00	SHAFT		1		
17-17	214-27213-00	COLLAR	20-24-31.5	1		
17-18	214-27216-00	SPRING, return		1		
17-19	275-27231-00	ROD, brake		1		
17-20	248-27228-00	PIN, link joint		1		
17-21	92901-06200	WASHER, plain		1		
17-22	91401-25012	PIN, cotter		1		


Fig. 18 FRONT FORK & FRONT FENDER



FRONT FORK & FRONT FENDER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
18- 0-1	275-23100-60-42	FRONT FORK ASS'Y		1		
18- 1	275-23126-60-35	. TUBE, outer (L.H)	(ISO)	1		
18- 2	275-23136-60-35	. TUBE, outer (R.H)	(ISO)	1		
18- 3	264-23170-60	. CYLINDER COMP.		1		
18- 4	214-23141-00	. SPRING, fork		2		
18- 5	275-23157-60	. RING, piston		4		
18- 6	275-23124-60	. TUBE, inner		2		
18- 7	214-23142-00	. SEAT, spring upper		2		
18- 8	264-23118-60	. SPACER		2		
18- 9	275-23125-60	. METAL, slide		2		
18-10	156-23147-00	. O-RING		2		
18-11	214-23150-00	. OUTER NUT COMP.		2		
18-12	168-23145-50 214-23145-50	. . OIL SEAL		2		
18-13	214-23155-00	. SEAL, dust		2		
18-14	214-23165-00	. WASHER		2		
18-15	214-23144-01	. SEAL, dust		2		
18-16	275-23122-60	. COVER, outer		2		
18-17	214-23163-00	. PACKING (lamp stay)		2		
18-18	214-23116-00	. GUIDE, cover under		2		
18-19	214-23121-01-33	. COVER, upper (L.H)		1		
18-20	214-23131-01-33	. COVER, upper (R.H)		1		
18-21	214-23115-00	. GUIDE, cover upper		2		
18-22	214-23114-00	. PACKING (O-ring)		2		
18-23	214-23112-00	. WASHER, cap		2		
18-24	264-23111-60	. BOLT, cap		2		
18-25	275-23340-60-33	. UNDER BRACKET COMP.		1		
18-26	275-23346-60	. BOLT, under bracket		4		
18-27	92901-08100	. WASHER, spring		4		
18-28	91311-08020	. BOLT		2		
18-29	214-23158-00	. PACKING		2		
18-30	122-23119-01	. PLUG, drain	(ISO)	2		
18-31	122-23129-00	. GASKET, drain plug		2		
18-32	97201-08030	. BOLT	(ISO)	1		
18-33	92901-08100	. WASHER, spring		1		
18-34	214-23318-00	. HOLDER, wire		1		
18-35	164-23462-00	SEAL, dust		1		
18-36	156-23411-00	RACE, ball (1)		1		
18-37	156-23412-00	RACE, ball (2)		1		

Fig. 18 FRONT FORK & FRONT FENDER




FRONT FORK & FRONT FENDER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
18-38	93501-04011	BALL	1/4"	19		
18-39	122-23411-00	RACE, ball (1)		1		
18-40	122-23412-00	RACE, ball (2)		1		
18-41	93503-16010	BALL	3/16"	22		
18-42	122-23416-00	COVER, ball race		1		
18-43	137-23454-00	NUT, fitting		1		
18-44	275-23435-00	CROWN, handle		1		
18-45	97103-08045	BOLT	(ISO)	1		
18-46	98803-08700	NUT, crown	(ISO)	1		
18-47	92901-08100	WASHER, spring		7		
18-48	97103-08030	BOLT	(ISO)	2		
18-49	214-23443-00	WASHER, crown		1		
18-50	214-23451-00	BOLT, steering fitting		1		
18-51	141-23427-00	WASHER		1		
18-52	156-23418-00	WASHER, special	6.5-18-0.6	1		
18-53	214-23419-01	SHAFT, damper	(ISO)	1		
18-54	214-23441-00	HOLDER, handle upper		2		
18-55	97103-08030	BOLT	(ISO)	4		
18-56	214-23422-01	PLATE, damper (2)		1		
18-57	214-23421-02	PLATE, damper (1)	(ISO)	1		
18-58	214-23423-00	PLATE, damper (3)		1		
18-59	156-83525-00	CLIP		1		
18-60	91401-20015	PIN, cotter		1		
18-61	214-21510-00-35	FRONT FENDER COMP.		1		
18-62	214-21512-00	BRACKET, fender		1		
18-63	214-21513-00	STAY, fender (L.H)		1		
18-64	214-21514-00	STAY, fender (R.H)		1		
18-65	214-21717-00	DAMPER, battery box		5		
18-66	214-21633-00	COLLAR, fender mount		5		
18-67	91201-06020	BOLT		5		
18-68	92801-06100	NUT		4		
18-69	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	5		
18-70	91201-06012	BOLT		4		
18-71	92901-06100	WASHER, spring		4		
18-72	98802-08200	NUT		2		
18-73	97103-08025	BOLT	(ISO)	2		
18-74	92901-08100	WASHER, spring		2		
18-75	233-85111-00	REFLECTOR	(ISO)	2		



Fig. 18 FRONT FORK & FRONT FENDER




FRONT FORK & FRONT FENDER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
18-76	92901-05100	WASHER, spring		2		
18-77	92901-05200	WASHER, plain		2		
www.legends-yamaha-enduro.com						



Fig. 19 HANDLE & WIRE




HANDLE & WIRE

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
19- 1	214-26111-00	HANDLE		1		
19- 0-1	214-82910-01	LEVER HOLDER ASS'Y (L.H)		1		
19- 2	214-82911-00	. HOLDER, lever (L.H)		1		
19- 3	214-83912-01	. LEVER (L.H)		1		
19- 4	91203-06020	. BOLT		1		
19- 5	92901-06100	. WASHER, spring		1		
19- 6	91203-06020	. BOLT		1		
19- 7	92802-06500	. NUT, slotted		1		
19- 8	214-83913-00	. COLLAR, lever		1		
19- 9	214-26241-00	GRIP (L.H)		1		
19- 0-2	233-82920-31	LEVER HOLDER ASS'Y (R.H)		1		
19-10	233-82921-31	. HOLDER, lever (R.H)		1		
19-11	233-83922-31	. LEVER (R.H)		1		
19-12	91203-06020	. BOLT		1		
19-13	92901-06100	. WASHER, spring		1		
19-14	233-83915-01	. SCREW, lever fitting	(ISO)	1		
19-15	98802-05500	. NUT, slotted	(ISO)	1		
19-16	91402-12015	. PIN, cotter		1		
19-17	92901-05200	. WASHER, plain		1		
19-18	214-26281-01	CAP, grip upper		1		
19-19	214-26282-01	CAP, grip under	(ISO)	1		
19-20	98503-05020	SCREW, pan head	(ISO)	2		
19-21	214-26243-00	TUBE, guide		1		
19-22	150-26249-00	RING, leaf		1		
19-23	214-26242-00	GRIP (R.H)		1		
19-24	233-83980-30	FRONT STOP SWITCH ASS'Y		1		
19-25	214-26311-02	WIRE, throttle (1)		1		
19-26	214-26261-00	CYLINDER		1		
19-27	275-26312-00	WIRE, throttle (2)		1		
19-28	214-26321-00	WIRE, pump		1		
19-29	214-26335-00	WIRE, clutch		1		
19-30	214-26346-00	BOLT, adjusting		1		
19-31	168-26344-00	NUT, adjusting		2		
19-32	214-26337-00	BOLT, adjusting		1		
19-33	214-26341-00	WIRE, brake		1		
19-34	253-26290-10	BACK MIRROR ASS'Y (L.H)		1		
		ALTERNATE PARTS				
19-35	253-26290-00	BACK MIRROR ASS'Y (R.H)		1		

(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.

Fig. 20 FUEL TANK




FUEL TANK

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
20- 1	214-24110-03-05	FUEL TANK COMP.	(ISO)	1		
20- 2	122-24610-01	CAP ASS'Y		1		
20- 3	214-24500-00	FUEL COCK ASS'Y		1		
20- 4	214-24512-00	. GASKET, body		1		
20- 5	214-24515-00	. NET, filter		1		
20- 6	214-24522-00	. GASKET, filter		1		
20- 7	214-24521-00	. CUP, filter		1		
20- 8	214-24542-00	. NUT, ring		1		
20- 9	214-24523-00	. VALVE		1		
20-10	214-24524-00	. LEVER, cock		1		
20-11	137-24518-00	. WASHER, wave		1		
20-12	214-24525-00	. PLATE, lever fitting		1		
20-13	214-24535-00	. SCREW, lever fitting		2		
20-14	214-24143-00	BOLT, cock fitting		2		
20-15	178-14766-00	WASHER, protector	6.2-12-1.5	2		
20-16	214-24311-00	PIPE, fuel		1		
20-17	143-24356-00	CLIP, pipe		2		
20-18	156-24181-00	DAMPER, tank locating		2		
20-19	214-24184-00	DAMPER, locating (4)		1		
20-20	211-24161-00	EMBLEM, fuel tank		2		
20-21	98501-04008	SCREW, pan head	(ISO)	4		
20-22	214-24173-00	BAND, tank fitting		1		
20-23	248-24173-00	BAND, tank fitting		1		
20-24	214-21269-00	SEAL, fuel tank		1		



Fig. 21 OIL TANK




OIL TANK

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
21- 1	214-21705-00-04	OIL TANK ASS'Y		1		
21- 2	214-21761-00	. GAUGE, level		1		
21- 3	214-21771-00	CAP, tank		1		
21- 4	214-21722-00	GASKET, cap	29-37-2	1		
21- 5	214-21638-00	DAMPER, fender mount (1)		1		
21- 6	214-21633-00	COLLAR, fender mount (1)	7-10-7	2		
21- 7	91201-06025	BOLT		2		
21- 8	92901-06100	WASHER, spring		2		
21- 9	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	1		
21-10	214-21717-00	DAMPER, battery box (1)		1		
21-11	214-21746-00	DAMPER, tool box		1		
21-12	214-21779-00	DAMPER, oil tank (2)		1		
21-13	214-21768-00	SCREW, union		1		
21-14	137-21767-00	GASKET, union	10.2-15-1.5	2		
21-15	214-21769-00	COLLAR, union screw		1		
21-16	214-21766-00	PIPE, oil		1		
21-17	101-24356-00	CLIP, pipe		2		
21-18	214-21745-00	PIPE, oil tank breather		1		
21-19	275-21787-01	EMBLEM, enduro		1		




Fig. 22 SEAT



SEAT

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
22- 1	214-24710-00	SINGLE SEAT ASS'Y		1		
22- 1-1	214-24711-00	. COVER, single seat		1		
22- 2	214-24726-00	HINGE, seat		2		
22- 3	91202-06012	BOLT		6		
22- 4	92902-06100	WASHER, spring		6		
22- 5	91502-05055	PIN, clevis		2		
22- 6	92902-05200	WASHER, plain		2		
22- 7	156-83525-00	CLIP		2		
22- 8	214-24728-00	BRACKET, seat		1		
22- 9	214-24718-00	BRACKET, seat under		1		
22-10	214-24776-00	LEVER, seat		1		
22-11	214-24758-00	SPRING, seat		1		
22-12	214-24727-00	PIN, seat fitting		1		
22-13	91201-06010	BOLT		1		
22-14	92902-06200	WASHER, plain		1		
22-15	214-24724-00	DAMPER, seat		4		
22-16	214-24778-00	BAND, seat fitting		1		
22-17	214-24745-00	STOPPER, seat		1		

Fig. 23 FRONT WHEEL




FRONT WHEEL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S · R	Remarks
23- 1	214-25111-00	HUB, front		1		
23- 2	214-25104-00	SPOKE SET		1s		
23- 3	94416-19035	RIM, front	1.60A-19	1		
23- 4	94132-19063	TIRE, front	3.25-194PR	1		☆
23- 5	94232-19029	TUBE, front	3.25-19	1		☆
23- 6	94332-19021	BAND, rim	3.25-19	1		
23- 7	214-25117-00	SPACER, bearing		1		
23- 8	136-25115-00	FLANGE, spacer		1		
23- 9	93306-20201	BEARING	6202	1		
23-10	93102-20009	OIL SEAL	SD-20-35-7	1		
23-11	93306-20204	BEARING	6202RS	1		
23-12	93410-22014	CIRCLIP	S-22	1		
23-13	214-25147-00	WASHER, thrust (2)	22.5-29-1	2		
23-14	214-25149-00	CLUTCH, meter		1		
23-15	214-25135-00	GEAR, drive		1		
23-16	214-25121-01	PLATE, brake shoe		1		
23-17	214-25151-00	CAM, shaft		1		
23-18	137-25153-00	SHIM, cam shaft	12.2-22-0.5	1		
23-19	93105-50010	OIL SEAL	SDD-50-62-7	1		
23-20	214-25130-00	BRAKE SHOE COMP.		2		
23-21	246-25333-00	SPRING, brake shoe return		2		
23-22	214-25155-00	LEVER, cam shaft		1		
23-23	91201-06030	BOLT		1		
23-24	92801-06100	NUT		1		
23-25	92901-06100	WASHER, spring		1		
23-26	92901-06200	WASHER, plain		1		
23-27	214-25138-00	GEAR, meter		1		
23-28	183-25146-00	WASHER, thrust (1)	7-12-0.8	1		
23-29	109-25136-00	BUSH		1		
23-30	93104-07003	OIL SEAL	SO-7-14-4	1		
23-31	93210-14104	O-RING		1		
23-32	102-25137-00	RING, stop	18φ	1		
23-33	275-25181-00	SHAFT, wheel		1		
23-34	214-25118-00	COVER, hub dust		1		
23-35	136-25183-00	COLLAR, wheel shaft	15-20-12.4	1		
23-36	214-25182-01	NUT, shaft	(ISO)	1		
23-37	91401-30028	PIN, cotter		1		
23-38	214-25194-00	SPACER, bead		1		



Fig. 23 FRONT WHEEL




FRONT WHEEL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
23-39	93700-06001	NIPPLE, grease		1		
23-40	275-25186-00	COLLAR		1		

www.legends-yamaha-enduros.com

Fig. 24 REAR WHEEL




REAR WHEEL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
24- 1	275-25311-00	HUB, rear		1		
24- 2	275-25304-00	SPOKE SET		1s		
24- 3	94418-18051	RIM, rear	1.85B-18	1		
24- 4	94140-18062	TIRE, rear	4.00-18-4PR	1		☆
24- 5	94240-18024	TUBE, rear	4.00-18	1		☆
24- 6	94340-18022	BAND, rim	4.00-18	1		
24- 7	275-25317-00	SPACER, bearing		1		
24- 8	93306-20301	BEARING	6203	3		
24- 9	93104-46029	OIL SEAL	SD-46-56-4	1		
24-10	275-25328-00	BUSHING, shaft		1		
24-11	275-25321-00	PLATE, brake shoe		1		
24-12	214-25351-00	CAM SHAFT		1		
24-13	148-25353-00	SHIM, cam shaft		1		
24-14	214-25130-00	BRAKE SHOE COMP.		2		
24-15	246-25333-00	SPRING, return		2		
24-16	168-25355-00	LEVER, cam shaft		1		
24-17	91203-06020	BOLT	legends-yamaha-enduro.com	1		
24-18	150-25381-00	SHAFT, wheel		1		
24-19	168-25389-00	PULLER, chain		2		
24-20	275-25383-00	COLLAR wheel shaft		1		
24-21	275-25327-00	COVER, plate dust		1		
24-22	93210-31114	O-RING	2.4-31	1		
24-23	93700-06001	NIPPLE, grease		1		
24-24	275-25366-00	CLUTCH, hub		1		
24-25	275-25364-00	DAMPER, clutch		6		
24-26	214-25439-10	GEAR, sprocket wheel	39T	1		S. T. D
	214-25440-10	GEAR, sprocket wheel	40T	1		
	214-25441-10	GEAR, sprocket wheel	41T	1		
	214-25442-10	GEAR, sprocket wheel	42T	1		
	214-25443-10	GEAR, sprocket wheel	43T	1		
	214-25445-10	GEAR, sprocket wheel	45T	1		
	214-25447-10	GEAR, sprocket wheel	47T	1		
	214-25449-10	GEAR, sprocket wheel	49T	1		
	214-25450-10	GEAR, sprocket wheel	50T	1		
24-27	214-25411-00	BOLT, fitting		6		
24-28	214-25412-00	WASHER, lock		3		
24-29	93106-25003	OIL SEAL	DD-25-40-9	1		
24-30	93410-52022	CIRCLIP		1		




Fig. 24 REAR WHEEL



REAR WHEEL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
24-31	275-25377-00	COLLAR, shaft		1		
24-32	275-25367-00	COVER, dust		1		
24-33	275-25382-00	NUT, shaft		1		
24-34	91401-30028	PIN, cotter		1		
24-35	168-25379-00	BOLT, chain puller 90101-08034		2		
24-36	98803-08300	NUT	(ISO)	2		
24-37	275-25371-00	BAR, tension		1		
24-38	275-25373-00	BOLT, tension bar		2		
24-39	275-22123-00	BUSHING		2		
24-40	92901-10100	WASHER, spring		2		
24-41	98801-10500	NUT, slotted		1		
24-42	91401-25018	PIN, cotter		2		
24-43	98801-10500	NUT	(ISO)	1		
24-44	156-27237-00	PIN, clevis		1		
24-45	206-27238-00	NUT, adjusting	(ISO)	1		
24-46	180-27236-00	SPRING, rod		1		
24-47	94515-20100	CHAIN	520T-100P	1		
24-48	94615-20001	JOINT, chain		1		
24-49	214-25394-00	SPACER, bead		2		

Fig. 25 HEAD LAMP & SPEEDOMETER




HEAD LAMP & SPEEDOMETER

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
25- X	214-84130-61-33	BODY ASS'Y 4 90		1		
25- 2	214-84153-60	. GROMMET		1		
25- 0-1	233-84110-60	HEAD LAMP UNIT ASS'Y	(ISO)	1		
25- 3	233-84120-60	. LENS ASS'Y		1		
25- 4	233-84115-60	. RIM, head lamp	(ISO)	1		
25- 5	261-84312-61	. SOCKET		1		
25- 6	214-84159-61	. CORD, head lamp		1		
25- 7	98501-05012	. SCREW, pan head	(ISO)	2		
25- 8	92901-05100	. WASHER, spring		2		
25- 9	98801-05200	. NUT		2		
25-10	195-84325-00	. SCREW, rim fitting	(ISO)	1		
25-11	214-84131-61	. SCREW, rim adjusting	(ISO)	1		
25-12	233-84127-60	. WASHER, plain		1		
25-13	233-84133-60	. SPACER		1		
25-14	92901-04200	. WASHER, plain		1		
25-15	132-84328-60	. SPACER		1		
26-16	802-84126-00	. NUT	(ISO)	2		
25-17	198-84334-60	. NUT, adjust	(ISO)	1		
25-18	132-84335-60	. SPRING, lens adjust		1		
25- 0-2	214-84101-60	PILOT LAMP ASS'Y		1		
25-19	214-84150-60	. SOCKET CORD ASS'Y		1		
25-20	104-83517-10	. BULB	6V1.5W	1		☆
25-21	214-84158-60	. NUT, pilot lamp		1		
25-22	92901-12300	. WASHER, tooth		1		
25-23	214-84157-60	. BODY, high beam		1		
25-24	214-84154-60	. GROMMET B		1		
25-25	233-83570-31	SPEEDOMETER ASS'Y		1		MILE/H
25-26	275-83540-00	TACHOMETER ASS'Y		1		
25-27	122-83516-10	. BULB	6V 3W	2		☆
25-28	233-83536-00	. SOCKET, meter		2		
25-29	214-83550-00	SPEEDOMETER CABLE ASS'Y ✓		1		
25-30	214-83560-00	TACHOMETER CABLE ASS'Y		1		
25-31	214-83519-00	BRACKET, meter		1		
25-32	214-83523-00	DAMPER		2		
25-33	214-83524-00	WASHER, special		4		
25-34	156-83525-00	CLIP		4		
25-35	214-83528-00	BUSHING, meter		2		
25-36	91201-06030	BOLT		2		


(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.

Fig. 25 HEAD LAMP & SPEEDOMETER



HEAD LAMP & SPEEDOMETER

Fig. 26 TAIL LAMP



TAIL LAMP

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
26- 0-1	214-84510-61	TAIL LAMP UNIT ASS'Y	(ISO)	1		
26- 1	214-84511-61	. BASE, tail lamp	(ISO)	1		
26- 2	122-84514-30	. BULB, tail lamp	6V17/5.3W	1		☆
26- 3	168-84712-60	. SEAT, base		1		
26- 4	168-84721-60	. LENS, tail lamp		1		
26- 5	193-84724-00	. SCREW, lens fitting	(ISO)	2		
26- 6	92901-06100	. WASHER, spring		2		
26- 7	92501-06010	. SCREW, pan head		2		
26- 8	214-84551-61-35	BRACKET, licence		1		
26- 9	214-84517-00	CORD, tail lamp		1		
26-10	91101-06035	BOLT		1		
26-11	214-21717-00	DAMPER, battery box (1)	6.5-20-1.6	2		
26-12	214-21633-00	COLLAR, fender mount (1)		2		
26-13	116-28324-00	WASHER, leg shield (2)	6.5-20-1.6	2		
26-14	92803-06700	NUT, crown		1		
26-15	92901-06100	WASHER, spring		1		
26-16	168-21738-00	BOLT		2		
26-17	214-84553-01	DAMPER, licence bracket		1		
26-18	214-84554-00	WASHER, special		1		
26-19	92801-06100	NUT		2		
26-20	92901-06200	WASHER, plain		2		


(ISO) : SOME OF THE PARTS IN THIS BOOK HAVE ISO-THREADING. PLEASE MAKE SURE TO



YAMAHA MOTOR CO., LTD.

CONSULT THIS BOOK WHEN ORDERING PARTS FOR THE MOTORCYCLE DESCRIBED HEREIN.

Fig. 27 ELECTRICAL




ELECTRICAL

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
27- 1	214-82110-10	BATTERY ASS'Y		1		
27- 1-1	104-82111-10	. CAP, battery		3		
27- 2	214-82124-00	BAND, battery		1		
27- 3	214-82112-00	PIPE, breather		1		
27- 4	214-82122-00	SEAT, battery		1		
27- 5	214-82131-00	BAND, battery		1		
27- 6	214-82121-00	PAD, battery		1		
27- 7	116-82150-00	FUSE HOLDER ASS'Y		1		
27- 8	116-82151-00	. FUSE 315-81970-60		2		
27- 9	214-81970-20	RECTIFIER ASS'Y 315-81970-60		1		
27-10	98501-05010	SCREW, pan head	(ISO)	1		
27-11	92901-05100	WASHER, spring		1		
27-12	233-82508-20	MAIN SWITCH ASS'Y		1		
27-13	214-82511-00	. KEY, main switch		3		
27-14	98501-05008	SCREW, pan head		2		
27-15	92901-05100	WASHER, spring		2		
27-16	214-82310-40	IGNITION COIL ASS'Y		1		
27-17	98501-05020	SCREW, pan head	(ISO)	2		
27-18	92901-05100	WASHER, spring		2		
27-19	166-82370-20	PLUG CAP ASS'Y		1		
27-20	94700-00035	PLUG, spark	B-9E	1		
27-21	214-82530-00	STOP SWITCH ASS'Y		1		
27-22	214-82537-00	ATTACHMENT, stop switch.		1		
27-23	98501-05008	SCREW, pan head		1		
27-24	92901-05100	WASHER, spring		1		
27-25	214-83371-10	HORN		1		
27-26	91201-06012	BOLT		2		
27-27	92901-06100	WASHER, spring		2		
27-28	214-83974-00	HOLDER, handle switch		1		
27-29	214-83975-00	SWITCH, handle (2)		1		
27-30	98503-05015	SCREW, pan head		1		
27-31	168-83936-01	BAND, switch cord		2		
27-32	233-82590-21	WIRE HARNESS ASS'Y		1		
27-33	214-82599-00	COVER, connector		1		



Fig. 28 FLASHER LAMP (ALTERNATE PARTS)



FLASHER LAMP (ALTERNATE PARTS)


Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
28- 1	233-83310-60	FRONT FLASHER LAMP ASS'Y	(ISO)	2		AMBER
28- 2	233-83330-60	REAR FLASHER LAMP ASS'Y (L.H)	(ISO)	1		AMBER
	233-83330-65	REAR FLASHER LAMP ASS'Y (L.H)	(ISO)	1		RED
	233-83340-60	REAR FLASHER LAMP ASS'Y (R.H)	(ISO)	1		AMBER
	233-83340-65	REAR FLASHER LAMP ASS'Y (R.H)	(ISO)	1		RED
28- 3	183-83312-70	. LENS, flasher		4		AMBER
	211-83332-75	. LENS, flasher		2		RED
28- 4	183-83333-71	. SCREW, lens fitting	(ISO)	8		
28- 5	183-83313-70	. GASKET, flasher lens		4		
28- 6	115-83311-60	. BULB, flasher	6V21CP	4		☆
28- 7	98801-08100	NUT	(ISO)	2		
28- 8	92901-08100	WASHER, spring		2		
28- 9	256-83321-00	DAMPER, flasher		2		
28-10	256-83316-00	COLLAR, flasher		2		
28-11	275-83359-00	WASHER, special		2		
28-12	214-83354-00	WIRE, flasher		1		
28-13	275-83336-00	CORD (L.H)	f-250	1		
28-14	275-83346-00	CORD (R.H)	f-380	1		
28-15	233-83973-00	SWITCH, handle (3)		1		
28-16	233-83350-60	FLASHER RELAY ASS'Y 475		1		
28-17	92801-06100	NUT		1		
28-18	92901-06100	WASHER, spring		1		
28- 0-1	233-84102-60	PILOT LAMP ASS'Y (2)		18		
28-19	233-84150-60	. SOCKET CORD ASS'Y		1		
28-20	104-83517-10	. BULB, pilot	6V1.5W	1		☆
28-21	214-84158-60	. NUT, pilot lamp		1		
28-22	92901-12300	. WASHER, tooth		1		
28-23	233-84157-60	. BODY, pilot lamp		1		

RT1-M

www.legends-yamaha-enduros.com



Fig. 29 ENGINE(CYLINDER & TRANSMISSION)




ENGINE (CYLINDER & TRANSMISSION)

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
29- 1	284-11111-00	HEAD, cylinder		1		
29- 2	284-11311-00	CYLINDER		1		
29- 3	284-11631-00-95	PISTON (STD)	79.95mm	U. R 1		
	284-11631-00-96	PISTON (STD)	79.96mm			
	284-11631-00-97	PISTON (STD)	79.97mm			
	284-11631-00-98	PISTON (STD)	79.98mm			
	284-11635-00	PISTON (1st o. s)	80.25mm	1		
	284-11636-00	PISTON (2nd o. s)	80.50mm	1		
29- 4	284-11611-00	RING, piston (STD)		1		
	284-11611-10	RING, piston (1st o. s)	0.25mm	1		
	284-11611-20	RING, piston (2nd o. s)	0.50mm	1		
29- 5	183-16333-70	SPRING, clutch		6		
29- 6	214-17411-60	AXLE, main	16T	1		
29- 7	214-17121-60	GEAR, 2nd pinion	20T	1		
29- 8	214-17211-60	GEAR, 1st wheel	36T	1		
29- 9	214-17221-60	GEAR, 2nd wheel	33T	1		
29-10	214-17231-60	GEAR, 3rd wheel	29T	2		
29-11	241-17819-00	CAP, housing		1		
29-12	94700-00016	PLUG, spark	NGK B-9EN	1		
		ALTERNATE PARTS (for without oil pump)				
29-13	161-15426-00	COVER, oil pump		1		



Fig. 30 ENGINE(CARBURETOR & EXHAUST)




FWD

ENGINE (CARBURETOR & EXHAUST)

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
30- 1	284-14101-60	CARBURETOR ASS'Y	VM34SH	1		MIKUNI
30- 2	137-14143-62	JET, main	#310	1		
	137-14143-64	JET, main	#320	1		
	137-14143-66	JET, main	#330	1		S. T. D
	137-14143-68	JET, main	#340	1		
	137-14143-70	JET, main	#350	1		
30- 3	284-14141-55	NOZZLE, main	Q-5	1		
30- 4	239-14116-06	NEEDLE	6FJ6-3	1		
30- 5	285-14610-10	EXHAUST PIPE ASS'Y		1		
30- 6	285-14781-11	STAY, muffler (2)		1		
30- 7	91201-06020	BOLT		1		
30- 8	92901-06100	WASHER, spring		1		
30- 9	92801-06100	NUT		2		
30-10	285-14791-10	STAY, muffler (3)		1		
30-11	214-14793-01	PLATE, muffler		1		
30-12	214-14763-02	SPACER		1		
30-13	214-14794-00	PLATE, muffler (2)		1		
30-14	91201-06045	BOLT		1		
30-15	214-21635-00	NUT, crown		1		
30-16	92901-06100	WASHER, spring		1		
30-17	285-14411-00	CASE, air cleaner		1		
30-18	285-14451-00	ELEMENT		1		
30-19	285-14458-00	GUIDE, element		1		
30-20	285-14412-00	CAP, case		1		
30-21	285-14455-00	BAND		1		
30-22	284-14453-00	JOINT		1		
30-23	92501-06008	SCREW, pan head		4		
30-24	284-82319-00	WIRE, sub lead		1		



Fig. 31 CHASSIS(FRONT FORK & FRONT FENDER)





CHASSIS (FRONT FORK & FRONT FENDER)

Ref No.	Parts No.	Parts Name	Description	Q'ty	S-R	Remarks
31- 1	284-23100-00-35	FRONT FORK ASS'Y	(ISO)	1		
31- 2	263-23485-00	PLATE, number		1		
31- 3	91201-06015	BOLT		2		
31- 4	92901-06100	WASHER, spring		2		
31- 5	156-24187-00	WASHER, special (2)	6.5-26-1.6	2		
31- 6	263-23487-00	STAY, plate		1		
31- 7	93210-67057	O-RING	3-66.5	1		
31- 8	92901-08200	WASHER, plain		2		
31- 9	263-21581-00	STAY, plate fitting (L.H)		1		
31-10	263-21591-00	STAY, plate fitting (R.H)		1		
31-11	284-21510-00-35	FRONT FENDER COMP.		1		
31-12	284-21513-00-35	STAY, fender (1)		1		
31-13	284-21514-00-35	STAY, fender		1		
31-14	284-21512-00-35	BRACKET, fender		1		
31-15	91201-06018	BOLT		2		
31-16	256-21615-00	WASHER, special	6.5-19-1.2	2		
31-17	256-21544-00	COLLAR, fender mount		2		
31-18	256-21541-00	DAMPER, fender mount		2		
31-19	92901-06200	WASHER, plain		5		
31-20	92901-06100	WASHER, spring		5		
31-21	92803-06700	NUT, crown		2		
31-22	91201-06012	BOLT		1		
31-23	92801-06100	NUT		1		
31-24	91201-06012	BOLT		2		
31-25	97201-08015	BOLT	(ISO)	2		
31-26	92901-08100	WASHER, spring		2		
31-27	284-21787-00	EMBLEM MX		1		
31-28	285-21639-00	DAMPER		1		
31-29	170-21746-00	DAMPER, cleaner stop		2		
31-30	214-83915-01	SCREW, lefer fitting		1		
31-31	92802-06500	NUT, slotted		1		
32	214-26111-70	W/BARS.				



Fig. 32 CHASSIS(FRONT & REAR WHEEL)



CHASSIS (FRONT & REAR WHEEL)

Ref No.	Parts No.	Parts Name	Description	Q'ty	S·R	Remarks
32- 1	94127-21071	TIRE, front	2.75-21-4PR	1		☆
32- 2	94227-21031	TUBE, front	2.75-21	1		☆
32- 3	94327-21024	BAND, rim	2.75-21	1		
32- 4	94416-21038	RIM, front	1.60A-21	1		
32- 5	214-25104-10	SPOKE SET		1 s		
32- 6	152-25139-00	PLUG, blind		1		
32- 7	94140-18070	TIRE, rear	4.00-18-4PR	1		☆
32- 8	214-25394-10	SPACER, bead		2		

www.legends-yamaha-enduros.com



NUMERICAL INDEX

www.legends-yamaha-enduros.com



NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
21-17	101-24356-00	4-22	132-16346-00	4-21	137-16345-00
13- 7	102-18138-00	5- 9	132-17216-00	5-11	137-17427-00
23-32	102-25137-00	8-17	132-17414-00	6-18	137-18547-00
14-13	104-81328-20	7- 2	132-18113-01	6-17	137-18557-00
27- 1-1	104-82111-10			6-15	137-18577-00
25-20	104-83517-10	7-15	132-18133-00	21-14	137-21767-00
28-20	104-83517-10	25-15	132-84328-60	10-19	137-21778-00
23-29	109-25136-00	25-15	132-84328-60		
14-14	110-81345-20	25-18	132-84335-60	18-43	137-23454-00
14-11	110-81346-20	11- 3	136-14195-00	20-11	137-24518-00
14- 8	110-81347-20	6- 4	136-18551-00	23-18	137-25135-00
14- 5	110-81348-20	16-14	136-22316-00	18-51	141-23427-00
28- 6	115-83311-60	23- 8	136-25115-00	16-11	141-82596-00
10-10	116-28324-00	23-35	136-25183-00	20-17	143-24356-00
15-19	116-28324-00	13-18	137-13128-00	16- 5	148-22123-00
15-32	116-28324-00	13-13	137-13137-00	24-13	148-25353-00
18-69	116-28324-00	13-14	137-13138-01	8- 9	150-17219-00
21- 9	116-28324-00	13-25	137-13165-00	7-13	150-18138-00
26-13	116-28324-00	13-30	137-13165-00	16- 4	150-22124-00
27- 7	116-82150-00	13-24	137-13167-00	16- 3	150-22126-00
27- 8	116-82151-00	13-29	137-13167-00	16- 7	150-22128-00
1-12	120-15371-00	13-23	137-13169-00	24-18	150-25381-00
14-12	120-81331-20	13- 4	137-13176-00	19-22	150-26249-00
18-30	122-23119-01	13-21	137-13187-00	11-28	152-14123-00
18-31	122-23129-00	11-22	137-14133-00	5- 3	152-17226-00
18-39	122-23411-00	11- 8	137-14143-44	5-37	152-17463-00
18-40	122-23412-00	11- 8	137-14143-46	32- 6	152-25139-00
18-42	122-23416-00	11- 8	137-14143-48	3-21	156-16174-00
20- 2	122-24610-01	11- 8	137-14143-50	4-13	156-16174-00
25-27	122-83516-10	30- 2	137-14143-62	5-15	156-17417-00-01
26- 2	122-84514-30	30- 2	137-14143-64	5-15	156-17417-00-02
13- 1	126-13116-00	30- 2	137-14143-66	5-15	156-17417-00-03
11-25	127-14124-20	30- 2	137-14143-68	5-30	156-17429-00
11-27	127-14134-00	30- 2	137-14143-70	5-36	156-17464-01
11-13	127-14186-00	11- 6	137-14153-00	15-11	156-21483-00
11-38	132-14146-00	1-14	137-15353-00	16- 6	156-22127-00
6-16	132-15353-00	4- 9	137-16333-00	18-10	156-23147-00
8-22	132-15644-00	4-10	137-16337-01	18-36	156-23411-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
18-37	156-23412-00	4-17	170-16164-00	11- 5	214-14145-00
18-52	156-23418-00	31-29	170-21746-00	11- 7	214-14147-00
20-18	156-24181-00	1-23	171-11161-00	11- 9	214-14166-00
31- 5	156-24187-00	11-29	174-14171-00	11-12	214-14187-00
24-44	156-27237-00	4-11	174-16356-00	11-37	214-14197-00
15-26	156-83524-00	12-10	178-14766-00	11-10	214-14198-00
15-27	156-83525-00	20-15	178-14766-00	10- 2	214-14451-02
18-59	156-83525-00	24-46	180-27236-00	10-11	214-14455-01
22- 7	156-83525-00	11-36	183-14197-00	10-13	214-14455-01
25-34	156-83525-00	29- 5	183-16333-70	10- 3	214-14458-00
29-13	161-15426-00	15-12	183-22143-00	12-12	214-14612-00
11-18	164-14137-00	23-28	183-25146-00	12-11	214-14613-00
5-40	164-17417-00	28- 3	183-83312-70	12-15	214-14683-01
18-35	164-23462-00	28- 5	183-83313-70	12- 7	214-14718-00
27-19	166-82370-20	28- 4	183-83333-71	12-16	214-14763-02
11-14	168-14184-00	11- 1	193-14142-30	30-12	214-14763-02
8-16	168-15653-00	25-17	193-84334-60	12- 9	214-14766-00
8-19	168-15675-00	26- 5	193-84724-00	12-21	214-14771-00
8-20	168-15676-00	25-10	195-84325-00	12-17	214-14793-01
4- 6	168-16321-00	11-23	204-14122-00	30-11	214-14793-01
4- 7	168-16325-00	24-45	206-27238-00	12-18	214-14794-00
4- 5	168-16367-00	14- 3	207-81313-20	30-13	214-14794-00
5-26	168-17116-00	20-20	211-24161-00	1-15	214-15351-00
5-31	168-17428-01-03	28- 3	211-83332-75	2-12	214-15363-00
5-31	168-17428-01-04	1-22	214-11175-00	1- 8	214-15385-00
5-31	168-17428-01-05	1-24	214-11197-00	2- 7	214-15451-01
6-13	168-18552-00	1-25	214-11198-01	2- 8	214-15461-00
18-12	168-23145-00	1-16	214-11361-00	1- 9	214-15492-00
24-16	168-25355-00	3-23	214-11545-01	8- 2	214-15612-01
24-35	168-25379-00	3-17	214-11555-01	8- 4	214-15616-00
24-19	168-25389-00	3-15	214-11557-01	8- 5	214-15617-00
19-31	168-26344-00	3- 3	214-11651-00	8- 6	214-15618-00
15-21	168-21615-00	13-26	214-13161-01	8- 3	214-15625-01
15-22	168-21639-00	13-27	214-13162-00	5-18	214-15631-00
26-16	168-21738-00	13-28	214-13164-00	8-15	214-15641-01
27-31	168-83936-01	13-31	214-13174-01	5-41	214-15651-02
26- 3	168-84712-60	13- 8	214-13178-01	8-14	214-15661-00
26- 4	168-84721-60	10-16	214-13558-00	8-13	214-15664-00
4-18	170-16154-02	11-33	214-14118-00		

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
8-12	214-15665-00	5-35	214-17461-30	15-24	214-21240-10
8-23	214-15668-00	5-35	214-17461-40	15-39	214-21268-00
8-18	214-15671-01	5-35	214-17461-50	20-24	214-21269-00
8-24	214-15674-00	5-35	214-17461-60	15- 3	214-21433-00
8-11	214-15676-00	5-34	214-17462-00	15- 2	214-21471-00
8-26	214-15684-00	5-20	214-17481-00	15- 9	214-21481-00
8-25	214-15686-00	9- 5	214-17811-01	15-10	214-21482-00
3-19	214-16111-00	9-11	214-17812-00	15- 6	214-21483-00
4-14	214-16119-00	9-10	214-17815-00	15- 7	214-21494-00
4-1	214-16150-00	9- 4	214-17830-00	18-61	214-21510-00-35
4-15	214-16181-00	9- 3	214-17837-00	18-62	214-21512-00
4- 4	214-16324-00	9- 6	214-17841-01	18-63	214-21513-00
4-20	214-16340-00	9-14	214-17843-00	18-64	214-21514-00
4-26	214-16343-00	9- 9	214-17847-00	10- 8	214-21633-00
4-27	214-16344-00	9- 1	214-17861-00	15-16	214-21633-00
4- 8	214-16351-00	7- 1	214-18111-01	15-29	214-21633-00
4-19	214-16357-00	7- 8	214-18121-01	18-66	214-21633-00
4- 3	214-16371-01	6-22	214-18123-00	21- 6	214-21633-00
4-24	214-16379-00	7- 7	214-18124-00	26-12	214-21633-00
4-23	214-16389-00	7- 6	214-18125-00	30-15	214-21635-00
5- 8	214-17121-10	6-19	214-18128-00	12-25	214-21635-00
29- 7	214-17121-60	7-14	214-18129-00	15-15	214-21638-00
5- 5	214-17131-10	7- 4	214-18131-00	21- 5	214-21638-00
5-22	214-17131-10	7-17	214-18139-01	21- 1	214-21705-00-04
5- 2	214-17141-10	6-24	214-18151-00	10- 7	214-21717-00
5-25	214-17211-10	6-23	214-18152-00	15-28	214-21717-00
29- 8	214-17211-60	6-26	214-18178-00	18-65	214-21717-00
5- 6	214-17216-00	6-27	214-18179-00	21-10	214-21717-00
5-29	214-17216-00	7- 9	214-18186-00	26-11	214-21717-00
5-21	214-17221-10	6-20	214-18188-00	21- 4	214-21722-00
29- 9	214-17221-60	6-12	214-18511-00	21-18	214-21745-00
5- 7	214-17231-10	6- 2	214-18512-00	15-34	214-21746-00
5-23	214-17231-10	6- 3	214-18513-00	21-11	214-21746-00
29-10	214-17231-60	6- 1	214-18531-00	15-25	214-21747-00
5-24	214-17241-10	6-14	214-18533-00	21- 2	214-21761-00
5- 1	214-17411-10	6- 8	214-18541-01	21-16	214-21766-00
29- 6	214-17411-60	6- 5	214-18552-00	21-13	214-21768-00
5-19	214-17421-00	6-10	214-18561-00	21-15	214-21769-00
		15-33	214-21170-00-33		

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
21- 3	214-21771-00	20- 7	214-24521-00	24-27	214-25411-00
15-41	214-21779-00	20- 6	214-24522-00	24-28	214-25412-00
21-12	214-21779-00	20- 9	214-24523-00	24-26	214-25439-10
16-10	214-22311-00-35	20-10	214-24524-00	24-26	214-25440-10
16-12	214-22317-00	20-12	214-24525-00	24-26	214-25441-10
15-37	214-22241-00	20-13	214-24535-00	24-26	214-25442-10
15-38	214-22241-00	20- 8	214-24542-00	24-26	214-25443-10
18-23	214-23112-00	22- 1	214-24710-00	24-26	214-25445-10
18-22	214-23114-00	22- 1-1	214-24711-00	24-26	214-25447-10
18-21	214-23115-00	22- 9	214-24718-00	24-26	214-25449-10
18-18	214-23116-00	22-15	214-24724-00	24-26	214-25450-10
18-19	214-23121-01-33	22- 2	214-24726-00	19- 1	214-26111-00
18-20	214-23131-01-33	22-12	214-24727-00	19- 9	214-26241-00
18- 4	214-23141-00	22- 8	214-24728-00	19-23	214-26242-00
18- 7	214-23142-00	22-17	214-24745-00	19-21	214-26243-00
18-15	214-23144-01	22-11	214-24758-00	19-26	214-26261-00
18-11	214-23150-00	22-10	214-24776-00	19-18	214-26281-01
18-13	214-23155-00	22-16	214-24778-00	19-19	214-26282-01
18-29	214-23158-00	23- 2	214-25104-00	19-25	214-26311-02
18-17	214-23163-00	32- 5	214-25104-10	19-28	214-26321-00
18-14	214-23165-00	23- 1	214-25111-00	19-29	214-26335-00
18-34	214-23318-00	23- 7	214-25117-00	19-32	214-26337-00
16-15	214-22318-01-33	23-34	214-25118-00	19-33	214-26341-00
18-53	214-23419-01	23-16	214-25121-01	19-30	214-26346-00
18-57	214-23421-02	23-20	214-25130-00	17-14	214-27211-00-33
18-56	214-23422-01	24-14	214-25130-00	17-16	214-27212-00
18-58	214-23423-00	23-15	214-25135-00	17-17	214-27213-00
18-54	214-23441-00	23-27	214-25138-00	17-18	214-27216-00
18-49	214-23443-00	23-13	214-25147-00	17- 9	214-27311-01
18-50	214-23451-00	23-14	214-25149-00	17- 1	214-27411-00
20- 1	214-24110-03-05	23-17	214-25151-00	17- 3	214-27413-00
20-14	214-24143-00	23-22	214-25155-00	17-13	214-27316-00
20-22	214-24173-00	23-36	214-25182-01	17- 6	214-27417-00
20-19	214-24184-00	23-38	214-25194-00	17- 5	214-27418-00
20-16	214-24311-00	24-12	214-25351-00	17- 2	214-27421-00
20- 3	214-24500-00			17- 4	214-27426-00
20- 4	214-24512-00	24-49	214-25394-00	15-35	214-28100-01
20- 5	214-24515-00	32- 8	214-25394-10	14- 7	214-81321-20

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
14- 2	214-81312-21	25-21	214-84158-60	18-75	233-85111-00
14-10	214-81326-20	28-21	214-84158-60	30- 4	239-14116-06
		25- 6	214-84159-61	11-19	239-14136-00
27- 9	214-81970-20	26- 0-1	214-84510-61		
27- 1	214-82110-10	26- 1	214-84511-61	11-21	239-14158-00
27- 3	214-82112-00	26- 9	214-84517-00	11- 2	239-14190-33
27- 6	214-82121-00	26- 8	214-84551-61-35	29-11	241-17819-00
27- 4	214-82122-00	26-17	214-84553-01	23-21	246-25333-00
27- 2	214-82124-00	26-18	214-84554-00	24-15	246-25333-00
27- 5	214-82131-00	2- 1	233-15411-00	1-13	248-15373-00
27-16	214-82310-40	2-10	233-15416-00	15-36	248-22210-71
27-13	214-82511-00	2- 3	233-15417-00	20-23	248-24173-00
27-21	214-82530-00	2- 2	233-15421-00	1'-20	248-27228-00
27-22	214-82537-00	2- 9	233-15431-00	19-34	253-26290-10
27-33	214-82599-00	27-12	233-82508-20	19-35	253-26290-00
19- 0-1	214-82910-01	27-32	233-82590-21	11-30	256-14135-00
19- 2	214-82911-00	19- 0-2	233-82920-31	31-18	256-21541-00
28-12	214-83354-00	19-10	233-82921-31	31-17	256-21544-00
27-25	214-83371-10	28- 1	233-83310-60	31-16	256-21615-00
25-31	214-83519-00	28- 2	233-83330-60	28-10	256-83316-00
25-32	214-83523-00	28- 2	233-83330-65	28- 9	256-83321-00
25-33	214-83524-00	28- 2	233-83340-60	25- 5	261-84312-61
25-35	214-83528-00	28- 2	233-83340-65	31- 9	263-21581-00
		28-16	233-83350-60	31-10	263-21591-00
25-29	214-83550-00	25-28	233-83536-00	31- 2	263-23485-00
25-30	214-83560-00	25-25	233-83570-31	31- 6	263-23487-00
19- 3	214-83912-01	19-14	233-83915-01	18-24	264-23111-60
19- 8	214-83913-00	19-11	233-83922-31	18- 8	264-23118-60
31-30	214-83915-01	28-15	233-83973-00	18- 3	264-23170-60
27-28	214-83974-00	19-24	233-83980-30	1-20	275-11111-00
27-29	214-83975-00	28- 0-1	233-84102-60	1-21	275-11171-00
25- 0-2	214-84101-60	25- 0-1	233-84110-60	1-19	275-11181-00
25- 1	214-84130-61-33	25- 4	233-84115-60	1-26	275-11179-00
25-11	214-84131-61	25- 3	233-84120-60	1-18	275-11311-00
25-19	214-84150-60	25-12	233-84127-60	1-17	275-11351-00
25- 2	214-84153-60	25-13	233-84133-60	3- 0-1	275-11400-00
25-24	214-84154-60	28-19	233-84150-60	3- 1	275-11412-00
25-23	214-84157-60	28-23	233-84157-60	3- 2	275-11422-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
3-11	275-11601-00	8- 1	275-15611-00-93	14- 4	275-81314-20
3-10	275-11601-10	4- 0-1	275-16301-00	14-15	275-81332-20
3-11	275-11601-20	15- 1	275-21110-00-33	14- 1	275-81350-20
		15-14	275-21610-00-35	28-13	275-83336-00
		15-20	275-21635-00	28-14	275-83346-00
		21-19	275-21787-01	28-11	275-83359-00
3- 7	275-11631-00-96	16- 1	275-22110-00-33	25-26	275-83540-00
3- 7	275-11631-00-97	24-39	275-22123-00	17-10	278-27317-00
3- 7	275-11631-00-98	16- 2	275-22141-00	29- 1	284-11111-00
3- 7	275-11631-00-99	18- 0-1	275-23100-60-42	29- 2	284-11311-00
3- 9	275-11633-00	18-16	275-23122-60	29- 4	284-11611-00
3- 7	275-11635-00	18- 6	275-23124-60	29- 4	284-11611-10
3- 7	275-11636-00	18- 9	275-23125-60	29- 4	284-11611-20
3- 4	275-11681-00	18- 1	275-23126-60-35	29- 3	284-11631-00-95
3- 6	275-11685-00	18- 2	275-23136-60-35	29- 3	284-11631-00-96
13- 0-1	275-13101-00	18- 5	275-23157-60	29- 3	284-11631-00-97
13-12	275-13110-00	18-25	275-23340-60-33	29- 3	284-11631-00-98
13- 2	275-13175-00	18-26	275-23346-60	29- 3	284-11635-00
10-14	275-13555-00	18-44	275-23435-00	29- 3	284-11636-00
10-15	275-13556-00	23-33	275-25181-00	30- 1	284-14101-60
11- 0-1	275-14101-60	23-40	275-25186-00	30- 3	284-14141-55
11-16	275-14112-15	24- 2	275-25304-00	30-22	284-14453-00
11-17	275-14116-01	24- 1	275-25311-00	31-27	284-21787-00
11-20	275-14131-00	24- 7	275-25317-00	31-11	284-21510-00-35
		24-11	275-25321-00	31-14	284-21512-00-35
11-32	275-14175-00	24-21	275-25327-00	31-12	284-21513-00-35
11-31	275-14178-00	24-10	275-25328-00	31-13	284-21514-00-35
11-15	275-14181-00	24-25	275-25364-00	31- 1	284-23100-00-35
11-11	275-14185-00	24-24	275-25366-00	30-24	284-82319-00
10- 1	275-14411-00	24-32	275-25367-00	30-17	285-14411-00
10- 4	275-14412-00	24-37	275-25371-00	30-20	285-14412-00
10-12	275-14453-00	24-38	275-25373-00	30-18	285-14451-00
12- 1	275-14610-30	24-31	275-25377-00	30-21	285-14455-00
12- 3	275-14752-30	24-33	275-25382-00	30-19	285-14458-00
12- 2	275-14753-30	24-20	275-25383-00	30- 5	285-14610-10
1- 1	275-15111-00	19-27	275-26312-00	30- 6	285-14781-11
1- 2	275-15121-00	17-19	275-27231-00	30-10	285-14791-10
8- 0-1	275-15610-00-93	14- 0-1	275-81300-20	31-28	285-21639-00
				3-10	604-11634-00
				11-24	802-14161-00
				11-26	802-14169-00
				11-35	802-14173-00
				11-34	802-14174-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
26-16	802-84126-00	23-37	91401-30028	13-15	92901-05100
7- 3	91101-06020	24-34	91401-30028	18-76	92901-05100
26-10	91101-06035	19-16	91402-12015	25- 8	92901-05100
12-13	91102-06020	17-12	91403-20025	27-11	92901-05100
9-12	91201-06010	22- 5	91502-05055	27-15	92901-05100
22-13	91201-06010	1- 3	91800-05016	27-18	92901-05100
15- 4	91201-06012	2-16	91800-05016	27-24	92901-05100
18-70	91201-06012	12- 8	91903-06012	18-77	92901-05200
27-26	91201-06012	30-23	92501-06008	19-17	92901-05200
31-22	91201-06012	10- 5	92501-06010	22- 6	92901-05200
31-24	91201-06012	12- 4	92501-06010	7-11	92901-06100
12-22	91201-06015	26- 7	92501-06010	9-13	92901-06100
31- 3	91201-06015	14-16	92501-06015	10- 6	92901-06100
31-15	91201-06018	1- 7	92501-06025	12- 5	92901-06100
10- 9	91201-06020	15-30	92501-06025	12-14	92901-06100
15-23	91201-06020	2-11	92501-06030	12-20	92901-06100
16-16	91201-06020	2-14	92501-06030	12-23	92901-06100
18-67	91201-06020	2-15	92501-06040	14-17	92901-06100
30- 7	91201-06020	1- 5	92501-06045	15- 5	92901-06100
15-17	91201-06025	2- 5	92501-06050	15-18	92901-06100
17-15	91201-06025	2- 6	92501-06050	15-31	92901-06100
21- 7	91201-06025	1- 6	92501-06060	16-18	92901-06100
23-23	91201-06030	1- 4	92501-06065	18-71	92901-06100
25-36	91201-06030	2-13	92501-06065	19- 5	92901-06100
12-19	91201-06035	7-10	92801-06100	19-13	92901-06100
30-14	91201-06045	16-17	92801-06100	21- 8	92901-06100
22- 3	91202-06012	18-68	92801-06100	23-25	92901-06100
19- 4	91203-06020	23-24	92801-06100	26- 6	92901-06100
19- 6	91203-06020	26-19	92801-06100	26-15	92901-06100
24-17	91203-06020	28-17	92801-06100	27-27	92901-06100
19-12	91203-06020	30- 9	92801-06100	28-18	92901-06100
18-28	91311-08020	31-23	92801-06100	30- 8	92901-06100
4-25	91401-10010	19- 7	92802-06500	30-16	92901-06100
13-19	91401-12018	31-31	92802-06500	31- 4	92901-06100
18-60	91401-20015	26-14	92803-06700	31-20	92901-06100
17-22	91401-25012	31-21	92803-06700	12- 6	92901-06200
6- 6	91401-25018	11-40	92901-04100	12-24	92901-06200
24-42	91401-25018	14- 6	92901-04100		
		14- 9	92901-04200		
		25-14	92901-04200		
		1-11	92901-05100		
		6-29	92901-05100	16-19	92901-06200

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
17-21	92901-06200	23-10	93102-20009	2- 2	93430-09019
23-26	92901-06200	5-33	93102-35054	6-21	93430-09019
25-37	92901-06200	3-14	93103-30044	6- 7	93430-10016
26-20	92901-06200	3-18	93103-42045	7-12	93430-10016
31-19	92901-06200	23-30	93104-07003	5- 4	93440-25019
10-18	92901-08100	24- 9	93104-46029	5-28	93440-25019
15-13	92901-08100	23-19	93105-50010	5-39	93450-40001
16-21	92901-08100	24-29	93106-25003	5-17	93450-52014
16-24	92901-08100	5-14	93109-07009	18-38	93501-04011
17- 8	92901-08100	9- 8	93210-07100	18-41	93503-16010
18-27	92901-08100	9- 7	93210-13016	4-12	93505-16006
18-33	92901-08100	23-31	93210-14104	13-22	93505-32002
18-47	92901-08100	3-20	93210-25070	13- 3	93603-22028
18-74	92901-08100	24-22	93210-31114	6- 9	93604-14012
28- 8	92901-08100	31- 7	93210-67057	23-39	93700-06001
31-26	92901-08100	11-41	93210-37140	24-23	93700-06001
1-28	92901-08200	4- 2	93210-20102	23- 4	94132-19063
16-25	92901-08200	23- 9	93306-20201	32- 1	94127-21071
31- 8	92901-08200	23-11	93306-20203	24- 4	94140-18062
13- 9	92901-08400	5-38	93306-20301	32- 7	94140-18070
15- 8	92901-10100	24- 8	93306-20301	32- 2	94227-21031
24-40	92901-10100	5-16	93306-20508	23- 5	94232-19029
16- 8	92901-14100	5-32	93306-30506	24- 5	94240-18024
3-16	92901-12100	3-12	93306-30602	32- 3	94327-21024
25-22	92901-12300	3- 8	93310-21824	23- 6	94332-19021
28-22	92901-12300	3- 5	93310-42541	24- 6	94340-18022
3-22	92901-18100	5-12	93315-22004	23- 3	94416-19035
		4-16	93341-23305	32- 4	94416-21038
		5-42	93410-15005	24- 3	94418-18051
		8-21	93410-15005	24-47	94515-20100
		5-10	93410-19015	24-48	94615-20001
		5-27	93410-19015	29-12	94700-00016
22- 4	92902-06100	8-10	93410-20009	27-20	94700-00035
15-40	92902-06200	23-12	93410-22014	17- 7	97101-08020
22-14	92902-06200	24-30	93410-52022	18-73	97103-08025
13-17	93101-10001	5-13	93420-26024	18-48	97103-08030
13- 5	93101-10002	3-13	93420-72023	18-55	97103-08030
7- 5	93101-12004	6-25	93430-07012	18-45	97103-08045
8- 8	93101-20008	13- 6	93430-08006		

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
16-20	97201-08015				
31-25	97201-08015				
16-22	97201-08025				
8- 7	97201-08030				
18-32	97201-08030				
20-21	98501-04008				
11-39	98501-04015				
27-14	98501-05008				
27-23	98501-05008				
1-10	98501-05010				
6-28	98501-05010				
16-13	98501-05010				
27-10	98501-05010				
25- 7	98501-05012				
2- 4	98501-05015				
13-11	98501-05015				
27-17	98501-05020				
27-30	98503-05015				
19-20	98503-05020				
6-11	98701-05015				
13-16	98801-05200				
25- 9	98801-05200				
10-17	98801-08100				
16-23	98801-08100				
28- 7	98801-08100				
1-27	98801-08200				
7-16	98801-08300				
13-10	98801-08300				
24-41	98801-10500				
24-43	98801-10500				
16- 9	98801-14100				
19-15	98802-05500				
18-72	98802-08200				
24-36	98803-08300				
18-46	98803-08700				
17-11	98803-10500				
13-20	98901-04008				

www.legends-yamaha-enduros.com

First edition, Feb., '70

YAMAHA RT1/RT1-M

PARTS LIST

YAMAHA MOTOR CO., LTD.

HAMAKITA JAPAN

www.legends-yamaha-enduros.com



YAMAHA MOTOR CO., LTD.

PRINTED IN JAPAN