



Motor Cycle
PARTS



PRICES
For CS1 and ES2 Models

Norton Motors (1926) Ltd.

**BRACEBRIDGE STREET,
BIRMINGHAM, England.**

**Telephone—
CENTRAL 2351-2352,
Private Branch Exchange**

**Telegrams—
"NORTOMO,
BIRMINGHAM."**

CONTENTS.

	Page No.	Illustration Page No.
Carburetter (state Type when ordering Spares)	8	III.
Connecting Rod, Cylinders, Pistons, etc.	3 and 4	I.
Crankcase, Flywheels, Main Bearings, etc.	3	I.
Deposit Account	2	
Dry Sump Oil Parts	7	III.
Estimates for Repairing Machines	2	
Exhaust Pipe and Silencer	8 and 9	IV.
Foot Rests and Rear Brake Actuating Parts	12	IX.
Frame, Stands, Mudguards, etc.	9 and 10	V. and VI.
Front Fork and Steering Damper	10	VII.
Gear Box Parts	14 to 16	XI. and XII.
Handle Bars and Fittings, etc.	11 and 12	IX.
Instructions for ordering Spare Parts	2	
Lucas K.R.J.I. Magneto and Separate Dynamo Parts, etc.	6 and 7	II. and III.
Mechanical Oil Pump, with Sight Feed	7 and 8	III.
Model ES2 Timing Cover, Pushrods, Rockers, etc.	4 and 5	II.
O.H.C. Vertical Shaft Drive and Rocker Box, etc.	5 and 6	II.
Parts by C.O.D. System	2	
Petrol Tank, Oil Tanks and Fittings	10 and 11	VIII.
Returning Machines for Overhauling	2	
Terms of Business	2	
Transmission Parts	16 and 17	XIII. and XIV.
Wheels	12 and 13	X.

CRANKCASE, FLYWHEELS, MAIN BEARINGS, ETC.

Part No.				£	s.	d.
4000	Crank Case, with Bevel and Oil Pump Cover, Studs, Bolts and Nuts complete	Model CS1	...	8	10	0
4001	Crank Case, with Timing Cover, Bushes, Studs, Bolts and Nuts complete	Model ES2	...	7	5	0
4002	Crank Case, Bevel and Oil Pump Cover	Model CS1	...	0	15	6
4003	Crank Case Timing Cover	Model ES2	...	1	5	0
4004	Camshaft Bush (Crank Case)	Model ES2	each	0	2	6
4005	Camshaft Bush (Timing Cover)	Model ES2	each	0	2	6
4006	Rocker Shaft Bush (Crank Case)	Model ES2	each	0	2	3
4007	Flywheels, complete with Shafts, Crank Pin Bearing and Connecting Rod	Model CS1	...	6	10	0
4008	Flywheels, complete with Shafts, Crank Pin Bearing and Connecting Rod	Model ES2	...	6	10	0
4009	Flywheel Timing Side, with Shaft	Model CS1	...	1	17	6
4010	Flywheel Timing Side, with Shaft	Model ES2	...	1	15	0
4011	Flywheel Driving Side, with Shaft	Models CS1 & ES2	...	1	15	0
4012	Crank Pin Bearing, with Nuts	Models CS1 & ES2	...	1	12	0
4013	Crank Pin Bearing Nut Locking Washer	Models CS1 & ES2 each	...	0	0	3
4014	Crank Pin Bearing Nut Locking Pin	Models CS1 & ES2 each	...	0	0	1
4015	Crank Pin Bearing Nuts	Models CS1 & ES2 each	...	0	0	8

NOTE.—CRANK PIN SPARE PARTS CANNOT BE SUPPLIED SEPARATELY, EACH OUTER RACE HAS ITS INDIVIDUAL PIN.

4016	Main Ball Bearing (state Model and whether for timing or driving side)	Models CS1 & ES2	...	0	11	6
4017	Bevel and Oil Pump Cover Screws	Model CS1	each	0	0	3
4018	Bevel and Oil Pump Cover Screws' Fibre Washers	Model CS1	...	0	0	9
4019	Timing Cover Screws	Model ES2	each	0	0	3
4020	Crank Case Drain Plug	Models CS1 & ES2	...	0	0	6
4021	Front Chain Oil Pipe Union	Models CS1 & ES2	...	0	1	3
4022	Front Chain Oil Pipe Union Nut	Models CS1 & ES2	...	0	0	8
4023	Front Chain Oil Pipe Union Washer	Models CS1 & ES2	...	0	0	2
4024	Front Chain Oil Pipe Union Disc	Models CS1 & ES2	...	0	0	1
4025	Front Chain Oil Pipe Union Disc Spring	Models CS1 & ES2	...	0	0	1
4026	Front Chain Oil Pipe Union Disc Plunger Spring	Models CS1 & ES2	...	0	0	1
4027	Front Chain Oil Pipe Union Plunger	Models CS1 & ES2	...	0	0	3
4028	Front Chain Oil Pipe	Models CS1 & ES2	...	0	2	0
4029	Crank Case Plug (front)	Models CS1 & ES2	...	0	0	6
4030	Crank Case Delivery or Return Oil Pipe Union ...	Models CS1 & ES2	...	0	1	3
4031	Crank Case Rocker Box Oil Pipe Union	Models CS1 & ES2	...	0	1	3
4032	Crank Case Cylinder Studs	Models CS1 & ES2 each	...	0	0	6
4033	Crank Case Bolt and Exhaust Pipe Support ...	Models CS1 & ES2 each	...	0	1	9
4034	Crank Case Bolt, with Nuts, $\frac{7}{16}$ in. $\times$ $5\frac{1}{4}$ in. ...	Models CS1 & ES2 each	...	0	1	6
4035	Crank Case Bolt, with Nuts, $\frac{3}{8}$ in. $\times$ 3 in.	Models CS1 & ES2 each	...	0	1	0
4036	Crank Case Bolt, with Nuts, $\frac{5}{16}$ in. $\times$ 4 in.	Models CS1 & ES2 each	...	0	1	3
4037	Crank Case Bolt, with Nuts, $\frac{1}{4}$ in. $\times$ $3\frac{3}{4}$ in. ...	Models CS1 & ES2 each	...	0	1	0
4038	Front Engine Plate	Models CS1 & ES2 each	...	0	7	6
4039	Front Engine Plate Cover	Models CS1 & ES2 each	...	0	2	3
4040	Frame Cradle Bolt, with Nuts, $\frac{5}{16}$ in. $\times$ $4\frac{1}{2}$ in. ...	Models CS1 & ES2 each	...	0	1	6
4041	Frame Cradle and Chain Case Attachment Bolt, with Nuts	Models CS1 & ES2 each	...	0	1	9
4042	Front Engine Plate, Bolts with Nuts, $\frac{7}{16}$ in. $\times$ $3\frac{1}{2}$ in.	Models CS1 & ES2 each	...	0	1	6
4043	Rear Engine Plate Bolts, with Nuts, $\frac{7}{16}$ in. $\times$ $3\frac{1}{2}$ in.	Models CS1 & ES2 each	...	0	1	6
4044	Rear Engine Plate Bolts, with Nuts, $\frac{3}{8}$ in. $\times$ $3\frac{1}{4}$ in.	Models CS1 & ES2 each	...	0	1	3

CONNECTING ROD, CYLINDERS, PISTONS, ETC.

4045	Connecting Rod, with Small End Bush	Models CS1 & ES2	...	1	5	6
4046	Connecting Rod Small End Bush	Models CS1 & ES2	...	0	3	6
4047	Piston	Models CS1 & ES2	...	1	10	0
4048	Piston High Compression, for use with Alcohol Fuels	Models CS1 & ES2	...	1	12	6

INSTRUCTIONS FOR ORDERING SPARE PARTS.

This Spare Parts List deals only with replacement parts for **CS1** and **ES2** Models. It is most essential that the Engine and Frame Number of the machine is stated. The Engine Number is to be found on the transmission side of the Crankcase, and the Frame Number is stamped on the Seat Lug of the Frame on the rear side of the machine. It is always advisable to order parts on a separate sheet, and not to include on the same sheet other matter of a different nature ; this facilitates prompt despatch.

It is found in a number of instances that money orders and postal orders are sent in parcels containing patterns ; this is inadvisable. We strongly recommend parts as patterns being despatched separately, and a covering letter sent containing the remittance for replacement parts.

RETURNING MACHINES FOR OVERHAULING.

When returning machines or parts for repair or overhaul, these should be sent carriage paid, and with the sender's name and address in full **securely** attached. It is also advisable to state on the tally that a letter has been sent respecting the parts, and giving the date. All easily detached fittings should be removed, such as Lamps, Horns, Tool Bags, Speedometers, etc., these are liable to be lost or damaged in transit, and the Company cannot accept any responsibility for them.

ESTIMATES FOR REPAIRING MACHINES.

We are always prepared to give approximate estimates for the cost of repairs ; it is quite impossible to give a firm quotation. Additional parts may be found necessary during the process of repair, unforeseen when preparing an estimate. Should our estimate for repair not be accepted, a charge may be made in accordance with work entailed in dismantling and re-assembling. When we give an estimate for the cost of repairs, and this is curtailed by the owner, we cannot accept any responsibility for the performance of the machine, it is always preferable to accept our estimate in full.

TERMS OF BUSINESS.

Our terms are strictly nett cash with order, or cash against repayment invoice. The exact amount, including postage, must be remitted, or when the cost of the parts required is unknown, a sum likely to cover the cost should be enclosed, if the amount remitted is more than the cost of the parts that are ordered, the balance will either be placed to a credit account or returned at our clients' option. Cheques and Postal Orders should be made payable to "Norton Motors (1926) Ltd." and crossed Barclays Bank Ltd. Prices quoted in this list do not include the cost of carriage or fitting. We reserve the right to alter prices or specification of any parts at any time without notice. Where parts are urgently required, remittance may be sent by Telegraphic Money Order, **but it is absolutely essential that the sender fill in his full name and address in the space provided on the Post Office Money Order Form.** Unless this is done the Post Office do not give us the information in the telegram. It is necessary that all orders given by wire or 'phone should be confirmed by letter at the earliest opportunity.

DEPOSIT ACCOUNT.

We strongly recommend riders of our machines to open a deposit account ; this can be done by depositing with us not less than £4. This will ensure goods to that value being despatched with the least possible delay. When ordering by 'phone, wire, or post, this often avoids great inconvenience, and for the benefit of the depositor a monthly statement of account is rendered, showing credit balance. Under no circumstances whatever can parts be despatched without remittance covering same has been sent, unless a deposit account is opened. Should the machine be disposed of at a later date we are always prepared to remit any amount that may be remaining.

PARTS BY C.O.D. SYSTEM.


We have made arrangements to supply spare parts in accordance with the Postal Regulations, and clients can confidently use the Cash on Delivery System when ordering spare parts. Spares can be ordered either by wire, telephone, or by letter, the cash to be payable to the Postal Authorities upon delivery of the parcel. **This should be definitely stated when ordering parts**, otherwise a *pro forma* invoice may be sent along, which, of course, occasions delay.


CONNECTING ROD, CYLINDERS, PISTONS, Etc.—continued.

Part No.						£	s.	d.
4049	Piston Rings	...	...	...	Models CS1 & ES2 each	0	1	9
4050	Gudgeon Pin	...	...	...	Models CS1 & ES2	0	4	6
4051	Gudgeon Pin Circlip	...	...	...	Models CS1 & ES2 (2 per set)	0	0	6
4052	Cylinder Barrel only	...	...	...	Model CS1	2	15	0
4053	Cylinder Barrel only	...	...	...	Model ES2	2	12	6
4054	Cylinder Head, with Valve Guides only	...	...	...	Model CS1	3	15	6
4055	Cylinder Head, with Valve Guides only	...	...	...	Model ES2	3	12	0
4056	Valve Guide Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	3	6
4057	Valve Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	9	9
4058	Valve Spring Outer Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	2	0
4059	Valve Spring Inner Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	0	8
4060	Valve Spring Collar Top Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	2	9
4061	Valve Spring Collar Bottom Inlet or Exhaust	...	...	...	Models CS1 & ES2	0	0	6
4062	Valve Cotter (Split)	...	...	...	Models CS1 & ES2 per valve	0	0	6
4063	Compression Plug	...	...	...	Models CS1 & ES2	0	3	0
4064	Compression Plug or Sparking Plug Washer	...	...	...	Models CS1 & ES2	0	0	3
4065	Sparking Plug (K.L.G., HS3)	...	...	...	Models CS1 & ES2	0	7	6
4066	Carburettor Adapter, 1¼ in.	...	...	...	Models CS1 & ES2	0	4	0
4067	Cylinder Head Holding-down Stud	...	...	...	Model ES2	0	0	9
4068	Cylinder Head Holding-down Sleeve Nut	...	...	...	Model ES2	0	1	0
4069	Cylinder Base Holding-down Nut	...	...	...	Model ES2	0	0	10
4070	Cylinder Base Holding-down Nut	...	...	...	Model CS1	0	0	9
4071	Cylinder Barrel and Head Attachment Bolt	...	...	...	Model CS1	0	1	9
4072	Cylinder Head Holding-down Sleeve Nut	...	...	...	Model CS1	0	1	3
4073	Cylinder Head Holding-down Sleeve Nut Washer	...	...	...	Model CS1	0	0	2
4074	Rocker Box Platform Securing Bolts	...	...	...	Model CS1	0	0	10
4075	Rocker Box Platform Securing Bolts' Spring Washers	...	...	...	Model CS1	0	0	2
4076	Cylinder Base Paper Washer	...	...	...	Models CS1 & ES2 (not illustrated)	0	0	3
4077	Pump and Bevel Cover Paper Washer	...	...	...	Model CS1	0	0	5

MODEL ES2 TIMING COVER, PUSHRODS, ROCKERS, ETC.

4078	Half-time Pinion	...	...	...	Model ES2	0	4	0
4079	Half-time Pinion Lock Nut	...	...	...	Model ES2	0	0	6
4080	Exhaust Cam Wheel	...	...	...	Model ES2	0	8	0
4081	Inlet Cam Wheel	...	...	...	Model ES2	0	8	0
4082	Exhaust Cam	...	...	...	Model ES2	0	12	6
4083	Inlet Cam	...	...	...	Model ES2	0	12	6
4084	Rocker Inlet (Crank Case)	...	...	...	Model ES2	0	5	0
4085	Rocker Exhaust (Crank Case)	...	...	...	Model ES2	0	5	0
4086	Tappet Guide Inlet or Exhaust	...	...	...	Model ES2	0	2	6
4087	Tappet Inlet or Exhaust	...	...	...	Model ES2	0	3	0
4088	Push Rod Return Spring Inlet or exhaust	...	...	...	Model ES2	0	0	9
4089	Push Rod Return Spring Cover	...	...	...	Model ES2	0	2	6
4090	Push Rod, complete with Ends Inlet or Exhaust	...	...	...	Model ES2	0	8	6
4091	Push Rod Top	...	...	...	Model ES2	0	2	3
4092	Push Rod Bottom	...	...	...	Model ES2	0	2	9
4093	Push Rod Oil Retaining Rubber Cover	...	...	...	Model ES2	0	0	4
4094	Rocker Adjusting Screw, with Lock Nut	...	...	...	Model ES2	0	2	0
4095	Rocker Adjusting Screw Lock Nut	...	...	...	Model ES2	0	0	4
4096	Rocker only (inlet)	...	...	...	Model ES2	1	0	0
4097	Rocker only (exhaust)	...	...	...	Model ES2	1	0	0
4098	Rocker Arm Grease Nipple	...	...	...	Model ES2	0	0	7
4099	Rocker Arm Centre Bolt, with Nut (Exhaust)	...	...	...	Model ES2	0	4	6
4100	Rocker Arm Centre Bolt, with Nut (Inlet)	...	...	...	Model ES2	0	3	0
4101	Rocker Centre Bolt Nut	...	...	...	Model ES2	0	0	2
4102	Rocker Roller Retaining Cage	...	...	...	Model ES2	0	8	6
4103	Rocker Rollers	...	...	...	Model ES2	0	2	6
4104	Rocker Roller Retaining Washers	...	...	...	Model ES2	0	0	5






MODEL ES2 TIMING COVER, PUSHRODS, ROCKERS, Etc.—continued.

Part No.				£	s.	d.
4105	Rocker Carrier Standards, complete with Tie Rod, Distance Tube and Nuts	Model ES2	...	1	13	0
4106	Rocker Carrier Standard only (Inlet)	Model ES2	...	0	15	0
4107	Rocker Carrier Standard only (Exhaust)... ..	Model ES2	...	0	16	0
4108	Rocker Carrier Standard Holding-down Bolt	Model ES2	...	0	2	3
4109	Rocker Carrier Standard Holding-down Bolt Washer	Model ES2	...	0	0	2
4110	Rocker Carrier Standard Tie Rod, with Nuts	Model ES2	...	0	1	3
4111	Rocker Carrier Standard Tie Rod Nuts	Model ES2	...	0	0	2
4112	Rocker Carrier Standard Tie Rod Distance Piece	Model ES2	each	0	0	9
4113	Exhaust Valve Lifter Arm	Model ES2	...	0	4	9
4114	Exhaust Valve Lifter Arm Return Spring	Model ES2	...	0	1	3

O.H.C. VERTICAL SHAFT DRIVE AND ROCKER BOX, ETC.

4115	Mainshaft Bevel	Model CS1	...	1	10	0
4116	Mainshaft Bevel Key	Model CS1	...	0	0	2
4117	Mainshaft Bevel Washer	Model CS1	...	0	0	2
4118	Vertical Shaft Bottom Bevel	Model CS1	...	2	10	0
4119	Vertical Shaft Bottom Bevel Washer	Model CS1	...	0	0	6
4120	Vertical Shaft Bottom Bevel Retaining Nut	Model CS1	...	0	1	3
4121	Vertical Shaft Bottom Bevel Bearing	Model CS1	...	0	11	6
4122	Vertical Shaft Bottom Bevel Bearing Housing	Model CS1	...	0	12	6
4123	Vertical Shaft Bottom Bevel Locking Ring	Model CS1	...	0	1	9
4124	Vertical Shaft Bottom Bevel Housing Bolts	Model CS1	each	0	0	6
4125	Vertical Shaft (only)	Model CS1	...	1	15	0
4126	Vertical Shaft Top Bevel	Model CS1	...	2	0	0
4127	Vertical Shaft Top Bevel Key	Model CS1	...	0	0	2
4128	Vertical Shaft Top Bevel Washer	Model CS1	...	0	0	3
4129	Vertical Shaft Top Bevel Locking Nut	Model CS1	...	0	1	9
4130	Vertical Shaft Top Bevel Bearing	Model CS1	...	0	11	6
4131	Vertical Shaft Top Bevel Bearing Locking Ring	Model CS1	...	0	1	0
4132	Vertical Shaft Top Bevel Bearing Housing	Model CS1	...	0	4	6
4133	Vertical Shaft Top Bevel Bearing Housing Lock- ing Ring	Model CS1	...	0	1	0
4134	Vertical Shaft Tube	Model CS1	...	0	3	6
4135	Vertical Shaft Tube Fibre Washer	Model CS1	...	0	0	1
4136	Vertical Shaft Tube Union Ring	Model CS1	...	0	1	9
4137	Vertical Shaft Tube Top Bevel bearing Housing Rubber Washer	Model CS1	...	0	0	9
4138	Camshaft Bevel	Model CS1	...	1	15	0
4139	Camshaft Bevel Key	Model CS1	...	0	0	2
4140	Camshaft Bevel Washer	Model CS1	...	0	0	4
4141	Camshaft Bevel Retaining Nut	Model CS1	...	0	0	2
4142	Camshaft Bevel Bearing	Model CS1	...	0	10	3
4143	Rocker Box Bearings Housing Locking Washer	Model CS1	...	0	0	5
4144	Rocker Box Bearings Housing Locking Washer Screws	Model CS1	each	0	0	1
4145	Rocker Box, with Cover	Model CS1	...	4	0	0
4146	Rocker Box Cover	Model CS1	...	1	2	6
4147	Rocker Box Cover Screws	Model CS1	...	0	0	2
4148	Rocker Box Cover Washer	Model CS1	...	0	0	1
4149	Exhaust Valve Lifter Cable Stop	Model CS1	each	0	0	6
4150	Exhaust Valve Lifter Arm	Model CS1	...	0	3	0
4151	Exhaust Valve Lifter Arm Bolt and Nut	Model CS1	...	0	1	3
4152	Exhaust Valve Lifter Arm Return Spring	Model CS1	...	0	0	9
4153	Cam Rocker Shaft Bushes (Cover)	Model CS1	...	0	2	6
4154	Cam Rocker Shaft Bushes (Rocker Box)... ..	Model CS1	...	0	2	6
4155	Cam Rocker Shaft Cork Oil Retaining Washers... ..	Model CS1	each	0	0	2
4156	Rocker Box Inspection Cover	Model CS1	...	0	2	6
4157	Rocker Box Inspection Cover Rubber Washer	Model CS1	...	0	0	3
4158	Rocker Box Inspection Cover Retaining Pins	Model CS1	each	0	0	2
4159	Vertical Shaft Tube Bottom Rubber Sealing Washer	Model CS1	...	0	0	9



O.H.C. VERTICAL SHAFT DRIVE AND ROCKER BOX, Etc.—continued.

Part No.						£	s.	d.
4160	Cam Shaft Bevel Bearing Housing	...	...	Model CS1	...	0	0	6
4161	Rocker Box Oil Pipe Union	...	...	Model CS1	...	0	1	3
4162	Rocker Box Oil Pipe Union Nut	...	...	Model CS1	...	0	0	8
4163	Rocker Box Oil Pipe Union Washer	...	...	Model CS1	...	0	0	2
4164	Rocker Box Oil Pipe	...	...	Model CS1	...	0	3	9
4165	Camshaft	...	...	Model CS1	...	0	8	6
4166	Camshaft Key	...	...	Model CS1	...	0	0	2
4167	Cams (Inlet, Exhaust, Integral)	...	...	Model CS1	...	1	5	0
4168	Cam Rocker (Inlet)	...	...	Model CS1	...	0	18	6
4169	Cam Rocker (Exhaust)	...	...	Model CS1	...	0	18	6
4170	Cam Rocker Pads	...	...	Model CS1	...	0	2	6
4171	Valve Rocker Arm (Exhaust)	...	...	Model CS1	...	0	4	0
4172	Valve Rocker Arm (Inlet)	...	...	Model CS1	...	0	4	0
4173	Valve Rocker Arm Key	...	...	Model CS1	...	0	0	2
4174	Valve Rocker Arm Nut	...	...	Model CS1	...	0	0	2
4175	Valve Rocker Adjusting Screw, with Lock Nut	...	...	Model CS1	...	0	2	0
4176	Valve Rocker Adjusting Screw Lock Nut	...	...	Model CS1	...	0	0	4
4177	Rocker Box Platform	...	...	Model CS1	...	0	2	6
4178	Rocker Box Bolt	...	...	Model CS1	...	0	0	9
4179	Rocker Box Bolt Spring Washers	...	...	Model CS1	... each	0	0	1

LUCAS K.R.J.I. MAGNETO AND SEPARATE DYNAMO PARTS, ETC.

4180	Magneto Lucas K.R.J.I., with Base Plate	...	Models CS1 & ES2	...	5	15	0
4181	Magneto Sprocket	...	Models CS1 & ES2	...	0	6	6
4182	Magneto Sprocket Nut	...	Models CS1 & ES2	...	0	0	6
4183	Magneto Sprocket Nut Washer	...	Models CS1 & ES2	...	0	0	2
4184	Magneto Base Plate	...	Models CS1 & ES2	...	0	3	0
4185	Magneto Base Plate Screws	...	Models CS1 & ES2 each	...	0	0	1
4186	Magneto Securing Stud	...	Models CS1 & ES2	...	0	1	0
4187	Magneto Securing Stud Nut...	...	Models CS1 & ES2	...	0	0	3
4188	Washer for above	...	Models CS1 & ES2	...	0	0	1
4189	High Tension Cable, with Terminal only	...	Models CS1 & ES2	...	0	1	9
4190	Carbon Brush Holder, with Brush and Spring	...	Models CS1 & ES2	...	0	4	6
4191	Carbon Brush, with Spring...	...	Models CS1 & ES2	...	0	0	8
4192	Contact Breaker, complete	...	Models CS1 & ES2	...	1	0	0
4193	Contact Breaker Pin	...	Models CS1 & ES2	...	0	0	6
4194	Bell Crank Lever, with Platinum Screw	...	Models CS1 & ES2	...	0	4	6
4195	Long Platinum Screw, with Lock Nut	...	Models CS1 & ES2	...	0	4	6
4196	Contact Breaker Cover	...	Models CS1 & ES2	...	0	2	0
4197	Contact Breaker Cover Spring, with Arm	...	Models CS1 & ES2	...	0	1	0
4198	Ignition Control Cable Adjuster, with Lock Nut	...	Models CS1 & ES2	...	0	0	6
4199	Ignition Control Cable Return Spring	...	Models CS1 & ES2	...	0	0	2
4200	Ignition Control Cable Rubber Cap	...	Models CS1 & ES2	...	0	0	6
4201	Magneto Platform	...	Models CS1 & ES2	...	0	11	9
4202	Engine Main Shaft Magneto Drive Sprocket	...	Models CS1 & ES2	...	0	7	6
4203	Magneto Chain	...	Models CS1 & ES2	...	0	6	6
4204	Magneto Chain Double Cranked Link	...	Models CS1 & ES2	...	0	1	6
4205	Magneto Chain Spring Link	...	Models CS1 & ES2	...	0	0	11
4206	Lucas Dynamo (only), complete	...	Models CS1 & ES2	...	2	15	0
4207	Dynamo Sprocket	...	Models CS1 & ES2	...	0	5	6
4208	Dynamo Sprocket Nut	...	Models CS1 & ES2	...	0	0	6
4209	Dynamo Sprocket Nut Cotter Pin	...	Models CS1 & ES2	...	0	0	1
4210	Dynamo Strap	...	Models CS1 & ES2	...	0	3	6
4211	Dynamo Strap Swivel Pin	...	Models CS1 & ES2	...	0	1	6
4212	Dynamo Strap Tension Bolt Anchor Pin	...	Models CS1 & ES2	...	0	1	0
4213	Dynamo Strap Tension Bolt	...	Models CS1 & ES2	...	0	1	6
4214	Front Engine Plate (Dynamo Model), left-hand side	...	Models CS1 & ES2	...	0	2	6
4215	Front Engine Plate (Dynamo Model), right-hand side	...	Models CS1 & ES2	...	0	2	6
4216	Dynamo Chain	...	Models CS1 & ES2	...	0	6	0

MECHANICAL OIL PUMP, WITH SIGHT FEED.—continued.

Part No.						£	s.	d.
4263	Bottom Plug Screw, with Fibre Washer	...	...	...	Model ES2	...	0	0 4
4264	Oil Feed Regulator Dial	...	...	...	Model ES2	...	0	1 8
4265	Oil Feed Control Bar	...	...	...	Model ES2	...	0	1 2
4266	Oil Feed Control Bar Cotter	...	...	...	Model ES2	...	0	0 1
4267	Oil Feed Control Bar Pin	...	...	...	Model ES2	...	0	0 1
4268	Oil Feed Control Bar Spring and Pin	...	...	...	Model ES2	...	0	0 3
4269	Plunger Leather Washer	...	...	...	Model ES2	...	0	0 3
4270	Pump Attachment Pin (long)	...	...	...	Model ES2	...	0	0 4
4271	Pump Attachment Pin (short)	...	...	...	Model ES2	...	0	0 4
4272	Pump Attachment Pin Nuts	...	...	...	Model ES2	each	0	0 1
4273	Pump Body Fibre Packing Washer	...	...	...	Model ES2	...	0	1 0

CARBURETTER (STATE TYPE WHEN ORDERING SPARES).

4274	Carburetter, complete	...	...	...	Models CS1 & ES2	...	3	1 0
4275	Float Chamber Body	...	...	...	Models CS1 & ES2	...	0	15 0
4276	Float Chamber Cap	...	...	...	Models CS1 & ES2	...	0	4 3
4277	Float Chamber Cap Spring	...	...	...	Models CS1 & ES2	...	0	0 6
4278	Float	...	...	...	Models CS1 & ES2	...	0	3 6
4279	Float Needle	...	...	...	Models CS1 & ES2	...	0	2 6
4280	Jet (Main), state size required. Size 14 fitted as standard	...	...	...	Models CS1 & ES2	...	0	1 2
4281	Jet (Pilot), state size required. Size 4 fitted as standard	...	...	...	Models CS1 & ES2	...	0	1 0
4282	Spraying Chamber Body	...	...	...	Models CS1 & ES2	...	1	2 0
4283	Spraying Chamber Slides	...	...	...	Models CS1 & ES2	per pair	0	6 10
4284	Spraying Chamber Slide	...	...	...	Models CS1 & ES2 each	...	0	0 10
4285	Spraying Chamber Cap	...	...	...	Models CS1 & ES2	...	0	3 0
4286	Control Cable Adjusters, with Lock Nuts	...	...	...	Models CS1 & ES2 each	...	0	1 6
4287	Spraying Chamber Cap Ring	...	...	...	Models CS1 & ES2	...	0	1 9
4288	Carburetter Adapter Clip Pin	...	...	...	Models CS1 & ES2	...	0	0 6
4289	Float Chamber Holding Screw, with Main Filter	...	...	...	Models CS1 & ES2	...	0	3 0
4290	Float Chamber Holding Screw, C.A. Washer	...	...	...	Models CS1 & ES2	...	0	0 6
4291	Float Needle Valve Seat	...	...	...	Models CS1 & ES2	...	0	1 6
4292	Float Needle Valve Seat Washer	...	...	...	Models CS1 & ES2	...	0	0 3
4293	Petrol Pipe Banjo Feed	...	...	...	Models CS1 & ES2	...	0	1 8
4294	Petrol Pipe Banjo Feed Filter	...	...	...	Models CS1 & ES2	...	0	1 2
4295	Petrol Pipe Banjo Feed Retaining Nut	...	...	...	Models CS1 & ES2	...	0	0 6
4296	Inner Cable	...	...	...	Models CS1 & ES2	...	0	1 7
4297	Outer Cable	...	...	...	Models CS1 & ES2	...	0	1 10
4298	Controls Two Lever, complete	...	...	...	Models CS1 & ES2	...	0	12 0
4299	Throttle Control Lever	...	...	...	Models CS1 & ES2	...	0	3 5
4300	Air Control Lever	...	...	...	Models CS1 & ES2	...	0	3 5
4301	Control Lever Body, with Clip	...	...	...	Models CS1 & ES2	...	0	2 9
4302	Control Lever Body (only)	...	...	...	Models CS1 & ES2	...	0	2 0
4303	Control Lever Cap	...	...	...	Models CS1 & ES2	...	0	0 6
4304	Control Lever Centre Screw	...	...	...	Models CS1 & ES2	...	0	0 4
4305	Twist Grip, complete (state left or right-hand)	...	...	...	Models CS1 & ES2	...	0	13 6

EXHAUST PIPE AND SILENCER.

4306	Exhaust Pipe only	...	...	...	Models CS1 & ES2	...	0	15 0
4307	Exhaust Pipe Flanged Locking Nut (Cylinder Head)	...	...	...	Models CS1 & ES2	...	0	4 6
4308	Exhaust Pipe Flanged Washer (Cylinder Head)	...	...	...	Models CS1 & ES2	...	0	0 6
4309	Exhaust Pipe Clip (for Crank Case Bolt Attachment)	...	...	...	Models CS1 & ES2	...	0	1 9
4310	Silencer, Double Chamber type, complete with Fish Tail	...	...	...	Models CS1 & ES2	...	2	2 0

LUCAS K.R.J.I. MAGNETO AND SEPARATE DYNAMO PARTS, Etc.—continued.

Part No.				£	s.	d.
4217	Dynamo Chain Double Cranked Link	...	Models CS1 & ES2	0	1	6
4218	Dynamo Chain Spring Link	...	Models CS1 & ES2	0	0	11
4219	Engine Shaft Dynamo Drive Sprocket	...	Models CS1 & ES2	0	5	6
4220	Dynamo End Cover Nut and Washer	...	Models CS1 & ES2	0	0	10
4221	Dynamo End Cover	...	Models CS1 & ES2	0	2	3

DRY SUMP OIL PARTS.

4222	Hollow Sleeve	...	Models CS1 & ES2 (when fitted)	0	9	6
4223	Plunger	...	Models CS1 & ES2 (when fitted)	0	5	0
4224	Plunger Knob	...	Models CS1 & ES2 (when fitted)	0	0	9
4225	Plunger Knob Retaining Screw	...	Models CS1 & ES2 (when fitted)	0	0	4
4226	Plunger Knob Track	...	Models CS1 & ES2 (when fitted)	0	4	9
4227	Plug for Bottom of Spindle Hole	...	Models CS1 & ES2 (when fitted)	0	1	6
4228	Worm Wheel...	...	Models CS1 & ES2 (when fitted)	0	4	9
4229	Worm Wheel Key	...	Models CS1 & ES2 (when fitted)	0	0	2
4230	Worm Wheel Nut	...	Models CS1 & ES2 (when fitted)	0	0	3
4231	Worm (Driving)	...	Models CS1 & ES2 (when fitted)	0	2	9
4232	Oil Level Regulator only	...	Models CS1 & ES2 (when fitted)	0	1	6
4233	Oil Level Regulator Knurled Adjuster	...	Models CS1 & ES2 (when fitted)	0	1	9
4234	Oil Level Regulator Knurled Adjuster Pin	...	Models CS1 & ES2 (when fitted)	0	0	2
4235	Oil Level Regulator Cork Washer	...	Models CS1 & ES2 (when fitted)	0	0	1
4236	Oil Level Regulator Ratchet Peg	...	Models CS1 & ES2 (when fitted)	0	0	3
4237	Oil Level Regulator Ratchet Plunger Spring	...	Models CS1 & ES2 (when fitted)	0	0	6
4238	Oil Level Regulator Ratchet Plunger	...	Models CS1 & ES2 (when fitted)	0	0	6
4239	Big End Restricting Jet	...	Models CS1 & ES2 (when fitted)	0	0	4
4240	Big End Restricting Jet Spring	...	Models CS1 & ES2 (when fitted)	0	0	2
4241	Big End Restricting Jet Retaining Screw	...	Models CS1 & ES2 (when fitted)	0	0	5
4242	Big End Restricting Jet Retaining Screw Washer	...	Models CS1 & ES2 (when fitted)	0	0	1
4243	Big End Restricting Jet Bush (Panel Cover)	...	Models CS1 & ES2 (when fitted)	0	0	3
4244	Plug for Oil Pump Body Hole	...	Models CS1 & ES2 (when fitted)	0	0	4
4245	Pump Track Pin	...	Models CS1 & ES2 (when fitted)	0	0	3
4246	Nut for above Pin	...	Models CS1 & ES2 (when fitted)	0	0	2
4247	Oil Delivery Pipe, complete with Regulator and Rubber Connection Pipe	...	Models CS1 & ES2 (when fitted)	0	8	3
4248	Oil Delivery Regulator	...	Models CS1 & ES2 (when fitted)	0	4	3
4249	Oil Delivery Rubber Connection	...	Models CS1 & ES2 (when fitted)	0	0	6
4250	Oil Delivery Pipe from Oil Tank to Rubber Connection	...	Models CS1 & ES2 (when fitted)	0	3	9
4251	Union Nut for above	...	Models CS1 & ES2 (when fitted)	0	0	6
4252	Oil Return Pipe, with Nuts and Unions Crank Case to Oil Box	...	Models CS1 & ES2 (when fitted)	0	3	9

MECHANICAL OIL PUMP, WITH SIGHT FEED.


4253	Mechanical Oil Pump, complete less Pipe	...	Model ES2	...	0	19	0
4254	Mechanical Oil Pump Body only	...	Model ES2	...	0	8	10
4255	Plunger, with Cam Block	...	Model ES2	...	0	6	7
4256	Driving Worm	...	Model ES2	...	0	2	9
4257	Driving Worm Bush	...	Model ES2	...	0	2	3
4258	Gear Wheel	...	Model ES2	...	0	2	3
4259	Sight Feed Celluloid Disc	...	Model ES2	...	0	0	5
4260	Sight Feed Celluloid Disc Frame	...	Model ES2	...	0	0	7
4261	Sight Feed Celluloid Disc Pins	...	Model ES2	each	0	0	1
4262	Top Plug Screw, with Fibre Washer	...	Model ES2	each	0	0	4

EXHAUST PIPE AND SILENCER—continued.

Part No.				l.	s.	d.
4311	Silencer Pin and Nut (Exhaust Pipe Attachment)	Models CS1 & ES2	...	0	0	9
4312	Silencer Pin and Nut (Fish Tail Attachment)	Models CS1 & ES2	...	0	0	9
4313	Fork End Lug Bolt	Models CS1 & ES2	...	0	1	6
4314	Fork End Lug Bolt Nut	Models CS1 & ES2	...	0	0	6
4315	Fork End Lug Bolt Distance Piece	Models CS1 & ES2	...	0	0	3
4316	Silencer Rear Attachment Arm	Models CS1 & ES2	...	0	1	6
4317	Silencer Rear Attachment Arm Pin and Nut	Models CS1 & ES2	...	0	0	3
4318	Fish Tail	Models CS1 & ES2	...	0	3	9
4319	Straight-through Exhaust Pipe only	Models CS1 & ES2	...	1	5	0
4320	Straight-through Exhaust Pipe Rear Clip	Models CS1 & ES2	...	0	2	0
4321	Straight-through Exhaust Pipe Muffle	Models CS1 & ES2	...	0	4	0

FRAME, STANDS, MUDGUARDS, ETC.

4322	Frame only, with Ball Races	Models CS1 & ES2	...	15	0	0
4323	Head Lug Fork Stop	Models CS1 & ES2	...	0	0	6
4324	Head Race	Models CS1 & ES2	...	0	1	6
4325	Head Balls	Models CS1 & ES2	...	0	2	0
		per set		0	2	0
4326	Rear Stand	Models CS1 & ES2	...	1	1	0
4327	Rear Stand Spring	Models CS1 & ES2	...	0	1	6
4328	Rear Stand Bolts	Models CS1 & ES2 each	...	0	0	8
4329	Front Stand	Models CS1 & ES2	...	0	10	0
4330	Front Stand Bolts	Models CS1 & ES2	...	0	0	5
4331	Front Stand Mudguard Attachment Stud, with Nuts	Models CS1 & ES2	...	0	0	9
4332	Nut for above	Models CS1 & ES2	...	0	0	3
4333	Washer for above	Models CS1 & ES2	...	0	0	1
4334	Rear Mudguard only	Models CS1 & ES2	...	0	11	0
4335	Rear Mudguard only (Narrow Racing type)	Models CS1 & ES2	...	0	8	6
4336	Rear Mudguard Stays (D Section) Mudguard	Models CS1 & ES2	...	0	10	0
4337	Rear Mudguard Stay Pins and Nuts	Models CS1 & ES2 each	...	0	0	5
4338	Rear Mudguard Stay Bridge Strap	Models CS1 & ES2	...	0	1	3
4339	Rear Mudguard Stay (Racing type), with Handle	Models CS1 & ES2	...	0	6	6
4340	Rear Mudguard Stay (Racing type), with Chain Guard Attachment Lug	Models CS1 & ES2	...	0	3	6
4341	Front Mudguard only, with Number Plate Studs and Stand Stud	Models CS1 & ES2	...	0	10	0
4342	Front Mudguard only (Narrow Racing type), with Number Plate Studs and Stand Stud	Models CS1 & ES2	...	0	8	0
4343	Front Mudguard Stay	Models CS1 & ES2	...	0	3	6
4344	Front Mudguard Stay Pins	Models CS1 & ES2 each	...	0	0	3
4345	Front Mudguard Stay Racing Type	Models CS1 & ES2 each	...	0	3	6
4346	Front Mudguard Stay Pins (Racing type)	Models CS1 & ES2	...	0	0	3
4347	Front Mudguard Stay Mudguard Attachment Pin and Nut	Models CS1 & ES2	...	0	0	5
4348	Carrier only	Models CS1 & ES2	...	0	12	6
4349	Carrier Attachment Pins and Nuts	Models CS1 & ES2 each	...	0	0	5
4350	Rear Number Plate	Models CS1 & ES2	...	0	1	6
4351	Rear Number Plate Attachment Plate for Lucas Electric Rear Lamps	Models CS1 & ES2	...	0	2	0
4352	Rear Number Plate Pins and Nuts	Models CS1 & ES2 each	...	0	0	2
4353	Front Number Plate	Models CS1 & ES2	...	0	1	6
4354	Front Number Plate Screws	Models CS1 & ES2 each	...	0	0	2
4355	Pannier Bag (left or right hand)	Models CS1 & ES2	...	0	9	0
4356	Pannier Bag Fixing Pin	Models CS1 & ES2 each	...	0	0	2
4357	Pannier Bag Fixing Pin Nut	Models CS1 & ES2 each	...	0	0	2
4358	Pannier Bag Fixing Pin Distance Piece	Models CS1 & ES2 each	...	0	0	1
4359	Pannier Bag, for Chain Stay Attachment (offside only)	Models CS1 & ES2	...	0	11	6
4360	Pannier Bag Chain Stay Attachment Clips, with Nuts and Bolts	Models CS1 & ES2	...	0	1	0
		per set		0	1	0



4306



4307



4308



4309



4310



4311



4312



4313



4314




4315




4316



4317



4318




4319



4320



4321



FRAME, STANDS, MUDGUARDS, Etc.—continued.


Part No.					£	s.	d.
4361	Pannier Bag Carrier Stay ...	...	...	Models CS1 & ES2 ...	0	2	0
4362	Pannier Bag Carrier Stay Clip ...	...	...	Models CS1 & ES2 ...	0	0	3
4363	Saddle ...	...	...	Models CS1 & ES2 ...	2	7	0
4364	Saddle Spring ...	...	...	Models CS1 & ES2 ...	0	4	6
4365	Saddle Spring Pin ...	...	...	Models CS1 & ES2 ...	0	0	4
4366	Saddle Spring Pin Nut ...	...	...	Models CS1 & ES2 ...	0	0	3
4367	Saddle Spring Pin Plain Washer ...	...	...	Models CS1 & ES2 each ...	0	0	2
4368	Saddle Spring Pin Spring Washer ...	...	...	Models CS1 & ES2 each ...	0	0	2
4369	Saddle Front Anchor Pin ...	...	...	Models CS1 & ES2 each ...	0	0	4
4370	Saddle Front Anchor Pin Cotter Pin ...	...	...	Models CS1 & ES2 each ...	0	0	1

FRONT FORK AND STEERING DAMPER.


4371	Norton-Webb Forks, complete with Steering Damper ...	...	...	Models CS1 & ES2 ...	9	7	6
4372	Front Fork Girder ...	...	...	Models CS1 & ES2 ...	5	5	0
4373	Front Fork Steering Crown and Column ...	...	...	Models CS1 & ES2 ...	0	17	6
4374	Front Fork Steering Crown and Column Ball Race ...	...	...	Models CS1 & ES2 ...	0	1	6
4375	Front Fork Top Clip ...	...	...	Models CS1 & ES2 ...	0	17	6
4376	Front Fork Top Clip Ball Race ...	...	...	Models CS1 & ES2 ...	0	1	6
4377	Front Fork Top Clip Bolt and Nut ...	...	...	Models CS1 & ES2 ...	0	1	9
4378	Front Fork Spring ...	...	...	Models CS1 & ES2 ...	0	12	6
4379	Front Fork Spring Lug ...	...	...	Models CS1 & ES2 ...	0	2	9
4380	Front Fork Spring Attachment Pin ...	...	...	Models CS1 & ES2 ...	0	0	7
4381	Front Fork Top Spindle ...	...	...	Models CS1 & ES2 ...	0	3	4
4382	Front Fork Top Spindle Spacing Washer ...	...	...	Models CS1 & ES2 ...	0	0	4
4383	Front Fork Top Spindle Nut (left hand) ...	...	...	Models CS1 & ES2 ...	0	0	7
4384	Front Fork Top Spindle Nut (right hand) ...	...	...	Models CS1 & ES2 ...	0	0	7
4385	Front Fork Top Spindle Washer ...	...	...	Models CS1 & ES2 ...	0	0	4
4386	Front Fork Bottom Spindle ...	...	...	Models CS1 & ES2 ...	0	5	0
4387	Front Fork Bottom Spindle Nut (left hand) ...	...	...	Models CS1 & ES2 ...	0	0	7
4388	Front Fork Bottom Spindle Nut (right hand) ...	...	...	Models CS1 & ES2 ...	0	0	7
4389	Front Fork Bottom Spindle Washer ...	...	...	Models CS1 & ES2 ...	0	0	4
4390	Front Fork Carrier Plate ...	...	...	Models CS1 & ES2 ...	0	3	0
4391	Front Fork Star Washer ...	...	...	Models CS1 & ES2 ...	0	2	6
4392	Front Fork Shock Absorber Hand Adjuster ...	...	...	Models CS1 & ES2 ...	0	3	10
4393	Front Fork Shock Absorber Friction Disc ...	...	...	Models CS1 & ES2 ...	0	3	0
4394	Front Fork Bottom Link (left hand) ...	...	...	Models CS1 & ES2 ...	0	8	3
4395	Front Fork Bottom Link (right hand) ...	...	...	Models CS1 & ES2 ...	0	8	3
4396	Front Fork Top Link (left hand) ...	...	...	Models CS1 & ES2 ...	0	2	9
4397	Front Fork Top Link (right hand) ...	...	...	Models CS1 & ES2 ...	0	2	9
4398	Front Fork Grease Nipple ...	...	...	Models CS1 & ES2 ...	0	0	7
4399	Front Fork Spring Washer for Spring Lug Bolt ...	...	...	Models CS1 & ES2 ...	0	0	2
4400	Front Fork Mudguard Bracket Plate ...	...	...	Models CS1 & ES2 ...	0	0	4
4401	Front Fork Mudguard Bracket Plate Bolt, with Nut ...	...	...	Models CS1 & ES2 ...	0	0	9
4402	Front Fork Steering Damper Adjuster Wheel...	...	...	Models CS1 & ES2 ...	0	3	0
4403	Front Fork Steering Damper Adjuster Wheel Washer ...	...	...	Models CS1 & ES2 ...	0	0	2
4404	Front Fork Steering Damper Adjuster Wheel Lock Nut ...	...	...	Models CS1 & ES2 ...	0	0	2
4405	Front Fork Steering Damper Rod ...	...	...	Models CS1 & ES2 ...	0	1	1
4406	Front Fork Steering Damper Star Washer ...	...	...	Models CS1 & ES2 ...	0	0	7
4407	Front Fork Steering Damper Anchor Bracket ...	...	...	Models CS1 & ES2 ...	0	1	0
4408	Front Fork Steering Damper Column Lock Nut ...	...	...	Models CS1 & ES2 ...	0	2	0
4409	Front Fork Steering Damper Friction Plate ...	...	...	Models CS1 & ES2 ...	0	2	3
4410	Front Fork Steering Damper Bottom Plate ...	...	...	Models CS1 & ES2 ...	0	1	8

PETROL TANK, OIL TANKS AND FITTINGS.


4411	Petrol Tank Only ...	...	...	Models CS1 & ES2 ...	5	5	0
4412	Petrol Tank Filler Cap ...	...	...	Models CS1 & ES2 ...	0	8	6
4413	Petrol Tank Filler Cap Leather Washer ...	...	...	Models CS1 & ES2 ...	0	1	0




4411



4434



4437



4438

4443

4445

4446

4447

PETROL TANK, OIL TANKS AND FITTINGS—continued.

Part No.						f.	s.	d.
4414	Petrol Tap	...	...	...	Models CS1 & ES2	0	2	0
4415	Petrol Drain Tap	...	...	...	Models CS1 & ES2	0	1	9
4416	Petrol Tap Sump, with Gauze and Circlip	...	...	...	Models CS1 & ES2	0	3	6
4417	Petrol Tap Sump Gauze	...	...	...	Models CS1 & ES2	0	0	3
4418	Petrol Tap Sump Gauze Circlip	...	...	...	Models CS1 & ES2	0	0	1
4419	Petrol Tap Sump Washer	...	...	...	Models CS1 & ES2	0	0	1
4420	Petrol Tap or Drain Tap Washer	...	...	...	Models CS1 & ES2	0	0	1
4421	Petrol Tap Tank Packing Rubber Top Tube (thin)	...	...	...	Models CS1 & ES2	0	1	0
4422	Petrol Tap Tank Packing Rubber Top Tube (thick)	...	...	...	Models CS1 & ES2	0	1	3
4423	Petrol Tap Rubber Washers (Platform Attachment)	...	...	...	Models CS1 & ES2 each	0	0	5
4424	Petrol Tap Fixing Pin	...	...	...	Models CS1 & ES2	0	0	4
4425	Petrol Tap Fixing Washer	...	...	...	Models CS1 & ES2	0	0	1
4426	Petrol Tap Banjo Union	...	...	...	Models CS1 & ES2	0	1	3
4427	Petrol Tap Banjo Union Washer	...	...	...	Models CS1 & ES2	0	0	1
4428	Petrol Tap Banjo Union Nut	...	...	...	Models CS1 & ES2	0	0	8
4429	Petrol Tap Connection Pipe	...	...	...	Models CS1 & ES2	0	0	6
4430	Petrol Feed Pipe, complete with Nuts	...	...	...	Models CS1 & ES2	0	4	0
4431	Petrol Feed Pipe, Tank End, with Nut	...	...	...	Models CS1 & ES2	0	1	9
4432	Petrol Tank Feed Pipe, Carburettor End, with Nut	...	...	...	Models CS1 & ES2	0	1	9
4433	Petrol Tank Feed Pipe Rubber Connection	...	...	...	Models CS1 & ES2	0	0	6
4434	Oil Tank only, with Dry Sump Lubrication	...	...	...	Models CS1 & ES2	1	17	6
4435	Oil Tank Filter, with Banjo Union, with Dry Sump Lubrication	...	...	...		0	2	0
4436	Oil Tank Filter Nut, with Dry Sump Lubrication	...	...	...		0	0	3
4437	Oil Tank only	...	...	...	Model ES2	1	17	6
4438	Oil Feed Pipe, complete	...	...	...	Model ES2	0	3	9
4439	Oil Tank Filler Cap	...	...	...	Models CS1 & ES2	0	4	0
4440	Oil Tank Bottom Fixing Pins	...	...	...	Models CS1 & ES2 each	0	0	5
4441	Oil Tank Bottom Distance Piece	...	...	...	Models CS1 & ES2	0	0	3
4442	Oil Tank Top Fixing Pin	...	...	...	Models CS1 & ES2	0	0	5
4443	Oil Tank Top Fixing Bracket	...	...	...	Models CS1 & ES2	0	0	6
4444	Knee Grips, complete (not illustrated)	...	...	...	Models CS1 & ES2			
					per pair	0	16	6
4445	Knee Grip, Rubber, only	...	...	...	Models CS1 & ES2	0	5	6
4446	Knee Grip Plate only	...	...	...	Models CS1 & ES2	0	2	0
4447	Knee Grip Plate Nut	...	...	...	Models CS1 & ES2	0	0	4

HANDLE BARS AND FITTINGS, ETC.

4448	Handle Bar Bend only (Adjustable)	...	...	Models CS1 & ES2	0	18	0
4449	Handle Bar Grips	...	per pair	Models CS1 & ES2	0	4	6
4450	Handle Bar Attachment Clips, with Pins	...	...	Models CS1 & ES2			
				per set	0	7	6
4451	Handle Bar Attachment Clip Pins (per set of 8)	...	...	Models CS1 & ES2			
				per set	0	1	8
4452	Front Brake Control Lever, complete	...	...	Models CS1 & ES2	0	6	6
4453	Front Brake Control Lever only	...	...	Models CS1 & ES2	0	3	0
4454	Front Brake Control Lever Body	...	...	Models CS1 & ES2	0	3	0
4455	Front Brake Control Lever Fulcrum Pin and Nut	...	...	Models CS1 & ES2	0	0	4
4456	Front Brake Control Cable (inner and outer)	...	...	Models CS1 & ES2	0	4	0
4457	Front Brake Control Cable (outer)	...	...	Models CS1 & ES2	0	2	9
4458	Front Brake Cable (inner)	...	...	Models CS1 & ES2	0	1	3
4459	Front Brake Cable Adjuster	...	...	Models CS1 & ES2	0	0	10
4460	Front Brake Cable "U" Clip	...	...	Models CS1 & ES2	0	0	3
4461	Front Brake Cable "U" Clip Pin and Split Cotter	...	...	Models CS1 & ES2	0	0	1
4462	Exhaust Valve Lifter Control Lever, complete	...	...	Models CS1 & ES2	0	5	0
4463	Exhaust Valve Lifter Control Lever only	...	...	Models CS1 & ES2	0	2	6
4464	Exhaust Valve Lifter Control Lever Body	...	...	Models CS1 & ES2	0	2	6
4465	Exhaust Valve Lifter Control Lever Fulcrum Pin and Nut	...	...	Models CS1 & ES2	0	0	4
4466	Exhaust Lifter Cable (inner and outer)	...	...	Models CS1 & ES2	0	3	6
4467	Exhaust Lifter Cable (outer)	...	...	Models CS1 & ES2	0	2	6



4343



4344




4345



4346



4347



4348



4349



4350



4351



4352



4353



4354



4355



4356



4357



4358



4359



4360



4361



4362



4363



4364



4365



4366



4367



4368



4369



4370

HANDLE BARS AND FITTINGS, Etc.—continued.


Part No.				£	s.	d.
4468	Exhaust Lifter Cable (inner)	...	Models CS1 & ES2	0	1	0
4469	Exhaust Lifter Cable Adjuster	...	Models CS1 & ES2	0	0	10
4470	Magneto Control Lever, complete	...	Models CS1 & ES2	0	4	9
4471	Magneto Control Lever only	...	Models CS1 & ES2	0	2	6
4472	Magneto Control Lever Body only	...	Models CS1 & ES2	0	3	0
4473	Magneto Control Lever Cap	...	Models CS1 & ES2	0	1	3
4474	Magneto Control Lever Cap Spring	...	Models CS1 & ES2	0	0	1
4475	Magneto Control Lever Clip	...	Models CS1 & ES2	0	1	6
4476	Magneto Control Lever Clip Pins	...	Models CS1 & ES2	0	0	1
4477	Magneto Control Cable (inner and outer)	...	Models CS1 & ES2	0	3	6
4478	Magneto Control Cable (outer)	...	Models CS1 & ES2	0	2	6
4479	Magneto Control Cable (inner)	...	Models CS1 & ES2	0	1	0

FOOT RESTS AND REAR BRAKE ACTUATING PARTS.

4480	Footrest Rubber	...	Models CS1 & ES2	0	1	3
4481	Footrest (Rubber) Bolts, with Nuts	...	Models CS1 & ES2 each	0	0	5
4482	Footrest Rubber Holder	...	Models CS1 & ES2	0	2	9
4483	Footrest Serrated Hanger, with Spindle	...	Models CS1 & ES2	0	6	0
4484	Footrest Serrated Hanger only	...	Models CS1 & ES2	0	4	10
4485	Footrest Serrated Hanger Spindle only	...	Models CS1 & ES2	0	1	2
4486	Footrest Serrated Hanger Spindle Nut	...	Models CS1 & ES2	0	0	3
4487	Footrest Centre Rod	...	Models CS1 & ES2	0	2	0
4488	Footrest Centre Rod Nuts	...	Models CS1 & ES2 each	0	0	5
4489	Footrest Centre Rod Serrated Distance Piece (left or right hand)	...	Models CS1 & ES2	0	3	0
4490	Rear Brake Pedal, with Spindle	...	Models CS1 & ES2	0	16	0
4491	Rear Brake Pedal Spindle Nut	...	Models CS1 & ES2	0	0	3
4492	Rear Brake Pedal Spindle Washer	...	Models CS1 & ES2	0	0	1
4493	Rear Brake Pedal Arm	...	Models CS1 & ES2	0	4	6
4494	Rear Brake Pedal Arm Eye Bolt	...	Models CS1 & ES2	0	0	9
4495	Rear Brake Pedal Arm Eye Bolt Nut	...	Models CS1 & ES2	0	0	3
4496	Rear Brake Pedal Arm Eye Bolt Washer	...	Models CS1 & ES2	0	0	1
4497	Rear Brake Pedal Arm Adjuster and Stop	...	Models CS1 & ES2	0	0	9
4498	Rear Brake Rod only	...	Models CS1 & ES2	0	2	0
4499	Rear Brake Knurled Hand Adjuster	...	Models CS1 & ES2	0	1	6
4500	Rear Brake Rod Jaw Joint	...	Models CS1 & ES2	0	2	0
4501	Rear Brake Rod Jaw Joint pin, with Split Cotter	...	Models CS1 & ES2	0	0	1
4502	Rear Brake Anchor Arm Frame Bolt	...	Models CS1 & ES2	0	0	3
4503	Rear Brake Anchor Arm Frame Bolt Spring Washer	...	Models CS1 & ES2	0	0	1
4504	Rear Brake Return Spring	...	Models CS1 & ES2	0	1	0

WHEELS.

4505	Front Wheel, complete, less Tyre 26 x 3.25	...	Models CS1 & ES2	3	19	0
4506	Front Wheel Hub, complete	...	Models CS1 & ES2	2	18	6
4507	Front Wheel Hub Shell, with Brake Drum only	...	Models CS1 & ES2	0	19	6
4508	Front Hub Spindle	...	Models CS1 & ES2	0	2	6
4509	Front Hub Adjustable Cone	...	Models CS1 & ES2	0	2	0
4510	Front Hub Fixed Cone	...	Models CS1 & ES2	0	2	0
4511	Front Hub Cup	...	Models CS1 & ES2	0	2	3
4512	Front Hub Balls	...	Models CS1 & ES2	0	1	6
			per set	0	1	6
4513	Front Hub Spindle Nut (closed end)	...	Models CS1 & ES2	0	1	1
4514	Front Hub Spindle Nut (open end)	...	Models CS1 & ES2	0	0	8
4515	Front Hub Spindle Washers	...	Models CS1 & ES2 each	0	0	2
4516	Front Hub Dust Cap	...	Models CS1 & ES2	0	1	0
4517	Front Hub Felt Oil Retaining Washers	...	Models CS1 & ES2 each	0	0	2
4518	Front Hub Grease Nipple	...	Models CS1 & ES2	0	0	7
4519	Front Hub Brake Shoe Plate only	...	Models CS1 & ES2	0	7	9



WHEELS—continued.

Part No.					£	s.	d.
4520	Front Hub Brake Cam and Lever...	...	...	Models CS1 & ES2	...	0	3 6
4521	Front Hub Brake Cam and Lever Grease Nipple	...	...	Models CS1 & ES2	...	0	0 7
4522	Front Hub Brake Shoes, with Linings	...	...	Models CS1 & ES2			
				per pair		0	18 0
4523	Front Hub Brake Linings	...	...	Models CS1 & ES2			
				per pair		0	6 0
4524	Front Hub Brake Lining Rivets	...	...	Models CS1 & ES2			
				per set		0	0 6
4525	Front Hub Brake Shoe Fulcrum Bolt, with Nut and Washer	...	...	Models CS1 & ES2	...	0	0 9
4526	Front Hub Brake Shoe Return Spring	...	...	Models CS1 & ES2	...	0	0 6
4527	Front Hub Brake Plate Locking Nut	...	...	Models CS1 & ES2	...	0	1 1
4528	Front Wheel Rim, 26 x 3.25	...	...	Models CS1 & ES2	...	0	9 0
4529	Front Wheel Spokes (per set of 40)	...	...	Models CS1 & ES2	...	0	4 0
4530	Front Wheel Spoke Nipples (per set of 40)	...	...	Models CS1 & ES2	...	0	2 3
4531	Rear Wheel, complete with all Fittings less Tyre	...	...	Models CS1 & ES2	...	6	18 6
4532	Rear Wheel Hub complete	...	...	Models CS1 & ES2	...	5	5 6
4533	Rear Wheel Hub Shell, with Cups only	...	...	Models CS1 & ES2	...	1	13 6
4534	Rear Wheel Hub Brake Drum only	...	...	Models CS1 & ES2	...	1	5 0
4535	Rear Hub Spindle	...	...	Models CS1 & ES2	...	0	2 6
4536	Rear Hub Adjusting Cone	...	...	Models CS1 & ES2	...	0	2 0
4537	Rear Hub Fixed Cone	...	...	Models CS1 & ES2	...	0	2 0
4538	Rear Hub Dust Cap	...	...	Models CS1 & ES2	...	0	1 0
4539	Rear Hub Spindle Nut (closed end)	...	...	Models CS1 & ES2	...	0	1 1
4540	Rear Hub Spindle Nut (open end)	...	...	Models CS1 & ES2	...	0	0 8
4541	Rear Wheel Sprocket	...	...	Models CS1 & ES2	...	1	1 0
4542	Rear Wheel Sprocket Studs	...	...	Models CS1 & ES2	...	0	0 6
4543	Rear Wheel Sprocket Stud Nuts	...	...	Models CS1 & ES2	...	0	0 3
4544	Rear Wheel Sprocket Stud Washers	...	...	Models CS1 & ES2	...	0	0 2
4545	Rear Wheel Sprocket Buffer Rubbers (per set of 6)	...	...	Models CS1 & ES2	...	0	7 6
4546	Rear Wheel Sprocket Plate	...	...	Models CS1 & ES2	...	0	1 9
4547	Rear Wheel Brake Plate	...	...	Models CS1 & ES2	...	0	8 6
4548	Rear Wheel Cup	...	...	Models CS1 & ES2	...	0	2 3
4549	Rear Wheel Anchor Plate Lock Nut	...	...	Models CS1 & ES2	...	0	1 1
4550	Rear Wheel Brake Shoe Spring	...	...	Models CS1 & ES2	...	0	0 6
4551	Rear Wheel Brake Shoes, with Linings	...	...	Models CS1 & ES2			
				per pair		0	18 0
4552	Rear Wheel Brake Shoe Linings	...	...	Models CS1 & ES2			
				per pair		0	6 0
4553	Rear Wheel Brake Shoe Lining Rivets	...	...	Models CS1 & ES2			
				per set		0	0 6
4554	Rear Wheel Brake Cam, with Lever	...	...	Models CS1 & ES2	...	0	3 6
4555	Rear Wheel Chain Adjuster, complete	...	...	Models CS1 & ES2	...	0	1 9
4556	Rear Wheel Chain Adjuster Plate	...	...	Models CS1 & ES2	...	0	0 4
4557	Rear Wheel Chain Adjuster Plate Nut	...	...	Models CS1 & ES2	...	0	0 2
4558	Rear Wheel Grease Nipple	...	...	Models CS1 & ES2	...	0	0 7
4559	Rear Hub Anchor Arm Plate Bolt, with Nuts	...	...	Models CS1 & ES2	...	0	0 6
4560	Rear Hub Ball Retaining Washer	...	...	Models CS1 & ES2	...	0	0 7
4561	Rear Hub Balls	...	...	Models CS1 & ES2			
				per set		0	1 6
4562	Rear Hub Plate Anchor Arm	...	...	Models CS1 & ES2	...	0	2 9



GEAR BOX PARTS.




IMPORTANT.

When ordering Gear Box parts,
it is essential that the exact type
of Gear Box should be stated, and
ratios.

Part No.					£	s.	d.
4563	Gear Box Casing, with End Cover	...	...	Models CS1 & ES2	3	9	6
4564	Gear Box Main Axle	...	...	Models CS1 & ES2	0	14	10
4565	Gear Box Main Gear Wheel	...	...	Models CS1 & ES2	0	17	6
4566	Gear Box Main Axle Sliding Pinion	...	...	Models CS1 & ES2	0	11	0
4567	Lay Shaft Pinion	...	...	Models CS1 & ES2	0	5	6
4568	Lay Shaft Sliding Pinion	...	...	Models CS1 & ES2	0	9	4
4569	Main Axle Thrust Washer	...	...	Models CS1 & ES2	0	1	8
4570	Gear Box Lay Shaft	...	...	Models CS1 & ES2	0	18	9
4571	Gear Box Lay Shaft (T.T. Gear Box without k.s.)	...	...	Models CS1 & ES2	0	18	9
4572	Gear Box Main Shaft Pinion	...	...	Models CS1 & ES2	0	17	7
4573	Gear Box Kick-starter and Low Gear Wheel	...	...	Models CS1 & ES2	0	11	0
4574	Gear Box Lay Shaft Low Gear Wheel (T.T. Gear Box without k.s.)	...	...	Models CS1 & ES2	0	11	0
4575	Gear Box Kick-starter Axle, with Bush	...	...	Models CS1 & ES2	0	9	4
4576	Gear Box Kick-starter Axle Distance Piece	...	...	Models CS1 & ES2	0	0	8
4577	Gear Box Kick-starter Pawl	...	...	Models CS1 & ES2	0	1	4
4578	Gear Box Kick-starter Pawl Plunger	...	...	Models CS1 & ES2	0	0	4
4579	Gear Box Kick-starter Pawl Pin	...	...	Models CS1 & ES2	0	0	4
4580	Gear Box Kick-starter Pawl Spring	...	...	Models CS1 & ES2	0	0	2
4581	Gear Box Kick-starter Crank	...	...	Models CS1 & ES2	0	13	6
4582	Gear Box Kick-starter Crank Cotter	...	...	Models CS1 & ES2	0	0	6
4583	Gear Box Kick-starter Crank Cotter Nut	...	...	Models CS1 & ES2	0	0	2
4584	Gear Box Kick-starter Crank Cotter Washer	...	...	Models CS1 & ES2	0	0	1
4585	Gear Box Kick-starter Return Spring	...	...	Models CS1 & ES2	0	1	2
4586	Gear Box Kick-starter Return Spring Cover	...	...	Models CS1 & ES2	0	1	2
4587	Gear Box Kick-starter Relief Cam	...	...	Models CS1 & ES2	0	0	5
4588	Gear Box Kick-starter Relief Cam Rivet...	...	...	Models CS1 & ES2	0	0	1
4589	Gear Box Kick-starter Axle Bush	...	...	Models CS1 & ES2	0	4	5
4590	Gear Box Ball Bearing Cover Cap (T.T. Gear Box without k.s.)	...	...	Models CS1 & ES2	0	1	3
4591	Gear Box Sliding Gear Fork	...	...	Models CS1 & ES2	0	7	2
4592	Gear Box Sliding Gear Plate	...	...	Models CS1 & ES2	0	2	9
4593	Gear Box Rocking Shaft	...	...	Models CS1 & ES2	0	1	4
4594	Gear Box Rocking Shaft End Bush	...	...	Models CS1 & ES2	0	2	2
4595	Gear Box Rocking Shaft Nut	...	...	Models CS1 & ES2	0	0	4
4596	Gear Box Rocking Shaft Lever	...	...	Models CS1 & ES2	0	3	10
4597	Gear Box Rocking Shaft Lever Bush	...	...	Models CS1 & ES2	0	2	2
4598	Gear Box Rocking Shaft Lever Lock Washer	...	...	Models CS1 & ES2	0	0	2
4599	Gear Box Felt Oil Retaining Washer	...	...	Models CS1 & ES2	0	0	3
4600	Gear Box Sprocket Locking Washer	...	...	Models CS1 & ES2	0	0	6
4601	Gear Box Sprocket Locking Washer Screw	...	...	Models CS1 & ES2	0	0	1
4602	Gear Box Left-hand Ball Cup	...	...	Models CS1 & ES2	0	5	6
4603	Gear Box Left-hand Ball Cone	...	...	Models CS1 & ES2	0	2	9
4604	Gear Box Left-hand Ball Cone Adjusting Washers	...	...	Models CS1 & ES2	0	0	2
4605	Gear Box Left-hand Ball Cup Ball Bearings (per set of 40)	...	...	Models CS1 & ES2	0	1	6





GEAR BOX PARTS—continued.

Part No.			£	s.	d.
4606	Gear Box Left-hand Ball Cup Dust Cap ...	Models CS1 & ES2	0	0	4
4607	Gear Box Axle Bearing Adjusting Washer ...	Models CS1 & ES2	0	0	2
4608	Gear Box R.L. 5a. S.K.F. Bearing ...	Models CS1 & ES2	0	9	6
4609	Gear Box Clutch Worm ...	Models CS1 & ES2	0	3	0
4610	Gear Box Clutch Worm Lever ...	Models CS1 & ES2	0	2	9
4611	Gear Box Clutch Worm Lever Pin ...	Models CS1 & ES2	0	0	2
4612	Gear Box Clutch Worm Nut ...	Models CS1 & ES2	0	5	6
4613	Gear Box Clutch Worm Oil Retaining Cap ...	Models CS1 & ES2	0	1	8
4614	Gear Box Clutch Worm Oil Retaining Cap Felt Washer ...	Models CS1 & ES2	0	0	2
4615	Gear Box Clutch Body (electrically equipped model) ...	Models CS1 & ES2	0	14	10
4616	Gear Box Clutch Body ...	Models CS1 & ES2	0	14	10
4617	Gear Box Clutch Roller Cage, complete ...	Models CS1 & ES2	0	5	3
4618	Gear Box Clutch Body Nut ...	Models CS1 & ES2	0	0	8
4619	Gear Box Clutch Body Nut Locking Washer ...	Models CS1 & ES2	0	0	2
4620	Gear Box Clutch Spring ...	Models CS1 & ES2	0	1	10
4621	Gear Box Clutch Spring Nut ...	Models CS1 & ES2	0	0	10
4622	Gear Box Clutch Spring Nut Packing Washer ...	Models CS1 & ES2	0	0	1
4623	Gear Box Clutch Spring Collar ...	Models CS1 & ES2	0	0	8
4624	Gear Box Clutch Thrust Pin (electrically equipped model) ...	Models CS1 & ES2	0	0	10
4625	Gear Box Clutch Thrust Pin ...	Models CS1 & ES2	0	0	10
4626	Gear Box Clutch Rod ...	Models CS1 & ES2	0	0	11
4627	Gear Box Clutch Back Plate ...	Models CS1 & ES2	0	2	9
4628	Gear Box Clutch Centre Plate (dished) ...	Models CS1 & ES2	0	2	9
4629	Gear Box Clutch Centre Plate (flat) ...	Models CS1 & ES2	0	2	9
4630	Gear Box Clutch Plate (outer) ...	Models CS1 & ES2	0	2	9
4631	Gear Box Clutch Spring Cup ...	Models CS1 & ES2	0	3	4
4632	Gear Box Clutch End Cup ...	Models CS1 & ES2	0	1	8
4633	Gear Box Clutch Friction Ring, with Inserts ...	Models CS1 & ES2	0	5	6
4634	Gear Box Clutch Sprocket ...	Models CS1 & ES2	1	13	0
4635	Gear Box Clutch Inserts $\frac{1}{8}$ per dozen ...	Models CS1 & ES2	0	1	2
4636	Gear Box Clutch Inserts $\frac{1}{16}$ per dozen ...	Models CS1 & ES2	0	1	2
4637	Gear Box Clutch Cable (inner and outer), complete ...	Models CS1 & ES2	0	4	3
4638	Gear Box Clutch Control Cable (inner wire only) ...	Models CS1 & ES2	0	1	9
4639	Gear Box Clutch Control (outer cable only) ...	Models CS1 & ES2	0	2	6
4640	Gear Box Clutch Control Cable Adjuster ...	Models CS1 & ES2	0	0	10
4641	Gear Box Clutch Control Cable Stop Stud ...	Models CS1 & ES2	0	1	1
4642	Gear Box Clutch Worm Lever Cable Stop ...	Models CS1 & ES2	0	0	6
4643	Gear Box Clutch Handle Bar Control Lever, complete less Cable ...	Models CS1 & ES2	0	8	9
4644	Gear Box Clutch Handle Bar Control Lever Fulcrum Pin and Nut ...	Models CS1 & ES2	0	0	2
4645	Gear Box Clutch Handle Bar Control Clip Pin and Nut ...	Models CS1 & ES2	0	0	1
4646	Gear Box Clutch Handle Bar Control Cable Stop ...	Models CS1 & ES2	0	0	4
4647	Gear Box Clutch Handle Bar Control Cable Swivel ...	Models CS1 & ES2	0	0	2
4648	Gear Box Clutch Handle Bar Control Cable Swivel Nipple ...	Models CS1 & ES2	0	0	1
4649	Gear Box Clutch Handle Bar Control Cable Nipple ...	Models CS1 & ES2	0	0	1
4650	Gear Box Control Quadrant ...	Models CS1 & ES2	0	5	6
4651	Gear Box Control Quadrant Bush... ..	Models CS1 & ES2	0	1	2
4652	Gear Box Control Quadrant Stud ...	Models CS1 & ES2	0	1	8
4653	Gear Box Clutch Control Quadrant Stud Nut ...	Models CS1 & ES2	0	0	6
4654	Gear Box Control Quadrant Stud Spring Washer ...	Models CS1 & ES2	0	0	1
4655	Gear Box Control Quadrant Spring ...	Models CS1 & ES2	0	0	6
4656	Gear Box Control Quadrant Spring Box ...	Models CS1 & ES2	0	0	6
4657	Gear Box Control Quadrant Spring Nut ...	Models CS1 & ES2	0	0	7
4658	Gear Box Control Quadrant Spring Nut Washer ...	Models CS1 & ES2	0	0	1
4659	Gear Box Control Quadrant Stop Peg ...	Models CS1 & ES2	0	3	1
4660	Gear Box Control Quadrant Securing Pegs ...	Models CS1 & ES2	0	0	9
4661	Gear Box Control Rod ...	Models CS1 & ES2	0	1	2
4662	Gear Box Control Rod Nut ...	Models CS1 & ES2	0	0	2



4689



4690



4693



4694



4695




4696




4697



4698




4699




4700




4701



4702



4703



4704



4705




4706



4707



4708



4709



4710

GEAR BOX PARTS—continued.

Part No.				£	s.	d.
4663	Gear Box Control Rod Connection	...	Models CS1 & ES2	...	0	1 0
4664	Gear Box Control Rod Connection Pin	...	Models CS1 & ES2	...	0	0 2
4665	Gear Box Control Rod Connection Washer	...	Models CS1 & ES2	...	0	0 1
4666	Gear Box Control Rod Connection Split Pin	...	Models CS1 & ES2	...	0	0 1
4667	Gear Box Control Lever, with Knob	...	Models CS1 & ES2	...	0	6 8
4668	Gear Box Control Lever Knob	...	Models CS1 & ES2	...	0	0 10
4669	Gear Box Control Lever Knob Washer	...	Models CS1 & ES2	...	0	0 1
4670	Gear Box Control Lever, Knob Plug	...	Models CS1 & ES2	...	0	0 2
4671	Gear Box Control Lever Bolt	...	Models CS1 & ES2	...	0	0 3
4672	Gear Box Control Lever Bolt Spring Washer	...	Models CS1 & ES2	...	0	0 1
4673	Gear Box Oil Plug	...	Models CS1 & ES2	...	0	0 10
4674	Gear Box Cover Studs	...	Models CS1 & ES2 each	...	0	0 5
4675	Gear Box Cover Stud Nuts	...	Models CS1 & ES2 each	...	0	0 2
4676	Gear Box Suspension Bolt and Nut Top	...	Models CS1 & ES2	...	0	3 0
4677	Gear Box Bottom Bolt and Nuts	...	Models CS1 & ES2	...	0	1 6
4678	Gear Box Control Quadrant Top Connection Stud	...	Models CS1 & ES2	...	0	1 1
4679	Gear Box Control Quadrant Top Connection Stud Nut	...	Models CS1 & ES2	...	0	0 2
4680	Gear Box Control Quadrant Top Connection Stud Washer	...	Models CS1 & ES2	...	0	0 1
4681	Gear Box Control Quadrant Top Connection Stud Split Pin	...	Models CS1 & ES2	...	0	0 1
4682	Gear Box Front Chain Adjuster Plate	...	Models CS1 & ES2	...	0	1 0
4683	Gear Box Front Chain Adjuster Plate Pin	...	Models CS1 & ES2	...	0	0 6
4684	Gear Box Front Chain Adjuster Plate Stud	...	Models CS1 & ES2	...	0	1 0
4685	Gear Box Front Chain Adjuster Plate Nut	...	Models CS1 & ES2	...	0	0 4
4686	Gear Box Axle Sprocket	...	Models CS1 & ES2	...	0	10 0
4687	Gear Box Axle Sprocket Nut	...	Models CS1 & ES2	...	0	0 10
4688	Gear Box Control Index Plate	...	Models CS1 & ES2	...	0	7 2

TRANSMISSION PARTS.

NOTE.—When ordering Sprockets, state whether for electrically equipped model or otherwise.

4689	Engine Sprocket 15T, 16T, 17T, 18T, 19T, 20T	Models CS1 & ES2	...	0	11	0
4690	Engine Sprocket 15T, 16T, 17T, 18T, 19T, 20T (electrically equipped models)	Models CS1 & ES2	...	0	11	6
4691	Engine Sprocket 21T, 22T, 23T, 24T 25T, 26T	Models CS1 & ES2	...	0	12	0
4692	Engine Sprocket 21T, 22T, 23T, 24T, 25T, 26T (electrically equipped models)	Models CS1 & ES2	...	0	12	6

The following size Engine Sprockets are fitted as standard equipment to Models CS1 and ES2 :—Solo, 20T ; Sidecar, 17T.


4693	Front Driving Chain	Models CS1 & ES2	...	0	10	6
4694	Rear Driving Chain	Models CS1 & ES2	...	0	18	11
4695	Front Driving Chain Spring Link	Models CS1 & ES2	...	0	0	11
4696	Front Driving Chain Double Cranked Link	Models CS1 & ES2	...	0	1	6
4697	Rear Driving Chain Spring Link	Models CS1 & ES2	...	0	0	11
4698	Rear Driving Chain Double Cranked Link	Models CS1 & ES2	...	0	1	6
4699	Front Chain Case, complete	Models CS1 & ES2	...	3	5	0
4700	Front Chain Case, complete (electrically equipped models)		...	3	12	6
4701	Front Chain Case (top portion)	Models CS1 & ES2	...	1	8	0
4702	Front Chain Case (top portion) (electrically equipped models)		...	1	15	6
4703	Front Chain Case, bottom portion	Models CS1 & ES2	...	1	14	0

TRANSMISSION PARTS—continued.

Part No.					£	s.	d.
4704	Front Chain Case Clutch Cover ...	...	...	Models CS1 & ES2 ...	0	3	0
4705	Front Chain Case Clutch Cover Screws ...	...	...	Models CS1 & ES2 each ...	0	0	1
4706	Front Chain Case Pin (long) ...	...	...	Models CS1 & ES2 each ...	0	0	5
4707	Front Chain Case Pin (short) ...	...	...	Models CS1 & ES2 each ...	0	0	4
4708	Front Chain Case and Rear Chain Guard Attachment Pin ...	...	...	Models CS1 & ES2 ...	0	0	3
4709	Rear Chain Guard ...	...	...	Models CS1 & ES2 ...	0	14	0
4710	Rear Chain Guard Mudguard Stay Attachment Pin ...	...	...	Models CS1 & ES2 ...	0	0	2
4711	Tool Kit, complete (state Model CS1 or ES2) ...	...	...	Models CS1 & ES2 ...	1	10	0
4712	Tool Roll only ...	...	...	Models CS1 & ES2 ...	0	5	0
4713	Exhaust Pipe Flange Nut Spanner ...	...	...	Models CS1 & ES2 ...	0	1	6
4714	Valve-removing Tool ...	...	...	Model ES2 ...	0	7	6
4715	Screwdriver ...	...	...	Models CS1 & ES2 ...	0	1	3
4716	Adjustable Spanner ...	...	...	Models CS1 & ES2 ...	0	3	6
4717	Open-ended Spanner ...	...	...	Models CS1 & ES2 ...	0	2	0
4718	Valve-removing Tool (not illustrated) ...	...	...	Model CS1 ...	0	10	0
4719	Rocker Adjusting Screw Lock Nut Spanner ...	...	...	Models CS1 & ES2 ...	0	0	6
4720	Rocker Adjusting Screw Spanner ...	...	...	Models CS1 & ES2 ...	0	0	6
4721	Combination Pliers ...	...	...	Models CS1 & ES2 ...	0	2	6
4722	Vertical Shaft Top Bevel Locking Ring Spanner... Model CS1 ...	...	...	Model CS1 ...	0	1	6
4723	Grease Gun ...	...	...	Models CS1 & ES2 ...	0	7	6
4724	Control Cable Adjuster Spanner ...	...	...	Models CS1 & ES2 ...	0	0	6
4725	Box Spanner Tommy Bar ...	...	...	Models CS1 & ES2 ...	0	0	4
4726	Double-ended Box Spanner ...	...	...	Models CS1 & ES2 ...	0	1	0
4727	Vertical Shaft Tube Top Locking Ring Spanner... Model CS1 ...	...	...	Model CS1 ...	0	1	6
4728	Sparking Plug Spanner ...	...	...	Model CS1 ...	0	2	3
4729	1/4 in. Open-ended Spanner ...	...	...	Models CS1 & ES2 ...	0	1	0
4730	Chain Rivet Extractor ...	...	...	Models CS1 & ES2 ...	0	3	3
4731	Double-ended Spanner ...	...	...	Models CS1 & ES2 ...	0	1	0
4732	Tyre Inflator... ...	...	...	Models CS1 & ES2 ...	0	4	0
4733	Tyre Inflator Connection ...	...	...	Models CS1 & ES2 ...	0	1	9



4711



4712



4713



4714



4715



4716



4717



4718



4719



4720



4721



4722



4723



4724



4725



4726



4727



4728



4729



4730



4731



4732



4733